

SIP-T2 Series/T19(P) E2/T4 Series/CP860 IP Phones Administrator Guide

Copyright

Copyright © 2016 YEALINK(XIAMEN) NETWORK TECHNOLOGY CO., LTD.

Copyright © 2016 Yealink(Xiamen) Network Technology CO., LTD. All rights reserved. No parts of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, photocopying, recording, or otherwise, for any purpose, without the express written permission of Yealink(Xiamen) Network Technology CO., LTD. Under the law, reproducing includes translating into another language or format.


When this publication is made available on media, Yealink(Xiamen) Network Technology CO., LTD. gives its consent to downloading and printing copies of the content provided in this file only for private use but not for redistribution. No parts of this publication may be subject to alteration, modification or commercial use. Yealink(Xiamen) Network Technology CO., LTD. will not be liable for any damages arising from use of an illegally modified or altered publication.

Warranty

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS GUIDE ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS GUIDE ARE BELIEVED TO BE ACCURATE AND PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF PRODUCTS.

YEALINK(XIAMEN) NETWORK TECHNOLOGY CO., LTD. MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS GUIDE, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Yealink(Xiamen) Network Technology CO., LTD. shall not be liable for errors contained herein nor for incidental or consequential damages in connection with the furnishing, performance, or use of this guide.

Declaration of Conformity

 Hereby, Yealink(Xiamen) Network Technology CO., LTD. declares that this phone is in conformity with the essential requirements and other relevant provisions of the CE, FCC. Statements of compliance can be obtained by contacting support@yealink.com.

CE Mark Warning

For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860 IP phones:

This device is marked with the CE mark in compliance with EC Directives 2014/35/EU, 2014/30/EU.

For SIP VP-T49G IP phones:

This device is marked with the CE mark in compliance with R&TTE Directive 1999/5/EC.

Part 15 FCC Rules

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Class B Digital Device or Peripheral

Note: This device is tested and complies with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experience radio/TV technician for help.

WEEE Warning



To avoid the potential effects on the environment and human health as a result of the presence of hazardous substances in electrical and electronic equipment, end users of electrical and electronic equipment should understand the meaning of the crossed-out wheeled bin symbol. Do not dispose of WEEE as unsorted municipal waste and have to collect such WEEE separately.

Customer Feedback

We are striving to improve our documentation quality and we appreciate your feedback. Email your opinions and comments to DocsFeedback@yealink.com.

GNU GPL INFORMATION

Yealink IP phone firmware contains third-party software under the GNU General Public License (GPL).

Yealink uses software under the specific terms of the GPL. Please refer to the GPL for the exact terms and conditions of the license.

The original GPL license, source code of components licensed under GPL and used in Yealink products can be downloaded from Yealink web site:

<http://www.yealink.com/GPLOpenSource.aspx?BaseInfoCatId=293&NewsCatId=293&CatId=293>.

About This Guide

This guide is intended for administrators who need to properly configure, customize, manage, and troubleshoot the IP phone system rather than end-users. It provides details on the functionality and configuration of IP phones.

Many of the features described in this guide involve network settings, which could affect the IP phone's performance in the network. So an understanding of IP networking and a prior knowledge of IP telephony concepts are necessary.

Documentations

This guide covers SIP VP-T49G, SIP-T48G, SIP-T46G, SIP-T42G, SIP-T41P, SIP-T40P, SIP-T29G, SIP-T27P, SIP-T23P/G, SIP-T21(P) E2, SIP-T19(P) E2 and CP860 IP phones. The following related documents are available:

- Quick Start Guides, which describe how to assemble IP phones and configure the most basic features available on IP phones.
- User Guides, which describe the basic and advanced features available on IP phones.
- Auto Provisioning Guide, which describes how to provision IP phones using the configuration files.
- Description of Configuration Parameters in CFG Files, which describes all configuration parameters in configuration files.
- <y0000000000xx>.cfg and <MAC>.cfg template configuration files.
- IP Phones Deployment Guide for BroadSoft UC-One Environments, which describes how to configure BroadSoft features on the BroadWorks web portal and IP phones.

For support or service, please contact your Yealink reseller or go to Yealink Technical Support online: <http://support.yealink.com/>.

Conventions Used in Yealink Documentations

Yealink documentations contain a few typographic conventions.

You need to know the following basic typographic conventions to distinguish types of in-text information:

Convention	Description
Bold	Highlights the web/phone user interface items such as menus, menu selections, soft keys, or directory names when

Convention	Description
	they are involved in a procedure or user action (e.g., Click on Settings->Upgrade). Also used to emphasize text (e.g., Important!).
<i>Italics</i>	Used to show the format of examples (e.g., <i>http(s)://[IPv6 address]</i>), or to show the title of a section in the reference documentations available on the Yealink Technical Support Website (e.g., <i>Triggering the IP phone to Perform the Auto Provisioning</i>).
Blue Text	Used for cross references to other sections within this documentation (e.g., refer to Ring Tones on page 755), for hyperlinks to non-Yealink websites (e.g., RFC 3315) or for hyperlinks to Yealink Technical Support website.
<i>Blue Text in Italics</i>	Used for hyperlinks to Yealink resources outside of this documentation such as the Yealink documentations (e.g., Yealink_SIP-T2_Series_T19(P)_E2_T4_Series_CP860_W56P_IP_Phones_Auto_Provisioning_Guide).

In This Guide

The information detailed in this guide is applicable to firmware version 80 or higher. The firmware format is like x.x.x.x.rom. The second x from left must be greater than or equal to 80 (e.g., the firmware version of SIP-T23G IP phone: 44.80.0.60.rom). This administrator guide includes the following chapters:

- Chapter 1, "[Product Overview](#)" describes the SIP components and SIP IP phones.
- Chapter 2, "[Getting Started](#)" describes how to install and connect IP phones, configuration methods and resource files.
- Chapter 3, "[Configuring Basic Features](#)" describes how to configure the basic features on IP phones.
- Chapter 4, "[Configuring Advanced Features](#)" describes how to configure the advanced features on IP phones.
- Chapter 5, "[Configuring Audio Features](#)" describes how to configure the audio features on IP phones.
- Chapter 6, "[Configuring Video Features](#)" describes how to configure the video features on IP phones.
- Chapter 7, "[Configuring Security Features](#)" describes how to configure the security features on IP phones.
- Chapter 8, "[Troubleshooting](#)" describes how to troubleshoot IP phones and provides some common troubleshooting solutions.

- Chapter 9, “[Appendix](#)” provides the glossary, reference information about IP phones compliant with [RFC 3261](#), SIP call flows and the sample configuration files.

Summary of Changes

This section describes the changes to this guide for each release and guide version.

Changes for Release 80, Guide Version 80.130

The following section is new for this version:

- [Power Saving](#) on page 124

Major updates have occurred to the following sections:

- [Reading Icons](#) on page 38
- [Screen Saver](#) on page 117
- [NTP Time Server](#) on page 174
- [Key As Send](#) on page 231
- [Call Park](#) on page 429
- [DTMF](#) on page 448
- [Ring Tones](#) on page 755
- [Power and Startup Issues](#) on page 917
- [Appendix C: Trusted Certificates](#) on page 924

Changes for Release 80, Guide Version 80.95

Major updates have occurred to the following sections:

- [Transport Layer Security](#) on page 838
- [Appendix C: Trusted Certificates](#) on page 924

Changes for Release 80, Guide Version 80.91

The following section is new for this version:

- [Onscreen Keyboard Input Method Customization](#) on page 206

Major updates have occurred to the following sections:

- [Reading Icons](#) on page 38
- [Obtaining Configuration Files and Resource Files](#) on page 52
- [Configuring Transmission Methods of the Internet Port and PC Port](#) on page 87

- [Wi-Fi](#) on page 139
- [Customizing Softkey Layout Template File](#) on page 221
- [Customizing a Local Contact File \(Color Screen Phones\)](#) on page 273
- [Recent Call In Dialing](#) on page 419
- [Bandwidth](#) on page 491
- [External Monitor](#) on page 497
- [Shared Call Appearance \(SCA\)](#) on page 556
- [VQ-RTCPXR](#) on page 695
- [Sending Volume](#) on page 781
- [Audio Codecs](#) on page 784
- [Video Codecs](#) on page 816
- [Appendix F: Configurations Defined Never be Saved to <MAC>-local.cfg file](#) on page 945

Changes for Release 80, Guide Version 80.90

The following section is new for this version:

- [Exporting All the Diagnostic Files](#) on page 899

Major updates have occurred to the following sections:

- [Expansion Module](#) on page 17
- [Connecting the Handset and Optional Headset \(not Applicable to CP860 IP Phones\)](#) on page 28
- [Connecting the Power and Network](#) on page 30
- [Configuring Transmission Methods of the Internet Port and PC Port](#) on page 87
- [Backlight](#) on page 131
- [Incoming Intercom Calls](#) on page 468
- [Busy Lamp Field \(BLF\)](#) on page 524
- [Voice Quality Monitoring](#) on page 692
- [Sending Volume](#) on page 781
- [Capturing Packets](#) on page 886

Changes for Release 80, Guide Version 80.82

Major updates have occurred to the following sections:

- [Verifying Startup](#) on page 37
- [Reading Icons](#) on page 38
- [Incoming Intercom Calls](#) on page 468

Changes for Release 80, Guide Version 80.81

Documentations of the newly released SIP VP-T49G IP phones have also been added.

The following sections are new for this version:

- [Answer By Hand](#) on page 490
- [Bandwidth](#) on page 491
- [Screenshot and Recording](#) on page 494
- [Reserved Ports](#) on page 719
- [Configuring Video Features](#) on page 807
- [Getting Information from Talk Statistics](#) on page 894

Major updates have occurred to the following sections:

- [Connecting the IP Phones](#) on page 19
- [Wi-Fi](#) on page 139
- [Customizing Softkey Layout Template File](#) on page 221
- [Customizing a Directory Template File](#) on page 258
- [Voice Quality Monitoring](#) on page 692
- [Quality of Service](#) on page 713
- [TR-069 Device Management](#) on page 737
- [Audio Codecs](#) on page 784
- [Capturing Packets](#) on page 886
- [Troubleshooting Solutions](#) on page 900
- [Appendix B: Time Zones](#) on page 923
- [Appendix F: Configurations Defined Never be Saved to <MAC>-local.cfg file](#) on page 945

Changes for Release 80, Guide Version 80.80

This version is updated to incorporate CP860 IP phones. Documentations of the newly released SIP-T40P IP phones have also been added. The following sections are new for

this version:

- [Conventions Used in Yealink Documentations](#) on page [v](#)
- [Wi-Fi](#) on page [139](#)

Major updates have occurred to the following sections:

- [Expansion Module](#) on page [17](#)
- [Bluetooth](#) on page [136](#)
- [Auto Answer](#) on page [299](#)
- [Session Timer](#) on page [349](#)
- [Dialog Info Call Pickup](#) on page [416](#)
- [Methods of Transmitting DTMF Digit](#) on page [449](#)
- [Busy Lamp Field \(BLF\)](#) on page [524](#)
- [Multicast Paging](#) on page [579](#)
- [Action URI](#) on page [637](#)
- [VPN](#) on page [687](#)
- [Quality of Service](#) on page [713](#)
- [NAT Traversal](#) on page [724](#)
- [IPv6 Support](#) on page [743](#)
- [Distinctive Ring Tones](#) on page [761](#)
- [Viewing Log Files](#) on page [869](#)
- [Troubleshooting Solutions](#) on page [900](#)
- [Appendix F: Configurations Defined Never be Saved to <MAC>-local.cfg file](#) on page [945](#)

Changes for Release 80, Guide Version 80.60

Documentations of the newly released SIP-T19(P) E2 IP phones have also been added. The following sections are new for this version:

- [Ringing Timeout](#) on page [472](#)
- [Shared Call Appearance \(SCA\)](#) on page [556](#)
- [Bridge Lines Appearance \(BLA\)](#) on page [569](#)
- [Short Message Service \(SMS\)](#) on page [578](#)
- [Appendix F: Configurations Defined Never be Saved to <MAC>-local.cfg file](#) on page [945](#)

Major updates have occurred to the following sections:

- [Documentations](#) on page [v](#)

- [Expansion Module](#) on page 15
- [Reading Icons](#) on page 38
- [Configuration Files](#) on page 48
- [Obtaining Configuration Files and Resource Files](#) on page 52
- [Account Registration](#) on page 150
- [Auto Answer](#) on page 299
- [Do Not Disturb \(DND\)](#) on page 323
- [Return Code When Refuse](#) on page 341
- [Call Forward](#) on page 359
- [LDAP](#) on page 509
- [Action URL](#) on page 618
- [Action URI](#) on page 637
- [Server Redundancy](#) on page 647

Changes for Release 80, Guide Version 80.21

The following sections are new for this version:

- [Expansion Module](#) on page 15
- [Obtaining Configuration Files and Resource Files](#) on page 52
- [DHCP Option](#) on page 73
- [Bluetooth](#) on page 136
- [Enable Page Tips](#) on page 147
- [Label Length](#) on page 149
- [Account Registration](#) on page 150
- [Display Method on Dialing](#) on page 168
- [Redial Tone](#) on page 293
- [Ringer Device for Headset](#) on page 295
- [IP Direct Auto Answer](#) on page 306
- [Allow IP Call](#) on page 307
- [Accept SIP Trust Server Only](#) on page 309
- [Transfer Mode via Dsskey](#) on page 390
- [Allow Trans Exist Call](#) on page 391
- [Call Number Filter](#) on page 427
- [Call Timeout](#) on page 471
- [Send user=phone](#) on page 472

- [SIP Send MAC](#) on page 475
- [SIP Send Line](#) on page 477
- [Reserve # in User Name](#) on page 480
- [Password Dial](#) on page 481
- [Unregister When Reboot](#) on page 484
- [100 Reliable Retransmission](#) on page 486
- [Reboot in Talking](#) on page 488
- [Logon Wizard](#) on page 614
- [Auto-Logout Time](#) on page 825
- [Appendix E: Auto Provisioning Flowchart \(Keep user personalized configuration settings\)](#) on page 944

Major updates have occurred to the following sections:

- [DHCP](#) on page 68
- [Time and Date](#) on page 173
- [Language](#) on page 191
- [Input Method](#) on page 202
- [Logo Customization](#) on page 215
- [Softkey Layout](#) on page 219
- [Dial Plan](#) on page 236
- [Directory](#) on page 258
- [Search Source in Dialing](#) on page 261
- [Local Directory](#) on page 270
- [SIP Session Timer](#) on page 346
- [Call Hold](#) on page 352
- [DTMF](#) on page 448
- [Remote Phone Book](#) on page 502
- [VLAN](#) on page 673
- [Network Address Translation](#) on page 722
- [Comfort Noise Generation](#) on page 801
- [Phone Lock](#) on page 826
- [Troubleshooting Methods](#) on page 869
- [Troubleshooting Solutions](#) on page 900

Changes for Release 80, Guide Version 80.20

This version is updated to incorporate SIP-T48G IP phones. Documentations of the newly released SIP-T27P and SIP-T21(P) E2 IP phones have also been added.

Major updates have occurred to the following sections:

- [Reading Icons](#) on page 37
- [Configuration Files](#) on page 48
- [Backlight](#) on page 131
- [Time and Date](#) on page 172
- [Auto Answer](#) on page 299
- [Return Code When Refuse](#) on page 341
- [DTMF](#) on page 448
- [Phone Lock](#) on page 826
- [Appendix B: Time Zones](#) on page 923

Changes for Release 80, Guide Version 80.6

This version is updated to incorporate SIP-T46G, SIP-T42G, SIP-T41P and SIP-T29G IP phones. The following sections are new for this version:

- [Wallpaper](#) on page 112
- [Hide Features Access Code](#) on page 547

Major updates have occurred to the following sections:

- [DHCP](#) on page 68
- [Call Display](#) on page 163
- [Input Method](#) on page 202
- [BLF List](#) on page 537
- [IPv6 Support](#) on page 743
- [Viewing Log Files](#) on page 869

Table of Contents

About This Guide	V
Documentations	v
Conventions Used in Yealink Documentations	v
In This Guide	vi
Summary of Changes	vii
Changes for Release 80, Guide Version 80.130.....	vii
Changes for Release 80, Guide Version 80.95.....	vii
Changes for Release 80, Guide Version 80.91.....	vii
Changes for Release 80, Guide Version 80.90.....	viii
Changes for Release 80, Guide Version 80.82.....	ix
Changes for Release 80, Guide Version 80.81.....	ix
Changes for Release 80, Guide Version 80.80.....	ix
Changes for Release 80, Guide Version 80.60.....	x
Changes for Release 80, Guide Version 80.21.....	xi
Changes for Release 80, Guide Version 80.20.....	xiii
Changes for Release 80, Guide Version 80.6.....	xiii
Table of Contents	xv
Product Overview.....	1
VoIP Principle	1
SIP Components.....	2
SIP IP Phone Models.....	3
Physical Features of IP Phones	4
Key Features of IP Phones.....	15
Expansion Module.....	17
Getting Started.....	19
Connecting the IP Phones	19
Attaching the Stand and the Optional Wall Mount Bracket (not Applicable to CP860 IP Phones).....	20
Inserting the Camera (Only Applicable to SIP VP-T49G IP Phones).....	27
Connecting the Handset and Optional Headset (not Applicable to CP860 IP Phones) .	28
Connecting the Power and Network	30
Connecting the Optional Extension Microphones (Only Applicable to CP860 IP Phones)	32

Connecting the Optional USB Flash Drive (Only Applicable to SIP VP-T49G and CP860 IP Phones)	33
Connecting the Optional PC or Mobile Device (Only Applicable to CP860 IP Phones) ..	34
Connecting the Optional External Monitor (Only Applicable to SIP VP-T49G IP Phones)	35
Initialization Process Overview	36
Verifying Startup	37
Reading Icons	38
Configuration Methods	48
Phone User Interface.....	48
Web User Interface	48
Configuration Files.....	48
Obtaining Configuration Files and Resource Files	52
Keep User Personalized Settings	55
Configuration Parameters.....	55
Scenario A Keep user personalized configuration settings	57
Scenario B Clear user personalized configuration settings	61
Scenario C Keep user personalized settings after factory reset	62
Scenario D Import or export the local configuration file	64
Provisioning Server	66
Supported Provisioning Protocols	66
Setting up the Provisioning Server.....	66
Deploying Phones from the Provisioning Server	67
Configuring Basic Network Parameters	68
DHCP	68
DHCP Option.....	73
Configuring Network Parameters Manually	79
PPPoE	84
Configuring Transmission Methods of the Internet Port and PC Port	87
Configuring PC Port Mode	91
Upgrading Firmware.....	93
Upgrading Firmware via Web User Interface	94
Upgrading Firmware from the Provisioning Server	94
Configuring Basic Features	101
Power Indicator LED	103
Notification Popups.....	108
Contrast	111
Wallpaper.....	113
Screen Saver.....	117
Power Saving	124
Backlight.....	131
Bluetooth	136
Wi-Fi	139
Enable Page Tips	147

Label Length.....	149
Account Registration	150
Call Display	163
Display Method on Dialing.....	168
Web Server Type.....	169
Time and Date	173
NTP Time Server	174
Time and Date Settings	179
Daylight Saving Time	183
Language	191
Loading Language Packs	192
Specifying the Language to Use.....	199
Input Method	202
Keypad Input Method Customization	202
Onscreen Keyboard Input Method Customization	206
Specifying the Default Input Method	214
Logo Customization.....	215
Customizing a Logo Template File	216
Configuring the Logo Shown on the Idle Screen.....	217
Softkey Layout.....	219
Customizing Softkey Layout Template File.....	221
Key As Send	231
Dial Plan.....	236
Replace Rule	237
Dial-now	242
Area Code.....	248
Block Out.....	251
Hotline	253
Off Hook Hot Line Dialing	256
Directory	258
Customizing a Directory Template File.....	258
Search Source in Dialing.....	261
Customizing a Super Search Template File	261
Save Call Log.....	264
Call List Show Number	266
Missed Call Log	268
Local Directory	270
Customizing a Local Contact File.....	270
Live Dialpad	287
Call Waiting.....	289
Redial Tone	293
Ringer Device for Headset	295
Auto Redial.....	297
Auto Answer	299

IP Direct Auto Answer.....	306
Allow IP Call	307
Accept SIP Trust Server Only	309
Call Completion.....	310
Anonymous Call.....	314
Anonymous Call Rejection	319
Do Not Disturb (DND).....	323
Busy Tone Delay.....	339
Return Code When Refuse	341
Early Media.....	342
180 Ring Workaround	343
Use Outbound Proxy in Dialog	344
SIP Session Timer	346
Session Timer	349
Call Hold.....	352
Music on Hold.....	356
Call Forward	359
Call Transfer	381
Network Conference	384
Feature Key Synchronization.....	386
Transfer on Conference Hang Up	388
Transfer Mode via Dsskey.....	390
Allow Trans Exist Call.....	391
Directed Call Pickup	393
Group Call Pickup.....	405
Dialog Info Call Pickup.....	416
Recent Call In Dialing	419
ReCall.....	421
Call Number Filter.....	427
Call Park	429
Calling Line Identification Presentation.....	441
Connected Line Identification Presentation	446
DTMF.....	448
Methods of Transmitting DTMF Digit	449
Suppress DTMF Display	455
Transfer via DTMF	457
Play Local DTMF Tone	459
Allow Mute	461
Intercom.....	462
Outgoing Intercom Calls.....	462
Incoming Intercom Calls	468
Call Timeout	471
Ringing Timeout	472
Send user=phone	473

SIP Send MAC.....	475
SIP Send Line.....	477
Reserve # in User Name.....	480
Password Dial.....	481
Unregister When Reboot.....	484
100 Reliable Retransmission	486
Reboot in Talking.....	488
Answer By Hand.....	490
Bandwidth	491
Screenshot and Recording	494
Screenshot	494
Call and Conference Recording (for SIP VPT49G IP Phones).....	495
Call and Conference Recording (for CP860 IP Phones)	497
External Monitor	497

Configuring Advanced Features.....501

Remote Phone Book	502
Customizing Remote Phone Book Template File.....	502
LDAP.....	509
Busy Lamp Field (BLF)	524
BLF List	539
Hide Features Access Code	547
Automatic Call Distribution (ACD)	549
Shared Call Appearance (SCA)	556
Bridge Lines Appearance (BLA)	569
Message Waiting Indicator	572
Short Message Service (SMS)	578
Multicast Paging	579
Sending RTP Stream.....	579
Receiving RTP Stream	593
Call Recording	598
Hot Desking.....	606
Logon Wizard	614
Action URL	618
Action URI.....	637
Configuring Trusted IP Address for Action URI.....	642
Scenario A - Capturing the Current Screen of the Phone.....	645
Scenario B - Placing a Call via Web User Interface.....	646
Server Redundancy.....	647
Server Domain Name Resolution.....	661
Static DNS Cache	665
VLAN	673
LLDP	674
CDP	677

Manual Configuration for VLAN in the Wired Network.....	680
DHCP VLAN	684
Configuring VLAN Feature in the Wireless Network.....	687
VPN.....	689
Voice Quality Monitoring	692
RTCP-XR.....	693
VQ-RTCPXR.....	695
Quality of Service	713
Configuring the IP phone for Use with a Firewall or NAT.....	719
Reserved Ports	719
Network Address Translation	722
Real-Time Transport Protocol.....	735
TR-069 Device Management	737
IPv6 Support	743

Configuring Audio Features755

Ring Tones	755
Distinctive Ring Tones	761
Tones	768
Voice Mail Tone.....	776
Headset Prior	777
Dual Headset.....	779
Sending Volume.....	781
Audio Codecs	784
Acoustic Clarity Technology.....	798
Acoustic Echo Cancellation	798
Background Noise Suppression.....	799
Automatic Gain Control	799
Voice Activity Detection	800
Comfort Noise Generation	801
Jitter Buffer	803

Configuring Video Features807

Video Settings.....	807
Video Codecs.....	816

Configuring Security Features.....821

User Password	821
Administrator Password	823
Auto-Logout Time.....	825
Phone Lock	826
Transport Layer Security.....	838

Secure Real-Time Transport Protocol	849
Encrypting Configuration Files	852
802.1X Authentication	857
Troubleshooting	869
Troubleshooting Methods	869
Viewing Log Files	869
Capturing Packets	886
Enabling Watch Dog Feature	892
Getting Information from Status Indicators.....	894
Getting Information from Talk Statistics.....	894
Analyzing Configuration File	895
Exporting All the Diagnostic Files.....	899
Troubleshooting Solutions	900
IP Address Issues	900
Time and Date Issues	901
Display Issues	901
Phone Book Issues	902
Audio Issues	902
Camera and Video Issues	903
Wi-Fi and Bluetooth Issues	904
Firmware and Upgrading Issues	905
Provisioning Issues.....	906
System Log Issues.....	907
Resetting Issues	907
Rebooting Issues.....	911
Protocols and Ports Issues.....	914
Password Issues.....	917
Logo Issues.....	917
Power and Startup Issues	917
Hardware Issues.....	918
Other Issues	919
Appendix	921
Appendix A: Glossary.....	921
Appendix B: Time Zones	923
Appendix C: Trusted Certificates	924
Appendix D: Configuring DSS Key.....	926
Appendix E: Auto Provisioning Flowchart (Keep user personalized configuration settings).....	944
Appendix F: Configurations Defined Never be Saved to <MAC>-local.cfg file	945
Appendix G: SIP (Session Initiation Protocol)	953
RFC and Internet Draft Support	953
SIP Request.....	956

SIP Header	957
SIP Responses	959
SIP Session Description Protocol (SDP) Usage	961
Appendix H: SIP Call Flows	962
Successful Call Setup and Disconnect	962
Unsuccessful Call Setup—Called User is Busy	965
Unsuccessful Call Setup—Called User Does Not Answer	967
Successful Call Setup and Call Hold	969
Successful Call Setup and Call Waiting	972
Call Transfer without Consultation	976
Call Transfer with Consultation.....	980
Always Call Forward.....	985
Busy Call Forward	988
No Answer Call Forward	991
Call Conference.....	994
Index	999

Product Overview

This chapter contains the following information about IP phones:

- [VoIP Principle](#)
- [SIP Components](#)
- [SIP IP Phone Models](#)
- [Expansion Module](#)

VoIP Principle

VoIP

VoIP (Voice over Internet Protocol) is a technology using the Internet Protocol instead of traditional Public Switch Telephone Network (PSTN) technology for voice communications.

It is a family of technologies, methodologies, communication protocols, and transmission techniques for the delivery of voice communications and multimedia sessions over IP networks. The H.323 and Session Initiation Protocol (SIP) are two popular VoIP protocols that are found in widespread implementation.

H.323

H.323 is a recommendation from the ITU Telecommunication Standardization Sector (ITU-T) that defines the protocols to provide audio-visual communication sessions on any packet network. The H.323 standard addresses call signaling and control, multimedia transport and control, and bandwidth control for point-to-point and multi-point conferences.

It is widely implemented by voice and video conference equipment manufacturers, is used within various Internet real-time applications such as GnuGK and NetMeeting and is widely deployed by service providers and enterprises for both voice and video services over IP networks.

SIP

SIP (Session Initiation Protocol) is the Internet Engineering Task Force's (IETF's) standard for multimedia conferencing over IP. It is an ASCII-based, application-layer control protocol (defined in [RFC 3261](#)) that can be used to establish, maintain, and terminate calls between two or more endpoints. Like other VoIP protocols, SIP is designed to address functions of signaling and session management within a packet telephony

network. Signaling allows call information to be carried across network boundaries. Session management provides the ability to control attributes of an end-to-end call.

SIP provides capabilities to:

- Determine the location of the target endpoint -- SIP supports address resolution, name mapping, and call redirection.
- Determine media capabilities of the target endpoint -- Via Session Description Protocol (SDP), SIP determines the "lowest level" of common services between endpoints. Conferences are established using only media capabilities that can be supported by all endpoints.
- Determine the availability of the target endpoint -- A call cannot be completed because the target endpoint is unavailable, SIP determines whether the called party is already on the IP phone or does not answer in the allotted number of rings. It then returns a message indicating why the target endpoint is unavailable.
- Establish a session between the origin and target endpoint -- The call can be completed, SIP establishes a session between endpoints. SIP also supports mid-call changes, such as the addition of another endpoint to the conference or the change of a media characteristic or codec.
- Handle the transfer and termination of calls -- SIP supports the transfer of calls from one endpoint to another. During a call transfer, SIP simply establishes a session between the transferee and a new endpoint (specified by the transferring party) and terminates the session between the transferee and the transferring party. At the end of a call, SIP terminates the sessions between all parties.

SIP Components

SIP is a peer-to-peer protocol. The peers in a session are called User Agents (UAs). A user agent can function as one of following roles:

- User Agent Client (UAC) -- A client application that initiates the SIP request.
- User Agent Server (UAS) -- A server application that contacts the user when a SIP request is received and that returns a response on behalf of the user.

User Agent Client (UAC)

The UAC is an application that initiates up to six feasible SIP requests to the UAS. The six requests issued by the UAC are: INVITE, ACK, OPTIONS, BYE, CANCEL and REGISTER. When the SIP session is being initiated by the UAC SIP component, the UAC determines the information essential for the request, which is the protocol, the port and the IP address of the UAS to which the request is being sent. This information can be dynamic and will make it challenging to put through a firewall. For this reason, it may be recommended to open the specific application type on the firewall. The UAC is also capable of using the information in the request URI to establish the course of the SIP

request to its destination, as the request URI always specifies the host which is essential. The port and protocol are not always specified by the request URI. Thus if the request does not specify a port or protocol, a default port or protocol is contacted. It may be preferential to use this method when not using an application layer firewall. Application layer firewalls like to know what applications are flowing through which ports and it is possible to use content types of other applications other than the one you are trying to let through what has been denied.

User Agent Server (UAS)

UAS is a server that hosts the application responsible for receiving the SIP requests from a UAC, and on reception it returns a response to the request back to the UAC. The UAS may issue multiple responses to the UAC, not necessarily a single response.

Communication between UAC and UAS is client/server and peer-to-peer.

Typically, a SIP endpoint is capable of functioning as both a UAC and a UAS, but it functions only as one or the other per transaction. Whether the endpoint functions as a UAC or a UAS depends on the UA that initiates the request.

SIP IP Phone Models

This section introduces SIP VP-T49G, SIP-T48G, SIP-T46G, SIP-T42G, SIP-T41P, SIP-T40P, SIP-T29G, SIP-T27P, SIP-T23P/G, SIP-T21(P) E2, SIP-T19(P) E2 and CP860 IP phone models. These IP phones are endpoints in the overall network topology, which are designed to interoperate with other compatible equipments including application servers, media servers, internet-working gateways, voice bridges, and other endpoints. These IP phones are characterized by a large number of functions, which simplify business communication with a high standard of security and can work seamlessly with a large number of SIP PBXs.

IP phones provide a powerful and flexible IP communication solution for Ethernet TCP/IP networks, delivering excellent voice quality. The high-resolution graphic display supplies content in multiple languages for system status, call log and directory access. IP phones also support advanced functionalities, including LDAP, Busy Lamp Field, Sever Redundancy and Network Conference.

IP phones comply with the SIP standard ([RFC 3261](#)), and they can only be used within a network that supports this model of phone.

For a list of key features available on Yealink IP phones running the latest firmware, refer to [Key Features of IP Phones](#) on page 15.

In order to operate as SIP endpoints in your network successfully, IP phones must meet the following requirements:

- A working IP network is established.
- VoIP gateways are configured for SIP.
- The latest (or compatible) firmware of IP phones is available.

- A call server is active and configured to receive and send SIP messages.

Physical Features of IP Phones

This section lists the available physical features of SIP VP-T49G, SIP-T48G, SIP-T46G, SIP-T42G, SIP-T41P, SIP-T40P, SIP-T29G, SIP-T27P, SIP-T23P/G, SIP-T21(P) E2, SIP-T19(P) E2 and CP860 IP phones.

SIP VPT49G



Physical Features:

- 8" 1280 x 800 pixel color touch screen with backlight
- 16 VoIP accounts, Broadsoft Validated/Asterisk® Compatible
- HD Voice: HD Codec, HD Handset, HD Speaker
- 3-way video conference, 5-way mixing audio and video conference
- 21 dedicated hard keys
- 1*RJ9 (4P4C) handset port
- 1*RJ9 (4P4C) headset port
- Support Bluetooth headset and Bluetooth-Enabled mobile phone
- 2*RJ45 10/100/1000Mbps Ethernet ports
- 1*HDMI port
- 6 LEDs: 1*power, 1*mute, 1*headset, 1*speakerphone, 1*message, 1*camera
- Power adapter: AC 100~240V input and DC 12V/2A output
- 1*Built-in USB2.0 port, support USB flash drive

- 1*Built-in USB3.0 port, support camera
- Built-in Wi-Fi, support 802.11a/b/g/n

SIPT48G



Physical Features:

- 7" 800 x 480 pixel color touch screen with backlight
- 24 bit depth color
- 16 VoIP accounts, Broadsoft Validated/Asterisk® Compatible
- HD Voice: HD Codec, HD Handset, HD Speaker
- 26 dedicated hard keys
- 1*RJ9 (4P4C) handset port
- 1*RJ9 (4P4C) headset port
- 2*RJ45 10/100/1000Mbps Ethernet ports
- 1*RJ12 (6P6C) expansion module port
- 4 LEDs: 1*power, 1*mute, 1*headset, 1*speakerphone
- Power adapter: AC 100~240V input and DC 5V/2A output
- Power over Ethernet (IEEE 802.3af)
- Built-in USB port, support Bluetooth headset and Wi-Fi
- Wall Mount

SIP-T46G



Physical Features:

- 4.3" 480 x 272 pixel color display with backlight
- 24 bit depth color
- 16 VoIP accounts, Broadsoft Validated/Asterisk® Compatible
- HD Voice: HD Codec, HD Handset, HD Speaker
- 36 dedicated hard keys and 4 context-sensitive soft keys
- 1*RJ9 (4P4C) handset port
- 1*RJ9 (4P4C) headset port
- 2*RJ45 10/100/1000Mbps Ethernet ports
- 1*RJ12 (6P6C) expansion module port
- 14 LEDs: 1*power, 10*line, 1*mute, 1*headset, 1*speakerphone
- Power adapter: AC 100~240V input and DC 5V/2A output
- Power over Ethernet (IEEE 802.3af)
- Built-in USB port, support Bluetooth headset
- Wall Mount

SIPT42G



Physical Features:

- 192 x 64 graphic LCD
- 12 VoIP accounts, Broadsoft Validated/Asterisk® Compatible
- HD Voice: HD Codec, HD Handset, HD Speaker
- 30 dedicated hard keys and 4 context-sensitive soft keys
- 1*RJ9 (4P4C) handset port
- 1*RJ9 (4P4C) headset port
- 2*RJ45 10/100/1000Mbps Ethernet ports
- 1*RJ12 (6P6C) EHS36 headset adapter port
- 10 LEDs: 1*power, 6*line, 1*mute, 1*headset, 1*speakerphone
- Power adapter: AC 100~240V input and DC 5V/1.2A output
- Power over Ethernet (IEEE 802.3af)
- Wall Mount

SIP-T41P



Physical Features:

- 192 x 64 graphic LCD
- 6 VoIP accounts, Broadsoft Validated/Asterisk® Compatible
- HD Voice: HD Codec, HD Handset, HD Speaker
- 30 dedicated hard keys and 4 context-sensitive soft keys
- 1*RJ9 (4P4C) handset port
- 1*RJ9 (4P4C) headset port
- 2*RJ45 10/100Mbps Ethernet ports
- 1*RJ12 (6P6C) EHS36 headset adapter port
- 10 LEDs: 1*power, 6*line, 1*mute, 1*headset, 1*speakerphone
- Power adapter: AC 100~240V input and DC 5V/1.2A output
- Power over Ethernet (IEEE 802.3af)
- Wall Mount

SIPT40P



Physical Features:

- 132 x 64 graphic LCD
- 3 VoIP accounts, Broadsoft Validated/Asterisk® Compatible
- HD Voice: HD Codec, HD Handset, HD Speaker
- 27 dedicated hard keys and 4 context-sensitive soft keys
- 1*RJ9 (4P4C) handset port
- 1*RJ9 (4P4C) headset port
- 2*RJ45 10/100Mbps Ethernet ports
- 1*RJ12 (6P6C) EHS36 headset adapter port
- 4 LEDs: 1*power, 3*line
- Power adapter: AC 100~240V input and DC 5V/600mA output
- Power over Ethernet (IEEE 802.3af)
- Wall Mount

SIP-T29G



Physical Features:

- 4.3" 480 x 272 pixel color display with backlight
- 24 bit depth color
- 16 VoIP accounts, Broadsoft Validated/Asterisk® Compatible
- HD Voice: HD Codec, HD Handset, HD Speaker
- 37 dedicated hard keys and 4 context-sensitive soft keys
- 1*RJ9 (4P4C) handset port
- 1*RJ9 (4P4C) headset port
- 2*RJ45 10/100/1000Mbps Ethernet ports
- 1*RJ12 (6P6C) expansion module port
- 13 LEDs: 1*power, 10*line, 1*headset, 1*message
- Power adapter: AC 100~240V input and DC 5V/2A output
- Power over Ethernet (IEEE 802.3af)
- Built-in USB port, support Bluetooth headset
- Wall Mount

SIPT27P



Physical Features:

- 240 x 120 graphic LCD
- 6 VoIP accounts, Broadsoft Validated/Asterisk® Compatible
- HD Voice: HD Codec, HD Handset, HD Speaker
- 35 dedicated hard keys and 4 context-sensitive soft keys
- 1*RJ9 (4P4C) handset port
- 1*RJ9 (4P4C) headset port
- 2*RJ45 10/100Mbps Ethernet ports
- 1*RJ12 (6P6C) expansion module port
- 11 LEDs: 1*power, 8*line, 1*headset, 1*message
- Power adapter: AC 100~240V input and DC 5V/1.2A output
- Power over Ethernet (IEEE 802.3af)
- Wall Mount

SIP-T23P/G



Physical Features:

- 132 x 64 graphic LCD with 4-level greyscales
- 3 VoIP accounts, Broadsoft Validated/Asterisk® Compatible
- HD Voice: HD Codec, HD Handset, HD Speaker
- 27 dedicated hard keys and 4 context-sensitive soft keys
- 1*RJ9 (4P4C) handset port
- 1*RJ9 (4P4C) headset port
- 2*RJ45 10/100/1000Mbps Ethernet ports (1000Mbps is only applicable to SIP-T23G IP phones)
- 5 LEDs: 1*power, 3*line, 1*message
- Power adapter: AC 100~240V input and DC 5V/600mA output
- Power over Ethernet (IEEE 802.3af)
- Wall Mount

SIPT21(P) E2



Physical Features:

- 132 x 64 graphic LCD
- 2 VoIP accounts, Broadsoft Validated/Asterisk® Compatible
- 26 dedicated hard keys and 4 context-sensitive soft keys
- 4 LEDs: 1*power, 2*line, 1*message
- HD Voice: HD Codec, HD Handset, HD Speaker
- 1*RJ9 (4P4C) handset port
- 1*RJ9 (4P4C) headset port
- 2*RJ45 10/100Mbps Ethernet ports
- Power adapter: AC 100~240V input and DC 5V/600mA output
- Power over Ethernet (IEEE 802.3af) (not applicable to SIP-T21 E2 IP phones)
- Wall Mount

SIP-T19(P) E2



Physical Features:

- 132 x 64 graphic LCD
- Single VoIP account, Broadsoft Validated/Asterisk® Compatible
- 24 dedicated hard keys and 4 context-sensitive soft keys
- 1 LED: 1*power
- HD Voice: HD Codec, HD Handset
- 1*RJ9 (4P4C) handset port
- 1*RJ9 (4P4C) headset port
- 2*RJ45 10/100Mbps Ethernet ports
- Power adapter: AC 100~240V input and DC 5V/600mA output
- Power over Ethernet (IEEE 802.3af) (not applicable to SIP-T19 E2 IP phones)
- Wall Mount

CP860



Physical Features:

- 192 x 64 graphic LCD
- One VoIP account
- 20 dedicated hard keys and 4 context-sensitive soft keys
- HD Voice: HD Codec
- 1 mobile phone/PC port: 3.5mm
- 1*RJ45 10/100Mbps Ethernet port
- 2*EXT mic ports
- 1*USB2.0 port
- Security lock port
- 3 LED indicators
- Power adapter (optional): AC 100~240V input and DC 5V/2A output
- Power over Ethernet (IEEE 802.3af)

Key Features of IP Phones

In addition to physical features introduced above, IP phones also support the following key features when running the latest firmware:

• Phone Features

- **Call Options:** emergency call, call waiting, call hold, call mute, call forward, call transfer, call pickup, three-way conference, five-way mixing audio and video conference (up to three-way video conference, only applicable to SIP VPT49G IP phones).
- **Basic Features:** DND, auto redial, live dialpad, dial plan, hotline, caller identity,

auto answer.

- **Advanced Features:** BLF, server redundancy, distinctive ring tones, remote phone book, LDAP

- **Codecs and Voice Features**

- Wideband codec: G.722, Opus (Opus is only applicable to SIP VP-T49G IP phones)
- Narrowband codec: G.711, G.726, G.729, iLBC, G.723 (G.723 is not applicable to SIP-T40P/T27P/T23P/T23G/T21(P) E2/T19(P) E2 IP phones)
- VAD, CNG, AEC, PLC, AJB, AGC
- Full-duplex speakerphone with AEC
- Built in microphone array, 360 degree voice pickup (only applicable to CP860 IP phones)

- **Video Features (only applicable to SIP VP-T49G IP phones)**

- Video codec: H264HP, H264 and H263
- Image codec: JPEG, PNG, BMP
- Adaptive bandwidth adjustment
- Video Resolution: Full-HD 1080P at 30fps (1920x1080)

- **Network Features**

- SIP v1 (RFC 2543), v2 (RFC 3261)
- NAT Traversal: STUN mode
- DTMF: INBAND, RFC 2833, SIP INFO
- Proxy mode and peer-to-peer SIP link mode
- IP assignment: Static/DHCP/PPPoE (PPPoE is not applicable to SIP-T42G/T41P/CP860 IP phones)
- VLAN assignment: LLDP/Static/DHCP/CDP
- Bridge mode for PC port (not applicable to CP860 IP phones)
- HTTP/HTTPS server
- DNS client
- NAT/DHCP server
- IPv6 support
- Wi-Fi (only applicable to SIP VP-T49G/SIP-T48G IP phones)

- **Management**

- FTP/TFTP/HTTP/PnP auto-provision
- Configuration: browser/phone/auto-provision
- Direct IP call without SIP proxy
- Dial number via SIP server
- Dial URL via SIP server

- TR-069
- **Security**
 - HTTPS (server/client)
 - SRTP (RFC 3711)
 - Transport Layer Security (TLS)
 - VLAN (802.1q), QoS
 - Digest authentication using MD5/MD5-sess
 - Secure configuration file via AES encryption
 - Phone lock for personal privacy protection
 - Admin/User configuration mode
 - 802.1X authentication

Expansion Module

This section introduces EXP20 and EXP40 expansion modules. EXP20 is only applicable to SIP-T29G and SIP-T27P IP phones. EXP40 is only applicable to SIP-T48G and SIP-T46G IP phones.

EXP20



Physical Features:

- Rich visual experience with 160 x 320 graphic LCD
- 20 physical keys each with a dual-color LED

- 20 additional keys through page switch
- Daisy-chain 6 modules up to 120 keys
- Expansion module (≤ 2) is powered by the host phone
- 2*RJ-12 (6P6C) ports for data in and out

EXP40



Physical Features:

- Rich visual experience with 160 x 320 graphic LCD
- 20 physical keys each with a dual-color LED
- 20 additional keys through page switch
- Supports up to 6 modules daisy-chain
- Power adapter: AC 100~240V input and DC 5V/1.2A output
- 2*RJ-12 (6P6C) ports for data in and out
- Wall Mount

Getting Started

This chapter provides basic information and installation instructions of SIP VP-T49G/SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860 IP phones.

This chapter provides the following sections:

- [Connecting the IP Phones](#)
- [Initialization Process Overview](#)
- [Verifying Startup](#)
- [Reading Icons](#)
- [Configuration Methods](#)
- [Obtaining Configuration Files and Resource Files](#)
- [Keep User Personalized Settings](#)
- [Provisioning Server](#)
- [Configuring Basic Network Parameters](#)
- [Upgrading Firmware](#)

Connecting the IP Phones

This section introduces how to install SIP VP-T49G/SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860 IP phones with components in packaging contents.

1. Attach the stand and the optional wall mount bracket (not applicable to CP860 IP phones)
2. Insert the camera (only applicable to SIP VP-T49G IP phones)
3. Connect the handset and optional headset (not applicable to CP860 IP phones)
4. Connect the power and network
5. Connect the optional extension microphones kit (only applicable to CP860 IP phones)
6. Connect the optional USB flash drive (only applicable to SIP VP-T49G and CP860 IP phones)
7. Connect the optional PC or mobile device (only applicable to CP860 IP phones)
8. Connect the optional external monitor (only applicable to SIP VP-T49G IP phones)


Note

The optional accessories are not included in packaging contents. You need to purchase them separately if required.

Attaching the Stand and the Optional Wall Mount Bracket (not Applicable to CP860 IP Phones)

To attach the stand and the optional wall mount bracket:

For SIP VP-T49G:




Desk Mount Method

Note


Wall Mount Method is not applicable to SIP VP-T49G IP phones.

For SIP-T48G:



Desk Mount Method

Desk Mount Method




Wall Mount Method (Optional)


Note

The top two slots on SIP-T48G IP phones are plugged up by silica gel. You need to pull out silica gel before attaching the wall mount bracket.

For SIP-T46G:




Desk Mount Method




Wall Mount Method (Optional)

For SIP-T42G/T41P/T40P:




Desk Mount Method




Wall Mount Method (Optional)

For SIP-T29G/T27P:




Desk Mount Method

Desk Mount Method




Wall Mount Method (Optional)

For SIP-T23P/T23G:




Desk Mount Method




Wall Mount Method (Optional)

For SIP-T21(P) E2:




Desk Mount Method




Wall Mount Method (Optional)

For SIP-T19(P) E2:



Desk Mount Method



Wall Mount Method (Optional)

Note


The hookswitch tab has a lip which allows the handset to stay on-hook when the IP phone is mounted vertically.

For more information on how to mount the IP phone to a wall, refer to [Yealink Wall Mount Quick Installation Guide](#).

Inserting the Camera (Only Applicable to SIP VP-T49G IP Phones)

To insert the camera:


For SIP VP-T49G:




Connecting the Handset and Optional Headset (not Applicable to CP860 IP Phones)

To connect the handset and optional headset:


For SIP VP-T49G:




For SIP-T48G/T46G/T29G:



For SIP-T42G/T41P/T40P:



For SIP-T27P:



Note


Wireless headset adapter EHS36 or Bluetooth USB dongle BT40 should be purchased separately.

For more information on how to use the EHS36 on the IP phone, refer to [Yealink EHS36 User Guide](#).


Bluetooth USB dongle BT40 can only be used on the SIP-T48G/T46G/T29G IP phones. For more information on how to use the Bluetooth on SIP-T48G/T46G/T29G IP phones, refer to [Yealink Bluetooth USB Dongle BT40 User Guide](#).

The EXT port on SIP-T48G/T46G IP phones can also be used to connect the expansion module EXP40. The EXT port on SIP-T29G/T27P IP phones can also be used to connect the expansion module EXP20. For more information on how to connect the EXP40/EXP20, refer to [Yealink EXP-specific user guide](#).

For SIP-T23P/T23G/T21(P) E2:



For SIP-T19(P) E2:




Connecting the Power and Network

AC Power (Optional)


To connect the AC power and network:

- 1) Connect the DC plug of the power adapter to the DC5V (for SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860) or DC12V (for SIP VP-T49G) port on the IP phone and connect the other end of the power adapter into an electrical power outlet.
- 2) Connect the included or a standard Ethernet cable between the Internet port on the IP phone and the one on the wall or switch/hub device port.

For SIP VP-T49G:




For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2:



Note

You can also connect the SIP VP-T49G or SIP-T48G IP phone to a wireless network according to your office environment. For more information, refer to [Yealink phone-specific user guide](#).

For CP860:



Note

The IP phone should be used with Yealink original power adapter only. The use of the third-party power adapter may cause the damage to the phone.

Power over Ethernet

With the included or a regular Ethernet cable, IP phones can be powered from a PoE-compliant switch or hub.


Note

PoE is not applicable to the SIP VP-T49G, SIP-T21 E2 and SIP-T19 E2 IP phones.


To connect the PoE:

- 1) Connect the Ethernet cable between the Internet port on the IP phone and an available port on the in-line power switch/hub.

For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21P E2/T19P E2:



For CP860:



Note

If in-line power switch/hub is provided, you don't need to connect the phone to the power adapter. Make sure the switch/hub is PoE-compliant.

The IP phone can also share the network with another network device such as a PC (personal computer). It is an optional connection.


Important! Do not unplug or remove the power while the IP phone is updating firmware and configurations.

Connecting the Optional Extension Microphones (Only Applicable to CP860 IP Phones)

You can connect optional extension microphones to enhance the room coverage of the conference phone. The Yealink-provided extension microphone kit contains two extension microphones.

To connect the extension microphones:

- 1) Connect the free end of the optional extension microphone cable to one of the MIC ports on the phone.




Connecting the Optional USB Flash Drive (Only Applicable to SIP VP-T49G and CP860 IP Phones)

You can connect a USB flash drive to record and play back calls. For SIP VP-T49G IP phones, you can also connect a USB flash drive to display pictures on your phone and capture screenshots.


To connect a USB flash drive:

- 1) Insert a USB flash drive into the USB port on the phone.

For SIP VP-T49G:



For CP860:




Connecting the Optional PC or Mobile Device (Only Applicable to CP860 IP Phones)

You can connect a PC or mobile device to listen to the PC or mobile audio using your conference phone.

To connect a PC or mobile device:

- 1) Connect one end of the 3.5mm jack cable to the PC/mobile port on the phone, and connect the other end to the headset jack on the mobile device or the AUX/MIC jack on the PC.




Connecting the Optional External Monitor (Only Applicable to SIP VP-T49G IP Phones)

You can connect an external monitor to the IP phone to have a clearer view with the far site during a video call.

To connect an external monitor:

- 1) Remove one piece of the fastener's liner; take the gap of the camera as the touchline and attach the fastener to the camera from the top; connect one end of the USB3.0 cable to the camera.
- 2) Remove the other piece of the fastener's liner; attach the fastener to the external monitor; attach the camera to the external monitor by pressing two sides of Dual Lock together. You are advised to attach the camera to the external monitor whose back is straight.
- 3) Connect the other end of the USB3.0 cable to the IP phone.
- 4) Connect one end of the HDMI cable to the HDMI port on the phone, and connect the other end to the HDMI port on the external monitor.



Note

The Extended Display Accessories ED10 which is not included with your IP phone is required for connecting the external monitor. Contact your reseller to purchase it separately. For more information, refer to [Yealink Extended Display Accessories Quick Installation Guide for SIP VP-T49G](#).

The following tips you need to know when mounting the camera to the external monitor:

- a) Be aware of attaching the camera to the external monitor from the back of the monitor and make sure the camera lens is on the same side with the monitor screen.
- b) Confirm that the camera is vertical and not askew when using Dual Lock to attach the camera to the external monitor otherwise the near-site video image will be crooked.
- c) Make sure that you firstly press the back of the camera when you rotate the camera. It can reduce the risk of falling off.
- d) Be aware that the stick area of two sides of Dual Lock (on the camera and external

monitor) is as large as possible.

- e) Ensure that you insert forcibly until the camera indicator LED is solid green; and the embossing on the camera does not need to insert into the groove on the IP phone if you want to insert the camera back to the IP phone and do not torn the 3M Dual Lock.

Initialization Process Overview

The initialization process of the IP phone is responsible for network connectivity and operation of the IP phone in your local network.

Once you connect your IP phone to the network and to an electrical supply, the IP phone begins its initialization process.

During the initialization process, the following events take place:

Loading the ROM file

The ROM file resides in the flash memory of the IP phone. The IP phone comes from the factory with a ROM file preloaded. During initialization, the IP phone runs a bootstrap loader that loads and executes the ROM file.

Configuring the VLAN

If the IP phone is connected to a switch, the switch notifies the IP phone of the VLAN information defined on the switch (if using LLDP or CDP). The IP phone can then proceed with the DHCP request for its network settings (if using DHCP).

Querying the DHCP (Dynamic Host Configuration Protocol) Server

The IP phone is capable of querying a DHCP server. DHCP is enabled on the IP phone by default. The following network parameters can be obtained from the DHCP server during initialization:

- IP Address
- Subnet Mask
- Gateway
- Primary DNS (Domain Name Server)
- Secondary DNS

You need to configure network parameters of the IP phone manually if any of them is not supplied by the DHCP server. For more information on configuring network parameters manually, refer to [Configuring Network Parameters Manually](#) on page 79.

Contacting the provisioning server

If the IP phone is configured to obtain configurations from the provisioning server, it will connect to the provisioning server and download the configuration file(s) during startup. The IP phone will be able to resolve and update configurations written in the

configuration file(s). If the IP phone does not obtain configurations from the provisioning server, the IP phone will use configurations stored in the flash memory.

Updating firmware

If the access URL of firmware is defined in the configuration file, the IP phone will download firmware from the provisioning server. If the MD5 value of the downloaded firmware file differs from that of the image stored in the flash memory, the IP phone will perform a firmware update.

Downloading the resource files

In addition to configuration file(s), the IP phone may require resource files before it can deliver service. These resource files are optional, but if some particular features are being deployed, these files are required.

The followings show examples of resource files:

- Language packs
- Ring tones
- Contact files

Verifying Startup

After connected to the power and network, the IP phone begins the initializing process by cycling through the following steps:

1. The power indicator LED illuminates solid red.
2. The message "Welcome Initializing... please wait" appears on the LCD screen when the IP phone starts up.

If you are using CP860 IP phones, and the phones are first powered on or the phone settings are reset to factory defaults, the setup wizard will appear on the LCD screen after startup. If not, go to the next step.

Note

For more information on the setup wizard, refer to [Yealink_CP860_User_Guide](#).


























































































3. The main LCD screen displays the following:
 - Time and date
 - Soft key labels
4. Press the OK/√ key or tap **Menu->Status** to check the IP phone status, the LCD screen displays the valid IP address, MAC address, firmware version, etc.






















































































If the IP phone has successfully passed through these steps, it starts up properly and is ready for use.



































Reading Icons











































Icons associated with different features may appear on the LCD screen. The following table provides a description for each icon on IP phones.












































T49G	T48G	T46G	T42G/T41P	T40P	T29G	T27P	T23P/T23G /T21(P) E2	T19(P) E2	CP860	Description
										Network is unavailable.
										Private line registers successfully.
										Registration failed
 (Flashing)	 (Flashing)									Registering
										Hands-free speakerphone mode
									/	Handset mode
									/	Headset mode













































T49G	T48G	T46G	T42G/T41P	T40P	T29G	T27P	T23P/T23G /T21(P) E2	T19(P) E2	CP860	Description
										Voice Mail
			/							Text Message
			AA							Auto Answer
			DND							Do Not Disturb
										Call Forward
	/	/	/	/	/	/	/	/	/	Camera is not detected
	/	/	/	/	/	/	/	/	/	Call Hold (video)
										Call Hold (audio-only)
										Call Mute (audio-only)
										Ringer volume is 0
										Phone Lock










































T49G	T48G	T46G	T42G/T41P	T40P	T29G	T27P	T23P/T23G /T21(P) E2	T19(P) E2	CP860	Description
										Received Calls
										Placed Calls
										Missed Calls
										Forwarded Calls
								/		Recording box is full
								/		A call cannot be recorded
								/		Recording starts successfully
								/		Recording cannot be started
								/		Recording cannot be stopped

T49G	T48G	T46G	T42G/T41P	T40P	T29G	T27P	T23P/T23G /T21(P) E2	T19(P) E2	CP860	Description
			VPN	VPN		VPN	VPN	/	VPN	VPN is enabled
			/	/		/	/	/	/	Bluetooth mode is on
			/	/		/	/	/	/	Bluetooth headset is both paired and connected
	/	/	/	/	/	/	/	/	/	Bluetooth-Enabled mobile phone is both paired and connected
		/	/	/	/	/	/	/	/	Wi-Fi connection is successful
		/	/	/	/	/	/	/	/	Wi-Fi connection failed
/	/		/	/		/	/	/	/	Conference
										The default contact icon
			/	/		/	/	/	/	The default caller photo
	/	/	/	/	/	/	/	/	/	The default Bluetooth-Enabled mobile phone caller photo and Bluetooth-Enabled mobile


T49G	T48G	T46G	T42G/T41P	T40P	T29G	T27P	T23P/T23G /T21(P) E2	T19(P) E2	CP860	Description
										phone contacts icon
		/	/	/	/	/	/	/	/	DSS Key
			/	/		/	/	/	/	Line key type is Line (line is seized)
			/	/		/	/	/	/	Line key type is Speed Dial
			/	/		/	/	/	/	Line key type is BLF/BLF List (BLF/BLF list idle state)
			/	/		/	/	/	/	Line key type is BLF/BLF List (BLF/BLF list ringing state)
			/	/		/	/	/	/	Line key type is BLF (BLF hold state)
			/	/		/	/	/	/	Line key type is BLF/BLF List (BLF/BLF list calling state)
			/	/		/	/	/	/	Line key type is BLF/BLF List (BLF/BLF list failed state)
			/	/		/	/	/	/	Line key type is BLF List (BLF list call park state)
			/	/		/	/	/	/	Line key type is Voice Mail
			/	/		/	/	/	/	Line key type is Direct Pickup

T49G	T48G	T46G	T42G/T41P	T40P	T29G	T27P	T23P/T23G /T21(P) E2	T19(P) E2	CP860	Description
			/	/		/	/	/	/	Line key type is Group Pickup
			/	/		/	/	/	/	Line key type is Call Park (park successfully/call park idle state)
			/	/		/	/	/	/	Line key type is Call Park (call park ringing state)
			/	/		/	/	/	/	Park failed
/			/	/		/	/	/	/	Line key type is Retrieve
			/	/		/	/	/	/	Line key type is Intercom
			/	/		/	/	/	/	Line key type is DTMF/Prefix
			/	/		/	/	/	/	Line key type is Local Group/XML Group
			/	/		/	/	/	/	Line key type is XML Browser
			/	/		/	/	/	/	Line key type is LDAP
			/	/		/	/	/	/	Line key type is Conference

T49G	T48G	T46G	T42G/T41P	T40P	T29G	T27P	T23P/T23G /T21(P) E2	T19(P) E2	CP860	Description
			/	/		/	/	/	/	Line key type is Forward
			/	/		/	/	/	/	Line key type is Transfer
			/	/		/	/	/	/	Line key type is Hold
			/	/		/	/	/	/	Line key type is DND
			/	/		/	/	/	/	Line key type is Recall
			/	/		/	/	/	/	Line key type is SMS
			/	/		/	/	/	/	Line key type is Record/URL Record
			/	/		/	/	/	/	Line key type is Record/URL Record (recording starts successfully)
			/	/		/	/	/	/	Line key type is Multicast Paging/Group Listening
			/	/		/	/	/	/	Line key type is Hot Desking
			/	/		/	/	/	/	Line key type is Zero Touch

T49G	T48G	T46G	T42G/T41P	T40P	T29G	T27P	T23P/T23G /T21(P) E2	T19(P) E2	CP860	Description
			/	/		/	/	/	/	Line key type is URL
			/	/		/	/	/	/	Line key type is Phone Lock
	/	/	/	/	/	/	/	/	/	Line key type is Mobile Account (Bluetooth-Enabled mobile phone is connected successfully)
	/	/	/	/	/	/	/	/	/	Line key type is Mobile Account (Bluetooth-Enabled mobile phone connection failed)
 (Flashing)	/	/	/	/	/	/	/	/	/	Line key type is Mobile Account (Bluetooth-Enabled mobile phone is connecting)
										The ACD state is available
			 and x	 and x		 and x	 and x	 and x	 and x	The ACD state is unavailable
										The ACD state is Wrap up

T49G	T48G	T46G	T42G/T41P	T40P	T29G	T27P	T23P/T23G /T21(P) E2	T19(P) E2	CP860	Description
										Log out of the ACD system
										The shared line/bridged line is idle
			/	/		/	/	/	/	The shared line receives ring-back tone
			/	/		/	/	/	/	The shared line receives an incoming call
			/	/		/	/	/	/	The shared line is in conversation
			/	/		/	/	/	/	The shared line conversation is placed on public hold
	/	/	/	/	/	/	/	/		USB flash drive is detected
	/	/	/	/	/	/	/	/		USB flash drive is detecting
										High Definition Voice

T49G	T48G	T46G	T42G/T41P	T40P	T29G	T27P	T23P/T23G /T21(P) E2	T19(P) E2	CP860	Description
	/	/	/	/	/	/	/	/	/	External monitor (EXT Display) is connected

Configuration Methods

IP phones can be configured automatically through configuration files stored on a central provisioning server, manually via phone user interface or web user interface, or by a combination of the automatic and manual methods.

The recommended method for configuring IP phones is automatically through a central provisioning server. If a central provisioning server is not available, the manual method will allow changes to most features.

The following sections describe how to configure IP phones using each method.

- [Phone User Interface](#)
- [Web User Interface](#)
- [Configuration Files](#)

Phone User Interface

An administrator or a user can configure and use IP phones via phone user interface. Access to specific features is restricted to the administrator. The default password is "admin" (case-sensitive). Not all features are available on phone user interface. For more information, refer to [Yealink phone-specific user guide](#).

Web User Interface

An administrator or a user can configure IP phones via web user interface. The default user name and password for the administrator to log into the web user interface are both "admin" (case-sensitive). Most features are available for configuring via web user interface. IP phones support both HTTP and HTTPS protocols for accessing the web user interface. For more information, refer to [Web Server Type](#) on page 167.

Configuration Files

An administrator can deploy and maintain a mass of IP phones using configuration files. The configuration files consist of:

- Common CFG file
- MAC-Oriented CFG file
- MAC-local CFG file

Common CFG file

A Common CFG file contains parameters that affect the basic operation of the IP phone, such as language and volume. It will be effectual for all IP phones of the same model.

The common CFG file has a fixed name for each IP phone model. The name of the Common CFG file for each IP phone model is:

- SIP VP-T49G: y000000000051.cfg
- SIP-T48G: y000000000035.cfg
- SIP-T46G: y000000000028.cfg
- SIP-T42G: y000000000029.cfg
- SIP-T41P: y000000000036.cfg
- SIP-T40P: y000000000054.cfg
- SIP-T29G: y000000000046.cfg
- SIP-T27P: y000000000045.cfg
- SIP-T23P/G: y000000000044.cfg
- SIP-T21(P) E2: y000000000052.cfg
- SIP-T19(P) E2: y000000000053.cfg
- CP860: y000000000037.cfg

MAC-Oriented CFG file

A MAC-Oriented CFG file contains parameters unique to a particular phone. It will only be effectual for a specific IP phone. The MAC-Oriented CFG file is named after the MAC address of the IP phone. For example, if the MAC address of an IP phone is 00156574B150, the name of the MAC-Oriented CFG file must be 00156574b150.cfg (case-sensitive).

MAC-local CFG file

A MAC-local CFG file contains changes that users make via web user interface and phone user interface. It will only be effectual for a specific IP phone. The MAC-local CFG file is named after the MAC address of the IP phone. This file is stored locally on the IP phone and can also be uploaded to the provisioning server.

Most configurations made by users via web user interface and phone user interface can be saved to the <MAC>-local.cfg file, but some configurations listed as below are defined never to be saved to the <MAC>-local.cfg file:

- Configurations associated with the password.

For example,

```
#Configure the password for PPPoE connection. (PPPoE is not applicable to
SIP-T42G/T41P/CP860 IP phones)
```

```
network.pppoe.password =
```

- Configurations requiring a reboot during auto provisioning.

For example,

```
#Configure the IP address mode.
```

network.ip_address_mode =

- The following specified configurations.

#Configure always forward feature.

forward.always.enable =

forward.always.target =

forward.always.on_code =

forward.always.off_code =

#Configure busy forward feature.

forward.busy.enable =

forward.busy.target =

forward.busy.on_code =

forward.busy.off_code =

#Configure no answer forward feature.

forward.no_answer.enable =

forward.no_answer.target =

forward.no_answer.timeout =

forward.no_answer.on_code =

forward.no_answer.off_code =

#Configure DND feature.

features.dnd.enable =

features.dnd.on_code =

features.dnd.off_code =

#Configure always forward feature for account X. (It is not applicable to SIP-T19(P) E2 and CP860 IP phones. X stands for the serial number of account)

account.X.always_fwd.enable =

account.X.always_fwd.target =

account.X.always_fwd.on_code =

account.X.always_fwd.off_code =

#Configure busy forward feature for account X. (It is not applicable to SIP-T19(P) E2 and CP860 IP phones. X stands for the serial number of account)

account.X.busy_fwd.enable =

account.X.busy_fwd.target =

account.X.busy_fwd.on_code =

account.X.busy_fwd.off_code =

#Configure no answer forward feature for account X. (It is not applicable to SIP-T19(P) E2 and CP860 IP phones. X stands for the serial number of account)

account.X.timeout_fwd.enable =

account.X.timeout_fwd.target =

```

account.X.timeout_fwd.timeout =
account.X.timeout_fwd.on_code =
account.X.timeout_fwd.off_code =
#Configure DND feature for account X. (It is not applicable to SIP-T19(P) E2 and
CP860 IP phones. X stands for the serial number of account)
account.X.dnd.enable =
account.X.dnd.on_code =
account.X.dnd.off_code =
#Configure the access URL of the firmware file.
firmware.url =
#Configure the access URL of configuration files.
auto_provision.server.url=

```

The following configurations are defined to be bundled together. If a user modifies one of the configurations in a group via web user interface and phone user interface, the other configurations in this group can also be saved to the <MAC>-local.cfg file (if the configuration value is blank, write "%NULL%" into the configuration) in addition to the modified configuration.

```

#Group1: Configure line key. (Line key is not applicable to SIP-T19(P) E2 and CP860 IP
phones. X stands for the serial number of line key)
linekey.X.line =
linekey.X.value =
linekey.X.pickup_value =
linekey.X.type =
linekey.X.xml_phonebook =
linekey.X.label =
#Group2: Configure programable key. (X stands for the serial number of programable
key)
programablekey.X.type =
programablekey.X.line =
programablekey.X.value =
programablekey.X.xml_phonebook =
programablekey.X.history_type =
programablekey.X.label =
#Group3: Configure expansion module key. (Expansion module key is only applicable
to the SIP-T48G/T46G/T29G/T27P IP phones. X stands for the serial number of expansion
module, Y stands for the serial number of expansion key)
expansion_module.X.key.Y.type =
expansion_module.X.key.Y.line =

```

expansion_module.X.key.Y.value =
 expansion_module.X.key.Y.pickup_value =
 expansion_module.X.key.Y.label =
 expansion_module.X.key.Y.xml_phonebook =

The MAC-local CFG file enables the phone to keep user personalized settings. For more information on how to keep user personalized settings, refer to [Keep User Personalized Settings](#) on page 55.

Central Provisioning

IP phones can be centrally provisioned from a provisioning server using the configuration files (<y0000000000xx>.cfg and <MAC>.cfg). You can use a text-based editing application to edit configuration files, and then store configuration files to a provisioning server. For more information on the provisioning server, refer to [Provisioning Server](#) on page 66.

IP phones can obtain the provisioning server address during startup. Then IP phones download configuration files from the provisioning server, resolve and update the configurations written in configuration files. This entire process is called auto provisioning. For more information on auto provisioning, refer to [Yealink_SIP-T2 Series_T19\(P\) E2_T4 Series_CP860_W56P_IP_Phones_Auto_Provisioning_Guide](#).

Obtaining Configuration Files and Resource Files

When configuring particular features, you may need to upload resource files (e.g., local contact directory, remote phone book) to IP phones. If the resource file is to be used for all IP phones of the same model, the resource file access URL is best specified in the <y0000000000xx>.cfg file. However, if you want to specify the desired phone to use the resource file, the resource file access URL should be specified in the <MAC>.cfg file.

The names of the Yealink-supplied template files are:

Template File		File Name
Configuration Files	Common CFG file	Common.cfg
	MAC-Oriented CFG file	MAC.cfg
Resource Files	AutoDST Template	AutoDST.xml
	Language Packs	For example, 000.GUI.English.lang 1.English_note.xml 1.English.js

Template File		File Name
	Keypad Input Method File (not applicable to SIP VP-T49G IP phones)	ime.txt
	Onscreen Keyboard Input Method Files (only applicable to SIP VP-T49G IP phones)	For example, keyboard_lang.xml keyboard_ime_1.xml keyboard_ime_num.xml keyboard_layout_1.xml
	Replace Rule Template	dialplan.xml
	Dial-now Template	dialnow.xml
	Softkey Layout Template	CallFailed.xml CallIn.xml Connecting.xml Dialing.xml (not applicable to SIP VP-T49G and SIP-T48G IP phones) RingBack.xml Talking.xml
	Directory Template	favorite_setting.xml (not applicable to SIP VP-T49G IP phones)
	Super Search Template	super_search.xml
	Local Contact File	contact.xml
	Remote Phone Book Template	Department.xml Menu.xml


You can ask the distributor or Yealink FAE for template files. You can also obtain the template files online:

<http://support.yealink.com/documentFront/forwardToDocumentFrontDisplayPage>.

To download template files:

1. Go to Yealink [Document Download](#) page and select the desired phone model.
2. Download and extract the combined configuration files to your local system.

The following illustration shows the template files available for SIP-T23G IP phones running firmware version 80.



3. Open the folder you extracted and identify the template file you will edit according to the table introduced above.

For some features, you can customize the filename as required. The following table lists the special characters supported by Yealink IP phones:

Platform \ Server	HTTP/HTTPS	TFTP/FTP
Windows	Support: ~ ` ! @ \$ ^ () _ - , . ' ; [] { } (including space) Not Support: < > : " / \ * ? # % & = +	Support: ~ ` ! @ \$ ^ () _ - , . ' ; [] { } % & = + (including space) Not Support: < > : " / \ * ? #

Platform \ Server	HTTP/HTTPS	TFTP/FTP
Linux	Support: ~ ` ! @ \$ ^ () _ - , . ' ; [] { } < > : " (including space) Not Support: / \ * ? # % & = +	Support: ~ ` ! @ \$ ^ () _ - , . ' ; [] { } < > : " " % & = + (including space) Not Support: / \ * ? #

Keep User Personalized Settings

Generally, the administrator deploys phones in batch via auto provisioning, yet some users would like to keep the personalized settings (e.g., ringtones, dial plan, time format and DSS keys), after auto provisioning. These specific scenarios are applicable to SIP VP-T49G/SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860 IP phones running firmware version 80 or later. The following demonstrated specific scenarios are taking SIP-T46G/T23G IP phones as example for reference.

Note

Yealink IP phones support FTP, TFTP, HTTP and HTTPS protocols for uploading the MAC-local CFG file. This section takes the TFTP protocol as an example. Before performing the following, make sure the provisioning server supports uploading.

If you are using the HTTP/HTTPS server, you can specify the way the IP phone uploads the MAC-local CFG file to the provisioning server. It is determined by the value of the parameter "auto_provision.custom.upload_method".

Configuration Parameters

The following table lists the configuration parameters used to determine the phone behavior for keeping user personalized settings:

Parameters	Permitted Values	Default
auto_provision.custom.protect	0 or 1	0
Description: Enables or disables the IP phone to keep user personalized settings after auto provisioning. 0-Disabled 1-Enabled If it is set to 1 (Enabled), personalized settings configured via web or phone user interface will be kept after auto provisioning. Web User Interface:		

Parameters	Permitted Values	Default
None Phone User Interface: None		
auto_provision.custom.sync	0 or 1	0
Description: <p>Enables or disables the IP phone to periodically (every 5 minutes) upload the <MAC>-local.cfg file to the provisioning server, and download the <MAC>-local.cfg file from the provisioning server during auto provisioning.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 1 (Enabled), the IP phone will periodically upload the <MAC>-local.cfg file to the provisioning server to back up this file. During auto provisioning, the IP phone will download the <MAC>-local.cfg file from the provisioning server to override the one stored on the phone.</p> <p>If it is set to 0 (Disabled), the IP phone will not upload the <MAC>-local.cfg file to the provisioning server. During auto provisioning, the IP phone will not download the <MAC>-local.cfg file from the provisioning server.</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		
auto_provision.custom.upload_method	0 or 1	0
Description: <p>Configures the way the IP phone uploads the <MAC>-local.cfg file to the provisioning server (for HTTP/HTTPS server only).</p> <p>0-PUT 1-POST</p> <p>Note: It works only if the value of the parameter "auto_provision.custom.sync" is set to 1 (Enabled).</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		

For more information on how to configure these parameters in different scenarios, refer to the following introduced scenarios.

Scenario A Keep user personalized configuration settings

Scenario (A) Keep user personalized configuration settings (IP phones are running firmware version prior to X.73.0.1)

The administrator wishes to upgrade firmware from the old version to the latest version. Meanwhile, keep user personalized settings after auto provisioning and upgrade. This scenario is only applicable to SIP-T48G/T46G/T42G/T41P IP phones.

Scenario Conditions:

- The current firmware version of the SIP-T46G IP phone is 28.71.0.181. This firmware version does not support keeping user personalized settings and generating a <MAC>-local.cfg file.
- The target firmware version of the SIP-T46G IP phone is 28.80.0.60. This firmware version supports keeping user personalized settings after auto provisioning or upgrade.
- The MAC address of the SIP-T46G IP phone: 001565221229
- Provisioning server URL: tftp://192.168.1.211
- Place the target firmware to the root directory of the provisioning server.
- Create a new directory "ProvisioningDir_new" under the root directory of the provisioning server.

Note

The IP phone with old firmware does not support keeping user personalized settings after auto provisioning and upgrade. You can configure the value of the parameter "auto_provision.custom.protect" to 1 in the configuration file to keep user personalized settings after auto provisioning and upgrade.

Do the following operations:

1. Place the configuration files (y000000000028.cfg and 001565221229.cfg) that you want the IP phone to download to the new directory "ProvisioningDir_new" of the provisioning server.
2. Add/Edit the following parameter in the y000000000028.cfg file or 001565221229.cfg file you want the IP phone to download:

```
auto_provision.custom.protect = 1
```

3. Create a blank configuration file "y000000000028.cfg" on the root directory of the

provisioning server and add the following parameters to this file.

```
firmware.url = tftp://192.168.1.211/28.80.0.60.rom  
auto_provision.server.url = tftp://192.168.1.211/ProvisioningDir_new
```

Note

If your IP phone is running firmware version prior to 61, the IP phone can only recognize the old (M1) configuration file for auto provisioning, so the blank configuration file created above uses the M1 template.

4. Trigger the IP phone to perform the auto provisioning process. For more information on how to trigger auto provisioning process, refer to *Triggering the IP Phone to Perform the Auto Provisioning* section in [Yealink SIP-T2 Series_T19\(P\) E2_T4 Series_CP860_W56P_IP_Phones_Auto_Provisioning_Guide](#).

During auto provisioning, the IP phone first downloads the y000000000028.cfg file, and then downloads firmware from the root directory of the provisioning server.

The IP phone reboots to complete firmware upgrade, and then starts auto provisioning process again which is triggered by phone reboot (the power on mode is enabled by default). It downloads the y000000000028.cfg and 001565221229.cfg files in sequence from the new directory "ProvisioningDir_new" of the provisioning server. As no 001565221229-local.cfg file exists on the IP phone, the IP phone automatically generates a 001565221229-local.cfg file which saves the personalized settings of the old firmware.

The IP phone updates configurations in the downloaded configuration files orderly to the IP phone system. As the value of the parameter "auto_provision.custom.protect" is set to 1, the phone also updates the configurations stored in the 001565221229-local.cfg file on the phone. As a result, the personalized settings of the old firmware are remained after upgrade and auto provisioning.

Note

If a configuration item is both in the downloaded MAC-local.cfg file and Common CFG file/ MAC-Oriented CFG file, setting of the configuration item in the MAC-local CFG file will be written and saved to the IP phone system.

Scenario (B) Keep user personalized configuration settings (IP phones are running firmware version X.80.0.1 or later)

The administrator wishes to upgrade firmware from the old version to the latest version. Meanwhile, keep user personalized settings after auto provisioning and upgrade.

Scenario Conditions:

- SIP-T23G IP phone current firmware version: 44.80.0.1. This firmware supports keeping personalized settings and generating a <MAC>-local.cfg file.

- SIP-T23G IP phone target firmware version: 44.80.0.60. This firmware supports keeping personalized settings and generating a <MAC>-local.cfg file.
- SIP-T23G IP phone MAC: 001565770984
- Provisioning server URL: tftp://192.168.1.211
- Place the target firmware to the root directory of the provisioning server.

The old firmware version supports keeping personalized settings and generating a <MAC>-local.cfg file. To keep user personalized settings after auto provisioning and upgrade, you need to configure the value of the parameter "auto_provision.custom.protect" to 1 in the configuration file.

Do one of the following operations:

Scenario Operations I:

1. Add/Edit the following parameters in the y0000000000044.cfg file or 001565770984.cfg file you want the IP phone to download:

```
auto_provision.custom.protect=1

auto_provision.custom.sync=1

firmware.url = tftp://192.168.1.211/44.80.0.60.rom
```

2. Trigger the IP phone to perform the auto provisioning process. For more information on how to trigger auto provisioning process, refer to *Triggering the IP Phone to Perform the Auto Provisioning* section in [Yealink SIP-T2 Series_T19\(P\) E2_T4 Series_CP860_W56P_IP_Phones_Auto_Provisioning_Guide](#).

During auto provisioning, the IP phone first downloads the y0000000000044.cfg file, and then downloads firmware from the root directory of the provisioning server.

The IP phone reboots to complete firmware upgrade, and then starts auto provisioning process again which is triggered by phone reboot (the power on mode is enabled by default). It downloads the y0000000000044.cfg, 001565770984.cfg and the 001565770984-local.cfg file in sequence from the provisioning server, and then updates configurations in these downloaded configuration files orderly to the IP phone system. The IP phone starts up successfully, and the personalized settings in the 001565770984-local.cfg file are kept after auto provisioning.

When a user customizes feature configurations via web/phone user interface, the IP phone will save the personalized configuration settings to the 001565770984-local.cfg file on the IP phone, and then periodically (every 5 minutes) upload this file to the provisioning server.

Note

If a configuration item is both in the downloaded MAC-local.cfg file and Common CFG file/ MAC-Oriented CFG file, setting of the configuration item in the MAC-local CFG file will be written and saved to the IP phone system.

Scenario Operations II:

1. Add/Edit the following parameters in the y000000000044.cfg file or 001565770984.cfg file you want the IP phone to download:

```
auto_provision.custom.protect=1

auto_provision.custom.sync=0

firmware.url = tftp://192.168.1.211/44.80.0.60.rom
```

2. Trigger the IP phone to perform the auto provisioning process. For more information on how to trigger auto provisioning process, refer to *Triggering the IP Phone to Perform the Auto Provisioning* section in [Yealink_SIP-T2 Series_T19\(P\) E2_T4 Series_CP860_W56P_IP_Phones_Auto_Provisioning_Guide](#).

During auto provisioning, the IP phone first downloads the y000000000044.cfg file, and then downloads firmware from the root directory of the provisioning server.

The IP phone reboots to complete firmware upgrade, and then starts auto provisioning process again which is triggered by phone reboot (the power on mode is enabled by default). It downloads the y000000000044.cfg and 001565770984.cfg files in sequence, and then updates configurations in the downloaded configuration files orderly to the IP phone system. As the value of the parameter "auto_provision.custom.protect" is set to 1, configurations in the 001565770984-local.cfg file saved on the IP phone are also updated.

The IP phone starts up successfully, and personalized settings are kept after auto provisioning. When a user customizes feature configurations via web/phone user interface, the IP phone will save the personalized settings to the 001565770984-local.cfg file on the IP phone only.

Note

In this scenario, the IP phone will not upload the MAC-local.cfg file to provisioning server and request to download the MAC-local.cfg file from provisioning server during auto provisioning.

If a configuration item is both in the MAC-local.cfg file on the IP phone and Common CFG file/ MAC-Oriented CFG file downloaded from auto provisioning server, setting of the configuration item in the MAC-local CFG file will be written and saved to the IP phone system.

If value of the parameter "auto_provision.custom.protect" is set to 0, the personalized settings in the 001565770984-local.cfg file will be overridden after auto provisioning, no matter what the value of the parameter "auto_provision.custom.sync" is.

Note

If a configuration is modified via both web user interface and phone user interface, the later modification will prevail.

For more information on the flowchart of keep user personalized configuration settings, refer to [Appendix E: Auto Provisioning Flowchart \(Keep user personalized configuration settings\)](#) on page 944.

Scenario B Clear user personalized configuration settings

The administrator or user wishes to clear user personalized configuration settings via phone user interface.

Scenario Conditions:

- SIP-T23G IP phone MAC: 001565770984
- The current firmware of the phone is 44.80.0.60 or later.
- Provisioning server URL: tftp://192.168.1.211
- auto_provision.custom.protect = 1

Note

The **Reset Local Configuration** option on the web/phone user interface is available only if the value of the parameter "auto_provision.custom.protect" was set to 1.

If the value of the parameter "auto_provision.custom.sync" was set to 1, the configurations in the 001565770984-local.cfg file on the provisioning server will be also cleared after resetting personalized settings of the phone.


Scenario Operations:

You can clear the personalized settings of the phone via phone or web user interface.

To clear personalized configuration settings via phone user interface:

1. Press **Menu->Settings->Advanced Settings** (default password: admin).
2. Select **Reset Local Configuration**.

The LCD screen prompts "Reset local configurations?".




3. Press the **OK** soft key.

The LCD screen prompts "Deleted successfully".

To clear personalized configuration settings via web user interface:

1. Click on **Settings->Upgrade**.
2. Click **Reset Local Config**.

The web user interface prompts "Are you sure to reset the local configuration".



3. Click **OK**.

Configurations in the 001565770984-local.cfg file saved on the phone will be cleared. If the IP phone is triggered to perform auto provisioning after resetting local configuration file, it will download the configuration files from the provisioning server and update the configurations to the phone system. As there is no configuration in the 001565770984-local.cfg file, configurations in the y0000000000044.cfg/001565770984.cfg file will take effect.

Scenario C Keep user personalized settings after factory reset

The IP phone requires factory reset when it has a breakdown, but the user wishes to keep personalized settings of the phone after factory reset.

Scenario Conditions:

- SIP-T23G IP phone MAC: 001565770984
- Provisioning server URL: tftp://192.168.1.211
- auto_provision.custom.sync = 1
- auto_provision.custom.protect = 1

Note

As the parameter "auto_provision.custom.sync" was set to 1, the 001565770984-local.cfg file on the IP phone will be uploaded to the provisioning server at tftp://192.168.1.211.


Scenario Operations:

You can keep the personalized settings of the phone after factory reset via phone or web user interface.

To reset the phone to factory via phone user interface:

1. Press **Menu->Settings->Advanced Settings** (default password: admin).
2. Select **Reset to Factory**.

The LCD screen prompts “Reset to factory setting?”.



3. Press the **OK** soft key.


The LCD screen prompts “Resetting to factory, please Wait...”.

The LCD screen prompts “Welcome Initializing...please wait”.

To reset the phone to factory via web user interface:

1. Click on **Settings->Upgrade**.
2. Click **Reset to Factory Setting** to reset the phone.

The web user interface prompts “Do you want to reset to factory?”.



3. Click **OK**.

After startup, all configurations of the phone will be reset to factory defaults.

Configurations in the 001565770984-local.cfg file saved on the IP phone will also be cleared. But configurations in the 001565770984-local.cfg file stored on the provisioning server (tftp://192.168.1.211) will not be cleared after reset.

To retrieve personalized settings of the phone after factory reset:

1. Set the values of the parameters “auto_provision.custom.sync” and “auto_provision.custom.protect” to be 1 in the configuration file (y000000000044.cfg or 001565770984.cfg).
2. Trigger the phone to perform the auto provisioning process.

The IP phone will download the 001565770984-local.cfg file from the provisioning server, and then update configurations in it during auto provisioning. As a result, the personalized settings of the phone are retrieved after factory reset.

Scenario D Import or export the local configuration file

The administrator or user can export the local configuration file to check the personalized settings of the phone configured by the user, or import the local configuration file to configure or change settings of the phone.

Scenario Conditions:

- SIP-T23G IP phone MAC: 001565770984
- The current firmware of the phone is 44.80.0.60 or later.
- Provisioning server URL: tftp://192.168.1.211


Note

As the personalized settings of the base station cannot be changed via auto provisioning when the value of the parameter "auto_provision.custom.protect" is set to 1, it is cautious to change the settings in the <MAC>-local.cfg file before importing it.

Scenario Operations:

To export local configuration file via web user interface:

1. Click on **Settings->Configuration**.
2. Select **Local Configuration** from the pull-down list of **Export CFG Configuration File**, and then click **Export** to open file download window, and then save the 001565770984-local.cfg file to the local system.



The administrator or user can edit the 001565770984-local.cfg file after exporting.

To import local configuration file via web user interface:

1. Click on **Settings->Configuration**.

- In the **Import CFG Configuration File** field, click **Browse** to locate the 001565770984-local.cfg file from your local system and select **Local Configuration** from the pull-down list.

The screenshot shows the Yealink T236 web interface. The 'Settings' tab is selected. On the left sidebar, 'Configuration' is highlighted. The main content area shows the 'Import CFG Configuration File' section, which is outlined with a red rectangle. This section contains a 'Browse...' button, the text 'No file selected.', a dropdown menu set to 'Local Configuration', and an 'Import' button. Above this, there is an 'Export or Import Configuration' section with 'Browse...', 'Import', and 'Export' buttons. Below the red box, there are sections for 'Pcap Feature' (with Start, Stop, and Export buttons), 'Export System Log' (with radio buttons for Local, Server, and Ftp/Tftp Server, and an Export button), 'System Log Level' (with a dropdown set to 3), and 'Export All Diagnostic Files' (with Start, Stop, and Export buttons). At the bottom are 'Confirm' and 'Cancel' buttons. On the right, a 'NOTE' box provides information about configuration files and a link to guides.

- Click **Import**.

The configurations in the imported 001565770984-local.cfg file will override the one in the existing local configuration file. The configurations only in the existing local configuration file will not be cleared. The configurations in the new 001565770984-local.cfg file will be saved to the phone flash and take effect.

Note

If the value of the parameter "auto_provision.custom.sync" is set to 1, and the 001565770984-local.cfg file is successfully imported, the new 001565770984-local.cfg file will be uploaded to the provisioning server and overrides the existing one on the server.

Provisioning Server

Supported Provisioning Protocols

IP phones perform the auto provisioning function of downloading configuration files, downloading resource files and upgrading firmware. The transfer protocol is used to download files from the provisioning server. IP phones support several transport protocols for provisioning, including FTP, TFTP, HTTP, and HTTPS protocols. And you can specify the transport protocol in the provisioning server address, for example, `http://xxxxxxx`. If not specified, the TFTP protocol is used. The provisioning server address can be IP address, domain name or URL. If a user name and password are specified as part of the provisioning server address, for example, `http://user:pwd@server/dir`, they will be used only if the server supports them.

Note

A URL should contain forward slashes instead of back slashes and should not contain spaces. Escape characters are not supported.

If a user name and password are not specified as part of the provisioning server address, the User Name and Password of the provisioning server configured on the phone will be used.

There are two types of FTP methods—active and passive. IP phones are not compatible with active FTP.

Setting up the Provisioning Server

The provisioning server can be on the local LAN or anywhere on the Internet. Use the following procedure as a recommendation if this is your first provisioning server setup. For more information on how to set up a provisioning server, refer to [Yealink_SIP-T2_Series_T19\(P\)_E2_T4_Series_CP860_W56P_IP_Phones_Auto_Provisioning_Guide](#).

To set up the provisioning server:

1. Install a provisioning server application or locate a suitable existing server.
2. Create an account and home directory.
3. Set security permissions for the account.
4. Create configuration files and edit them as desired.
5. Copy the configuration files and resource files to the provisioning server.

For more information on how to deploy IP phones using configuration files, refer to [Deploying Phones from the Provisioning Server](#) on page 67.

Note

Typically all phones are configured with the same server account, but the server account provides a means of conveniently partitioning the configuration. Give each account a unique home directory on the server and change the configuration on a per-line basis.

Deploying Phones from the Provisioning Server

The parameters in the new downloaded configuration files will override the duplicate parameters in files downloaded earlier. During auto provisioning, IP phones download the common configuration file first, and then the MAC-oriented file. Therefore any parameter in the MAC-oriented configuration file will override the same one in the common configuration file.

Yealink supplies configuration files for each phone model, which is delivered with the phone firmware. The configuration files, supplied with each firmware release, must be used with that release. Otherwise, configurations may not take effect, and the IP phone will behave without exception. Before you configure parameters in the configuration files, Yealink recommends that you create new configuration files containing only those parameters that require changes.

To deploy IP phones from the provisioning server:

1. Create per-phone configuration files by performing the following steps:
 - a) Obtain a list of phone MAC addresses (the bar code label on the back of the IP phone or on the outside of the box).
 - b) Create per-phone <MAC>.cfg files by using the MAC-Oriented CFG file from the distribution as templates.
 - c) Edit the parameters in the file as desired.
2. Create new common configuration files by performing the following steps:
 - a) Create <y0000000000xx>.cfg files by using the Common CFG file from the distribution as templates.
 - b) Edit the parameters in the file as desired.
3. Copy configuration files to the home directory of the provisioning server.
4. Reboot IP phones to trigger the auto provisioning process.

IP phones discover the provisioning server address, and then download the configuration files from the provisioning server.

For more information on configuration files, refer to [Configuration Files](#) on page 48. For protecting against unauthorized access, you can encrypt configuration files. For more information on encrypting configuration files, refer to [Encrypting Configuration Files](#) on page 852.

During the auto provisioning process, the IP phone supports the following methods to discover the provisioning server address:

- **Zero Touch:** Zero Touch feature guides you to configure network settings and the provisioning server address via phone user interface after startup.
- **PnP:** PnP feature allows IP phones to discover the provisioning server address by broadcasting the PnP SUBSCRIBE message during startup.
- **DHCP:** DHCP option can be used to provide the address or URL of the provisioning

server to IP phones. When the IP phone requests an IP address using the DHCP protocol, the resulting response may contain option 66 or the custom option (if configured) that contains the provisioning server address.

- **Static:** You can manually configure the server address via phone user interface or web user interface.

For more information on the above methods, refer to [Yealink_SIP-T2 Series_T19\(P\) E2_T4 Series_CP860_W56P_IP_Phones_Auto_Provisioning_Guide](#).

Configuring Basic Network Parameters

In order to get your IP phones running, you must perform basic network setup, such as IP address and subnet mask configuration. This section describes how to configure basic network parameters for IP phones.

Note

This section mainly introduces IPv4 network parameters. IP phones also support IPv6. For more information on IPv6, refer to [IPv6 Support](#) on page 743.

DHCP

DHCP (Dynamic Host Configuration Protocol) is a network protocol used to dynamically allocate network parameters to network hosts. The automatic allocation of network parameters to hosts eases the administrative burden of maintaining an IP network. IP phones comply with the DHCP specifications documented in RFC 2131. If using DHCP, IP phones connected to the network become operational without having to be manually assigned IP addresses and additional network parameters.

Procedure

DHCP can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure DHCP on the IP phone. Parameter: network.internet_port.type
Local	Web User Interface	Configure DHCP on the IP phone. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T2 9G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=network&q=load">http://<phoneIPAddress>/servlet ?p=network&q=load For SIP VP-T49G:


		http://<phoneIPAddress>/servlet?m=mod_data&p=network&q=load
	Phone User Interface	Configure DHCP on the IP phone.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.internet_port.type	0, 1 or 2	0
<p>Description: Configures the Internet (WAN) port type for IPv4.</p> <p>0-DHCP 1-PPPoE (not applicable to SIP-T42G/T41P/CP860 IP phones) 2-Static IP Address</p> <p>Note: It works only if the value of the parameter “network.ip_address_mode” is set to 0 (IPv4) or 2 (IPv4 & IPv6). If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Basic->IPv4 Config</p> <p>Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->WAN Port->IPv4</p>		

To configure DHCP via web user interface:

1. Click on **Network->Basic**.
2. In the **IPv4 Config** block, mark the **DHCP** radio box.



3. Click **Confirm** to accept the change.

A dialog box pops up to prompt that settings will take effect after a reboot.

- Click **OK** to reboot the phone.

To configure DHCP via phone user interface:

- Press **Menu->Settings->Advanced Settings** (default password: admin)
->**Network->WAN Port->IPv4**.
- Select **DHCP IPv4 Client** and then press the **Enter** soft key.
- Press the **Save** soft key to accept the change.

The IP phone reboots automatically to make settings effective after a period of time.

Static DNS

Static DNS address(es) can be configured and used even though DHCP is enabled.

Procedure

Static DNS can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the static DNS feature. Parameters: network.static_dns_enable
	<MAC>.cfg	Configure static DNS address. Parameters: network.primary_dns network.secondary_dns
Local	Web User Interface	Configure the static DNS feature. Configure static DNS address. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=network&q=load">http://<phoneIPAddress>/servlet?p=network&q=load For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=network&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=network&q=load
	Phone User Interface	Configure the static DNS feature. Configure static DNS address.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.static_dns_enable	0 or 1	0
<p>Description: Triggers the static DNS feature to on or off.</p> <p>0-Off 1-On</p> <p>If it is set to 0 (Off), the IP phone will use the IPv4 DNS obtained from DHCP.</p> <p>If it is set to 1 (On), the IP phone will use manually configured static IPv4 DNS.</p> <p>Note: It works only if the value of the parameter "network.internet_port.type" is set to 0 (DHCP). If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Basic->IPv4 Config->Static DNS</p> <p>Phone User Interface: Menu->Settings->Advanced Settings (default password: admin)->Network->WAN Port->IPv4->DHCP IPv4 Client->Static DNS</p>		
network.primary_dns	IPv4 Address	Blank
<p>Description: Configures the primary IPv4 DNS server.</p> <p>Example: network.primary_dns = 202.101.103.55</p> <p>Note: It works only if the value of the parameter "network.static_dns_enable" is set to 1 (On). If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Basic->IPv4 Config->Static IP Address->Primary DNS</p> <p>Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->WAN Port->IPv4->DHCP IPv4 Client->Static DNS (Enabled) ->IPv4 Pri.DNS</p>		
network.secondary_dns	IPv4 Address	Blank
<p>Description:</p>		

Parameters	Permitted Values	Default
<p>Configures the secondary IPv4 DNS server.</p> <p>Example:</p> <p>network.secondary_dns = 202.101.103.54</p> <p>Note: It works only if the value of the parameter "network.static_dns_enable" is set to 1 (On). If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Network->Basic->IPv4 Config->Static IP Address->Secondary DNS</p> <p>Phone User Interface:</p> <p>Menu->Settings->Advanced Settings (default password: admin) ->Network->WAN Port->IPv4->DHCP IPv4 Client->Static DNS (Enabled) ->IPv4 Sec.DNS</p>		

To configure static DNS address when DHCP is used via web user interface:

1. Click on **Network->Basic**.
2. In the **IPv4 Config** block, mark the **DHCP** radio box.
3. In the **Static DNS** block, mark the **On** radio box.
4. Enter the desired values in the **Primary DNS** and **Secondary DNS** fields.

5. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
6. Click **OK** to reboot the phone.

To configure static DNS when DHCP is used via phone user interface:

1. Press **Menu->Settings->Advanced Settings** (default password: admin)
->**Network->WAN Port->IPv4->DHCP IPv4 Client**.
2. Press **←** or **→**, or the **Switch** soft key to select **Enabled** from the **Static DNS** field.

3. Enter the desired value in the **IPv4 Pri.DNS** and **IPv4 Sec.DNS** field respectively.
4. Press the **Save** soft key to accept the change.

The IP phone reboots automatically to make settings effective after a period of time.

DHCP Option

DHCP provides a framework for passing information to TCP/IP network devices. Network and other control information are carried in tagged data items that are stored in the options field of the DHCP message. The data items themselves are also called options.

DHCP can be initiated by simply connecting the IP phone with the network. IP phones broadcast DISCOVER messages to request the network information carried in DHCP options, and the DHCP server responds with specific values in corresponding options.

The following table lists common DHCP options supported by IP phones.

Parameter	DHCP Option	Description
Subnet Mask	1	Specify the client's subnet mask.
Time Offset	2	Specify the offset of the client's subnet in seconds from Coordinated Universal Time (UTC).
Router	3	Specify a list of IP addresses for routers on the client's subnet.
Time Server	4	Specify a list of time servers available to the client.
Domain Name Server	6	Specify a list of domain name servers available to the client.
Log Server	7	Specify a list of MIT-LCS UDP servers available to the client.
Host Name	12	Specify the name of the client.
Domain Server	15	Specify the domain name that client should use when resolving hostnames via DNS.
Broadcast Address	28	Specify the broadcast address in use on the client's subnet.
Network Time Protocol Servers	42	Specify a list of NTP servers available to the client by IP address.
Vendor-Specific Information	43	Identify the vendor-specific information.
Vendor Class	60	Identify the vendor type.

Parameter	DHCP Option	Description
Identifier		
TFTP Server Name	66	Identify a TFTP server when the 'sname' field in the DHCP header has been used for DHCP options.
Boot file Name	67	Identify a boot file when the 'file' field in the DHCP header has been used for DHCP options.

For more information on DHCP options, refer to
<http://www.ietf.org/rfc/rfc2131.txt?number=2131> or
<http://www.ietf.org/rfc/rfc2132.txt?number=2132>.

If you do not have the ability to configure the DHCP options for discovering the provisioning server on the DHCP server, an alternate method of automatically discovering the provisioning server address is required. Connecting to the secondary DHCP server that responds to DHCP INFORM queries with a requested provisioning server address is one possibility. For more information, refer to
<http://www.ietf.org/rfc/rfc3925.txt?number=3925>.

DHCP Option 66 and Option 43

Yealink IP phones support obtaining the provisioning server address by detecting DHCP options during startup.

The phone will automatically detect the option 66 and option 43 for obtaining the provisioning server address. DHCP option 66 is used to identify the TFTP server. DHCP option 43 is a vendor-specific option, which is used to transfer the vendor-specific information.

To use DHCP option 66 or DHCP option 43, make sure the DHCP Active feature is enabled.

Procedure

DHCP active can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure DHCP active. Parameters: auto_provision.dhcp_option.enable
Local	Web User Interface	Configure DHCP active. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29 G/T27P/T23P/T23G/T21(P) E2/T19(P)

		E2/CP860: http://<phoneIPAddress>/servlet?p=settings-autop&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet?m=mod_data&p=settings-autop&q=load
--	--	--

Details of Configuration Parameters:

Parameters	Permitted Values	Default
auto_provision.dhcp_option.enable	0 or 1	1
<p>Description: Triggers the DHCP Option feature to on or off. 0-Off 1-On If it is set to 1 (On), the IP phone will obtain the provisioning server address by detecting DHCP options.</p> <p>Web User Interface: Settings->Auto Provision->DHCP Active</p> <p>Phone User Interface: None</p>		

To configure the DHCP active feature via web user interface:

1. Click on **Settings->Auto Provision**.

- Mark the **On** radio box in the **DHCP Active** field.

The screenshot shows the Yealink T236 web interface. The 'Settings' tab is selected, and the 'Auto Provision' section is active. The 'DHCP Active' field is highlighted with a red box, and the 'On' radio button is selected. The 'Auto Provision' section includes fields for PNP Active, Custom Option, DHCP Option Value, Server URL, User Name, Password, Attempt Expired Time, Common AES Key, MAC-Oriented AES Key, Zero Active, Wait Time, Power On, Repeatedly, Interval, and Weekly. A NOTE section on the right explains the Auto Provision process.

- Click **Confirm** to accept the change.

DHCP Option 42 and Option 2

Yealink IP phones support using the NTP server address offered by DHCP.

DHCP option 42 is used to specify a list of NTP servers available to the client by IP address. NTP servers should be listed in order of preference. DHCP option 2 is used to specify the offset of the client's subnet in seconds from Coordinated Universal Time (UTC).

To update time with the offset time offered by the DHCP server, make sure the DHCP Time feature is enabled at the web path **Settings->Time & Date->DHCP Time**. For more information on how to configure DHCP time feature, refer to [NTP Time Server](#) on page 174.

DHCP Option 12 Hostname on the IP Phone

This option specifies the host name of the client. The name may or may not be qualified with the local domain name (based on RFC 2132). See RFC 1035 for character restrictions.

Procedure

DHCP option 12 hostname can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the DHCP option 12 hostname. Parameters:
---------------------------	---------------------	--

		network.dhcp_host_name
Local	Web User Interface	<p>Configure the DHCP option 12 hostname.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>http://<phoneIPAddress>/servlet? p=features-general&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet? m=mod_data&p=features-general&q=load</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.dhcp_host_name	String within 99 characters	Refer to the following content
<p>Description:</p> <p>Configures the DHCP option 12 hostname on the IP phone.</p> <p>For SIP VP-T49G IP phones:</p> <p>The default value is SIP VP-T49G.</p> <p>For SIP-T48G IP phones:</p> <p>The default value is SIP-T48G.</p> <p>For SIP-T46G IP phones:</p> <p>The default value is SIP-T46G.</p> <p>For SIP-T42G IP phones:</p> <p>The default value is SIP-T42G.</p> <p>For SIP-T41P IP phones:</p> <p>The default value is SIP-T41P.</p> <p>For SIP-T40P IP phones:</p> <p>The default value is SIP-T40P.</p> <p>For SIP-T29G IP phones:</p> <p>The default value is SIP-T29G.</p> <p>For SIP-T27P IP phones:</p> <p>The default value is SIP-T27P.</p>		

Parameters	Permitted Values	Default
<p>For SIP-T23P IP phones:</p> <p>The default value is SIP-T23P.</p> <p>For SIP-T23G IP phones:</p> <p>The default value is SIP-T23G.</p> <p>For SIP-T21(P) E2 IP phones:</p> <p>The default value is SIP-T21P_E2.</p> <p>For SIP-T19(P) E2 IP phones:</p> <p>The default value is SIP-T19P_E2.</p> <p>For CP860 IP phones:</p> <p>The default value is CP860.</p> <p>Note: If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Features->General Information->DHCP Hostname</p> <p>Phone User Interface:</p> <p>None</p>		

To configure DHCP option 12 hostname on the IP phone via web user interface:

1. Click on **Feature->General Information**.
2. Enter the desired host name in the **DHCP Hostname** field.

3. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
4. Click **OK** to reboot the phone.

Configuring Network Parameters Manually

If DHCP is disabled or IP phones cannot obtain network parameters from the DHCP server, you need to configure them manually. The following parameters should be configured for IP phones to establish network connectivity:

- IP Address
- Subnet Mask
- Default Gateway
- Primary DNS
- Secondary DNS

Procedure

Network parameters can be configured manually using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure network parameters of the IP phone manually. Parameters: network.internet_port.type network.ip_address_mode network.internet_port.ip network.internet_port.mask network.internet_port.gateway network.primary_dns network.secondary_dns
Local	Web User Interface	Configure network parameters of the IP phone manually. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet? ?p=network&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet? ?m=mod_data&p=network&q=load
	Phone User Interface	Configure network parameters of the IP phone manually.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.internet_port.type	0, 1 or 2	0
Description: Configures the Internet (WAN) port type for IPv4. 0-DHCP 1-PPPoE (not applicable to SIP-T42G/T41P/CP860 IP phones) 2-Static IP Address Note: It works only if the value of the parameter "network.ip_address_mode" is set to 0 (IPv4) or 2 (IPv4 & IPv6). If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Network->Basic->IPv4 Config Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->WAN Port->IPv4		
network.ip_address_mode	0, 1 or 2	0
Description: Configures the IP address mode. 0-IPv4 1-IPv6 2-IPv4 & IPv6 Note: If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Network->Basic->Internet Port-> Mode(IPv4/IPv6) Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->WAN Port->IP Mode		
network.internet_port.ip	IPv4 Address	Blank
Description: Configures the IPv4 address. Example: network.internet_port.ip = 192.168.1.20		

Parameters	Permitted Values	Default
<p>Note: It works only if the value of the parameter "network.ip_address_mode" is set to 0 (IPv4) or 2 (IPv4 & IPv6), and "network.internet_port.type" is set to 2 (Static IP Address). If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Basic->IPv4 Config->Static IP Address->IP Address</p> <p>Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->WAN Port->IPv4->Static IPv4 Client->IPv4</p>		
network.internet_port.mask	Subnet Mask	Blank
<p>Description: Configures the IPv4 subnet mask.</p> <p>Example: network.internet_port.mask = 255.255.255.0</p> <p>Note: It works only if the value of the parameter "network.ip_address_mode" is set to 0 (IPv4) or 2 (IPv4 & IPv6), and "network.internet_port.type" is set to 2 (Static IP Address). If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Basic->IPv4 Config->Static IP Address->Subnet Mask</p> <p>Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->WAN Port->IPv4->Static IPv4 Client->Subnet Mask</p>		
network.internet_port.gateway	IPv4 Address	Blank
<p>Description: Configures the IPv4 default gateway.</p> <p>Example: network.internet_port.gateway = 192.168.1.254</p> <p>Note: It works only if the value of the parameter "network.ip_address_mode" is set to 0 (IPv4) or 2 (IPv4 & IPv6), and "network.internet_port.type" is set to 2 (Static IP Address). If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Basic->IPv4 Config->Static IP Address->Gateway</p> <p>Phone User Interface:</p>		

Parameters	Permitted Values	Default
Menu->Settings->Advanced Settings (default password: admin) ->Network->WAN Port->IPv4->Static IPv4 Client->Default Gateway		
network.primary_dns	IPv4 Address	Blank
<p>Description: Configures the primary IPv4 DNS server.</p> <p>Example: network.primary_dns = 202.101.103.55</p> <p>Note: It works only if the value of the parameter "network.ip_address_mode" is set to 0 (IPv4) or 2 (IPv4 & IPv6), and "network.internet_port.type" is set to 2 (Static IP Address). If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Basic->IPv4 Config->Static IP Address->Primary DNS</p> <p>Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->WAN Port->IPv4->Static IPv4 Client->IPv4 Pri.DNS</p>		
network.secondary_dns	IPv4 Address	Blank
<p>Description: Configures the secondary IPv4 DNS server.</p> <p>Example: network.secondary_dns = 202.101.103.54</p> <p>Note: It works only if the value of the parameter "network.ip_address_mode" is set to 0 (IPv4) or 2 (IPv4 & IPv6), and "network.internet_port.type" is set to 2 (Static IP Address). If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Basic->IPv4 Config->Static IP Address->Secondary DNS</p> <p>Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->WAN Port->IPv4->Static IPv4 Client->IPv4 Sec.DNS</p>		

To configure the IP address mode via web user interface:

1. Click on **Network->Basic**.

2. Select desired value from the pull-down list of **Mode(IPv4/IPv6)**.

Yealink | T236

Log Out

Status Account **Network** DSSKey Features Settings Directory Security

Basic PC Port Advanced

Internet Port

Mode(IPv4/IPv6) IPv4 & IPv6

IPv4 Config

☒ DHCP

☐ Static IP Address

IP Address

Subnet Mask

Gateway

Static DNS ☐ On ☒ Off

Primary DNS

Secondary DNS

NOTE

DHCP
DHCP (Dynamic Host Configuration Protocol) is a network protocol used to dynamically allocate network parameters to IP phones.

Static IP Address
Specifies the network parameters of IP phones manually.

PPPoE
It allows users to share a common DSL connection to the Internet.

IPv6 Support
IPv6 is developed to deal with the long-anticipated problem of IPv4 address exhaustion.

3. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
4. Click **OK** to reboot the phone.

To configure a static IPv4 address via web user interface:

1. Click on **Network->Basic**.
2. In the **IPv4 Config** block, mark the **Static IP Address** radio box.
3. Enter the desired values in the **IP Address**, **Subnet Mask**, **Gateway**, **Primary DNS** and **Secondary DNS** fields.

Yealink | T236

Log Out

Status Account **Network** DSSKey Features Settings Directory Security

Basic PC Port Advanced

Internet Port

Mode(IPv4/IPv6) IPv4 & IPv6

IPv4 Config

☐ DHCP

☒ Static IP Address

IP Address 192.168.1.10

Subnet Mask 255.255.255.0

Gateway 192.168.1.254

Static DNS ☒ On ☐ Off

Primary DNS 202.101.103.55

Secondary DNS 202.101.103.54

☐ PPPoE

User Name

Password

NOTE

DHCP
DHCP (Dynamic Host Configuration Protocol) is a network protocol used to dynamically allocate network parameters to IP phones.

Static IP Address
Specifies the network parameters of IP phones manually.

PPPoE
It allows users to share a common DSL connection to the Internet.

IPv6 Support
IPv6 is developed to deal with the long-anticipated problem of IPv4 address exhaustion.

You can click here to get more guides.

4. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
5. Click **OK** to reboot the phone.

To configure the IP address mode via phone user interface:

1. Press **Menu->Settings->Advanced Settings** (default password: admin)

->**Network**->**WAN Port**.

2. Press ◀ or ▶ to select **IPv4** or **IPv4 & IPv6** from the **IP Mode** field.
3. Press the **Save** soft key to accept the change.

The IP phone reboots automatically to make settings effective after a period of time.

To configure a static IPv4 address via phone user interface:

1. Press **Menu->Settings->Advanced Settings** (default password: admin)
->**Network**->**WAN Port**->**IPv4**->**Static IPv4 Client**.
2. Enter the desired value in the **IPv4**, **Subnet Mask**, **Default Gateway** and **IPv4 Pri.DNS** and **IPv4 Sec.DNS** field respectively.
3. Press the **Save** soft key to accept the change.

The IP phone reboots automatically to make settings effective after a period of time.

PPPoE

PPPoE (Point-to-Point Protocol over Ethernet) is a network protocol used by Internet Service Providers (ISPs) to provide Digital Subscriber Line (DSL) high speed Internet services. PPPoE allows an office or building-full of users to share a common DSL connection to the Internet. PPPoE connection is supported by the IP phone Internet port. Contact your ISP for the PPPoE user name and password. PPPoE is not applicable to SIP-T42G, SIP-T41P and CP860 IP phones.

Procedure

PPPoE can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure PPPoE on the IP phone. Parameters: network.internet_port.type
	<y0000000000xx>.cfg	Configure the user name and password for PPPoE on the IP phone. Parameters: network.pppoe.user network.pppoe.password
Local	Web User Interface	Configure PPPoE on the IP phone. Configure the user name and password for PPPoE on the IP phone. Navigate to: For SIP-T48G/T46G/T40P/T29G/T27P/T2

		3P/T23G/T21(P) E2/T19(P) E2: http://<phoneIPAddress>/servlet ?p=network&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=network&q=load
	Phone User Interface	Configure PPPoE on the IP phone. Configure the user name and password for PPPoE on the IP phone.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.internet_port.type	0, 1 or 2	0
<p>Description: Configures the Internet (WAN) port type for IPv4.</p> <p>0-DHCP 1-PPPoE (not applicable to SIP-T42G/T41P/CP860 IP phones) 2-Static IP Address</p> <p>Note: It works only if the value of the parameter "network.ip_address_mode" is set to 0 (IPv4) or 2 (IPv4 & IPv6). If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Basic->IPv4 Config</p> <p>Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->WAN Port->IPv4</p>		
network.pppoe.user	String within 32 characters	Blank
<p>Description: Configures the user name for PPPoE connection.</p> <p>Example: network.pppoe.user = Xmyl0592123</p> <p>Note: It works only if the value of the parameter "network.ip_address_mode" is set to 0 (IPv4) or 2 (IPv4 & IPv6), and "network.internet_port.type" is set to 1 (PPPoE). If you</p>		

Parameters	Permitted Values	Default
<p>change this parameter, the IP phone will reboot to make the change take effect. It is not applicable to SIP-T42G, SIP-T41P and CP860 IP phones.</p> <p>Web User Interface:</p> <p>Network->Basic->IPv4 Config->PPPoE->User Name</p> <p>Phone User Interface:</p> <p>Menu->Settings->Advanced Settings (default password: admin) ->Network->WAN Port->IPv4->PPPoE IPv4 Client->PPPoE User</p>		
network.pppoe.password	String within 99 characters	Blank
<p>Description:</p> <p>Configures the password for PPPoE connection.</p> <p>Example:</p> <p>network.pppoe.password = yealink123</p> <p>Note: It works only if the value of the parameter "network.ip_address_mode" is set to 0 (IPv4) or 2 (IPv4 & IPv6), and "network.internet_port.type" is set to 1 (PPPoE). If you change this parameter, the IP phone will reboot to make the change take effect. It is not applicable to SIP-T42G, SIP-T41P and CP860 IP phones.</p> <p>Web User Interface:</p> <p>Network->Basic->IPv4 Config->PPPoE->Password</p> <p>Phone User Interface:</p> <p>Menu->Settings->Advanced Settings (default password: admin) ->Network->WAN Port->IPv4->PPPoE IPv4 Client->PPPoE PWD</p>		

To configure PPPoE via web user interface:

1. Click on **Network->Basic**.
2. In the **IPv4 Config** block, mark the **PPPoE** radio box.

3. Enter the user name and password in corresponding fields.

The screenshot shows the Yealink T236 web interface. The 'Network' tab is selected, and the 'Internet Port' configuration page is displayed. Under the 'IPv4 Config' section, the 'PPPoE' option is selected. The 'User Name' field is filled with 'Xmyl0592123' and the 'Password' field is masked with asterisks. A red box highlights the PPPoE section. The right sidebar contains a 'NOTE' section with information about DHCP, Static IP Address, PPPoE, and IPv6 Support.

4. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
5. Click **OK** to reboot the phone.

To configure PPPoE via phone user interface:

1. Press **Menu->Settings->Advanced Settings** (default password: admin)
->**Network->WAN Port->IPv4->PPPoE IPv4 Client**.
2. Enter the user name and password in corresponding fields.
3. Press the **Save** soft key to accept the change.

The IP phone reboots automatically to make settings effective after a period of time.

Configuring Transmission Methods of the Internet Port and PC Port

Yealink SIP VP-T49G/SIPT48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2 IP phones support two Ethernet ports: Internet port and PC port. The CP860 IP phones have Internet port only. Three optional methods of transmission configuration for IP phone Internet or PC Ethernet ports:

- Auto-negotiate
- Half-duplex
- Full-duplex

Auto-negotiate is configured for both Internet and PC ports on the IP phone by default.


Auto-negotiate

Auto-negotiate means that two connected devices choose common transmission

parameters (e.g., speed and duplex mode) to transmit voice or data over Ethernet. This process entails devices first sharing transmission capabilities and then selecting the highest performance transmission mode supported by both. You can configure the Internet port and PC port on the IP phone to automatically negotiate during the transmission.


Half-duplex

Half-duplex transmission refers to transmitting voice or data in both directions, but in one direction at a time; this means one device can send data on the line, but not receive data simultaneously. You can configure the half-duplex transmission on both Internet port and PC port for the IP phone to transmit in 10Mbps or 100Mbps.



Full-duplex

Full-duplex transmission refers to transmitting voice or data in both directions at the same time; this means one device can send data on the line while receiving data. You can configure the full-duplex transmission on both Internet port and PC port for the IP phone to transmit in 10Mbps, 100Mbps or 1000Mbps (1000Mbps is only applicable to SIP VP-T49G/SIP-T48G/T46G/T42G/T29G/T23G/CP860 IP phones).



Procedure

The transmission methods of Ethernet ports can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	<p>Configure the transmission methods of the Internet (WAN) port.</p> <p>Parameters:</p> <p>network.internet_port.speed_duplex</p> <p>network.pc_port.speed_duplex</p>
Local	Web User Interface	<p>Configure the transmission methods of the Internet (WAN) port.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/ T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>http://<phoneIPAddress>/servlet?p= network-adv&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet?m =mod_data&p=network-adv&q=load</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.internet_port.speed_duplex	0, 1, 2, 3, 4 or 5	0
<p>Description:</p> <p>Configures the transmission method of the Internet (WAN) port.</p> <p>0-Auto Negotiate</p> <p>1-Full Duplex 10Mbps</p> <p>2-Full Duplex 100Mbps</p> <p>3-Half Duplex 10Mbps</p> <p>4-Half Duplex 100Mbps</p> <p>5-Full Duplex 1000Mbps (only applicable to SIP VP-T49G/SIP-T48G/T46G/T42G/T29G/T23G/CP860 IP phones)</p> <p>Note: For SIP VP-T49G/SIP-T48G/T46G/T42G/T29G/T23G IP phones, you can set the transmission speed to 1000Mbps/Auto Negotiate to transmit in 1000Mbps if the IP</p>		

Parameters	Permitted Values	Default
<p>phone is connected to the switch supports Gigabit Ethernet. We recommend that you do not change this parameter. If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Advanced->Port Link->WAN Port Link</p> <p>Phone User Interface: None</p>		
network.pc_port.speed_duplex	0, 1, 2, 3, 4 or 5	0
<p>Description: Configures the transmission method of the PC (LAN) port.</p> <p>0-Auto Negotiate 1-Full Duplex 10Mbps 2-Full Duplex 100Mbps 3-Half Duplex 10Mbps 4-Half Duplex 100Mbps 5-Full Duplex 1000Mbps (only applicable to SIP VP-T49G/SIP-T48G/T46G/T42G/T29G/T23G IP phones)</p> <p>Note: It works only if the value of the parameter "network.pc_port.enable" is set to 1 (Auto Negotiate). It is not applicable to CP860 IP phones. For SIP VP-T49G/SIP-T48G/T46G/T42G/T29G/T23G IP phones, you can set the transmission speed to 1000Mbps/Auto Negotiate to transmit in 1000Mbps if the IP phone is connected to the switch supports Gigabit Ethernet. We recommend that you do not change this parameter. If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Advanced->Port Link->PC Port Link</p> <p>Phone User Interface: None</p>		

To configure the transmission methods of Ethernet ports via web user interface:

1. Click on **Network->Advanced**.
2. Select the desired value from the pull-down list of **WAN Port Link**.

3. Select the desired value from the pull-down list of **PC Port Link**.

The screenshot shows the Yealink T236 web interface. The 'Network' tab is selected. Under the 'Port Link' section, the 'PC Port Link' dropdown menu is highlighted with a red box, showing 'Auto Negotiate' as the selected option. Other settings visible include LLDP (Active, Enabled), CDP (Active, Disabled), VLAN (Active, Disabled), and Voice QoS (Voice QoS 0~63: 46, SIP QoS 0~63: 26). The interface also includes a 'NOTE' section on the right with information about VLAN, NAT Traversal, Quality of Service (QoS), Web Server Type, 802.1X Authentication, and VPN.

4. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
5. Click **OK** to reboot the phone.

Configuring PC Port Mode

The PC port on the back of the IP phone is used to connect a PC. You can enable or disable the PC (LAN) port on the IP phones via web user interface or using configuration files. PC port is not applicable to CP860 IP phones.

Procedure

PC port mode can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the PC (LAN) port. Parameter: network.pc_port.enable
Local	Web User Interface	Configure the PC (LAN) port. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T2


		9G/T27P/T23P/T23G/T21(P) E2/T19(P) E2: http://<phoneIPAddress>/servlet ?p=network-pcport&q=load For SIP VPT49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=network-pcport&q=load
--	--	---

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.pc_port.enable	0 or 1	1
<p>Description: Enables or disables the PC (LAN) port. 0-Disabled 1-Auto Negotiate Note: It is not applicable to CP860 IP phones. If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Network->PC Port->PC Port Active Phone User Interface: None</p>		

To enable the PC port via web user interface:


1. Click on **Network->PC Port**.
2. Select **Auto Negotiate** from the pull-down list of **PC Port Active**.



3. Click **Confirm** to accept the change.
 A dialog box pops up to prompt that settings will take effect after a reboot.
4. Click **OK** to reboot the phone.

To disable the PC port via web user interface:

1. Click on **Network->PC Port**.
2. Select **Disabled** from the pull-down list of **PC Port Active**.



3. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
4. Click **OK** to reboot the phone.

Upgrading Firmware

This section provides information on upgrading the IP phone firmware. Two methods of firmware upgrade:

- Manually, from the local system for a single phone.
- Automatically, from the provisioning server for a mass of phones.

The following table lists the associated and latest firmware name for each IP phone model (X is replaced by the actual firmware version).

IP Phone Model	Associated Firmware Name	Firmware Name Example
SIP VPT49G	51.x.x.x.rom	51.80.0.100.rom
SIPT48G	35.x.x.x.rom	35.80.0.130.rom
SIPT46G	28.x.x.x.rom	28.80.0.130.rom
SIPT42G	29.x.x.x.rom	29.80.0.130.rom
SIP-T41P	36.x.x.x.rom	36.80.0.130.rom
SIP-T40P	54.x.x.x.rom	54.80.0.130.rom
SIPT29G	46.x.x.x.rom	46.80.0.130.rom
SIP-T27P	45.x.x.x.rom	45.80.0.130.rom
SIP-T23P/G	44.x.x.x.rom	44.80.0.130.rom
SIP-T21(P) E2	52.x.x.x.rom	52.80.0.130.rom
SIP-T19(P) E2	53.x.x.x.rom	53.80.0.130.rom

IP Phone Model	Associated Firmware Name	Firmware Name Example
CP860	37.x.x.x.rom	37.80.0.10.rom

Note

You can download the latest firmware online:

<http://support.yealink.com/documentFront/forwardToDocumentFrontDisplayPage>.

Do not unplug the network and power cables when the IP phone is upgrading firmware.


Upgrading Firmware via Web User Interface

To manually upgrade firmware via web user interface, you need to store firmware to your local system in advance.

To upgrade firmware manually via web user interface:

1. Click on **Settings->Upgrade**.
2. Click **Browse** to locate the required firmware from your local system.
3. Click **Upgrade**.

A dialog box pops up to prompt "Firmware of the SIP Phone will be updated. It will take 5 minutes to complete. Please don't power off!".



4. Click **OK** to confirm the upgrade.

Note

Do not close and refresh the browser when the IP phone is upgrading firmware via web user interface.

Upgrading Firmware from the Provisioning Server

IP phones support using FTP, TFTP, HTTP and HTTPS protocols to download configuration files and firmware from the provisioning server, and then upgrade firmware automatically.

IP phones can download firmware stored on the provisioning server in one of two ways:

- Check for configuration files and then download firmware during startup.

- Automatically check for configuration files and then download firmware at a fixed interval or specific time.

Method of checking for configuration files is configurable.

Procedure

Configuration changes can be performed using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	<p>Configure the way for the IP phone to check for configuration files.</p> <p>Parameters:</p> <p>auto_provision.power_on</p> <p>auto_provision.repeat.enable</p> <p>auto_provision.repeat.minutes</p> <p>auto_provision.weekly.enable</p> <p>auto_provision.weekly.begin_time</p> <p>auto_provision.weekly.end_time</p> <p>auto_provision.weekly.dayofweek</p>
		<p>Specify the access URL of firmware.</p> <p>Parameter:</p> <p>firmware.url</p>
Local	Web User Interface	<p>Configure the way for the IP phone to check for configuration files.</p> <p>Navigate to:</p> <p>http://<phoneIPAddress>/servlet?p=settings-autop&q=load</p>
		<p>Upload firmware.</p> <p>Navigate to:</p> <p>For</p> <p>SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>http://<phoneIPAddress>/servlet?p=settings-upgrade&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet?m=mod_data&p=settings-upgrade&q=load</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
auto_provision.power_on	0 or 1	1
Description: Triggers the power on feature to on or off. 0 -Off 1 -On If it is set to 1 (On), the IP phone will perform an auto provisioning process when powered on. Web User Interface: Settings->Auto Provision->Power On Phone User Interface: None		
auto_provision.repeat.enable	0 or 1	0
Description: Triggers the repeatedly feature to on or off. 0 -Off 1 -On If it is set to 1 (On), the IP phone will perform an auto provisioning process repeatedly. Web User Interface: Settings->Auto Provision->Repeatedly Phone User Interface: None		
auto_provision.repeat.minutes	Integer from 1 to 43200	1440
Description: Configures the interval (in minutes) for the IP phone to perform an auto provisioning process repeatedly. Note: It works only if the value of the parameter "auto_provision.repeat.enable" is set to 1 (On). Web User Interface: Settings->Auto Provision->Interval(Minutes)		

Parameters	Permitted Values	Default
Phone User Interface: None		
auto_provision.weekly.enable	0 or 1	0
Description: Triggers the weekly feature to on or off. 0-Off 1-On If it is set to 1 (On), the IP phone will perform an auto provisioning process weekly. Web User Interface: Settings->Auto Provision->Weekly Phone User Interface: None		
auto_provision.weekly.begin_time	Time from 00:00 to 23:59	00:00
Description: Configures the begin time of the day for the IP phone to perform an auto provisioning process weekly. Note: It works only if the value of the parameter "auto_provision.weekly.enable" is set to 1 (On). Web User Interface: Settings->Auto Provision->Time Phone User Interface: None		
auto_provision.weekly.end_time	Time from 00:00 to 23:59	00:00
Description: Configures the end time of the day for the IP phone to perform an auto provisioning process weekly. Note: It works only if the value of the parameter "auto_provision.weekly.enable" is set to 1 (On). Web User Interface: Settings->Auto Provision->Time Phone User Interface: None		

Parameters	Permitted Values	Default
auto_provision.weekly.dayofweek	0, 1, 2, 3, 4, 5, 6 or a combination of these digits	0123456
<p>Description: Configures the days of the week for the IP phone to perform an auto provisioning process weekly.</p> <p>0-Sunday 1-Monday 2-Tuesday 3-Wednesday 4-Thursday 5-Friday 6-Saturday</p> <p>Example: auto_provision.weekly.dayofweek = 01 It means the IP phone will perform an auto provisioning process every Sunday and Monday.</p> <p>Note: It works only if the value of the parameter "auto_provision.weekly.enable" is set to 1 (On).</p> <p>Web User Interface: Settings->Auto Provision->Day of Week</p> <p>Phone User Interface: None</p>		
firmware.url	URL within 511 characters	Blank
<p>Description: Configures the access URL of the firmware file.</p> <p>Example: firmware.url = http://192.168.1.20/44.80.0.60.rom</p> <p>Note: If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface: Settings->Upgrade->Select and Upgrade Firmware</p> <p>Phone User Interface: None</p>		

To configure the way for the IP phone to check for configuration files via web user interface:

1. Click on **Settings->Auto Provision**.
2. Make the desired change.

The screenshot shows the Yealink T236 web interface. The top navigation bar includes tabs for Status, Account, Network, DSSKey, Features, Settings, Directory, and Security. The left sidebar lists various configuration categories, with 'Auto Provision' selected. The main content area displays the 'Auto Provision' settings. Key settings include:

- PHP Active:** On (selected)
- DHCP Active:** On (selected)
- Custom Option(128~254):** [Empty field]
- DHCP Option Value:** yealink
- Server URL:** [Empty field]
- User Name:** [Empty field]
- Password:** [Masked field]
- Attempt Expired Time(s):** 5
- Common AES Key:** [Masked field]
- MAC-Oriented AES Key:** [Masked field]
- Zero Active:** Disabled
- Wait Time(1~100s):** 5
- Power On:** On (selected)
- Repeatedly:** Off (selected)
- Interval(Minutes):** 1440
- Weekly:** Off (selected)
- Time:** 00 : 00 - 00 : 00
- Day of Week:** All days (Sunday through Saturday) are checked.

A 'NOTE' section on the right states: 'Auto Provision: The IP phone can interoperate with provisioning server using auto provisioning for deploying the IP phones. When the IP phone triggers to perform auto provisioning, it will request to download the configuration files from the provisioning server. During the auto provisioning process, the IP phone will download and update configuration files to the phone flash. You can click here to get more guides.' At the bottom of the settings area, there are 'Confirm' and 'Cancel' buttons.

3. Click **Confirm** to accept the change.

When the "Power On" is set to **On**, the IP phone will check configuration files stored on the provisioning server during startup and then will download firmware from the server.

Configuring Basic Features

This chapter provides information for making configuration changes for the following basic features:

- [Power Indicator LED](#)
- [Notification Popups](#)
- [Contrast](#)
- [Wallpaper](#)
- [Screen Saver](#)
- [Power Saving](#)
- [Bluetooth](#)
- [Wi-Fi](#)
- [Enable Page Tips](#)
- [Label Length](#)
- [Account Registration](#)
- [Call Display](#)
- [Display Method on Dialing](#)
- [Web Server Type](#)
- [Time and Date](#)
- [Language](#)
- [Input Method](#)
- [Logo Customization](#)
- [Softkey Layout](#)
- [Key As Send](#)
- [Dial Plan](#)
- [Hotline](#)
- [Off Hook Hot Line Dialing](#)
- [Directory](#)
- [Search Source in Dialing](#)
- [Save Call Log](#)
- [Call List Show Number](#)
- [Missed Call Log](#)
- [Local Directory](#)

- [Live Dialpad](#)
- [Call Waiting](#)
- [Redial Tone](#)
- [Ringer Device for Headset](#)
- [Auto Redial](#)
- [Auto Answer](#)
- [IP Direct Auto Answer](#)
- [Allow IP Call](#)
- [Accept SIP Trust Server Only](#)
- [Call Completion](#)
- [Anonymous Call](#)
- [Anonymous Call Rejection](#)
- [Do Not Disturb](#)
- [Busy Tone Delay](#)
- [Return Code When Refuse](#)
- [Early Media](#)
- [180 Ring Workaround](#)
- [Use Outbound Proxy in Dialog](#)
- [SIP Session Timer](#)
- [Session Timer](#)
- [Call Hold](#)
- [Call Forward](#)
- [Call Transfer](#)
- [Network Conference](#)
- [Feature Key Synchronization](#)
- [Transfer on Conference Hang Up](#)
- [Transfer Mode via Dsskey](#)
- [Allow Trans Exist Call](#)
- [Directed Call Pickup](#)
- [Group Call Pickup](#)
- [Dialog Info Call Pickup](#)
- [Recent Call In Dialing](#)
- [ReCall](#)
- [Call Number Filter](#)

- [Call Park](#)
- [Calling Line Identification Presentation](#)
- [Connected Line Identification Presentation](#)
- [DTMF](#)
- [Allow Mute](#)
- [Intercom](#)
- [Call Timeout](#)
- [Ringing Timeout](#)
- [Send user=phone](#)
- [SIP Send MAC](#)
- [SIP Send Line](#)
- [Reserve # in User Name](#)
- [Password Dial](#)
- [Unregister When Reboot](#)
- [100 Reliable Retransmission](#)
- [Reboot in Talking](#)
- [Answer By Hand](#)
- [Bandwidth](#)
- [Screenshot and Recording](#)
- [External Monitor](#)

Power Indicator LED

Power indicator LED indicates power status and phone status. It is not applicable to CP860 IP phones. There are six configuration options for power indicator LED:

Common Power Light On

Common Power Light On allows the power indicator LED to be turned on.

Ringing Power Light Flash

Ringing Power Light Flash allows the power indicator LED to flash when the IP phone receives an incoming call.

Voice/Text Mail Power Light Flash

Voice/Text Mail Power Light Flash allows the power indicator LED to flash when the IP phone receives a voice mail or a text message.

Mute Power Light Flash

Mute Power Light Flash allows the power indicator LED to flash when a call is muted.

Hold/Held Power Light Flash

Hold/Held Power Light Flash allows the power indicator LED to flash when a call is placed on hold or is held.

Talk/Dial Power Light On

Talk/Dial Power Light On allows the power indicator LED to be turned on when the IP phone is busy.

Procedure

Power indicator LED can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	<p>Configure the power indicator LED.</p> <p>Parameters:</p> <p>phone_setting.common_power_led_enable</p> <p>phone_setting.ring_power_led_flash_enable</p> <p>phone_setting.mail_power_led_flash_enable</p> <p>phone_setting.mute_power_led_flash_enable</p> <p>phone_setting.hold_and_held_power_led_flash_enable</p> <p>phone_setting.talk_and_dial_power_led_enable</p>
Local	Web User Interface	<p>Configure the power indicator LED.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2:</p> <p>http://<phoneIPAddress>/servlet?p=features-powerled&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet?m=mod_data&p=features-powerled&q=load</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
phone_setting.common_power_led_enable	0 or 1	0
<p>Description: Enables or disables the power indicator LED to be turned on.</p> <p>For SIP VP-T49G/SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2 IP phones: 0-Disabled (power indicator LED is off) 1-Enabled (power indicator LED is solid red)</p> <p>For SIP-T19(P) E2 IP phones: 0-Disabled (power indicator LED is off) 1-Enabled (power indicator LED is solid yellow)</p> <p>Note: It is not applicable to CP860 IP phones.</p> <p>Web User Interface: Features->Power LED->Common Power Light On</p> <p>Phone User Interface: None</p>		
phone_setting.ring_power_led_flash_enable	0 or 1	1
<p>Description: Enables or disables the power indicator LED to flash when the IP phone receives an incoming call.</p> <p>For SIP VP-T49G/SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2 IP phones: 0-Disabled (power indicator LED does not flash) 1-Enabled (power indicator LED fast flashes (300ms) red)</p> <p>For SIP-T19(P) E2 IP phones: 0-Disabled (power indicator LED does not flash) 1-Enabled (power indicator LED fast flashes (300ms) yellow)</p> <p>Note: It is not applicable to CP860 IP phones.</p> <p>Web User Interface: Features->Power LED->Ringing Power Light Flash</p> <p>Phone User Interface: None</p>		


Parameters	Permitted Values	Default
phone_setting.mail_power_led_flash_enable	0 or 1	1
Description: Enables or disables the power indicator LED to flash when the IP phone receives a voice mail or a text message. For SIP VP-T49G/SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2 IP phones: 0-Disabled (power indicator LED does not flash) 1-Enabled (power indicator LED slow flashes (1000ms) red) For SIP-T19(P) E2 IP phones: 0-Disabled (power indicator LED does not flash) 1-Enabled (power indicator LED slow flashes (1000ms) yellow) Note: It is not applicable to CP860 IP phones. Web User Interface: Features->Power LED->Voice/Text Mail Power Light Flash Phone User Interface: None		
phone_setting.mute_power_led_flash_enable	0 or 1	0
Description: Enables or disables the power indicator LED to flash when a call is muted. For SIP VP-T49G/SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2 IP phones: 0-Disabled (power indicator LED does not flash) 1-Enabled (power indicator LED fast flashes (300ms) red) For SIP-T19(P) E2 IP phones: 0-Disabled (power indicator LED does not flash) 1-Enabled (power indicator LED fast flashes (300ms) yellow) Note: It is not applicable to CP860 IP phones. Web User Interface: Features->Power LED->Mute Power Light Flash Phone User Interface: None		
phone_setting.hold_and_held_power_led_flash_enable	0 or 1	0

Parameters	Permitted Values	Default
<p>Description: Enables or disables the power indicator LED to flash when a call is placed on hold or is held.</p> <p>For SIP VP-T49G/SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2 IP phones: 0-Disabled (power indicator LED does not flash) 1-Enabled (power indicator LED fast flashes (500ms) red)</p> <p>For SIP-T19(P) E2 IP phones: 0-Disabled (power indicator LED does not flash) 1-Enabled (power indicator LED fast flashes (500ms) yellow)</p> <p>Note: It is not applicable to CP860 IP phones.</p> <p>Web User Interface: Features->Power LED->Hold/Held Power Light Flash</p> <p>Phone User Interface: None</p>		
phone_setting.talk_and_dial_power_led_enable	0 or 1	0
<p>Description: Enables or disables the power indicator LED to be turned on when the IP phone is busy.</p> <p>For SIP VP-T49G/SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2 IP phones: 0-Disabled (power indicator LED is off) 1-Enabled (power indicator LED is solid red)</p> <p>For SIP-T19(P) E2 IP phones: 0-Disabled (power indicator LED is off) 1-Enabled (power indicator LED is solid yellow)</p> <p>Note: It is not applicable to CP860 IP phones.</p> <p>Web User Interface: Features->Power LED->Talk/Dial Power Light On</p> <p>Phone User Interface: None</p>		

To configure the power Indicator LED via web user interface:

1. Click on **Features->Power LED**.
2. Select the desired value from the pull-down list of **Common Power Light On**.

3. Select the desired value from the pull-down list of **Ringing Power Light Flash**.
4. Select the desired value from the pull-down list of **Voice/Text Mail Power Light Flash**.
5. Select the desired value from the pull-down list of **Mute Power Light Flash**.
6. Select the desired value from the pull-down list of **Hold/Held Power Light Flash**.
7. Select the desired value from the pull-down list of **Talk/Dial Power Light On**.



8. Click **Confirm** to accept the change.

Notification Popups

Notification popups feature allows the IP phone to display the pop-up message when it misses a call, forwards an incoming call to other party or receives a new voice mail or a new text message.

Procedure

Notification popups can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure notification popups. Parameters: features.voice_mail_popup.enable features.missed_call_popup.enable features.forward_call_popup.enable features.text_message_popup.enable
Local	Web User Interface	Configure notification popups. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T 27P/T23P/T23G/T21(P) E2/T19(P)

		<p>E2/CP860:</p> <p><a href="http://<phoneIPAddress>/servlet?p=features-notifypop&q=load">http://<phoneIPAddress>/servlet?p=features-notifypop&q=load</p> <p>For SIP VP-T49G:</p> <p><a href="http://<phoneIPAddress>/servlet?m=mod_data&p=features-notifypop&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=features-notifypop&q=load</p>
--	--	--

Details of Configuration Parameters:


Parameters	Permitted Values	Default
features.voice_mail_popup.enable	0 or 1	1
<p>Description:</p> <p>Enables or disables the IP phone to display the pop-up message box when it receives a new voice mail.</p> <p>0-Disabled 1-Enabled</p> <p>Note: If the voice mail pop-up message box disappears, it won't pop up again unless the user receives a new voice mail or the user re-registers the account that has unread voice mail(s).</p> <p>Web User Interface:</p> <p>Features->Notification Popups->Display Voice Mail Popup</p> <p>Phone User Interface:</p> <p>None</p>		
features.missed_call_popup.enable	0 or 1	1
<p>Description:</p> <p>Enables or disables the IP phone to display the pop-up message box when it misses a call.</p> <p>0-Disabled 1-Enabled</p> <p>Web User Interface:</p> <p>Features->Notification Popups->Display Missed Call Popup</p> <p>Phone User Interface:</p> <p>None</p>		
features.forward_call_popup.enable	0 or 1	1

Parameters	Permitted Values	Default
Description: Enables or disables the IP phone to display the pop-up message box when it forwards an incoming call to other party. 0-Disabled 1-Enabled Web User Interface: Features->Notification Popups->Display Forward Call Popup Phone User Interface: None		
features.text_message_popup.enable	0 or 1	1
Description: Enables or disables the IP phone to display the pop-up message box when it receives a new text message. 0-Disabled 1-Enabled Note: It works only if the value of the parameter "features.text_message.enable" is set to 1 (Enabled). Web User Interface: Features->Notification Popups->Display Text Message Popup Phone User Interface: None		

To configure the notification popups via web user interface:

1. Click on **Features->Notification Popups**.
2. Select the desired value from the pull-down list of **Display Voice Mail Popup**.
3. Select the desired value from the pull-down list of **Display Missed Call Popup**.
4. Select the desired value from the pull-down list of **Display Forward Call Popup**.

5. Select the desired value from the pull-down list of **Display Text Message Popup**.



6. Click **Confirm** to accept the change.

Contrast

Contrast determines the readability of the texts displayed on the LCD screen. Adjusting the contrast to a comfortable level can optimize the screen viewing experience. When configured properly, contrast allows users to read the LCD's display with minimal eyestrain. You can configure the LCD's contrast of SIP-T40P, SIP-T27P, SIP-T23P/G, SIP-T21(P) E2, SIP-T19(P) E2, CP860 IP phones, EXP20 connected to SIP-T29G/T27P IP phones and EXP40 connected to SIP-T48G/T46G IP phones. Make sure the expansion module has been connected to the IP phone before adjustment. It is not applicable to SIP VP-T49G/SIP-T42G/T41P IP phones.

Procedure

Contrast can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the contrast of the LCD screen. Parameter: phone_setting.contrast
Local	Web User Interface	Configure the contrast of the LCD screen. Navigate to: http://<phoneIPAddress>/servlet?p=settings-preference&q=load
	Phone User Interface	Configure the contrast of the LCD


		screen.
--	--	---------

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
phone_setting.contrast	Integer from 1 to 10	6
<p>Description:</p> <p>Configures the contrast of the LCD screen.</p> <p>For T48G/T46G IP phones, it configures the LCD's contrast of the connected EXP40 only.</p> <p>For T29G IP phones, it configures the LCD's contrast of the connected EXP20 only.</p> <p>For T27P IP phones, it configures the LCD's contrast of the IP phone and the connected EXP20.</p> <p>For T40P/T23P/T23G/T21(P) E2/T19(P) E2 and CP860 IP phones, it configures the LCD's contrast of the IP phone.</p> <p>Note: We recommend that you set the contrast of the LCD screen to 6 as a more comfortable level. It is not applicable to SIP VP-T49G/SIP-T42G/T41P IP phones.</p> <p>Web User Interface:</p> <p>Settings->Preference->Contrast</p> <p>Phone User Interface:</p> <p>Menu->Settings->Basic Settings->Display->Contrast</p>		

To configure contrast via web user interface:

1. Click on **Settings->Preference**.
2. Select the desired value from the pull-down list of **Contrast**.



3. Click **Confirm** to accept the change.

To configure contrast via phone user interface:

1. Press **Menu->Settings->Basic Settings->Display->Contrast**.
2. Press ◀ or ▶, or the **Switch** soft key to increase or decrease the intensity of contrast.
3. Press the **Save** soft key to accept the change.

Wallpaper

Wallpaper is an image used as the background of the IP phone idle screen. Users can select an image from IP phone's built-in background or customize wallpaper from personal pictures. To set the custom wallpaper as the IP phone background, you need to upload the custom wallpaper to the IP phone in advance. The wallpaper is only applicable to SIP VP-T49G, SIP-T48G, SIP-T46G and SIP-T29G IP phones.

For SIP VP-T49G IP phones, you can also set a custom picture stored in your USB flash drive as the wallpaper. In order to do this, make sure the USB flash drive containing pictures is connected to your phone. For more information, refer to [Yealink phone-specific user guide](#).

The wallpaper image format must meet the following:

Phone Model	Format	Resolution	Single File Size	Total File Size
SIP VP-T49G	.jpg/.png/.bmp	<=1280*800	<=5MB	<=20MB
SIP-T48G	.jpg/.png/.bmp	<=800*480	<=5MB	<=20MB
SIP-T46G/T29G	.jpg/.png/.bmp	<=480*272	<=5MB	<=20MB

Procedure

Wallpaper can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the wallpaper displayed on the IP phone. Parameter: phone_setting.backgrounds
		Specify the access URL of the custom wallpaper. Parameter: wallpaper_upload.url
Local	Web User Interface	Configure the wallpaper displayed on the IP phone. Upload the custom wallpaper.

		Navigate to: For SIP-T48G/T46G/T29G: http://<phoneIPAddress>/servlet?p=settings-preference&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet?m=mod_data&p=settings-preference&q=load
	Phone User Interface	Configure the wallpaper displayed on the IP phone.

Details of the Configuration Parameter:

Parameters	Permitted Values	Default
phone_setting.backgrounds	Refer to the following content	Refer to the following content
<p>Description: Configures the wallpaper displayed on the IP phone.</p> <p>For SIP VP-T49G:</p> <p>Permitted Values: Resource:X (Valid values of X are: Default.png, 1.jpg, 2.jpg, 3.jpg, 4.jpg, 5.jpg, 6.jpg, 7.jpg, 8.jpg or 9.jpg) or Config:wallpaper name The default value is Default:Default.png.</p> <p>Example: To configure a phone built-in picture (e.g., 1.jpg) to be wallpaper, the value format is: phone_setting.backgrounds = Resource:1.jpg To configure a custom picture (e.g., custom1.jpg) to be wallpaper, the value format is: phone_setting.backgrounds = Config:custom1.jpg</p> <p>For SIP-T48G:</p> <p>Permitted Values: Resource:X (Valid values of X are: Default.png, 1.png, 2.png, 3.png, 4.png, 5.png, 6.png, 7.png, 8.png or 9.png) or Config:wallpaper name The default value is Default:Default.jpg.</p> <p>Example: To configure a phone built-in picture (e.g., 1.png) to be wallpaper, the value format is: phone_setting.backgrounds = Resource:1.png To configure a custom picture (e.g., custom1.png) to be wallpaper, the value format</p>		

Parameters	Permitted Values	Default
<p>is: phone_setting.backgrounds = Config:custom1.png</p> <p>For SIP-T46G/T29G:</p> <p>Permitted Values:</p> <p>Resource:X (Valid values of X are: Default.jpg, 01.jpg, 02.jpg, 03.jpg, 04.jpg, 05.jpg, 06.jpg, 07.jpg, 08.jpg, 09.jpg or 10.jpg) or Config:wallpaper name</p> <p>The default value is Default:Default.jpg.</p> <p>Example:</p> <p>To set a phone built-in picture (e.g., 01.jpg) to be wallpaper, the value format is: phone_setting.backgrounds = Resource:01.jpg</p> <p>To configure a custom picture (e.g., custom1.jpg) to be wallpaper, the value format is: phone_setting.backgrounds = Config:custom1.jpg</p> <p>Note: It is only applicable to SIP VP-T49G/SIPT48G/T46G/T29G IP phones.</p> <p>Web User Interface: Settings->Preference->Wallpaper</p> <p>Phone User Interface: Menu->Basic->Display->Wallpaper</p>		
wallpaper_upload.url	URL within 511 characters	Blank
<p>Description:</p> <p>Configures the access URL of the wallpaper image.</p> <p>Example:</p> <p>wallpaper_upload.url = http://192.168.10.25/wallpaper.jpg</p> <p>Note: It is only applicable to SIP VP-T49G/SIPT48G/T46G/T29G IP phones.</p> <p>Web User Interface: Settings->Preference->Upload Wallpaper(480*272)</p> <p>Phone User Interface: None</p>		

To upload custom wallpaper via web user interface:

1. Click on **Settings->Preference**.
2. In the **Upload Wallpaper(480*272)** field, click **Browse** to locate the wallpaper image from your local system.

- Click **Upload** to upload the file.

The screenshot shows the Yealink T466 web interface. The 'Settings' tab is selected, and the 'Preference' sub-tab is active. The 'Upload Wallpaper(480*272)' section is highlighted with a red box. It contains a 'Browse...' button, a 'No file selected.' message, and 'Upload' and 'Cancel' buttons. The 'Wallpaper' dropdown menu is set to 'Default.jpg'. The 'Upload Ringtone' section is also visible, showing a 'Browse...' button and 'Upload' and 'Cancel' buttons. The 'Wallpaper' dropdown is highlighted with a red box.

The custom wallpaper appears in the pull-down list of **Wallpaper**.

To change the wallpaper via web user interface:

- Click on **Settings->Preference**.
- Select the desired wallpaper from the pull-down list of **Wallpaper**.

The screenshot shows the Yealink T466 web interface. The 'Settings' tab is selected, and the 'Preference' sub-tab is active. The 'Wallpaper' dropdown menu is highlighted with a red box, showing 'Default.jpg' as the selected option. The 'Upload Wallpaper(480*272)' section is also visible, showing a 'Browse...' button and 'Upload' and 'Cancel' buttons. The 'Wallpaper' dropdown is highlighted with a red box.

- Click **Confirm** to accept the change.

To change the wallpaper via phone user interface:

- Press **Menu->Basic->Display->Wallpaper**.
- Press **◀** or **▶**, or the **Switch** soft key to select the desired wallpaper.

- Press the **Save** soft key to accept the change.

Screen Saver

The screen saver will automatically start each time the IP phone is idle for a certain amount of time. You can stop the screen saver and return to the idle screen at any time by pressing a key on the phone or tapping the touch screen (only applicable to SIP VP-T49G and SIP-T48G IP phones). The screen saver is only applicable to SIP VP-T49G, SIP-T48G, SIP-T46G and SIP-T29G IP phones.

Users can select to display the built-in screen saver or custom screen saver. To set the custom screen saver for the IP phone, you need to upload the custom screen saver in advance. If multiple pictures are uploaded, all pictures are displayed like a slide show when screen saver starts.

The screen saver image format must meet the following:

Phone Model	Format	Resolution	Single File Size	Total File Size
SIP VP-T49G	.jpg/.png/.bmp	<=1280*800	<=5MB	<=20MB
SIP-T48G	.jpg/.png/.bmp	<=800*480	<=5MB	<=20MB
SIP-T46G/T29G	.jpg/.png/.bmp	<=480*272	<=5MB	<=20MB

Procedure

Screen saver can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the time to wait in the idle state before the screen saver starts. Parameter: screensaver.wait_time
		Configure the type of screen saver to display. Parameter: screensaver.type
		Specify the access URL of the custom screen saver image. Parameter: screensaver.upload_url

		<p>Delete custom screen saver image.</p> <p>Parameter: screensaver.delete</p>
		<p>Configure the IP phone to display the clock when the screen saver starts.</p> <p>Parameter: screensaver.display_clock_on_upload_picture.enable</p>
		<p>Configure the interval for the IP phone to change the picture when the screen saver starts.</p> <p>Parameter: screensaver.picture_change_interval</p>
		<p>Configure the interval for the IP phone to move the clock when the screen saver starts.</p> <p>Parameter: screensaver.clock_move_interval</p>
	Local	Web User Interface
	Local	<p>Configure the time to wait in the idle state before the screen saver starts.</p> <p>Configure the type of screen saver to display.</p> <p>Upload the custom screen saver image.</p> <p>Delete custom screen saver image.</p> <p>Navigate to: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=settings-preference&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=settings-preference&q=load</p>
		Phone User Interface

Details of the Configuration Parameter:

Parameters	Permitted Values	Default
screensaver.wait_time	0, 15, 30, 60, 120, 300, 600 or 1800	Refer to the following content
<p>Description:</p> <p>Configures the time (in seconds) to wait in the idle state before the screen saver starts.</p> <p>0-Never (not applicable to SIP VP-T49G IP phones)</p> <p>15-15s</p> <p>30-30s</p> <p>60-1min</p> <p>120-2min</p> <p>300-5min</p> <p>600-10min</p> <p>1800-30min</p> <p>For SIP VP-T49G:</p> <p>The default value is 600.</p> <p>For SIP-T48G/T46G/T29G:</p> <p>The default value is 0.</p> <p>Note: It is only applicable to SIP VP-T49G, SIP-T48G, SIP-T46G and SIP-T29G IP phones.</p> <p>Web User Interface:</p> <p>Settings->Preference->Screensaver Wait Time</p> <p>Phone User Interface:</p> <p>Menu->Basic->Display->Screensaver->Wait Time(s)</p>		
screensaver.type	0 or 1	0
<p>Description:</p> <p>Configures the type of screen saver to display.</p> <p>0-System</p> <p>1-Upload Picture</p> <p>If it is set to 0 (System), the LCD screen saver will display the system screen saver images.</p> <p>If it is set to 1 (Upload Picture), the LCD screen will display the custom screen saver images (you need to upload custom image files to the IP phone).</p>		

Parameters	Permitted Values	Default
<p>Note: It is only applicable to SIP VP-T49G, SIP-T48G, SIP-T46G and SIP-T29G IP phones.</p> <p>Web User Interface: Settings->Preference->Screensaver Type</p> <p>Phone User Interface: None</p>		
screensaver.upload_url	URL within 511 characters	Blank
<p>Description: Configures the access URL of the custom screen saver image.</p> <p>Example: screensaver.upload_url = http://192.168.10.25/Screencapture.jpg</p> <p>During the auto provisioning process, the IP phone connects to the HTTP provisioning server "192.168.10.25", and downloads the screen saver image "Screencapture.jpg".</p> <p>If you want to download multiple screen saver images to the phone simultaneously, you can configure as following: screensaver.upload_url = http://192.168.10.25/Screencapture.jpg screensaver.upload_url = http://192.168.10.25/Screensaver.jpg</p> <p>Note: It works only if the value of the parameter "screensaver.type" is set to 1 (Upload Picture). It is only applicable to SIP VP-T49G, SIP-T48G, SIP-T46G and SIP-T29G IP phones.</p> <p>Web User Interface: Settings->Preference->Upload Screensaver</p> <p>Phone User Interface: None</p>		
screensaver.delete	http://localhost/all or http://localhost/ <i>name</i> . <i>(jpg/png/bmp)</i>	Blank
<p>Description: Deletes the specified or all custom screen saver images.</p> <p>Example: Delete all custom screen saver images: screensaver.delete = http://localhost/all</p> <p>Delete a custom screen saver image (e.g., Screencapture.jpg):</p>		

Parameters	Permitted Values	Default
gui_lang.delete = http://localhost/Screenshot.jpg Note: It is only applicable to SIP VP-T49G, SIP-T48G, SIP-T46G and SIP-T29G IP phones. Web User Interface: None Phone User Interface: None		
screensaver.display_clock_on_upload_picture.enable	0 or 1	1
Description: Enables or disables the IP phone to display the clock and icon on the custom screen saver image when the screen saver starts. 0 -Disabled 1 -Enabled Note: It works only if the value of the parameter "screensaver.type" is set to 1 (Upload Picture) and the parameter "screensaver.upload_url" should be configured in advance. It is only applicable to SIP VP-T49G, SIP-T48G, SIP-T46G and SIP-T29G IP phones. Web User Interface: None Phone User Interface: None		
screensaver.picture_change_interval	Integer from 5 to 1200	60
Description: Configures the interval (in seconds) for the IP phone to change the picture when the screen saver starts. Note: It works only if the value of the parameter "screensaver.type" is set to 1 (Upload Picture) and the parameter "screensaver.upload_url" should be configured in advance. It is only applicable to SIP VP-T49G, SIP-T48G, SIP-T46G and SIP-T29G IP phones. Web User Interface: None Phone User Interface: None		
screensaver.clock_move_interval	Integer from 5 to	600

Parameters	Permitted Values	Default
	1200	
<p>Description:</p> <p>Configures the interval (in seconds) for the IP phone to move the clock and icon when the screen saver starts.</p> <p>Note: For custom screen saver, this parameter works only if the value of the parameter "screensaver.display_clock_on_upload_picture.enable" is set to 1 (Enabled). It is only applicable to SIP VP-T49G, SIP-T48G, SIP-T46G and SIP-T29G IP phones.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		

To upload custom screen saver via web user interface:

1. Click on **Settings->Preference**.
2. Select **Upload Picture** from the pull-down list of **Screensaver Type**.
3. In the **Upload Screensaver** field, click **Browse** to locate the custom picture from your local system.
4. Click **Upload** to upload the file.

The **Upload Screensaver** field appears only if **Screensaver Type** is set to **Upload Picture**.

The screenshot shows the Yealink T46G web interface. The 'Settings' tab is selected, and the 'Preference' sub-tab is active. The 'Screensaver Type' is set to 'Upload Picture'. The 'Upload Screensaver' field is highlighted with a red box, showing 'No file selected.' and buttons for 'Browse...', 'Upload', and 'Cancel'. The 'Screensaver Wait Time' is set to '10min'. The 'Confirm' and 'Cancel' buttons are at the bottom.

The custom screen saver appears in the pull-down list of **Screensaver**.

To set the system screen saver via web user interface:

1. Click on **Settings->Preference**.
2. Select **System** from the pull-down list of **Screensaver Type**.

The screenshot shows the Yealink T466 web interface. The 'Settings' tab is selected, and the 'Preference' sub-tab is active. On the left sidebar, 'Preference' is highlighted. The main content area lists various settings. The 'Screensaver Type' dropdown is highlighted with a red box and is set to 'System'. Below it, the 'Screensaver' dropdown is set to 'System.jpg'. At the bottom, there are 'Confirm' and 'Cancel' buttons. On the right, a 'NOTE' section provides information about Language, Live Dialpad, Backlight, Contrast, and Ring Tones.

3. Click **Confirm** to accept the change.

To configure the screen saver wait time via web user interface:

1. Click on **Settings->Preference**.
2. Select the desired wait time from the pull-down list of **Screensaver Wait Time**.

This screenshot is similar to the previous one, showing the same 'Settings > Preference' page. However, the 'Screensaver Wait Time' dropdown is highlighted with a red box and is set to '15s'. The 'Screensaver Type' and 'Screensaver' settings remain the same. The 'Confirm' and 'Cancel' buttons are still at the bottom, and the 'NOTE' section is on the right.

3. Click **Confirm** to accept the change.

Power Saving

The power saving feature is used to turn off the screen to conserve energy. The IP phone enters power-saving mode after it has been idle for a certain period of time. And the IP phone will exit power-saving mode if a phone event occurs—for example, if the phone has an incoming call or message, or you press a key on the phone or tap the touch screen (only applicable to SIP VP-T49G/SIP-T48G). If the screen saver is enabled on your phone, power-saving mode will still occur. The power saving is only applicable to SIP VP-T49G, SIP-T48G, SIP-T46G and SIP-T29G IP phones.

You can configure the following power-saving settings:

- **Office Hour:** Configures the starting time and duration of the day's office hour each day using configuration files (or configures the starting and ending time of office hour each day via web user interface).
- **Idle Timeout (minutes):** Configures the period of time before the IP phone enter power-saving mode.

Procedure

Power saving can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the power saving feature. Parameter: features.power_saving.enable
		Configure the office hour. Parameter: features.power_saving.office_hour.monday features.power_saving.office_hour.tuesday features.power_saving.office_hour.wednesday features.power_saving.office_hour.thursday features.power_saving.office_hour.friday features.power_saving.office_hour.saturday features.power_saving.office_hour.sunday

		<p>Configure the idle timeout.</p> <p>Parameter:</p> <p>features.power_saving.office_hour.idle_timeout</p> <p>features.power_saving.office_hour.idle_timeout</p> <p>features.power_saving.user_input_ext.idle_timeout</p>
Local	Web User Interface	<p>Configure the power saving feature.</p> <p>Configure the office hour.</p> <p>Configure the idle timeout.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T29G:</p> <p>http://<phoneIPAddress>/servlet?p=settings-powersaving&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet?m=mod_data&p=settings-powersaving&q=load</p>

Details of the Configuration Parameter:

Parameters	Permitted Values	Default
features.power_saving.enable	0 or 1	1
<p>Description:</p> <p>Enables or disables the power saving feature.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>Note: It is only applicable to SIP-T48G, SIP-T46G and SIP-T29G IP phones.</p> <p>Web User Interface:</p> <p>Settings->Power Saving->Power Saving</p> <p>Phone User Interface:</p> <p>None</p>		
features.power_saving.office_hour.idle_timeout	Refer to the following content	Refer to the following

		content
<p>Description:</p> <p>Configures the time (in minutes) to wait in the idle state before IP phone enters power-saving mode during the office hours.</p> <p>Permitted Values:</p> <p>1 to 240 (for SIP VP-T49G)</p> <p>1 to 600 (for SIP-T48G/T46G/T29G)</p> <p>For SIP VP-T49G:</p> <p>The default value is 120.</p> <p>For SIP-T48G/T46G/T29G:</p> <p>The default value is 480.</p> <p>Note: It is only applicable to SIP VP-T49G, SIP-T48G, SIP-T46G and SIP-T29G IP phones.</p> <p>Web User Interface:</p> <p>Settings->Power Saving->Office Hour Idle TimeOut</p> <p>Phone User Interface:</p> <p>None</p>		
features.power_saving.off_hour.idle_timeout	Integer from 1 to 10	10
<p>Description:</p> <p>Configures the time (in minutes) to wait in the idle state before IP phone enters power-saving mode during the non-office hours.</p> <p>Note: It is only applicable to SIP VP-T49G, SIP-T48G, SIP-T46G and SIP-T29G IP phones.</p> <p>Web User Interface:</p> <p>Settings->Power Saving->Off Hour Idle TimeOut</p> <p>Phone User Interface:</p> <p>None</p>		
features.power_saving.user_input_ext.idle_timeout	Integer from 1 to 20	10
<p>Description:</p> <p>Configures the time (in minutes) to wait in the idle state before IP phone enters power-saving mode when using the IP phone (for example, press a key on the phone, pick up/hang up the handset or tap the touch screen (only applicable to SIP VP-T49G/SIP-T48G)).</p> <p>Note: If you use the IP phone, the idle timeout that applies (User input extension Idle Timeout or Office Hours/Off Hours Idle Timeout) is the timeout with the highest value. If the phone has an incoming call or message, the User input extension Idle Timeout is ignored. It is only applicable to SIP VP-T49G, SIP-T48G, SIP-T46G and SIP-T29G IP</p>		


<p>phones.</p> <p>Web User Interface:</p> <p>Settings->Power Saving->User input extension Idle TimeOut</p> <p>Phone User Interface:</p> <p>None</p>		
features.power_saving.office_hour.monday	Integer from 0 to 23, Integer from 0 to 23	7,12
<p>Description:</p> <p>Configures the starting time and duration of the day's office hour on Monday. Starting time and duration are separated by a comma.</p> <p>Note: It is only applicable to SIP VP-T49G, SIP-T48G, SIP-T46G and SIP-T29G IP phones.</p> <p>Web User Interface:</p> <p>Settings->Power Saving->Monday</p> <p>Phone User Interface:</p> <p>None</p>		
features.power_saving.office_hour.tuesday	Integer from 0 to 23, Integer from 0 to 23	7,12
<p>Description:</p> <p>Configures the starting time and duration of the day's office hour on Tuesday. Starting time and duration are separated by a comma.</p> <p>Note: It is only applicable to SIP VP-T49G, SIP-T48G, SIP-T46G and SIP-T29G IP phones.</p> <p>Web User Interface:</p> <p>Settings->Power Saving->Tuesday</p> <p>Phone User Interface:</p> <p>None</p>		
features.power_saving.office_hour.wednesday	Integer from 0 to 23, Integer from 0 to 23	7,12
<p>Description:</p> <p>Configures the starting time and duration of the day's office hour on Wednesday. Starting time and duration are separated by a comma.</p> <p>Note: It is only applicable to SIP VP-T49G, SIP-T48G, SIP-T46G and SIP-T29G IP phones.</p> <p>Web User Interface:</p> <p>Settings->Power Saving->Wednesday</p>		

Phone User Interface: None		
features.power_saving.office_hour.thursday	Integer from 0 to 23, Integer from 0 to 23	7,12
Description: Configures the starting time and duration of the day's office hour on Thursday. Starting time and duration are separated by a comma. Note: It is only applicable to SIP VP-T49G, SIP-T48G, SIP-T46G and SIP-T29G IP phones. Web User Interface: Settings->Power Saving->Thursday Phone User Interface: None		
features.power_saving.office_hour.friday	Integer from 0 to 23, Integer from 0 to 23	7,12
Description: Configures the starting time and duration of the day's office hour on Friday. Starting time and duration are separated by a comma. Note: It is only applicable to SIP VP-T49G, SIP-T48G, SIP-T46G and SIP-T29G IP phones. Web User Interface: Settings->Power Saving->Friday Phone User Interface: None		
features.power_saving.office_hour.saturday	Integer from 0 to 23, Integer from 0 to 23	7,0
Description: Configures the starting time and duration of the day's office hour on Saturday. Starting time and duration are separated by a comma. Note: It is only applicable to SIP VP-T49G, SIP-T48G, SIP-T46G and SIP-T29G IP phones. Web User Interface: Settings->Power Saving->Saturday Phone User Interface: None		
features.power_saving.office_hour.sunday	Integer from 0 to	7,0

	23, Integer from 0 to 23	
<p>Description:</p> <p>Configures the starting time and duration of the day's office hour on Sunday. Starting time and duration are separated by a comma.</p> <p>Note: It is only applicable to SIP VP-T49G, SIP-T48G, SIP-T46G and SIP-T29G IP phones.</p> <p>Web User Interface:</p> <p>Settings->Power Saving->Sunday</p> <p>Phone User Interface:</p> <p>None</p>		

To enable the power saving feature via web user interface:

1. Click on **Settings->Power Saving**.
2. Select **Enabled** from the pull-down list of **Power Saving**.



3. Click **Confirm** to accept the change.

To configure the office hour via web user interface:

1. Click on **Settings->Power Saving**.
2. Select a desired day of the week.

3. Enter the starting time and ending time respectively in the desired day field.

The screenshot shows the Yealink T46G web interface. The 'Settings' tab is selected, and the 'Power Saving' section is active. The 'Power Saving' dropdown is set to 'Enabled'. The 'Office Hour' section is highlighted with a red box, showing a table with days of the week and time ranges. Below it, the 'Idle TimeOut (minutes)' section has three input fields: 'Office Hour Idle TimeOut' (480), 'Off Hour Idle TimeOut' (10), and 'User input extension Idle TimeOut' (10). A 'NOTE' panel on the right contains a message about guides.

Day	Start Time	End Time
Monday	07	19
Tuesday	07	19
Wednesday	07	19
Thursday	07	19
Friday	07	19
Saturday	07	07
Sunday	07	07

Idle TimeOut (minutes)

Office Hour Idle TimeOut: 480

Off Hour Idle TimeOut: 10

User input extension Idle TimeOut: 10

NOTE

settings-powersaving-note

You can click here to get more guides.

4. Click **Confirm** to accept the change.

To configure the idle timeout via web user interface:

1. Click on **Settings->Power Saving**.
2. Enter the desired value in the **Office Hours Idle Timeout** field.
The default value is 480, you can set to 1-600.
3. Enter the desired value in the **Off Hours Idle Timeout** field.
The default value is 10, you can set to 1-10.
4. Enter the desired value in the **User input extension Idle Timeout** field.

The default value is 10, you can set to 1-20.

The screenshot shows the Yealink T46G web interface. The 'Settings' tab is selected. Under 'Power Saving', 'Office Hour' is set to 'Enabled'. The 'Office Hour' table shows times for each day: Monday through Friday (07:00 - 19:00), Saturday (07:00 - 07:00), and Sunday (07:00 - 07:00). Below this, the 'Idle TimeOut (minutes)' section is highlighted with a red box. It contains three input fields: 'Office Hour Idle TimeOut' (480), 'Off Hour Idle TimeOut' (10), and 'User input extension Idle TimeOut' (10). Each field has a help icon. At the bottom of the form are 'Confirm' and 'Cancel' buttons. A 'NOTE' section on the right mentions 'settings-powersaving-note' and provides a link to more guides.

5. Click **Confirm** to accept the change.

Backlight

Backlight determines the brightness of the LCD screen display, allowing users to read easily in dark environments. Backlight time specifies the delay time to change the intensity of the LCD screen when the IP phone is inactive. Backlight turns off quickly if a short backlight time is configured, this may not give users enough time to read messages. Backlight time is applicable to SIP

VP-T49G/SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/CP860 IP phones and EXP40 connected to SIP-T48G/T46G IP phones and EXP20 connected to SIP-T29G/T27P IP phones.

You can configure the backlight time as one of the following types:

- **Always Off:** Backlight is turned off permanently (not applicable to SIP VP-T49G/SIP-T48G/T46G/T29G IP phones).
- **Always On:** Backlight is turned on permanently.
- **15s, 30s, 60s, 120s, 300s, 600s or 1800s:** Backlight is turned off when the IP phone is inactive after a preset period of time (in seconds), but it is automatically turned on if the status of the IP phone changes or any key is pressed.

Backlight Active Level is used to adjust the backlight intensity of the LCD screen when the phone is active. Backlight Inactive Level is used to adjust the backlight intensity of the LCD screen when the phone is inactive. Backlight Active Level is applicable to SIP VP-T49G IP phones, SIP-T48G/T46G IP phones and the connected EXP40, SIP-T29G/T27P IP phones and the connected EXP20. Backlight Inactive Level is only applicable to SIP VP-T49G, SIP-T48G, SIP-T46G and SIP-T29G IP phones.

Note

It is not applicable to SIP-T19(P) E2 IP phones.

Before you adjust the LCD's backlight of expansion module, make sure the expansion module has been connected to the IP phone.

The following table lists available methods and configuration options to configure the backlight of phone models/expansion modules.

Phone Model (and the connected expansion module)	Configuration Methods	Configuration Options
SIP VP-T49G/SIP-T48G/T46G/ T29G	Configuration Files Web User Interface Phone User Interface	Backlight Inactive Level
SIP VP-T49G/SIP-T48G(EXP40) /T46G(EXP40)/T29G(EXP20)/T27P(EXP20)	Configuration Files Web User Interface Phone User Interface	Backlight Active Level Backlight Time
SIP-T42G/T41P/T40P/T23P /T23G/T21(P) E2/CP860	Configuration Files Web User Interface Phone User Interface	Backlight Time

Procedure

Backlight can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the backlight of the LCD screen. Parameters: phone_setting.active_backlight_level phone_setting.inactive_backlight_level phone_setting.backlight_time
Local	Web User Interface	Configure the backlight of the LCD screen.

		Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/CP860: http://<phoneIPAddress>/servlet?p=settings-preference&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet?m=mod_data&p=settings-preference&q=load
	Phone User Interface	Configure the backlight of the LCD screen.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
phone_setting.active_backlight_level	Integer from 1 to 10	8
Description: Configures the intensity of the LCD screen when the phone is active. 10 is the highest intensity. For T49G IP phones, it configures the LCD's intensity of the IP phone. For T48G/T46G IP phones, it configures the LCD's intensity of the IP phone and the connected EXP40. For T29G/T27P IP phones, it configures the LCD's intensity of the IP phone and the connected EXP20. Note: It is applicable to SIP VP-T49G IP phones, SIP-T48G/T46G IP phones and the connected EXP40, SIP-T29G/T27P IP phones and the connected EXP20. Web User Interface: Settings->Preference->Backlight Active Level Phone User Interface: Menu->Basic->Display->Backlight->Backlight Active Level		
phone_setting.inactive_backlight_level	0 or 1	1
Description: Configures the intensity of the LCD screen when the phone is inactive. 0-Off 1-Low		

Note: It is only applicable to SIP VP-T49G/SIPT48G/T46G/T29G IP phones.

Web User Interface:

Settings->Preference->Backlight Inactive Level

Phone User Interface:

Menu->Basic->Display->Backlight->Backlight Inactive Level

phone_setting.backlight_time

**0, 1, 15, 30, 60, 120, 300, 600
or 1800**

**Refer to
the
following
content**

Description:

Configures the delay time (in seconds) to change the intensity of the LCD screen when the IP phone is inactive.

0-Always On

1-Always Off (not applicable to SIP VP-T49G/SIP-T48G/T46G/T29G IP phones)

15-15s

30-30s

60-60s

120-120s

300-300s

600-600s

1800-1800s

If it is set to 60 (60s), the intensity of the LCD screen will be changed when the IP phone has been inactivated for 60 seconds.

For SIP VP-T49G/SIPT48G/T46G/T42G/T41P/T29G/CP860:

The default value is 0.

For SIPT40P/T27P/T23P/T23G/T21(P) E2:

The default value is 30.

Note: It is not applicable to SIP-T19(P) E2 IP phones.

Web User Interface:

Settings->Preference->Backlight Time(seconds)

Phone User Interface:

Menu->Settings->Basic Settings->Display->Backlight->Backlight Time

To configure backlight via web user interface (take SIPT23G IP phones for example):

1. Click on **Settings->Preference**.

2. Select the desired value from the pull-down list of **Backlight Time(seconds)**.

3. Click **Confirm** to accept the change.

To configure backlight via phone user interface (take SIP-T23G IP phones for example):







1. Press **Menu->Settings->Basic Settings->Display->Backlight**.
2. Press **◀** or **▶**, or the **Switch** soft key to select the desired value from the **Backlight Time** field.
3. Press the **Save** soft key to accept the change.

To configure the backlight via web user interface (take SIP-T46G IP phones for example):

1. Click on **Settings->Preference**.
2. Select the desired value from the pull-down list of **Backlight Inactive Level**.
3. Select the desired value from the pull-down list of **Backlight Active Level**.
4. Select the desired value from the pull-down list of **Backlight Time(seconds)**.

5. Click **Confirm** to accept the change.

To configure the backlight via phone user interface (take SIP-T46G IP phones for example):

1. Press **Menu->Basic->Display->Backlight**.
2. Press  or  , or the **Switch** soft key to select the desired level from the **Backlight Active Level** field.
3. Press  or  , or the **Switch** soft key to select the desired value from the **Backlight Inactive Level** field.
4. Press  or  , or the **Switch** soft key to select the desired time from the **Backlight Time** field.
5. Press the **Save** soft key to accept the change.

Bluetooth

Bluetooth enables low-bandwidth wireless connections within a range of 10 meters (32 feet). The best performance is in the 1 to 2 meter (3 to 6 feet) range. You can activate/deactivate the Bluetooth mode and then pair and connect the Bluetooth headset with your phone. It is only applicable to SIP VP-T49G/SIP-T48G/T46G/T29G IP phones. You can also activate/deactivate the Bluetooth mode and then pair and connect the Bluetooth-Enabled mobile phone for Yealink SIP VP-T49G IP phones. For more information, refer to the [Yealink SIP VP-T49G User Guide](#).

You can personalize the Bluetooth device name for the IP phone. The pre-configured Bluetooth device name will display in scanning list of other devices. It is helpful for the other Bluetooth devices to identify and pair with your IP phone.

Note

To use this feature on SIP-T48G/T46G/T29G IP phones, make sure the Bluetooth USB dongle is properly connected to the USB port on the back of the phone.

Procedure

Bluetooth mode can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure Bluetooth mode. Parameter: features.bluetooth_enable
		Configure the Bluetooth device name. Parameter: features.bluetooth_adapter_name
Local	Web User Interface	Configure Bluetooth mode. Navigate to:

		For SIPT48G/T46G/T29G: http://<phoneIPAddress>/servlet ?p=features-bluetooth&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=features-blue tooth&q=load
	Phone User Interface	Configure Bluetooth mode. Configure the Bluetooth device name.


Details of the Configuration Parameter:

Parameter	Permitted Values	Default
features.bluetooth_enable	0 or 1	0
Description: Triggers Bluetooth mode to on or off. 0-Off 1-On Note: It is only applicable to SIP VP-T49G/SIPT48G/T46G/T29G IP phones. Web User Interface: Features->Bluetooth->Bluetooth Active Phone User Interface: Menu->Basic->Bluetooth->Bluetooth		
features.bluetooth_adapter_name	String within 64 characters	Refer to the following content
Description: Configures the Bluetooth device name. For SIP VP-T49G IP phones: The default value is SIP VP-T49G. For SIPT48G IP phones: The default value is Yealink-T48G. For SIPT46G IP phones: The default value is Yealink-T46G. For SIPT29G IP phones:		

Parameter	Permitted Values	Default
<p>The default value is Yealink-T29G.</p> <p>Note: It works only if the value of the parameter "features.bluetooth_enable" is set to 1 (On). It is only applicable to SIP VP-T49G/SIP-T48G/T46G/T29G IP phones.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>Menu->Basic->Bluetooth->Bluetooth (On)->Edit My Device Information->Device Name</p>		

To active the Bluetooth mode via web user interface:

1. Click on **Features->Bluetooth**.
2. Select the desired value from the pull-down list of **Bluetooth Active**.



3. Click **Confirm** to accept the change.

To active the Bluetooth mode via phone user interface:

1. Press **Menu->Basic->Bluetooth**.
2. Press **◀** or **▶**, or the **Switch** soft key to select **On** from the **Bluetooth** field.
3. Press the **Save** soft key to accept the change.

To edit device information via phone user interface:

1. Press **Menu->Basic->Bluetooth**.
2. Press **◀** or **▶**, or the **Switch** soft key to select **On** from the **Bluetooth** field.
3. Press the **Save** soft key to accept the change.
4. Select **Edit My Device Information** and then press the **Enter** soft key.

The LCD screen displays the device name and MAC address. The MAC address cannot be edited.

5. Enter the desired name in the **Device Name** field.
6. Press the **Save** soft key to accept the change or the **Back** soft key to cancel.

Wi-Fi

Wi-Fi feature enables users to connect their phones to the organization's wireless network. The wireless network is more convenient and cost-effective than wired network. Wi-Fi feature is only applicable to SIP VP-T49G and SIP-T48G IP phones.

When the Wi-Fi feature is enabled, the IP phone will automatically scan the available wireless networks. All the available wireless networks will display in scanning list on the touch screen. You can store up to 5 frequently-used wireless networks on your phone and specify the priority for them.

Yealink SIP VP-T49G IP phones support connecting to 2.4G/5G wireless network. The wireless channels in the 2.4 GHz/5 GHz band vary from country to country, so you may have problems connecting your phone to the wireless network in your area. You can configure the country wireless channel for your phone depending on the desired area as required.

Yealink IP phones support VLAN in the wireless network. For more information, refer to [Configuring VLAN Feature in the Wireless Network](#) on page 687.

Note

To use Wi-Fi feature on SIP-T48G IP phones, make sure the Wi-Fi USB dongle is properly connected to the USB port on the back of the phone.

When you connect the Ethernet cable, you can enable the Wi-Fi feature. But you have to disable the Wi-Fi feature if you want to use the wired network.

The following advices you need to know when using the IP phones in the wireless network:

- a) Check whether the wireless network is normal when the account registers failed or sometimes there is no sound during an active call.
- b) Ensure that the bandwidth of your wireless network is able to provide stable and real-time data transmission otherwise the quality of video calls may be affected. We recommend you to use the wired network for video calls.
- c) For SIP VP-T49G IP phones, no matter which network (wired network or wireless network) you are using, please properly consider whether to configure the uplink and downlink bandwidths according to your bandwidth capacity.
- d) We recommend you do not use the unstable router product in your home/office environment.
- e) We recommend you to set the password for the wireless network so as to ensure the network resource will not be occupied by the unknown user.

Procedure

Wi-Fi feature can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure Wi-Fi feature. Parameter: wifi.enable
		Configure the Wi-Fi settings. Parameters: wifi.X.label wifi.X.ssid wifi.X.priority wifi.X.security_mode wifi.X.cipher_type wifi.X.password
		Specify the delay time for the phone to disconnect the wireless network. Parameters: wifi.status_detection_timeout
		Configure the country wireless channel (in the 2.4 GHz and 5 GHz band) for the IP phones. Parameters: wifi.country
Local	Web User Interface	Configure Wi-Fi feature. Configure the Wi-Fi settings. Navigate to: For SIP-T48G: <a href="http://<phoneIPAddress>/servlet?p=network-wifi&q=load">http://<phoneIPAddress>/servlet?p=network-wifi&q=load For SIP VPT49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=network-wifi&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=network-wifi&q=load

		<p>Specify the delay time for the phone to disconnect the wireless network.</p> <p>Navigate to:</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet?m=mod_data&p=network-wifi&q=load</p>
	Phone User Interface	<p>Configure Wi-Fi feature.</p> <p>Configure the Wi-Fi settings.</p> <p>Specify the time for the phone to disconnect the wireless network.</p>

Details of the Configuration Parameter:

Parameters	Permitted Values	Default
wifi.enable	0 or 1	0
<p>Description:</p> <p>Enables or disables the Wi-Fi feature.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>Note: It is only applicable to SIP VP-T49G and SIP-T48G IP phones.</p> <p>Web User Interface:</p> <p>Network->Wi-Fi->Wi-Fi Active</p> <p>Phone User Interface:</p> <p>Menu->Basic->Wi-Fi->Wi-Fi</p>		
wifi.X.label (X ranges from 1 to 5)	String within 31 characters	Blank
<p>Description:</p> <p>Configures the profile name of the wireless network X for the IP phone.</p> <p>Note: It works only if the value of the parameter "wifi.enable" is set to 1 (Enabled). It is only applicable to SIP VP-T49G and SIP-T48G IP phones.</p> <p>Web User Interface:</p> <p>Network->Wi-Fi->Profile Name</p> <p>Phone User Interface:</p> <p>Menu->Basic->Wi-Fi->Wi-Fi (On)->Add->Profile Name</p>		

Parameters	Permitted Values	Default
wifi.X.ssid (X ranges from 1 to 5)	String within 32 characters	Blank
Description: Configures the Service Set Identifier (SSID) of the wireless network X. SSID is a unique identifier for accessing wireless access points. Note: It works only if the value of the parameter "wifi.enable" is set to 1 (Enabled). It is only applicable to SIP VP-T49G and SIP-T48G IP phones. Web User Interface: Network->Wi-Fi->SSID Phone User Interface: Menu->Basic->Wi-Fi->Wi-Fi (On)->Add->SSID		
wifi.X.priority (X ranges from 1 to 5)	Integer from 1 to 5	1
Description: Configures the priority for the wireless network X for the IP phone. 5 is the highest priority, 1 is the lowest priority. Note: It works only if the value of the parameter "wifi.enable" is set to 1 (Enabled). It is only applicable to SIP VP-T49G and SIP-T48G IP phones. Web User Interface: Network->Wi-Fi->Change Priority Phone User Interface: None		
wifi.X.security_mode (X ranges from 1 to 5)	NONE, WEP, WPA-PSK or WPA2-PSK	NONE
Description: Configures the security mode of the wireless network X. Note: It works only if the value of the parameter "wifi.enable" is set to 1 (Enabled). It is only applicable to SIP VP-T49G and SIP-T48G IP phones. Web User Interface: For SIP VP-T49G: Network->Wi-Fi->Security Mode For SIPT48G: Network->Wi-Fi->Secure Mode Phone User Interface:		

Parameters	Permitted Values	Default
Menu->Basic->Wi-Fi->Wi-Fi (On)->Add->Security Mode		
wifi.X.cipher_type (X ranges from 1 to 5)	NONE, WEP, TKIP, CCMP or TKIP CCMP	NONE
<p>Description: Configures the encryption type of the wireless network X.</p> <p>NONE-NONE WEP-WEP TKIP-TKIP CCMP-AES TKIP CCMP-TKIP AES</p> <p>Note: It works only if the value of the parameter “wifi.enable” is set to 1 (Enabled) and “wifi.X.security_mode” is set to WPA-PSK or WPA2-PSK. It is only applicable to SIP VP-T49G and SIP-T48G IP phones.</p> <p>Web User Interface: Network->Wi-Fi->Cipher Type</p> <p>Phone User Interface: Menu->Basic->Wi-Fi->Wi-Fi (On)->Add->Cipher Type</p>		
wifi.X.password (X ranges from 1 to 5)	String within 64 characters	Blank
<p>Description: Configures the password of the wireless network X.</p> <p>Note: It works only if the value of the parameter “wifi.enable” is set to 1 (Enabled) and “wifi.X.security_mode” is set to WEP, WPA-PSK or WPA2-PSK. It is only applicable to SIP VP-T49G and SIP-T48G IP phones.</p> <p>Web User Interface: Network->Wi-Fi->PSK</p> <p>Phone User Interface: Menu->Basic->Wi-Fi->Wi-Fi (On)->Add->WPA Shared Key</p>		
wifi.status_detection_timeout	Integer more than or equal to 0	120
<p>Description: Configures the delay time (in seconds) for the phone to disconnect the wireless network after failing to detect the wi-fi signal (Beacon) from the router.</p> <p>If it is set to 120, the IP phone will automatically disconnect the wireless network</p>		

Parameters	Permitted Values	Default
<p>when detecting no wi-fi signal (Beacon) sent from the router within 120 seconds.</p> <p>Note: It works only if the value of the parameter "wifi.enable" is set to 1 (Enabled). It is only applicable to SIP VP-T49G IP phones.</p> <p>Web User Interface:</p> <p>Network->Wi-Fi->Time-Out For Wi-Fi Status Detection</p> <p>Phone User Interface:</p> <p>None</p>		
wifi.country	Refer to the following content	China
<p>Description:</p> <p>Configures the country wireless channel (in the 2.4 GHz and 5 GHz band) for the IP phones.</p> <p>Permitted Values:</p> <p>United States, Canada, Europe, Switzerland, Russia, Japan, Singapore, China, Israel, Korea, Turkey, Australia, South Africa, Brazil, Taiwan, New Zealand.</p> <p>Example:</p> <p>wifi.country = United States</p> <p>Note: It is only applicable to SIP VP-T49G IP phones. For more information on the wireless channel, refer to https://en.wikipedia.org/wiki/List_of_WLAN_channels.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		

To enable the Wi-Fi feature via web user interface:

1. Click on **Network->Wi-Fi**.

2. Select **Enabled** from the pull-down list of **Wi-Fi Active**.

Yealink T48G

Log Out

Status Account **Network** DSSKey Features Settings Directory Security

Basic
PC Port
Advanced
Wi-Fi

Wi-Fi Active: Enabled

Profile Name	SSID	Secure Mode	Cipher Type	
				<input type="checkbox"/>
				<input type="checkbox"/>
				<input type="checkbox"/>
				<input type="checkbox"/>

Change Priority:

Profile Name:
 SSID:
 Secure Mode: NONE
 Cipher Type: NONE
 PSK:

NOTE
network-wifi-note
You can click here to get more guides.

3. Click **Confirm** to accept the change.

To add a wireless network via web user interface:

1. Click on **Network->Wi-Fi**.
2. Enter the desired value in the **Profile Name** field.
3. Enter the desired value in the **SSID** field.
4. Select the desired value from the pull-down list of **Secure Mode**.
 - If you select **WEP**:
 - 1) Enter the desired password in the **PSK** field.
 - If you select **WPA-PSK** or **WPA2-PSK**:
 - 1) Select **TKIP**, **AES** or **TKIP AES** from the pull-down list of the **Cipher Type**.
 - 2) Enter the desired password in the **PSK** field.

Yealink T48G

Log Out

Status Account **Network** DSSKey Features Settings Directory Security

Basic
PC Port
Advanced
Wi-Fi

Wi-Fi Active: Enabled

Profile Name	SSID	Secure Mode	Cipher Type	
HAHA	HAHA	WPA2-PSK	AES	<input type="checkbox"/>
				<input type="checkbox"/>
				<input type="checkbox"/>
				<input type="checkbox"/>



Change Priority:


Profile Name: test
 SSID: test
 Secure Mode: WPA2-PSK
 Cipher Type: TKIP AES
 PSK: *****

NOTE
network-wifi-note
You can click here to get more guides.

5. Click **Add** to accept the change.
6. Repeat steps 2 to 5 to add more wireless networks.

To adjust the priority of the added wireless network via web user interface:

1. Click on **Network->Wi-Fi**.
2. Click to select the desired wireless network which you want to adjust the priority, and then click  or .



Yealink T48G



Log Out

Status Account **Network** DSSKey Features Settings Directory Security

Basic
PC Port
Advanced
Wi-Fi

Wi-Fi Active: Enabled

Profile Name	SSID	Secure Mode	Cipher Type	
test	1234	WPA-PSK	TKIP AES	<input type="checkbox"/>
HAHA	HAHA	NONE	NONE	<input checked="" type="checkbox"/>
				<input type="checkbox"/>
				<input type="checkbox"/>

Change Priority:   Delete All Delete

Profile Name: test
SSID: 1234
Secure Mode: WPA-PSK
Cipher Type: TKIP
PSK:


Add Edit Cancel

NOTE
network-wifi-note
You can click here to get more guides.

3. Repeat the step 2 to adjust the priority of more wireless networks.

To configure the time-out for Wi-Fi status detection via web user interface:

1. Click on **Network->Wi-Fi**.
2. Enter the desired time (in seconds) in the **Time-Out For Wi-Fi Status Detection** field.



Yealink T49G



Log Out

Status Account **Network** DSSKey Features Settings Directory Security

Basic
PC Port
Advanced
Wi-Fi

Wi-Fi Active: Disabled

Profile Name	SSID	Security Mode	Cipher Type	
NETGEAR82-5G	NETGEAR82-5G	NONE	NONE	<input type="checkbox"/>
				<input type="checkbox"/>
				<input type="checkbox"/>
				<input type="checkbox"/>

Change Priority:   Delete All Delete

Profile Name: ?
SSID: ?
Security Mode: NONE ?
Cipher Type: NONE ?
PSK: ?

Add Edit


Time-Out For Wi-Fi Status Detection 120

Confirm Cancel


NOTE
network Wi-Fi note
You can click here to get more guides.

3. Click **Confirm** to accept the change.

To enable the Wi-Fi feature via phone user interface:

1. Tap  -> **Basic**->**Wi-Fi**.
 2. Tap the **On** radio box in the **Wi-Fi** field.
- The IP phone scans the available wireless network automatically.


To add a wireless network:



1. Tap  -> **Basic**->**Wi-Fi**.
2. Tap the **On** radio box in the **Wi-Fi** field.
3. Tap **Add**.
4. Tap the **Security Mode** field.
5. Tap the desired value in the pop-up dialog box.
 - If you select **None** or **WEP**:
 - 1) Enter the desired profile name in the **Profile Name** field.
 - 2) Enter the desired value in the **SSID** field.
 - 3) Enter the desired password in the **WPA Shared Key** field.
 - If you select **WPA-PSK** or **WPA2-PSK**:
 - 1) Enter the desired profile name in the **Profile Name** field.
 - 2) Enter the desired value in the **SSID** field.
 - 3) Tap the **Cipher Type** field.
 - 4) Tap the desired Cipher type (**TKIP**, **AES** or **TKIP AES**) in the pop-up dialog box.
 - 5) Enter the desired password in the **WPA Shared Key** field.
6. Tap the **Save** soft key to accept the change.

Enable Page Tips

Enable page tips feature allows users to enable the page icon and page switch key LED to indicate different statuses. It is mainly used in the scenario of configuring multi-page line key. It is only applicable to SIP-T46G/T42G/T41P/T29G/T27P IP phones.

The following table lists the page icons to indicate different statuses:

Phone Models	Icons	Description
SIP-T46G/T29G		Fast flashing: the BLF monitored user receives an incoming call on the non-current page. Solid: there is a parked call to the line on the non-current page.

Phone Models	Icons	Description
		Fast flashing: the line receives an incoming call on the non-current page.
SIP-T42G/T41P/T27P		Fast flashing: The BLF monitored user receives an incoming call on the non-current page. The line receives an incoming call on the non-current page. Solid: There is a parked call on the non-current page.

Procedure

Enable page tips can be configured using the configuration files or locally.


Configuration File	<y0000000000xx>.cfg	Configure enable page tips. Parameter: phone_setting.page_tip
Local	Web User Interface	Configure enable page tips. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=dsskey&model=1&q=load&linepage=1">http://<phoneIPAddress>/servlet?p=dsskey&model=1&q=load&linepage=1

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
phone_setting.page_tip	0 or 1	0
Description: Enables or disables the page icon and page switch key LED to indicate different states of line keys on the non-current page. 0-Disabled 1-Enabled Note: It is only applicable to SIP-T46G/T42G/T41P/T29G/T27P IP phones. Web User Interface: DSSKey->Line Key->Enable Page Tips Phone User Interface: None		

To configure the page icon to indicate status via web user interface:

- 1. Click on **DSSKey->Line Key**.
- 2. Select **Enabled** from the pull-down list of **Enable Page Tips**.



- 3. Click **Confirm** to accept the change.

Label Length

Label length allows IP phones to extend the display length of the line key label. If the label length feature is enabled, more characters will be displayed on the idle LCD screen. It is only applicable to SIP VP-T49G/SIP-T48G/T46G/T29G IP phones.

Procedure

Label length can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure label length. Parameter: features.config_dsskey_length
Local	Web User Interface	Configure label length. Navigate to: For SIP-T48G/T46G/T29G: http://<phoneIPAddress>/servlet ?p=dsskey&model=1&q=load&li nepage=1 For SIP VP-T49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=dsskey&q=lo ad

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
features.config_dsskey_length	0 or 1	0
<p>Description:</p> <p>Enables or disables the extended length of the label displayed on the idle LCD screen for the line key.</p> <p>0-Default</p> <p>1-Extended</p> <p>Note: It is only applicable to SIP VP-T49G/SIPT48G/T46G/T29G IP phones.</p> <p>Web User Interface:</p> <p>DSSKey->Line Key->Label Length</p> <p>Phone User Interface:</p> <p>None</p>		

To configure the label length via web user interface:

1. Click on **DSSKey->Line Key**.
2. Select **Extended** from the pull-down list of **Label Length**.

The screenshot shows the Yealink T46G web interface. The 'DSSKey' tab is selected. Under 'Line Key 1-9', the 'Label Length' dropdown is set to 'Extended'. The table below shows the configuration for Line Key1 through Line Key9.

Key	Type	Value	Label	Line	Extension
Line Key1	Line	Default	1006	Line 1	
Line Key2	Speed Dial	1000	speeddialtestta	Line 1	
Line Key3	Line	Default		Line 3	
Line Key4	Line	Default		Line 4	
Line Key5	Line	Default		Line 5	
Line Key6	Line	Default		Line 6	
Line Key7	Line	Default		Line 7	
Line Key8	Line	Default		Line 8	
Line Key9	Line	Default		Line 9	

NOTE: Line Keys allow you to quickly access features such as recall and voice mail. You can click here to get more guides.

3. Click **Confirm** to accept the change.

Account Registration

Registering a SIP account makes it easier for the IP phones to receive an incoming call, dial an outgoing call. The IP phones support SIP server redundancy for account registration. For more information, refer to [Server Redundancy](#) on page 647.

Procedure

Account registration can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	<p>Configure the account registration information.</p> <p>Parameter:</p> <ul style="list-style-type: none"> account.X.enable account.X.label account.X.display_name account.X.auth_name account.X.user_name account.X.password account.X.sip_server.Y.address account.X.sip_server.Y.port account.X.outbound_proxy_enable account.X.outbound_host account.X.outbound_port account.X.backup_outbound_host account.X.backup_outbound_port
		<p>Configure the interval for the IP phone to retry to re-register when registration fails.</p> <p>Parameter:</p> <ul style="list-style-type: none"> account.X.reg_fail_retry_interval
		<p>Configure the number of DSS keys to be assigned automatically.</p> <p>Parameter:</p> <ul style="list-style-type: none"> account.X.number_of_linekey
	<y0000000000xx>.cfg	<p>Configure auto linekeys.</p> <p>Parameter:</p> <ul style="list-style-type: none"> features.auto_linekeys.enable

Local	Web User Interface	<p>Configure the account registration information.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p><a href="http://<phoneIPAddress>/servlet?p=account-register&q=load&acc=0">http://<phoneIPAddress>/servlet?p=account-register&q=load&acc=0</p> <p>For SIP VP-T49G:</p> <p><a href="http://<phoneIPAddress>/servlet?m=mod_data&p=account-register&q=load&acc=0">http://<phoneIPAddress>/servlet?m=mod_data&p=account-register&q=load&acc=0</p>
		<p>Configure auto linekeys.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2:</p> <p><a href="http://<phoneIPAddress>/servlet?p=features-general&q=load">http://<phoneIPAddress>/servlet?p=features-general&q=load</p> <p>For SIP VP-T49G:</p> <p><a href="http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load</p>

		<p>Configure the interval for the IP phone to retry to register when registration fails.</p> <p>Configure the number of DSS keys to be assigned automatically.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0</p>
	Phone User Interface	Configure the account registration information.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
account.X.enable	0 or 1	0
<p>Description:</p> <p>Enables or disables the account X.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Web User Interface:</p> <p>Account->Register->Line Active</p> <p>Phone User Interface:</p> <p>Menu->Settings->Advanced Settings->Accounts->Active Line</p>		

Parameters	Permitted Values	Default
account.X.label	String within 99 characters	Blank
Description: (Optional.) Configures the label to be displayed on the LCD screen for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIPT42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Web User Interface: Account->Register->Label Phone User Interface: Menu->Settings->Advanced Settings->Accounts->Label		
account.X.display_name	String within 99 characters	Blank
Description: Configures the display name for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIPT42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Web User Interface: Account->Register->Display Name Phone User Interface: Menu->Settings->Advanced Settings->Accounts->Display Name		
account.X.auth_name	String within 99 characters	Blank
Description: Configures the user name for register authentication for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIPT42G)		

Parameters	Permitted Values	Default
X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Web User Interface: Account->Register->Register Name Phone User Interface: Menu->Settings->Advanced Settings->Accounts->Register Name		
account.X.user_name	String within 99 characters	Blank
Description: Configures the register user name for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIPT42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Web User Interface: Account->Register->User Name Phone User Interface: Menu->Settings->Advanced Settings->Accounts->User Name		
account.X.password	String within 99 characters	Blank
Description: Configures the password for register authentication for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIPT42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Web User Interface: Account->Register->Password		

Parameters	Permitted Values	Default
Phone User Interface: Menu->Settings->Advanced Settings->Accounts->Password		
account.X.sip_server.Y.address (X ranges from 1 to 16, Y ranges from 1 to 2)	String within 256 characters	Blank
Description: Configures the IP address or domain name of the SIP server Y for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIPT42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Example: account.1.sip_server.1.address = yealink.pbx.com Web User Interface: Account->Register->SIP Server Y->Server Host Phone User Interface: Menu->Settings->Advanced Settings->Accounts->SIP ServerY		
account.X.sip_server.Y.port (X ranges from 1 to 16, Y ranges from 1 to 2)	Integer from 0 to 65535	5060
Description: Configures the port of the SIP server Y for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIPT42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Example: account.1.sip_server.1.port = 5060 Web User Interface: Account->Register->SIP Server Y->Port Phone User Interface: None		

Parameters	Permitted Values	Default
account.X.outbound_proxy_enable	0 or 1	0
<p>Description:</p> <p>Enables or disables the IP phone to send requests to the outbound proxy server for account X.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIPT42G)</p> <p>X ranges from 1 to 6 (for SIPT41P/T27P)</p> <p>X ranges from 1 to 3 (for SIPT40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIPT21(P) E2)</p> <p>X is equal to 1 (for SIPT19(P) E2/CP860)</p> <p>Web User Interface:</p> <p>Account->Register->Enable Outbound Proxy Server</p> <p>Phone User Interface:</p> <p>Menu->Settings->Advanced Settings->Accounts->Outbound Status</p>		
account.X.outbound_host	IP address or domain name	Blank
<p>Description:</p> <p>Configures the IP address or domain name of the outbound proxy server 1 for account X.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIPT42G)</p> <p>X ranges from 1 to 6 (for SIPT41P/T27P)</p> <p>X ranges from 1 to 3 (for SIPT40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIPT21(P) E2)</p> <p>X is equal to 1 (for SIPT19(P) E2/CP860)</p> <p>Example:</p> <p>account.1.outbound_host = 10.1.8.11</p> <p>Note: It works only if the value of the parameter "account.X.outbound_proxy_enable" is set to 1 (Enabled).</p> <p>Web User Interface:</p> <p>Account->Register->Outbound Proxy Server 1</p> <p>Phone User Interface:</p>		

Parameters	Permitted Values	Default
Menu->Settings->Advanced Settings->Accounts->Outbound Proxy1		
account.X.outbound_port	Integer from 0 to 65535	5060
<p>Description:</p> <p>Configures the port of the outbound proxy server for account X.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Example:</p> <p>account.1.outbound_port = 5060</p> <p>Note: It works only if the value of the parameter "account.X.outbound_proxy_enable" is set to 1 (Enabled).</p> <p>Web User Interface:</p> <p>Account->Register->Outbound Proxy Server 1->Port</p> <p>Phone User Interface:</p> <p>None</p>		
account.X.backup_outbound_host	IP address or domain name	Blank
<p>Description:</p> <p>Configures the IP address or domain name of the outbound proxy server 2 for account X.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Example:</p> <p>account.1.backup_outbound_host = 5060</p> <p>Note: It works only if the value of the parameter "account.X.outbound_proxy_enable" is set to 1 (Enabled).</p>		

Parameters	Permitted Values	Default
Web User Interface: Account->Register->Outbound Proxy Server 2 Phone User Interface: Menu->Settings->Advanced Settings->Accounts->Outbound Proxy2		
account.X.backup_outbound_port	Integer from 0 to 65535	5060
Description: Configures the port of the outbound proxy server 2 for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Example: account.1.backup_outbound_port = 5060 Note: It works only if the value of the parameter "account.X.outbound_proxy_enable" is set to 1 (Enabled). Web User Interface: Account->Register->Outbound Proxy Server 2->Port Phone User Interface: None		
account.X.reg_fail_retry_interval	Integer from 0 to 1800	30
Description: Configures the interval (in seconds) for the IP phone to retry to re-register for account X when registration fails. X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Example:		

Parameters	Permitted Values	Default
account.1.reg_fail_retry_interval = 30 Web User Interface: Account->Advanced->SIP Registration Retry Timer(0~1800s) Phone User Interface: None		
account.X.number_of_linekey	String within 32 characters	1
Description: Configures the number of DSS keys to be assigned with Line type automatically from the first unused one (unused one means the DSS key is configured as N/A or Line). If a DSS key is used, the IP phone will skip to the next unused DSS key. The order of DSS key assigned automatically is Line Key->Ext Key. X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIPT42G) X ranges from 1 to 6 (for SIPT41P/T27P) X ranges from 1 to 3 (for SIPT40P/T23P/T23G) X ranges from 1 to 2 (for SIPT21(P) E2) Example: account.1.number_of_linekey = 2 Note: It works only if the value of the parameter "features.auto_linekeys.enable" is set to 1 (Enabled). It is not applicable to SIP-T19(P) E2 and CP860 IP phones. Web User Interface: Account->Advanced->Number of line key Phone User Interface: None		
features.auto_linekeys.enable	0 or 1	0
Description: Enables or disables the DSS keys to be assigned with Line type automatically. 0-Disabled 1-Enabled Note: The number of the DSS keys is determined by the value of the parameter "account.X.number_of_linekey". It is not applicable to SIP-T19(P) E2 and CP860 IP phones. Web User Interface:		

Parameters	Permitted Values	Default
Features->General Information->Auto Linekeys		
Phone User Interface:		
None		

To register an account via web user interface:

1. Click **Account->Register**.
2. Select the desired account from the pull-down list of **Account**.
3. Select **Enabled** from the pull-down list of **Line Active** field.
4. Enter the desired value in **Label**, **Display Name**, **Register Name**, **User Name**, **Password** and **SIP Server1/2** field respectively.
5. If you use outbound proxy servers, do the following:
 - 1) Select **Enabled** from the pull-down list of **Enable Outbound Proxy Server**.
 - 2) Enter the desired IP address or domain name in the **Outbound Proxy Server 1/2** field and the desired port of the outbound proxy server 1/2 in the **Port** field respectively.
 - 3) Enter the desired interval in the **Proxy Fallback Interval** field.

6. Click **Confirm** to accept the change.

To configure the interval for re-register when registration fails via web user interface:

1. Click **Account->Advanced**.
2. Enter the desired interval in the **SIP Registration Retry Timer(0~1800s)** field.

3. Click **Confirm** to accept the change.

To configure auto linekeys feature via web user interface:

1. Click on **Features->General Information**.
2. Select **Enabled** from the pull-down list of **Auto Linekeys**.

If **Auto LineKeys** is enabled, you can automatically assign multiple DSS keys with Line type for a registered line on the phone.

3. Click **Confirm** to accept the change.

To configure the number of line keys via web user interface:

1. Click **Account->Advanced**.
2. Enter the desired number in the **Number of line key** field.

This field appears only if **Auto Linekeys** is enabled.

3. Click **Confirm** to accept the change.

To register an account via phone user interface:

1. Press **Menu->Settings->Advanced Settings** (default password: admin) -> **Accounts**.
2. Select the desired account and then press the **Enter** soft key.
3. Select **Enabled** from the **Active Line** field.
4. Enter the desired value in **Label**, **Display Name**, **Register Name**, **User Name**, **Password** and **SIP Server1/2** field respectively. Contact your system administrator for more information.
5. If you use outbound proxy servers, do the following:
 - 1) Select **Enabled** from the **Outbound Status** field.
 - 2) Enter the desired IP address or domain name in the **Outbound Proxy1/2** field.
 - 3) Enter the desired interval in the **Proxy Fallback Interval** field.
6. Press the **Save** soft key to accept the change or the **Back** soft key to cancel.

Call Display


Display contact photo allows the IP phone to present the contact avatar when it receives an incoming call, dials an outgoing call or engages in a call. Display contact photo feature is only applicable to SIP VP-T49G/SIP-T48G/T46G/T29G IP phones.

Display called party information allows the IP phone to present the callee identity in

addition to the presentation of caller identity when it receives an incoming call.

The following figure shows an example of screen display when Display Called Party Information feature is enabled on the phone (a call from Tom (phone number: 1008) to Marry (phone number: 1009)).


For SIP-T42G/T41P/T40P/T27P/T23P/T23G/T21(P) E2/T19(P) E2 and CP860 IP phones:



For SIP-T48G/T46G/T29G IP phones:



For SIP VP-T49G IP phones:



You can customize the call information to be displayed on the IP phone as required. IP phones support five call information display methods: Number+Name, Name, Name+Number, Number or Full Contact Info (display name<sip:xxx@domain.com>).

Note

SIP-T42G/T41P/T40P/T23P/T23G/T21(P) E2/T19(P) E2 and CP860 IP phones have a limited display (up to three lines) due to their smaller screen size.

Procedure

Call Display can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure display contact photo feature. Parameter: phone_setting.contact_photo_display.enable
		Configure display called party information feature. Parameter: phone_setting.called_party_info_display.enable
		Specify the call information display method. Parameter: phone_setting.call_info_display_method
Local	Web User Interface	Configure call display features. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=settings-calldisplay&q=load">http://<phoneIPAddress>/servlet?p=settings-calldisplay&q=load For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=settings-calldisplay&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=settings-calldisplay&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
phone_setting.contact_photo_display.enable	0 or 1	1
Description: Enables or disables the IP phone to display contact avatar when it receives an		

Parameters	Permitted Values	Default
<p>incoming call, dials an outgoing call or engages in a call.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>Note: It is only applicable to SIP VP-T49G/SIPT48G/T46G/T29G IP phones.</p> <p>Web User Interface:</p> <p>Settings->Call Display->Display Contact Photo</p> <p>Phone User Interface:</p> <p>None</p>		
phone_setting.called_party_info_display.enable	0 or 1	0
<p>Description:</p> <p>Enables or disables the IP phone to display the called account information when receiving an incoming call.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>Web User Interface:</p> <p>Settings->Call Display->Display Called Party Information</p> <p>Phone User Interface:</p> <p>None</p>		
phone_setting.call_info_display_method	0, 1, 2, 3 or 4	0
<p>Description:</p> <p>Specifies the call information display method when the IP phone receives an incoming call, dials an outgoing call or is during an active call.</p> <p>0-Name+Number</p> <p>1-Number+Name</p> <p>2-Name</p> <p>3-Number</p> <p>4-Full Contact Info (display name<sip:xxx@domain.com>)</p> <p>Web User Interface:</p> <p>Settings->Call Display->Call Information Display Method</p> <p>Phone User Interface:</p> <p>None</p>		

To configure call display features via web user interface (take SIP-T23G IP phones for example):

1. Click on **Settings->Call Display**.
2. Select the desired value from the pull-down list of **Display Called Party Information**.
3. Select the desired value from the pull-down list of **Call Information Display Method**.

The screenshot shows the Yealink T23G web interface. The top navigation bar includes 'Status', 'Account', 'Network', 'DSSKey', 'Features', 'Settings', 'Directory', and 'Security'. The left sidebar lists 'Preference', 'Time & Date', 'Call Display', 'Upgrade', 'Auto Provision', and 'Configuration'. The main content area is titled 'Call Display' and contains two dropdown menus: 'Display Called Party Information' (set to 'Enabled') and 'Call Information Display Method' (set to 'Name+Number'). A red box highlights these two dropdowns. Below the dropdowns are 'Confirm' and 'Cancel' buttons. On the right, a 'NOTE' box states: 'Call Display: Display called party information allows the IP phone to present the callee identity in addition to the presentation of caller identity when it receives an incoming call. You can click here to get more guides.'

4. Click **Confirm** to accept the change.

To configure call display features via web user interface (take SIP-T46G IP phones for example):


1. Click on **Settings->Call Display**.
2. Select the desired value from the pull-down list of **Display Contact Photo**.
3. Select the desired value from the pull-down list of **Display Called Party Information**.
4. Select the desired value from the pull-down list of **Call Information Display Method**.

The screenshot shows the Yealink T46G web interface. The top navigation bar includes 'Status', 'Account', 'Network', 'DSSKey', 'Features', 'Settings', 'Directory', and 'Security'. The left sidebar lists 'Preference', 'Time & Date', 'Call Display', 'Upgrade', 'Auto Provision', and 'Configuration'. The main content area is titled 'Call Display' and contains three dropdown menus: 'Display Contact Photo' (set to 'Enabled'), 'Display Called Party Information' (set to 'Enabled'), and 'Call Information Display Method' (set to 'Name+Number'). A red box highlights these three dropdowns. Below the dropdowns are 'Confirm' and 'Cancel' buttons. On the right, a 'NOTE' box states: 'Call Display: Display called party information allows the IP phone to present the callee identity in addition to the presentation of caller identity when it receives an incoming call. You can click here to get more guides.'

5. Click **Confirm** to accept the change.

Display Method on Dialing

When the IP phone is on the pre-dialing or dialing screen, the account information will be displayed on the top left corner of the LCD screen.



You can customize the account information to be displayed on the IP phone as required. IP phones support three account information display methods: Label, Display Name or User Name.

Procedure

Display method on dialing can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure display method on dialing. Parameter: features.caller_name_type_on_dialing
Local	Web User Interface	Configure display method on dialing. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=features-general&q=load">http://<phoneIPAddress>/servlet?p=features-general&q=load For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load

Details of Configuration Parameters:

Parameter	Permitted Values	Default
features.caller_name_type_on_dialing	1, 2 or 3	3

Parameter	Permitted Values	Default
<p>Description:</p> <p>Configures the account information displayed on the top left corner of the LCD screen when the IP phone is on the pre-dialing or dialing screen.</p> <p>1-Label 2-Display Name 3-User Name</p> <p>Web User Interface:</p> <p>Features->General Information->Display Method on Dialing</p> <p>Phone User Interface:</p> <p>None</p>		

To configure display method on dialing via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Display Method on Dialing**.

The screenshot shows the Yealink T23G web interface. The 'Features' tab is selected, and the 'General Information' sub-tab is active. In the 'General Information' section, the 'Display Method on Dialing' dropdown menu is highlighted with a red box and currently shows 'User Name'. Other settings visible include 'Call Waiting' (Enabled), 'Auto Redial' (Disabled), 'Auto Redial Interval' (10), 'Auto Redial Times' (10), 'Voice Mail Tone' (Enabled), 'DHCP Hostname' (SIP-T23G), 'Reboot in Talking' (Disabled), 'Hide Feature Access Codes' (Enabled), and 'Auto Linekeys' (Disabled). A 'NOTE' section on the right provides additional information about features like Call Waiting, Auto Redial, Key As Send, Hotline, and Call Completion.

3. Click **Confirm** to accept the change.

Web Server Type

Web server type determines access protocol of the IP phone's web user interface. IP phones support both HTTP and HTTPS protocols for accessing the web user interface. HTTP is an application protocol that runs on top of the TCP/IP suite of protocols. HTTPS is a web protocol that encrypts and decrypts user page requests as well as pages returned by the web server. Both HTTP and HTTPS port numbers are configurable.

Procedure

Web server type can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	<p>Configure the web access type, HTTP port and HTTPS port.</p> <p>Parameters:</p> <p>wui.http_enable</p> <p>network.port.http</p> <p>wui.https_enable</p> <p>network.port.https</p>
Local	Web User Interface	<p>Configure the web access type, HTTP port and HTTPS port.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>http://<phoneIPAddress>/servlet?p=network-adv&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet?m=mod_data&p=network-adv&q=load</p>
	Phone User Interface	<p>Configure the web access type, HTTP port and HTTPS port.</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
wui.http_enable	0 or 1	1
<p>Description:</p> <p>Enables or disables the user to access web user interface of the IP phone using the HTTP protocol.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>Note: If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface:</p>		

Parameters	Permitted Values	Default
Network->Advanced->Web Server->HTTP Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->Webserver Type->HTTP Status		
network.port.http	Integer from 1 to 65535	80
Description: Configures the HTTP port for the user to access web user interface of the IP phone using the HTTP protocol. Note: If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Network->Advanced->Web Server->HTTP Port(1~65535) Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->Webserver Type->HTTP Port		
wui.https_enable	0 or 1	1
Description: Enables or disables the user to access web user interface of the IP phone using the HTTPS protocol. 0 -Disabled 1 -Enabled Note: If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Network->Advanced->Web Server->HTTPS Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->Webserver Type->HTTPS Status		
network.port.https	Integer from 1 to 65535	443
Description: Configures the HTTPS port for the user to access web user interface of the IP phone using the HTTPS protocol. Note: If you change this parameter, the IP phone will reboot to make the change take		

Parameters	Permitted Values	Default
<p>effect.</p> <p>Web User Interface:</p> <p>Network->Advanced->Web Server->HTTPS Port(1~65535)</p> <p>Phone User Interface:</p> <p>Menu->Settings->Advanced Settings (default password: admin)</p> <p>->Network->Webserver Type->HTTPS Port</p>		

To configure web server type via web user interface:

1. Click on **Network->Advanced**.
2. Select the desired value from the pull-down list of **HTTP**.
3. Enter the desired HTTP port number in the **HTTP Port(1~65535)** field.
The default HTTP port number is 80.
4. Select the desired value from the pull-down list of **HTTPS**.
5. Enter the desired HTTPS port number in the **HTTPS Port(1~65535)** field.
The default HTTPS port number is 443.





The screenshot shows the Yealink T236 web interface. The 'Network' tab is selected, and the 'Advanced' sub-tab is active. On the left sidebar, 'Basic', 'PC Port', and 'Advanced' are listed. The main content area shows various network settings. The 'Web Server' section is highlighted with a red rectangle. It contains two rows: 'HTTP' with a dropdown set to 'Enabled' and a text field for 'HTTP Port (1~65535)' containing '80'; and 'HTTPS' with a dropdown set to 'Enabled' and a text field for 'HTTPS Port (1~65535)' containing '443'. Other sections visible include LLDP, CDP, VLAN, and VPN. A 'NOTE' sidebar on the right contains information about VLAN, NAT Traversal, Quality of Service (QoS), Web Server Type, and 802.1X Authentication.

6. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
7. Click **OK** to reboot the phone.

To configure web server type via phone user interface:

1. Press **Menu->Settings->Advanced Settings** (default password: admin)

->**Network->Webserver Type.**

2. Press  or  , or the **Switch** soft key to select the desired value from the **HTTP Status** field.
 3. Enter the desired HTTP port number in the **HTTP Port** field.
 4. Press  or  , or the **Switch** soft key to select the desired value from the **HTTP Status** field.
 5. Enter the desired HTTPS port number in the **HTTPS Port** field.
 6. Press the **Save** soft key to accept the change.
- The IP phone reboots automatically to make settings effective after a period of time.

Time and Date

IP phones maintain a local clock and calendar. Time and date are displayed on the idle screen of IP phones.

The following table lists available configuration methods for time and date.

Option	Configuration Methods
NTP time server	Configuration Files Web User Interface Phone User Interface
Time Zone	Configuration Files Web User Interface Phone User Interface
Time	Web User Interface Phone User Interface
Time Format	Configuration Files Web User Interface Phone User Interface
Date	Web User Interface Phone User Interface
Date Format	Configuration Files Web User Interface Phone User Interface
Daylight Saving Time	Configuration Files Web User Interface

NTP Time Server

A time server is a computer server that reads the actual time from a reference clock and distributes this information to the clients in a network. The Network Time Protocol (NTP) is the most widely used protocol that distributes and synchronizes time in the network.

The IP phones synchronize the time and date automatically from the NTP time server by default. The NTP time server address can be offered by the DHCP server or configured manually. NTP by DHCP Priority feature can configure the priority for the IP phone to use the NTP time server address offered by the DHCP server or configured manually.

Time Zone

A time zone is a region on Earth that has a uniform standard time. It is convenient for areas in close commercial or other communication to keep the same time. When configuring the IP phone to obtain the time and date from the NTP time server, you must set the time zone.

Procedure

NTP time server and time zone can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure NTP by DHCP priority feature and DHCP time feature. Parameters: local_time.manual_ntp_srv_prior local_time.dhcp_time
		Configure the NTP server, time zone. Parameters: local_time.ntp_server1 local_time.ntp_server2 local_time.interval local_time.time_zone local_time.time_zone_name
Local	Web User Interface	Configure NTP by DHCP priority feature and DHCP time feature. Configure the NTP server, time zone. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P)

		E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet ?p=settings-datetime&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=settings-datetime&q=load
	Phone User Interface	Configure DHCP time feature. Configure the NTP server, time zone.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
local_time.manual_ntp_srv_prior	0 or 1	0
Description: Configures the priority for the IP phone to use the NTP server address offered by the DHCP server. 0 -High (use the NTP server address offered by the DHCP server preferentially) 1 -Low (use the NTP server address configured manually preferentially) Web User Interface: Settings->Time & Date->NTP by DHCP Priority Phone User Interface: None		
local_time.dhcp_time	0 or 1	0
Description: Enables or disables the IP phone to update time with the offset time offered by the DHCP server. 0 -Disabled 1 -Enabled Note: It is only available to offset from GMT 0. Web User Interface: Settings->Time & Date->DHCP Time Phone User Interface: Menu->Settings->Basic Settings->Time & Date->DHCP Time		

Parameters	Permitted Values	Default
local_time.ntp_server1	IP address or domain name	cn.pool.ntp.org
Description: Configures the IP address or the domain name of the NTP server 1. Example: local_time.ntp_server1 = 192.168.0.5 Web User Interface: Settings->Time & Date->Primary Server Phone User Interface: Menu->Settings->Basic Settings->Time & Date->SNTP Settings->NTP Server1		
local_time.ntp_server2	IP address or domain name	Refer to the following content
Description: Configures the IP address or the domain name of the NTP server 2. If the NTP server 1 is not configured or cannot be accessed, the IP phone will request the time and date from the NTP server 2. For SIP VP-T49G/CP860: The default value is cn.pool.ntp.org. For SIPT48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2: The default value is pool.ntp.org. Example: local_time.ntp_server2 = 192.168.0.6 Web User Interface: Settings->Time & Date->Secondary Server Phone User Interface: Menu->Settings->Basic Settings->Time & Date->SNTP Settings->NTP Server2		
local_time.interval	Integer from 15 to 86400	1000

Parameters	Permitted Values	Default
Description: Configures the interval (in seconds) to update time and date from the NTP server. Example: <code>local_time.interval = 1000</code> Web User Interface: Settings->Time & Date->Synchronism (15~86400s) Phone User Interface: None		
<code>local_time.time_zone</code>	-11 to +14	+8
Description: Configures the time zone. For more available time zones, refer to Appendix B: Time Zones on page 923. Example: <code>local_time.time_zone = +8</code> Web User Interface: Settings->Time & Date->Time Zone Phone User Interface: Menu->Settings->Basic Settings->Time & Date->SNTP Settings->Time Zone		
<code>local_time.time_zone_name</code>	String within 32 characters	China(Beijing)
Description: Configures the time zone name. The available time zone names depend on the time zone configured by the parameter "local_time.time_zone". For more information on the available time zone names for each time zone, refer to Appendix B: Time Zones on page 923. Example: <code>local_time.time_zone_name = China(Beijing)</code> Note: It works only if the value of the parameter "local_time.summer_time" is set to 2 (Automatic) and the parameter "local_time.time_zone" should be configured in advance. Web User Interface: Settings->Time & Date->Location Phone User Interface: Menu->Settings->Basic Settings->Time & Date->SNTP Settings->Location		

To configure NTP by DHCP priority feature via web user interface:

1. Click on **Settings->Time & Date**.
2. Select the desired value from the pull-down list of **NTP by DHCP Priority**.

The screenshot shows the Yealink T236 web interface. The 'Settings' tab is selected, and the 'Time & Date' sub-tab is active. The 'NTP by DHCP Priority' dropdown menu is highlighted with a red rectangle and is currently set to 'High'. Other visible settings include 'DHCP Time' (Disabled), 'Time Zone' (+8 China, Singapore, Australia, Russia), 'Daylight Saving Time' (Automatic), 'Location' (China(Beijing)), 'Fixed Type' (DST by Date), 'Start Date' and 'End Date' (Month/Day/Hour), 'Offset(minutes)' (1000), 'Primary Server' (cn.pool.ntp.org), 'Secondary Server' (cn.pool.ntp.org), 'Synchronism (15~86400s)', 'Manual Time' (Disabled), 'Time Format' (Hour 24), and 'Date Format' (WWW MMM DD). A 'NOTE' section on the right provides information about Time and Date, Time Zone, NTP Server, and Daylight Saving Time.

3. Click **Confirm** to accept the change.

To configure the NTP server, time zone via web user interface:

1. Click on **Settings->Time & Date**.
2. Select **Disabled** from the pull-down list of **Manual Time**.
3. Select the desired time zone from the pull-down list of **Time Zone**.
4. Select the desired location from the pull-down list of **Location**.
5. Enter the domain name or IP address in the **Primary Server** and **Secondary Server** field respectively.

- Enter the desired time interval in the **Synchronism (15~86400s)** field.

- Click **Confirm** to accept the change.

To configure the NTP server and time zone via phone user interface:

- Press **Menu->Settings->Basic Settings->Time & Date->SNTP Settings**.
- Press **◀** or **▶**, or the **Switch** soft key to select the time zone that applies to your area from the **Time Zone** field.
The default time zone is "+8".
- Enter the domain name or IP address in the **NTP Server1** and **NTP Server2** field respectively.
- Press **◀** or **▶**, or the **Switch** soft key to select the desired value from the **Daylight Saving** field.
If **Automatic** is selected, the **Location** field will appear.
- Press **◀** or **▶**, or the **Switch** soft key to select the desired value from the **Location** field.
- Press the **Save** soft key to accept the change.

Time and Date Settings

You can set the time and date manually when IP phones cannot obtain the time and date from the NTP time server. The time and date display can use one of several different formats.

Procedure

Time and date can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure the time and date manually. Parameter: local_time.manual_time_enable
		Configure the time and date formats. Parameters: local_time.time_format local_time.date_format
Local	Web User Interface	Configure the time and date manually. Configure the time and date formats. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=settings-datetime&q=load">http://<phoneIPAddress>/servlet?p=settings-datetime&q=load For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=settings-datetime&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=settings-datetime&q=load
	Phone User Interface	Configure the time and date manually. Configure the time and date formats.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
local_time.manual_time_enable	0 or 1	0

Parameters	Permitted Values	Default
Description: Enables or disables the IP phone to obtain time and date from manual settings. 0 -Disabled (obtain time and date from NTP server) 1 -Enabled (obtain time and date from manual settings) Web User Interface: Settings->Time & Date->Manual Time Phone User Interface: None		
local_time.time_format	0 or 1	1
Description: Configures the time format. 0 -Hour 12 1 -Hour 24 If it is set to 0 (Hour 12), the time will be displayed in 12-hour format with AM or PM specified. If it is set to 1 (Hour 24), the time will be displayed in 24-hour format (e.g., 2:00 PM displays as 14:00). Web User Interface: Settings->Time & Date->Time Format Phone User Interface: Menu->Settings->Basic Settings->Time & Date->Time & Date Format->Time Format		
local_time.date_format	0, 1, 2, 3, 4, 5 or 6	0
Description: Configures the date format. Valid values are: 0 -WWW MMM DD 1 -DD-MMM-YY 2 -YYYY-MM-DD 3 -DD/MM/YYYY 4 -MM/DD/YY 5 -DD MMM YYYY 6 -WWW DD MMM Note: "WWW" represents the abbreviation of the week, "DD" represents a two-digit		

Parameters	Permitted Values	Default
<p>day, "MMM" represents the first three letters of the month, "YYYY" represents a four-digit year, and "YY" represents a two-digit year.</p> <p>Web User Interface:</p> <p>Settings->Time & Date->Date Format</p> <p>Phone User Interface:</p> <p>Menu->Settings->Basic Settings->Time & Date->Time & Date Format->Date Format</p>		

To configure the time and date manually via web user interface:

1. Click on **Settings->Time & Date**.
2. Select **Enabled** from the pull-down list of **Manual Time**.
3. Enter the time and date in the corresponding fields.

The screenshot shows the Yealink T236 web interface. The 'Settings' tab is selected, and the 'Time & Date' configuration page is displayed. The 'Manual Time' option is selected from the 'Manual Time' dropdown menu and is highlighted with a red box. The date is set to Year 2015, Month 5, Day 18, and the time is set to Hour 16, Minute 8, Second 15. The Time Format is set to Hour 24 and the Date Format is set to WWW MMM DD. The 'Confirm' and 'Cancel' buttons are visible at the bottom of the form.

4. Click **Confirm** to accept the change.

To configure the time and date format via web user interface:

1. Click on **Settings->Time & Date**.
2. Select the desired value from the pull-down list of **Time Format**.

3. Select the desired value from the pull-down list of **Date Format**.

The screenshot shows the Yealink T236 web interface. The 'Settings' tab is selected, and the 'Time & Date' configuration page is displayed. The 'Date Format' field is highlighted with a red box, showing 'WWW MMM DD'. The 'Time Format' field shows 'Hour 24'. The page includes a sidebar with navigation options like Preference, Time & Date, Call Display, Upgrade, Auto Provision, Configuration, Dial Plan, Voice, Ring, Tones, Softkey Layout, TR069, Voice Monitoring, and SIP. A 'NOTE' section on the right provides information about Time and Date, Time Zone, NTP Server, and Daylight Saving Time.

4. Click **Confirm** to accept the change.

To configure the time and date manually via phone user interface:

1. Press **Menu->Settings->Basic Settings->Time & Date->Manual Settings**.
2. Enter the date in the **Date(YMD)** field.
3. Enter the time in the **Time(HMS)** field.
4. Press the **Save** soft key to accept the change.

To configure the time and date formats via phone user interface:

1. Press **Menu->Settings->Basic Settings->Time & Date->Time & Date Format**.
2. Press **◀** or **▶**, or the **Switch** soft key to select the desired time format from the **Time Format** field.
3. Press **◀** or **▶**, or the **Switch** soft key to select the desired date format from the **Date Format** field.
4. Press the **Save** soft key to accept the change.

Daylight Saving Time

Daylight Saving Time (DST) is the practice of temporary advancing clocks during the summer time so that evenings have more daylight and mornings have less. Typically, clocks are adjusted forward one hour at the start of spring and backward in autumn. Many countries have used the DST at various times, details vary by location. By default, the DST is set to Automatic, so it can be adjusted automatically from the current time zone configuration. You can configure DST for the desired area as required.

Procedure

Daylight saving time can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure DST. Parameters: local_time.summer_time local_time.dst_time_type local_time.start_time local_time.end_time local_time.offset_time
Local	Web User Interface	Configure DST. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=settings-datetime&q=load">http://<phoneIPAddress>/servlet?p=settings-datetime&q=load For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=settings-datetime&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=settings-datetime&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
local_time.summer_time	0, 1 or 2	2
Description: Configures Daylight Saving Time (DST) feature. 0 -Disabled 1 -Enabled 2 -Automatic Web User Interface: Settings->Time & Date->Daylight Saving Time Phone User Interface: Menu->Settings->Basic Settings->Time & Date->SNTP Settings->Daylight Saving		

Parameters	Permitted Values	Default
local_time.dst_time_type	0 or 1	0
<p>Description: Configures the DST time type.</p> <p>0-DST by Date 1-DST by Week</p> <p>Note: It works only if the value of the parameter "local_time.summer_time" is set to 1 (Enabled).</p> <p>Web User Interface: Settings->Time & Date->Fixed Type</p> <p>Phone User Interface: None</p>		
local_time.start_time	Time	1/1/0
<p>Description: Configures the start time of the DST.</p> <p>Value formats are:</p> <ul style="list-style-type: none"> Month/Day/Hour (for DST by Date) Month/Week of Month/Day of Week/Hour of Day (for DST by Week) <p>If "local_time.dst_time_type" is set to 0 (DST by Date), use the mapping:</p> <p>Month: 1=January, 2=February,..., 12=December</p> <p>Day: 1=the first day in a month,..., 31= the last day in a month</p> <p>Hour: 0=0am, 1=1am,..., 23=11pm</p> <p>If "local_time.dst_time_type" is set to 1 (DST by Week), use the mapping:</p> <p>Month: 1=January, 2=February,..., 12=December</p> <p>Week of Month: 1=the first week in a month,..., 5=the last week in a month</p> <p>Day of Week: 1=Monday, 2=Tuesday,..., 7=Sunday</p> <p>Hour of Day: 0=0am, 1=1am,..., 23=11pm</p> <p>Note: It works only if the value of the parameter "local_time.summer_time" is set to 1 (Enabled).</p> <p>Web User Interface: Settings->Time & Date->Start Date</p> <p>Phone User Interface: None</p>		

Parameters	Permitted Values	Default
local_time.end_time	Time	12/31/23
<p>Description: Configures the end time of the DST.</p> <p>Value formats are:</p> <ul style="list-style-type: none"> Month/Day/Hour (for DST by Date) Month/Week of Month/Day of Week/Hour of Day (for DST by Week) <p>If "local_time.dst_time_type" is set to 0 (DST by Date), use the mapping:</p> <p>Month: 1=January, 2=February,..., 12=December</p> <p>Day: 1=the first day in a month,..., 31= the last day in a month</p> <p>Hour: 0=0am, 1=1am,..., 23=11pm</p> <p>If "local_time.dst_time_type" is set to 1 (DST by Week), use the mapping:</p> <p>Month: 1=January, 2=February,..., 12=December</p> <p>Week of Month: 1=the first week in a month,..., 5=the last week in a month</p> <p>Day of Week: 1=Monday, 2=Tuesday,..., 7=Sunday</p> <p>Hour of Day: 0=0am, 1=1am,..., 23=11pm</p> <p>Note: It works only if the value of the parameter "local_time.summer_time" is set to 1 (Enabled).</p> <p>Web User Interface: Settings->Time & Date->End Date</p> <p>Phone User Interface: None</p>		
local_time.offset_time	Integer from -300 to 300	Blank
<p>Description: Configures the offset time (in minutes) of DST.</p> <p>Note: It works only if the value of the parameter "local_time.summer_time" is set to 1 (Enabled).</p> <p>Web User Interface: Settings->Time & Date->Offset(minutes)</p> <p>Phone User Interface: None</p>		

To configure the DST via web user interface:

1. Click on **Settings->Time & Date**.

2. Select **Disabled** from the pull-down list of **Manual Time**.
3. Select the desired time zone from the pull-down list of **Time Zone**.
4. Enter the domain name or IP address in the **Primary Server** and **Secondary Server** field respectively.
5. Enter the desired time interval in the **Synchronism (15~86400s)** field.
6. Mark the **Enabled** radio box in the **Daylight Saving Time** field.
 - Mark the **DST by Date** radio box in the **Fixed Type** field.

Enter the start time in the **Start Date** field.

Enter the end time in the **End Date** field.

The screenshot displays the 'Time & Date' configuration page in the Yealink T236 web interface. The left sidebar shows navigation options like Preference, Time & Date, Call Display, Upgrade, Auto Provision, Configuration, Dial Plan, Voice, Ring, Tones, Softkey Layout, TR069, Voice Monitoring, and SIP. The main content area is titled 'Time & Date' and contains various settings. A red box highlights the 'Daylight Saving Time' section, where 'Enabled' is selected under the 'Fixed Type' radio buttons, and 'DST by Date' is chosen. The 'Start Date' is configured with Month 1, Day 1, and Hour 2. The 'End Date' is configured with Month 12, Day 12, and Hour 22. Other visible settings include 'Time Zone' set to '+8 China, Singapore, Australia, Russia', 'Primary Server' and 'Secondary Server' both set to 'cn.pool.ntp.org', 'Synchronism (15~86400s)' set to '1000', 'Manual Time' set to 'Disabled', 'Time Format' set to 'Hour 24', and 'Date Format' set to 'WWW MMM DD'. A 'NOTE' section on the right provides additional information about time zones, NTP servers, and daylight saving time.

- Mark the **DST by Week** radio box in the **Fixed Type** field.

Select the desired values of DST Start Month, DST Start Week of Month, DST Start Day of Week, Start Hour of Day; DST Stop Month, DST Stop Week of Month, DST Stop Day of Week and End Hour of Day from the pull-down lists.

The screenshot shows the Yealink T236 web interface. The 'Settings' tab is selected, and the 'Time & Date' configuration page is displayed. The 'Daylight Saving Time' section is highlighted with a red box, showing the 'Enabled' radio button selected. The 'Fixed Type' section shows 'DST by Week' selected. The 'Start Date' and 'End Date' fields are also visible, with pull-down menus for month, week, day, and hour. The 'Offset(minutes)' field is empty. The 'NTP by DHCP Priority' is set to 'High'. The 'Primary Server' and 'Secondary Server' are both set to 'cn.pool.ntp.org'. The 'Synchronism (15~86400s)' is set to '1000'. The 'Manual Time' is set to 'Disabled'. The 'Time Format' is set to 'Hour 24'. The 'Date Format' is set to 'WWW MMM DD'. There are 'Confirm' and 'Cancel' buttons at the bottom.

7. Enter the desired offset time in the **Offset(minutes)** field.
8. Click **Confirm** to accept the change.

Customizing an AutoDST Template File

The time zone and corresponding DST pre-configurations exist in the AutoDST file. If the DST is set to Automatic, the IP phone obtains the DST configuration from the AutoDST file. You can customize the AutoDST file if required. The AutoDST file allows you to add or modify time zone and DST settings for your area each year.

Before customizing, you need to obtain the AutoDST file. You can ask the distributor or Yealink FAE for DST template. You can also obtain the DST template online:

<http://support.yealink.com/documentFront/forwardToDocumentFrontDisplayPage>. For more information on obtaining the template file, refer to [Obtaining Configuration Files and Resource Files](#) on page 52.

The following table lists description of each element in the template file:

Element	Type	Values	Description
DSTData	required	no	File root element
DST	required	no	Time Zone item's root element
szTime	required	[+/-][X]:[Y], X=0~14, Y=0~59	Time Zone
szZone	required	String (if the content is more than one city, it is the best to	Time Zone name

Element	Type	Values	Description
		keep their daylight saving time the same)	
iType	optional	0/1 0: DST by Date 1: DST by Week	DST time type (This item is needed if you want to configure DST.)
szStart	optional	Month/Day/Hour (for iType=0) Month: 1~12 Day: 1~31 Hour: 0 (midnight)~23 Month/Week of Month/Day of Week/Hour of Day (for iType=1) Month: 1~12 Week of Month: 1~5 (the last week) Day of Week: 1~7 Hour of Day: 0 (midnight)~23	Start time of the DST
szEnd	optional	Same as szStart	End time of the DST
szOffset	optional	Integer from -300 to 300	The offset time (in minutes) of DST

When customizing an AutoDST file, learn the following:

- <DSTData> indicates the start of a template and </DSTData> indicates the end of a template.
- Add or modify time zone and DST settings between <DSTData> and </DSTData>.
- The display order of time zone is corresponding to the szTime order specified in the AutoDST.xml file.
- If the start time of DST is greater than the end time, the valid time of DST is from the start time of this year to the end time of the next year.

Customizing an AutoDST file:

1. Open the AutoDST file using an ASCII editor.
2. Add or modify time zone and DST settings as you want in the AutoDST file.

Example 1:

To modify the DST settings for the existing time zone "+5 Pakistan(Islamabad)" and add DST settings for the existing time zone "+5:30 India(Calcutta)".

```

AutoDST.xml x
<DST szTime="+3:30" szZone="Iran (Teheran)" iType="0" szStart="3/22/0" szEnd="9/22/0" szOffset="60"/>
<DST szTime="+4" szZone="Armenia (Yerevan)" iType="1" szStart="3/5/7/2" szEnd="10/5/7/3" szOffset="60"/>
<DST szTime="+4" szZone="Azerbaijan (Baku)" iType="1" szStart="3/5/7/4" szEnd="10/5/7/5" szOffset="60"/>
<DST szTime="+4" szZone="Georgia (Tbilisi)" />
<DST szTime="+4" szZone="Kazakhstan (Aktau)" />
<DST szTime="+4" szZone="Russia (Samara)" />
<DST szTime="+4:30" szZone="Afghanistan (Kabul)" />
<DST szTime="+5" szZone="Kazakhstan (Aqtobe)" />
<DST szTime="+5" szZone="Kyrgyzstan (Bishkek)" />
<DST szTime="+5" szZone="Pakistan (Islamabad)" iType="0" szStart="4/15/0" szEnd="11/1/0" szOffset="60"/>
<DST szTime="+5" szZone="Russia (Chelyabinsk)" />
<DST szTime="+5:30" szZone="India (Calcutta)" iType="1" szStart="9/5/7/3" szEnd="4/1/7/2" szOffset="60"/>
<DST szTime="+5:45" szZone="Nepal (Katmandu)" />
<DST szTime="+6" szZone="Kazakhstan (Astana, Almaty)" />
<DST szTime="+6" szZone="Russia (Novosibirsk, Omsk)" />
<DST szTime="+6:30" szZone="Myanmar (Naypyitaw)" />
<DST szTime="+7" szZone="Russia (Krasnoyarsk)" />
<DST szTime="+7" szZone="Thailand (Bangkok)" />
<DST szTime="+8" szZone="China (Beijing)" />
<DST szTime="+8" szZone="Singapore (Singapore)" />

```

Example 2:

Add a new time zone (+6 Paradise) with daylight saving time 30 minutes.

```

AutoDST.xml x
<DST szTime="+4:30" szZone="Afghanistan (Kabul)" />
<DST szTime="+5" szZone="Kazakhstan (Aqtobe)" />
<DST szTime="+5" szZone="Kyrgyzstan (Bishkek)" />
<DST szTime="+5" szZone="Pakistan (Islamabad)" iType="0" szStart="4/15/0" szEnd="11/1/0" />
<DST szTime="+5" szZone="Russia (Chelyabinsk)" />
<DST szTime="+5:30" szZone="India (Calcutta)" />
<DST szTime="+5:45" szZone="Nepal (Katmandu)" />
<DST szTime="+6" szZone="Paradise" iType="1" szStart="3/5/7/2" szEnd="10/5/7/3" szOffset="30"/>
<DST szTime="+6" szZone="Kazakhstan (Astana, Almaty)" />
<DST szTime="+6" szZone="Russia (Novosibirsk, Omsk)" />
<DST szTime="+6:30" szZone="Myanmar (Naypyitaw)" />
<DST szTime="+7" szZone="Russia (Krasnoyarsk)" />
<DST szTime="+7" szZone="Thailand (Bangkok)" />
<DST szTime="+8" szZone="China (Beijing)" />
<DST szTime="+8" szZone="Singapore (Singapore)" />
<DST szTime="+8" szZone="Australia (Perth)" iType="1" szStart="10/1/7/2" szEnd="3/5/7/3" />
<DST szTime="+8" szZone="Russia (Irkutsk, Ulan-Ude)" />
<DST szTime="+8:45" szZone="Eucla" />
<DST szTime="+9" szZone="Korea (Seoul)" />
<DST szTime="+9" szZone="Japan (Tokyo)" />
<DST szTime="+9" szZone="Russia (Yakutsk, Chita)" />
<DST szTime="+9:30" szZone="Australia (Adelaide)" iType="1" szStart="10/1/7/2" szEnd="4/1/7/3" />
<DST szTime="+9:30" szZone="Australia (Darwin)" />
<DST szTime="+10" szZone="Australia (Sydney, Melbourne, Canberra)" iType="1" szStart="10/1/7/2" />
<DST szTime="+10" szZone="Australia (Brisbane)" />

```

3. Save this file and place it to the provisioning server (e.g., 192.168.1.100).
4. Specify the access URL of the AutoDST file in the configuration files.

Procedure

The access URL of the AutoDST file can be specified using the configuration files.

Configuration File	<MAC>.cfg	Specify the access URL of the AutoDST file. Parameters: auto_dst.url
--------------------	-----------	---

Details of Configuration Parameters:

Parameters	Permitted Values	Default
auto_dst.url	URL within 511 characters	Blank
<p>Description: Configures the access URL of the AutoDST file (AutoDST.xml).</p> <p>Example: auto_dst.url = tftp://192.168.1.100/AutoDST.xml</p> <p>During the auto provisioning process, the IP phone connects to the provisioning server "192.168.1.100", and downloads the AutoDST file "AutoDST.xml". After update, you will find a new time zone "Paradise" and updated DST of "Pakistan (Islamabad)" and "India (Calcutta)" via web user interface: Settings->Time & Date->Time Zone.</p> <p>Note: It works only if the value of the parameter "local_time.summer_time" is set to 2 (Automatic).</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		

Language

IP phones support multiple languages. Languages used on the phone user interface and web user interface can be specified respectively as required.

The following table lists languages supported by the phone user interface and the web user interface.

Phone/Web User Interface
English
Chinese Simplified
Chinese Traditional
French
German
Italian
Polish
Portuguese
Spanish

Phone/Web User Interface
Turkish
Russian

Loading Language Packs

Languages available for selection depend on language packs currently loaded to the IP phone. You can customize the translation of the existing language on the phone user interface or web user interface. You can also make new languages (not included in the available language list) available for use on the phone user interface and web user interface by loading language packs to the IP phone. Language packs can only be loaded using configuration files.

You can ask the distributor or Yealink FAE for language packs. You can also obtain the language packs online:

<http://support.yealink.com/documentFront/forwardToDocumentFrontDisplayPage>. For more information on obtaining the language packs, refer to [Obtaining Configuration Files and Resource Files](#) on page 52.

Note

To modify translation of an existing language, do not rename the language file.

The new added language must be supported by the font library on the IP phone. If the characters in the custom language file are not supported by the phone, the IP phone will display “?” instead.

Customizing a Language for Phone User Interface

The following table lists the available languages and associated language packs for the phone user interface:

Available Language	Associated Language Pack
English	000.GUI.English.lang
Chinese Simplified	001.GUI.Chinese_S.lang
Chinese Traditional	002.GUI.Chinese_T.lang
French	003.GUI.French.lang
German	004.GUI.German.lang
Italian	005.GUI.Italian.lang
Polish	006.GUI.Polish.lang
Portuguese	007.GUI.Portuguese.lang
Spanish	008.GUI.Spanish.lang


Available Language	Associated Language Pack
Turkish	009.GUI.Turkish.lang
Russian	010.GUI.Russian.lang

When adding a new language pack for the phone user interface, the language pack must be formatted as "X.GUI.name.lang" (X starts from 011, "name" is replaced with the language name). If the language name is the same as the existing one, the existing language pack will be overridden by the new uploaded one. We recommend that the filename of the new language pack should not be the same as the existing one.

To customize a language file:

1. Open the desired language template file (e.g., 000.GUI.English.lang) using an ASCII editor.
2. Modify the characters within the double quotation marks on the right of the equal sign. Don't modify the translation item on the left of the equal sign.

The following shows a portion of the language pack "000.GUI.English.lang" for the phone user interface (take SIP-T23G IP phones for example):



```

000.GUI.English.lang x
1 [ Lang ]
2
3 "Conference"="Conference"
4 "*" or '#' as send="Key as send"
5 "(Empty)"="(Empty)"
6 "12 Hour"="12 Hour"
7 "120s"="120s"
8 "15s"="15s"
9 "1800s"="1800s"
10 "24 Hour"="24 Hour"
11 "300s"="300s"
12 "30s"="30s"
13 "600s"="600s"
14 "60s"="60s"
15 "802.1x Mode"="802.1x Mode"
16 "802.1x Settings"="802.1x Settings"
17 "ACD Login"="ACD Login"
18 "ACD State"="ACD State"
19 "ACD Status"="ACD Status"
20 "ACD Trace"="Trace"
21 "ACD"="ACD"
22 "ALERT"="ALERT"
23 "AM"="AM"

```

3. Save the language file and place it to the provisioning server (e.g., 192.168.10.25).
4. Specify the access URL of the phone user interface language pack in the configuration files.

If you want to add a new custom language (e.g., Guilan) to your IP phone (e.g., SIP-T23G), prepare the language file named as "011.GUI.Guilan.lang" for downloading. After update, you will find a new language selection "Guilan" on the IP phone user

interface: **Menu->Settings->Basic Settings->Language.**

Procedure

Loading language pack can only be performed using the configuration files.

Configuration File	<y0000000000xx>.cfg	Specify the access URL of the phone user interface language pack. Parameter: gui_lang.url
		Delete custom LCD language packs of the phone user interface. Parameter: gui_lang.delete

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
gui_lang.url	URL within 511 characters	Blank
<p>Description: Configures the access URL of the custom LCD language pack for the phone user interface.</p> <p>Example: gui_lang.url = http://192.168.10.25/000.GUI.English.lang</p> <p>During the auto provisioning process, the IP phone connects to the HTTP provisioning server "192.168.10.25", and downloads the language pack "000.GUI.English.lang". The English language translation will be changed accordingly if you have modified the language template file.</p> <p>If you want to download multiple language packs to the phone simultaneously, you can configure as following:</p> <p>gui_lang.url = http://192.168.10.25/000.GUI.English.lang gui_lang.url = http://192.168.10.25/001.GUI.Chinese_S.lang</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		
gui_lang.delete	http://localhost/all or	Blank

Parameter	Permitted Values	Default
	<code>http://localhost/Y.GUI.name.lang</code>	
<p>Description: Deletes the specified or all custom LCD language packs of the phone user interface.</p> <p>Example: Delete all custom language packs of the phone user interface: gui_lang.delete = http://localhost/all</p> <p>Delete a custom language pack of the phone user interface (e.g., 001.GUI.Chinese_S.lang): gui_lang.delete = http://localhost/001.GUI.Chinese_S.lang</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		

Customizing a Language for Web User Interface

The following table lists available languages and associated language packs for the web user interface:


Available Language	Associated Language Pack	Associated Note Language Pack
English	1.English.js	1.English_note.xml
Chinese Simplified	2.Chinese_S.js	2.Chinese_S_note.xml
Chinese Traditional	3.Chinese_T.js	3.Chinese_T_note.xml
French	4.French.js	4.French_note.xml
German	5.German.js	5.German_note.xml
Italian	6.Italian.js	6.Italian_note.xml
Polish	7.Polish.js	7.Polish_note.xml
Portuguese	8.Portuguese.js	8.Portuguese_note.xml
Spanish	9.Spanish.js	9.Spanish_note.xml
Turkish	10.Turkish.js	10.Turkish_note.xml
Russian	11.Russian.js	11.Russian_note.xml

When adding a new language pack for the web user interface, the language pack must be formatted as "Y.name.js" (Y starts from 12, "name" is replaced with the language name). If the language name is the same as the existing one, the existing language file will be overridden by the new uploaded one. We recommend that the name of the new language file should not be the same as the existing languages.

To customize a language file:

1. Open the desired language template file (e.g., 1.English.js) using an ASCII editor.
2. Modify the characters within the double quotation marks on the right of the colon. Don't modify the translation item on the left of the colon.

The following shows a portion of the language pack "1.English.js" for the web user interface (take SIP-T23G IP phones for example):




```

1  var _objTrans =
2  {
3
4    " Call Number Filter":"Call Number Filter",
5    " Distinctive Ring Tones":"Distinctive Ring Tones",
6    " Do you want to reboot ?":"Do you want to reboot?",
7    "(800*480)":"(800*480)",
8    "0":"0",
9    "1":"1",
10   "10min":"10min",
11   "1min":"1min",
12   "2":"2",
13   "2min":"2min",
14   "3":"3",
15   "30min":"30min",
16   "4":"4",
17   "404 (Not found)": "404 (Not Found)",
18   "480 (Temporarily not available)": "480 (Temporarily Not Available)",
19   "486 (Busy here)": "486 (Busy Here)",
20   "5":"5",
21   "5min":"5min",
22   "6":"6",
23   "603 (Decline)": "603 (Decline)",
24   "ACD Auto Available Timer (0~120s)": "ACD Auto Available Timer (0~120s)",
25   "ACD Auto Available": "ACD Auto Available",

```

3. Save the language file and place it to the provisioning server (e.g., 192.168.10.25).
4. Specify the access URL of the web user interface language pack in the configuration files.

You can also customize the translation of the note language pack. The note information is displayed in the icon  of the web user interface. The note language pack must be formatted as "Y.name_note.xml" ("Y" and "name" are associated with web language pack).

To customize a note language file:

1. Open the desired note language template file (e.g., 1.English_note.xml) using an ASCII editor.
2. Modify the text of the note field. Don't modify the name of the note field.

The following shows a portion of the note language pack "1.English_note.xml" for the web user interface (take SIP-T23G IP phones for example):

- 3. Save the language file and place it to the provisioning server (e.g., 192.168.10.25).
- 4. Specify the access URL of the note language pack of the web user interface.

If you want to add a new language (e.g., Wuilan) to IP phones, prepare the language file named as “12.Wuilan.js” and “12.Wuilan_note.xml” for downloading. After update, you will find a new language selection “Wuilan” on the web user interface:

Settings->Preference->Language, and new note information is displayed in the icon when the new language is selected.

Procedure

Loading language pack can only be performed using the configuration files.

Configuration File	<y0000000000xx>.cfg	Specify the access URL of the custom language pack for web user interface. Parameter: wui_lang.url
		Specify the access URL of the custom note language pack for web user interface. Parameter: wui_lang_note.url
		Delete custom language packs and note language packs of the web user interface. Parameter: wui_lang.delete

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
wui_lang.url	URL within 511 characters	Blank
<p>Description: Configures the access URL of the custom language pack for the web user interface.</p> <p>Example: wui_lang.url = http://192.168.10.25/1.English.js</p> <p>During the auto provisioning process, the IP phone connects to the HTTP provisioning server "192.168.10.25", and downloads the language pack "1.English.js". The English language translation will be changed accordingly if you have modified the language template file.</p> <p>If you want to download multiple language packs to the web user interface simultaneously, you can configure as following: wui_lang.url = http://192.168.10.25/1.English.js wui_lang.url = http://192.168.10.25/11.Russian.js</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		
wui_lang_note.url	URL within 511 characters	Blank
<p>Description: Configures the access URL of the custom note language pack for web user interface.</p> <p>Example: wui_lang_note.url = http://192.168.10.25/1.English_note.xml</p> <p>During the auto provisioning process, the IP phone connects to the HTTP provisioning server "192.168.10.25", and downloads the note language pack "1.English_note.xml". The English language translation will be changed accordingly if you have modified the language template file.</p> <p>If you want to download multiple language packs to the phone simultaneously, you can configure as following: wui_lang.url = http://192.168.10.25/1.English_note.xml wui_lang.url = http://192.168.10.25/11.Russian_note.xml</p> <p>Web User Interface: None</p> <p>Phone User Interface:</p>		

Parameter	Permitted Values	Default
None		
wui_lang.delete	http://localhost/all or http://localhost/ <i>Y.name.js</i>	Blank
<p>Description:</p> <p>Delete the specified or all custom web language packs and note language packs of the web user interface.</p> <p>Example:</p> <p>Delete all custom language packs of the web user interface:</p> <p>wui_lang.delete = http://localhost/all</p> <p>Delete a custom language pack of the web user interface (e.g., 11.Russian.js):</p> <p>wui_lang.delete = http://localhost/11.Russian.js</p> <p>The corresponding note language pack (e.g., 11.Russian_note.xml) will also be deleted.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		

Specifying the Language to Use

The default language used on the phone user interface is English. If the language of your web browser is not supported by the IP phone, the web user interface will use English by default. You can specify the languages for the phone user interface and web user interface respectively.

Procedure

Specify the language for the phone user interface or the web user interface using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Specify the languages for the phone user interface and the web user interface. Parameters: lang.gui lang.wui
Local	Web User Interface	Specify the language for the web user interface.

		Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=settings-preference&q=load">http://<phoneIPAddress>/servlet?p=settings-preference&q=load For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=settings-preference&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=settings-preference&q=load
	Phone User Interface	Specify the language for the phone user interface.


Details of Configuration Parameters:

Parameters	Permitted Values	Default
lang.gui	Refer to the following content	English
Description: Configures the language used on the phone user interface. Permitted Values: English, Chinese_S, Chinese_T, French, German, Italian, Polish, Portuguese, Spanish, Turkish, Russian or the custom language name. Example: lang.gui = English If you want to use the custom language (e.g., Guilan) for the IP phone, configure the parameter "lang.gui = Guilan". Web User Interface: None Phone User Interface: Menu->Settings->Basic Settings->Language		
lang.wui	Refer to the following content	English
Description: Configures the language used on the web user interface. Permitted Values: English, Chinese_S, Chinese_T, French, German, Italian, Polish, Portuguese, Spanish,		

Parameters	Permitted Values	Default
<p>Turkish, Russian or the custom language name.</p> <p>Example: lang.wui = English</p> <p>If you want to use the custom language (e.g., Wuilan) for the IP phone, configure the parameter “lang.wui = Wuilan”.</p> <p>Note: If the language of your browser is not supported by the IP phone, the web user interface will use English by default.</p> <p>Web User Interface: Settings->Preference->Language</p> <p>Phone User Interface: None</p>		

To specify the language for the web user interface via web user interface:

1. Click on **Settings->Preference**.
2. Select the desired language from the pull-down list of **Language**.



3. Click **Confirm** to accept the change.

To specify the language for the phone user interface via phone user interface:

1. Press **Menu->Settings->Basic Settings->Language**.
2. Press **▲** or **▼** to select the desired language.
3. Press the **Save** soft key to accept the change.

Input Method

Keypad Input Method Customization

Keypad input method customization allows users to customize the existing input method on IP phones. You can first customize the Yealink-supplied keypad input method file "ime.txt" or "Russian_ime.txt", and then download it to the IP phone. The changes in the "Russian_ime.txt" file becomes effective when the language is set to Russian. The changes in the "ime.txt" file is effective for all the languages. IP phones support 6 input methods: 2aB, abc, Abc, 123, ABC and Hebrew. By default, Hebrew input method is hidden, you can manually configure the IP phone to display the Hebrew input method. If you just want to customize the input method for a certain language, the filename must be formatted as "language name_ime.txt" (e.g., German_ime.txt).


Note

Keypad input method customization is not applicable to SIP VP-T49G IP phones.

You can ask the distributor or Yealink FAE for keypad input method file. You can also obtain the keypad input method file online:

<http://support.yealink.com/documentFront/forwardToDocumentFrontDisplayPage>. For more information on obtaining the keypad input method file, refer to [Obtaining Configuration Files and Resource Files](#) on page 52.

The following shows a portion of the keypad input method file "ime.txt":



```

1 [2aB]
2 1 = "1"
3 2 = "2aBABC"
4 3 = "3deFDEF"
5 4 = "4ghiGHI"
6 5 = "5jklJKL"
7 6 = "6mnoMNO"
8 7 = "7pqrsPQRS"
9 8 = "8tuvTUV"
10 9 = "9wxyzWXYZ"
11 0 = "0"
12 * = "*, '?!\\-()@/:_+&%=<>£$%[]{}~^;`$#"|"
13 # = "#"
14
15 [abc]
16 1 = ""
17 2 = "abc2äåäåäåä"
18 3 = "def3èéééééé"
19 4 = "ghi4íîîîî"
20 5 = "jkl5z"
21 6 = "mno6öøøøøøø"
22 7 = "pqrs7ßS"
23 8 = "tuv8ùúúúú"
24 9 = "wxyz9ýÿ"
25 0 = ""
26 * = "*, '?!\\-()@/:_+&%=<>£$%[]{}~^;`$#"|"
27 # = "#"
  
```

The following shows a portion of the keypad input method file "Russian_ime.txt":

```

C:\Users\yl0817\Desktop\Russian_ime.txt
1 [2aB]
2 1 = "1"
3 2 = "АБВГабвр2ABCabс"
4 3 = "ДЕЖЗдежз3DEFdef"
5 4 = "ИЙКЛийкл4GHIghi"
6 5 = "МНОПмпноп5JKLjkl"
7 6 = "РСТУрсту6MNOmno"
8 7 = "ФХЦцфхцц7PQRSpqrs"
9 8 = "ШЩъЫышщъ8TUVtuv"
10 9 = "ЪЮЯъюя9WXYZwxyz"
11 0 = "0"
12 * = "*, '?!\-()@/:_;&%=<>£$¥¤[]{}~^`¡¢£$%&'()*+,-./:;<=>?@A-Z[a-z]0-9"
13 # = "#"
14
15
16 [ABC]
17 1 = "., '?!\-()@/:_;&%=<>£$¥¤[]{}~^`¡¢£$%&'()*+,-./:;<=>?@A-Z[a-z]0-9"
18 2 = "АБВГABC"
19 3 = "ДЕЖЗDEF"
20 4 = "ИЙКЛIGHI"
21 5 = "МНОПJKL"
22 6 = "РСТУMNO"
23 7 = "ФХЦцPQRS"
24 8 = "ШЩъЫTUV"
25 9 = "ЪЮЯWXYZ"
26 0 = "0"
27 * = "*, '?!\-()@/:_;&%=<>£$¥¤[]{}~^`¡¢£$%&'()*+,-./:;<=>?@A-Z[a-z]0-9"
28 # = "#"

```

To customize a keypad input method file:

1. Open the desired keypad input method file (e.g., ime.txt) using an ASCII editor.
2. Under the input method field (e.g., [abc]), add new characters or adjust the characters order within the double quotation marks on the right of the equal sign.

Don't modify the item on the left of the equal sign.

3. Save the keypad input method file and place it to the provisioning server (e.g., 192.168.10.25).
4. Specify the access URL of the custom keypad input method file in the configuration files.

Note

When adding new characters for the existing input method, ensure that the added characters are supported by IP phones.

The IP phones can only recognize the keypad input method files uploaded using Unicode encoding.

Do not rename the keypad input method filename.

Procedure

Specify the access URL of the custom keypad input method file using the configuration files.

Configuration File	<y0000000000xx>.cfg	Specify the access URL of the custom keypad input method file. Parameter: gui_input_method.url
--------------------	---------------------	---

		Delete custom keypad input method file of the phone user interface. Parameter: gui_input_method.delete
		Configure the phone to display the Hebrew input method. Parameter: features.input.hebrew_enable

Details of Configuration Parameters:

Parameters	Permitted Values	Default
gui_input_method.url	URL within 511 characters	Blank
<p>Description: Configures the access URL of the custom keypad input method file.</p> <p>Example: gui_input_method.url = http://192.168.10.25/ime.txt</p> <p>During the auto provisioning process, the IP phone connects to the provisioning server "192.168.1.25", and downloads the custom keypad input method file "ime.txt".</p> <p>gui_input_method.url = http://192.168.10.25/Russian_ime.txt</p> <p>During the auto provisioning process, the IP phone connects to the provisioning server "192.168.1.25", and downloads the custom keypad input method file "Russian_ime.txt" for Russian language.</p> <p>Note: If you want to upload a custom keypad input method file for the desired language, you can name the file "language name_ime.txt". It is not applicable to SIP VPT49G IP phones.</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		
gui_input_method.delete	http://localhost/all or http://localhost/Name.txt	Blank
<p>Description: Delete the specified or all custom keypad input method files of the phone user interface.</p>		

Parameters	Permitted Values	Default
Example: Delete all custom keypad input method files: gui_input_method.delete = http://localhost/all Delete a custom keypad input method file (e.g., ime.txt) for the phone: gui_input_method.delete = http://localhost/ime.txt Note: It is not applicable to SIP VP-T49G IP phones. Web User Interface: None Phone User Interface: None		
features.input.hebrew_enable	0 or 1	0
Description: Enables or disables the IP phone to display the Hebrew input method. 0 -Disabled 1 -Enabled Note: If you change this parameter, the IP phone will reboot to make the change take effect. It is not applicable to SIP VP-T49G IP phones. Web User Interface: None Phone User Interface: None		

Onscreen Keyboard Input Method Customization

The SIP VP-T49G IP phones support using onscreen keyboard to enter data, and provide English and Russian onscreen keyboard by default. You can create a new language onscreen keyboard or customize the existing input method files of the onscreen keyboard. Yealink provides three types of input method files for onscreen keyboard customization. You can configure them as required.

The following table lists the file name format for the three types of input method files and the description of template files provided by Yealink:

File Type	File Name (* represents any character)	Template File	Description
Lang	keyboard_lang.xml	keyboard_lang.xml	Configures the language of keyboard.
Ime	keyboard_ime_*.xml	keyboard_ime_1.xml	Configures the alternative characters for English keyboard in alphabetic input mode.
		keyboard_ime_russia.xml	Configures the alternative characters for Russian keyboard in alphabetic input mode.
	keyboard_ime_num*.xml	keyboard_ime_num.xml	Configures the alternative characters for keyboard in numeric&symbolic input mode. These two template files are the same, you can just use one of them as the input method file for English or Russian onscreen keyboard.
		keyboard_ime_num2.xml	
Layout	keyboard_layout_*.xml	keyboard_layout_1.xml	Configures the layout of English keyboard in alphabetic input mode.
		keyboard_layout_2.xml	Configures the layout of English or Russian keyboard in numeric&symbolic input mode.
		keyboard_layout_russia.xml	Configures the layout of Russian keyboard in alphabetic input mode.

Note

Onscreen keyboard input method customization is only applicable to SIP VP-T49G IP phones.

You can ask the distributor or Yealink FAE for onscreen keyboard input method files. You can also obtain the onscreen keyboard input method files online:

<http://support.yealink.com/documentFront/forwardToDocumentFrontDisplayPage>. For more

information on obtaining the onscreen keyboard input method files, refer to [Obtaining Configuration Files and Resource Files](#) on page 52.

Customizing a Lang File

When customizing a Lang file, learn the following:

- <KeyboardLang> indicates the start of a Lang file and </KeyboardLang> indicates the end of a Lang file.
- Create a language of keyboard between <Lang> and </Lang>.
- Configure the Ime file(s) that the language will use between <Ime> and </Ime>.
- One Ime file can be used by multiple languages. For example, the keyboard in numeric&symbolic input mode is almost same for each language, you can use the template file (keyboard_ime_num.xml/ keyboard_ime_num2.xml) as the input method file for multiple languages.
- If you want to create a new language onscreen keyboard, we recommend you customize the keyboards in alphabetic input mode and numeric&symbolic input mode at a time.

To customize a keyboard_lang.xml file:

1. Open the template file using an ASCII editor.
2. Edit the corresponding string in the file.




3. Save the file and place this file to the provisioning server.
4. Specify the access URL of the custom Lang file in the configuration file.

Customizing an Ime File


When customizing an Ime file, learn the following:

- `<KeyboardIme>` indicates the start of an Ime file and `</KeyboardIme>` indicates the end of an Ime file.
- A Line element represents a line on the keyboard. The first Line element represents the first line of the keyboard.
- A Key element represents a key on the keyboard. The first Key element in the Line element represents the first key of this line.
- There are three types of keyboard for English or Russian onscreen keyboard, the following takes English onscreen keyboard as example:


Keyboard in alphabetic input mode (lowercase):



Keyboard in alphabetic input mode (uppercase):



Keyboard in numeric&symbolic input mode:



The following table lists meaning of each variable in the lme input method file:

Element	Attribute	Description
Keyboardlme	Layout	Configures the Layout file that the keyboard will use.
	DisplayName	Configures the display name of the input mode when the input mode changes to lowercase.
	CapitalName	Configures the display name of the input mode when the input mode changes to uppercase.
	lmeType	It can be set to Char or Symbol. If it is set to Symbol, the shift key will not take effect.
Key	lmeNormal	Configures the characters the key provides when the input mode is set to lowercase.
	lmeCapital	Configures the characters the key provides when the input mode is set to uppercase. It works only if the lmeType is set to Char.
	Function	Configures the key's function. There are 11 types of values for function attributes, you can set to different values to provide different functions. The details are introduced below.


- There are two types of keys, one kind of key provides characters that you can enter, the other kind of key provides other function.

The following table lists the usage of the function keys:

No.	Function Key	Usage
1	Backspace	Delete the entered characters.
2	Space	Enter spaces.
3	Enter	Confirm the settings/Go to the next field.
4	Left	Position the cursor.
5	Right	Position the cursor.
6	Up	Position the cursor.
7	Down	Position the cursor.
8	Hide	Hide the onscreen keyboard.
9	Shift	Switch between the uppercase input mode and the lowercase input mode.
10	Lang	Change the language of the keyboard.
11	Switch	Change input mode.

To customize a `Keyboard_ime_german.xml` file:

1. Open the template file using an ASCII editor.
2. Edit the corresponding string in the file.



3. Save the file and place this file to the provisioning server.
4. Specify the access URL of the custom Ime file in the configuration file.

Customizing a Layout File

When customizing a Layout file, learn the following:

- `<KeyboardLayout>` indicates the start of a Layout file and `</KeyboardLayout>` indicates the end of a Layout file.
- A Line element represents a line on the keyboard. The first Line element represents the first line of the keyboard.
- A Key element represents a key on the keyboard. The first Key element in the Line element represents the first key of this line.
- The Line elements and Key elements both have four attributes: `LeftIndent`, `TopIndent`, `Width` and `Height` (all attribute values are in pixels). The following picture shows meaning of the four attributes:




- The value of attributes in a line element is the default value of the corresponding attribute in the key element. For example, if you have not configured the width attribute in the key element, the key will automatically use the value of width attribute configured in line element as the width.
- The size of onscreen keyboard is 1280 pixels wide by 427 pixels high. If the area of the keyboard you configured is larger than the size of keyboard, the part of area beyond the keyboard will not be shown.

To customize a `Keyboard_layout_german.xml` file:

1. Open the template file using an ASCII editor.

2. Edit the corresponding string in the file.



3. Save the file and place this file to the provisioning server.
4. Specify the access URL of the custom Layout file in the configuration files.

Note

If you want to customize the existing input method files of the onscreen keyboard, you just need to upload the custom files.

If you want to create a new language onscreen keyboard, you should upload all three types of input method files at a time. For the example above, you should upload “keyboard_lang.xml”, “keyboard_ime_german.xml” and “keyboard_layout_german.xml” files at a time.

Procedure

Specify the access URL of the custom onscreen keyboard input method file using the configuration files.

Configuration File	<y0000000000xx>.cfg	Specify the access URL of the custom onscreen keyboard input method file. Parameter: gui_onscreen_keyboard.url
--------------------	---------------------	---

Details of Configuration Parameters:

Parameters	Permitted Values	Default
gui_onscreen_keyboard.url	URL within 511 characters	Blank

Parameters	Permitted Values	Default
<p>Description: Configures the access URL of the custom onscreen keyboard input method file.</p> <p>Example: gui_onscreen_keyboard.url = http://192.168.1.25/keyboard_lang.xml gui_onscreen_keyboard.url = http://192.168.1.25/keyboard_ime_german.xml gui_onscreen_keyboard.url = http://192.168.1.25/keyboard_layout_german.xml During the auto provisioning process, the IP phone connects to the provisioning server "192.168.1.25", and downloads the custom files "keyboard_lang.xml", "keyboard_ime_german.xml" and "keyboard_layout_german.xml".</p> <p>Note: It is only applicable to SIP VP-T49G IP phones. If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		

Specifying the Default Input Method

In addition to customizing the keypad input method file, you can also specify the default input method for the IP phone when editing or searching for contacts.

Note It is not applicable to SIP VP-T49G IP phones.

Procedure

Specify the default input methods using the configuration files.

Configuration File	<y0000000000xx>.cfg	Specify the default input method when editing contacts. Parameter: directory.edit_default_input_method
		Specify the default input method when searching for contacts. Parameter: directory.search_default_input_method

Details of Configuration Parameters:

Parameters	Permitted Values	Default
directory.edit_default_input_method	Abc, 2aB, 123, abc, ABC or Hebrew	Abc
<p>Description: Configures the default input method when the user edits contacts in the Local Directory, LDAP, Remote Phone Book or Blacklist.</p> <p>Example: directory.edit_default_input_method = abc</p> <p>Note: If you want to configure the default input method to Hebrew, you need to set the value of the parameter "features.input.hebrew_enable" to 1 (Enabled) in advance. It is not applicable to SIP VP-T49G IP phones.</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		
directory.search_default_input_method	Abc, 2aB, 123, abc, ABC or Hebrew	Abc
<p>Description: Configures the default input method when the user searches for contacts in the Local Directory, LDAP, Remote Phone Book or Blacklist.</p> <p>Example: directory.search_default_input_method = abc</p> <p>Note: If you want to configure the default input method to Hebrew, you need to set the value of the parameter "features.input.hebrew_enable" to 1 (Enabled) in advance. It is not applicable to SIP VP-T49G IP phones.</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		

Logo Customization

Logo customization allows unifying the IP phone appearance or displaying a custom image on the idle screen such as a company logo, instead of the default system logo. Logo is not applicable to SIP VPT49G, SIPT48G, SIPT46G and SIPT29G IP phones. These

three IP phone models use wallpaper instead. For more information on wallpaper, refer to [Wallpaper](#) on page 113.

The following table lists the supported logo file format and resolution for each phone model.

Phone Model	Logo File Format	Resolution
SIP-T42G/T41P/CP860	.dob	$\leq 192 \times 64$ 2 gray scale
SIP-T27P	.dob	$\leq 240 \times 120$ 2 gray scale
SIP-T40P/T23P/T23G/T21(P) E2/T19(P) E2	.dob	$\leq 132 \times 64$ 2 gray scale

Note


Before uploading your custom logo to IP phones, ensure your logo file is correctly formatted.

Customizing a Logo Template File

The common picture format can be *.gif/*.jpg/*.png/*.bmp. Yealink IP phones only support the *.dob format logo files. Yealink provides PictureExDemo tool to convert *.gif/*.jpg/*.png/*.bmp format to *.dob format. You can ask the distributor or Yealink FAE for the PictureExDemo tool.

To customize a dob formatted logo file using the PictureExDemo tool:


1. Double click the PictureExDemo.exe.



2. Click **Add** button to open a *.gif/*.jpg/*.png/*.bmp file.

You can repeat the second step to add multiple original picture files.

3. Click the **Convert** button.



Then you can find the **DOB** logo files in the **adv** directory.

Configuring the Logo Shown on the Idle Screen

Procedure

The logo shown on the idle screen can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the logo shown on the idle screen. Parameters: phone_setting.lcd_logo.mode
		Specify the access URL of the custom logo file. Parameters: lcd_logo.url
		Delete all custom logo files. Parameters: lcd_logo.delete
Local	Web User Interface	Configure the logo shown on the idle screen. Navigate to: http://<phoneIPAddress>/servlet ?p=features-general&q=load


Details of Configuration Parameters:

Parameters	Permitted Values	Default
phone_setting.lcd_logo.mode	0, 1 or 2	0
<p>Description: Configures the logo mode of the LCD screen.</p> <p>0-Off 1-System logo 2-Custom logo</p> <p>If it is set to 0 (Off), the IP phone is not allowed to display a logo. If it is set to 1 (System logo), the LCD screen will display the system logo. If it is set to 2 (Custom logo), the LCD screen will display the custom logo (you need to upload a custom logo file to the IP phone).</p> <p>Note: It is not applicable to SIP VP-T49G/SIP-T48G/T46G/T29G IP phones.</p> <p>Web User Interface: Features->General Information->Use Logo</p> <p>Phone User Interface: None</p>		
lcd_logo.url	URL within 511 characters	Blank
<p>Description: Configures the access URL of the custom logo file.</p> <p>Example: lcd_logo.url = http://192.168.10.25/logo.dob</p> <p>During the auto provisioning process, the IP phone connects to the provisioning server "192.168.10.25", and downloads the custom logo file "logo.dob".</p> <p>Note: It works only if the value of the parameter "phone_setting.lcd_logo.mode" is set to 2 (Custom logo). It is not applicable to SIP VP-T49G/SIP-T48G/T46G/T29G IP phones.</p> <p>Web User Interface: Features->General Information->Upload Logo</p> <p>Phone User Interface: None</p>		
lcd_logo.delete	http://localhost/all	Blank

Parameters	Permitted Values	Default
<p>Description: Deletes all custom logo files.</p> <p>Example: lcd_logo.delete = http://localhost/all</p> <p>Note: It is not applicable to SIP VP-T49G/SIP-T48G/T46G/T29G IP phones.</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		

To configure an image logo via web user interface:

1. Click on **Features->General Information**.
2. Select **Custom logo** from the pull-down list of **Use Logo**.
3. Click **Browse** to select the logo file from your local system.
4. Click **Upload** to upload the file.



5. Click **Confirm** to accept the change.

The image logo screen and the idle screen are displayed alternately.

Softkey Layout

Softkey layout is used to customize the soft keys at the bottom of the LCD screen to best meet users' requirements. In addition to specifying which soft keys to display, you can determine their display order. It can be configured based on call states.

You can configure the softkey layout using the softkey layout templates for different call states. For more information on how to configure a softkey layout template, refer to [Customizing Softkey Layout Template File](#) on page 221.

Procedure

Softkey layout can be configured using the configuration files or locally.





Configuration File	<y0000000000xx>.cfg	Configure the softkey layout. Parameters: phone_setting.custom_softkey_enable
Local	Web User Interface	Configure the softkey layout. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet? p=settings-softkey&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet? m=mod_data&p=settings-softkey&q=load

Details of Configuration Parameters:


Parameters	Permitted Values	Default
phone_setting.custom_softkey_enable	0 or 1	0
Description: Enables or disables custom soft keys layout feature. 0 -Disabled 1 -Enabled Web User Interface: Settings->Softkey Layout->Custom Softkey Phone User Interface: None		

To configure softkey layout via web user interface:

1. Click on **Settings->Softkey Layout**.

2. Select the desired value from the pull-down list of **Custom Softkey**.
3. Select the desired state from the pull-down list of **Call States**.
4. Select the desired soft key from the **Unselected Softkeys** column and then click  .
The selected soft key appears in the **Selected Softkeys** column. If more than four soft keys are selected, a **More** soft key will appear on the LCD screen, and the selected soft keys are displayed in two pages.
5. Repeat the step 4 to add more soft keys to the **Selected Softkeys** column.
6. To remove the soft key from the **Selected Softkeys** column, select the desired soft key and then click  .
7. To adjust the display order of soft keys, select the desired soft key and then click  or  .

The LCD screen displays the soft keys in the adjusted order.



8. Click **Confirm** to accept the change.

Customizing Softkey Layout Template File

The softkey layout template allows you to customize soft key layout for different call states. The call states include CallFailed, CallIn, Connecting, Dialing (not applicable to SIP VP-T49G and SIP-T48G IP phones), RingBack and Talking.

You can ask the distributor or Yealink FAE for softkey layout template. You can also obtain the softkey layout template online:

<http://support.yealink.com/documentFront/forwardToDocumentFrontDisplayPage>. For more information on obtaining the softkey layout template, refer to [Obtaining Configuration Files and Resource Files](#) on page 52.

The following table lists soft keys available for IP phones in different call states.

Call State		Default Soft Keys	Optional Soft Keys
CallFailed		<p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860 IP phones:</p> <p>NewCall</p> <p>Empty</p> <p>Empty</p> <p>Empty</p> <p>For SIP VP-T49G IP phones:</p> <p>NewCall</p>	<p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860 IP phones:</p> <p>Empty</p> <p>End Call</p> <p>For SIP VP-T49G IP phones:</p> <p>Switch</p> <p>End Call</p>
CallIn		<p>Answer</p> <p>Forward</p> <p>Silence</p> <p>Reject</p>	<p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860 IP phones:</p> <p>Empty</p> <p>Switch</p> <p>For SIP VP-T49G IP phones:</p> <p>Switch</p>
Connecting	Connecting	<p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860 IP phones:</p> <p>Empty</p> <p>Empty</p> <p>Empty</p> <p>End Call</p> <p>For SIP VP-T49G IP phones:</p> <p>End Call</p>	<p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860 IP phones:</p> <p>Empty</p> <p>Switch</p> <p>For SIP VP-T49G IP phones:</p> <p>Switch</p>
	SemiAttends	<p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860</p>	<p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P)</p>

Call State		Default Soft Keys	Optional Soft Keys
		IP phones: Transfer Empty Empty End Call For SIP VP-T49G IP phones: Transfer End Call	E2/CP860 IP phones: Empty Switch For SIP VP-T49G IP phones: Switch
Dialing (not applicable to SIP VP-T49G and SIP-T48G IP phones)		Send IME Delete End Call	Empty History Switch Line Favorite (Directory) GPickup DPickup Retrieve
RingBack	RingBack	For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860 IP phones: Empty Empty Empty End Call For SIP VP-T49G IP phones: End Call	For SIPT48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860 IP phones: Empty Switch For SIP VP-T49G IP phones: Switch
	SemiAttendTransBack	For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860 IP phones: Transfer Empty Empty End Call	For SIPT48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860 IP phones: Empty Switch For SIP VP-T49G IP phones:

Call State		Default Soft Keys	Optional Soft Keys
		For SIP VP-T49G IP phones: Transfer End Call	Switch
Talking	Talk	Transfer Hold Conference End Call	For SIP-T48G/T46G/T42G/T4 1P/T40P/T29G/T27P/T23P /T23G/T21(P) E2/T19(P) E2/CP860 IP phones: Empty Mute SWAP NewCall Switch Answer Reject PriHold Park GPark RTP Status For SIP VP-T49G IP phones: Mute SWAP NewCall Switch Answer Reject PriHold Park GPark RTP Status Screenshot Record
	Hold	Transfer Resume NewCall	For SIP-T48G/T46G/T42G/T4 1P/T40P/T29G/T27P/T23P

Call State		Default Soft Keys	Optional Soft Keys
		End Call	/T23G/T21(P) E2/T19(P) E2/CP860 IP phones: Empty Switch Answer Reject For SIP VP-T49G IP phones: Switch Answer Reject Screenshot Record
	Held	For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860 IP phones: Empty Empty Empty End Call For SIP VP-T49G IP phones: End Call	For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860 IP phones: Empty Switch Answer Reject NewCall For SIP VP-T49G IP phones: Switch Answer Reject NewCall Screenshot Record
	PreTrans (not applicable to SIP VP-T49G and SIP-T48G IP phones)	Transfer IME Delete End Call	Empty Directory Switch Send
	Conferenced	For	For

Call State		Default Soft Keys	Optional Soft Keys
		SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2 IP phones: Empty Hold Split End Call For CP860 IP phones: Split Hold Manager End Call For SIP VP-T49G IP phones: Hold Split End Call	SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2 IP phones: Empty Switch Answer Reject Mute Manager RTP Status For CP860 IP phones: Empty Switch Answer Reject Mute RTP Status For SIP VP-T49G IP phones: Switch Answer Reject Mute RTP Status Screenshot Record

When editing a softkey layout template, learn the following:

- <Call States> indicates the start of a template and </Call States> indicates the end of a template. For example, <CallFailed> </CallFailed>.
- <Disable> indicates the start of the disabled soft key list and </Disable> indicates the end of the soft key list. The disabled soft keys are not displayed on the LCD screen.
- Create disabled soft keys between <Disable> and </Disable>.
- <Enable> indicates the start of the enabled soft key list and </Enable> indicates the end of the soft key list. The enabled soft keys are displayed on the LCD screen.

- Create enabled soft keys between <Enable> and </Enable>.
- <Default> indicates the start of the default soft key list and </Default> indicates the end of the default soft key list. The default soft keys are displayed on the LCD screen by default.

To customize a softkey layout template:

1. Open the template file using an ASCII editor.
2. For each soft key that you want to enable, move the string in the disabled soft key list to enabled soft key list in the file.


```

1 <CallFailed>
2   <Disable>
3     <Key Type="Empty"/>
4     <Key Type="Switch"/>
5     <Key Type="Cancel"/>
6   </Disable>
7   <Enable>
8     <Key Type="NewCall"/>
9     <Key Type="Empty"/>
10    <Key Type="Empty"/>
11    <Key Type="Empty"/>
12  </Enable>
13  <Default>
14    <Key Type="NewCall"/>
15    <Key Type="Empty"/>
16    <Key Type="Empty"/>
17    <Key Type="Empty"/>
18  </Default>
19 </CallFailed>
20

```

If you want to enable Cancel soft key in CallFailed state, just move this string.

For each soft key that you want disabled, just move the string in the enabled soft key list to disabled soft key list.



3. Save the change and place this file to the provisioning server.
4. Specify the access URL of the softkey layout template in the configuration files.

Procedure

Specify the access URL of the softkey layout template using configuration files.

Configuration File	<y0000000000xx>.cfg	Specify the access URL of the softkey layout template. Parameters: custom_softkey_call_failed.url custom_softkey_call_in.url custom_softkey_connecting.url custom_softkey_dialing.url custom_softkey_ring_back.url custom_softkey_talking.url
---------------------------	---------------------	---

Details of Configuration Parameters:

Parameters	Permitted Values	Default
custom_softkey_call_failed.url	URL within 511 characters	Blank

Parameters	Permitted Values	Default
<p>Description:</p> <p>Configures the access URL of the custom file for the soft key presented on the LCD screen when in the CallFailed state.</p> <p>Example:</p> <p>custom_softkey_call_failed.url = http:// 192.168.1.20/XMLfiles/CallFailed.xml</p> <p>During the auto provisioning process, the IP phone connects to the provisioning server "192.168.1.20", and downloads the CallFailed state file from the "XMLfiles" directory.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		
custom_softkey_call_in.url	URL within 511 characters	Blank
<p>Description:</p> <p>Configures the access URL of the custom file for the soft key presented on the LCD screen when in the CallIn state.</p> <p>Example:</p> <p>custom_softkey_call_in.url = http://192.168.1.20/XMLfiles/CallIn.xml</p> <p>During the auto provisioning process, the IP phone connects to the provisioning server "192.168.1.20", and downloads the CallIn state file from the "XMLfiles" directory.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		
custom_softkey_connecting.url	URL within 511 characters	Blank
<p>Description:</p> <p>Configures the access URL of the custom file for the soft key presented on the LCD screen when in the Connecting state.</p> <p>Example:</p> <p>custom_softkey_connecting.url = http://192.168.1.20/XMLfiles/Connecting.xml</p> <p>During the auto provisioning process, the IP phone connects to the provisioning server "192.168.1.20", and downloads the Connecting state file from the "XMLfiles" directory.</p>		

Parameters	Permitted Values	Default
Web User Interface: None Phone User Interface: None		
custom_softkey_dialing.url	URL within 511 characters	Blank
Description: Configures the access URL of the custom file for the soft key presented on the LCD screen when in the Dialing state. Example: custom_softkey_dialing.url = http://192.168.1.20/XMLfiles/Dialing.xml During the auto provisioning process, the IP phone connects to the provisioning server "192.168.1.20", and downloads the Dialing state file from the "XMLfiles" directory. Note: It is not applicable to SIP VP-T49G and SIP-T48G IP phones. Web User Interface: None Phone User Interface: None		
custom_softkey_ring_back.url	URL within 511 characters	Blank
Description: Configures the access URL of the custom file for the soft key presented on the LCD screen when in the RingBack state. Example: custom_softkey_ring_back.url = http://192.168.1.20/XMLfiles/RingBack.xml During the auto provisioning process, the IP phone connects to the provisioning server "192.168.1.20", and downloads the RingBack state file from the "XMLfiles" directory. Web User Interface: None Phone User Interface: None		
custom_softkey_talking.url	URL within 511 characters	Blank

Parameters	Permitted Values	Default
<p>Description: Configures the access URL of the custom file for the soft key presented on the LCD screen when in the Talking state.</p> <p>Example: custom_softkey_talking.url = http://192.168.1.20/XMLfiles/Talking.xml</p> <p>During the auto provisioning process, the IP phone connects to the provisioning server "192.168.1.20", and downloads the Talking state file from the "XMLfiles" directory.</p> <p>Note: If you want to configure a Record or Screenshot soft key for SIP VPT49G IP phones, the value of the parameter "features.call_recording.enable" or "features.screenshot.enable" must be set to 1 (Enabled).</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		

Key As Send

Key as send allows assigning the pound key or asterisk key as the send key.

Send tone allows the IP phone to play a key tone when a user presses the send key. Key tone allows the IP phone to play a key tone when a user presses any key. Send tone works only if key tone is enabled.

Procedure

Key as send can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure a send key. Parameter: features.key_as_send
		Configure a send tone. Parameter: features.send_key_tone
		Configure a key tone. Parameter: features.key_tone
		Configure send pound key.

		Parameter: features.send_pound_key
Local	Web User Interface	Configure a send key. Configure send pound key. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet ?p=features-general&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=features-general&q=load
		Configure a send tone or key tone. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet ?p=features-audio&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=features-audio&q=load
	Phone User Interface	Configure a send key. Configure a key tone.

Details of Configuration Parameters:


Parameters	Permitted Values	Default
features.key_as_send	0, 1 or 2	1
Description: Configures the "#" or "*" key as the send key.		

Parameters	Permitted Values	Default
0-Disabled 1-# key 2-* key If it is set to 0 (Disabled), neither “#” nor “*” can be used as the send key. If it is set to 1 (# key), the pound key is used as the send key. If it is set to 2 (* key), the asterisk key is used as the send key. Web User Interface: Features->General Information->Key As Send Phone User Interface: Menu->Features->Key as send		
features.key_tone	0 or 1	1
Description: Enables or disables the IP phone to play a key tone when a user presses any key on your phone keypad. 0-Disabled 1-Enabled If it is set to 1 (Enabled), the IP phone will play a key tone when a user presses any key on your phone keypad. Web User Interface: Features->Audio->Key Tone Phone User Interface: Menu->Settings->Basic Settings->Sound->Key Tone		
features.send_key_tone	0 or 1	1
Description: Enables or disables the IP phone to play a key tone when a user presses a send key. 0-Disabled 1-Enabled If it is set to 1 (Enabled), the IP phone will play a key tone when a user presses a send key. Note: It works only if the value of the parameter “features.key_tone” is set to 1 (Enabled). Web User Interface: Features->Audio->Send Tone		

Parameters	Permitted Values	Default
Phone User Interface: None		
features.send_pound_key	0 or 1	0
Description: Enables or disables the IP phone not to send any pound key when pressing double #. 0-Disabled (Send one pound key by pressing double #) 1-Enabled (Do not send any pound key when pressing double #) Note: It works only if the value of the parameter "features.key_as_send" is set to 1 (Enabled). Web User Interface: Features->General Information->Send Pound Key Phone User Interface: None		

To configure a send key via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Key As Send**.



3. Click **Confirm** to accept the change.

To configure a send tone and key tone via web user interface:

1. Click on **Features->Audio**.
2. Select the desired value from the pull-down list of **Key Tone**.

3. Select the desired value from the pull-down list of **Send Tone**.

The screenshot shows the 'Audio Settings' page in the Yealink T23G web interface. The 'Send Tone' dropdown menu is highlighted with a red box, indicating it is the current selection. The 'Key Tone' dropdown is also highlighted. The 'NOTE' section on the right provides additional information about the 'Tone' feature and a link to guides.

4. Click **Confirm** to accept the change.

To configure send pound key via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Send Pound Key**.

The screenshot shows the 'General Information' page in the Yealink T23G web interface. The 'Send Pound Key' dropdown menu is highlighted with a red box, indicating it is the current selection. The 'NOTE' section on the right provides additional information about the 'Call Waiting' feature and a link to guides.

3. Click **Confirm** to accept the change.

To configure a send key via phone user interface:

1. Press **Menu->Features->Key as send**.
2. Press **◀** or **▶**, or the **Switch** soft key to select **#** or ***** from the **Key as send** field, or select **Disabled** to disable this feature.
3. Press the **Save** soft key to accept the change.

To configure a key tone via web user interface:

1. Press **Menu->Settings->Basic Settings->Sound->Key Tone**.
2. Press **◀** or **▶**, or the **Switch** soft key to select the desired value from the **Key**

Tone field.

- Press the **Save** soft key to accept the change.

Dial Plan

Regular expression, often called a pattern, is an expression that specifies a set of strings. A regular expression provides a concise and flexible means to "match" (specify and recognize) strings of text, such as particular characters, words, or patterns of characters. Regular expression is used by many text editors, utilities, and programming languages to search and manipulate text based on patterns.

Regular expression can be used to define IP phone dial plan. Dial plan is a string of characters that governs the way for IP phones to process the inputs received from the IP phone's keypads. IP phones support the following dial plan features:

- [Replace Rule](#)
- [Dial-now](#)
- [Area Code](#)
- [Block Out](#)

You need to know the following basic regular expression syntax when creating dial plan:

.	The dot "." can be used as a placeholder or multiple placeholders for any string. Example: "12." would match "123", "1234", "12345", "12abc", etc.
x	The "x" can be used as a placeholder for any character. Example: "12x" would match "121", "122", "123", "12a", etc.
-	The dash "-" can be used to match a range of characters within the brackets. Example: "[5-7]" would match the number "5", "6" or "7".
,	The comma "," can be used as a separator within the bracket. Example: "[2,5,8]" would match the number "2", "5" or "8".
[]	The square bracket "[]" can be used as a placeholder for a single character which matches any of a set of characters. Example: "91[5-7]1234" would match "9151234", "9161234", "9171234".
()	The parenthesis "(")" can be used to group together patterns, for instance, to logically combine two or more patterns. Example: "([1-9])([2-7])3" would match "923", "153", "673", etc.
\$	The "\$" followed by the sequence number of a parenthesis means

	<p>the characters placed in the parenthesis. The sequence number stands for the corresponding parenthesis. Example:</p> <p>A replace rule configuration, Prefix: "001(xxx)45(xx)", Replace: "9001\$145\$2". When you dial out "0012354599" on your phone, the IP phone will replace the number with "90012354599". "\$1" means 3 digits in the first parenthesis, that is, "235". "\$2" means 2 digits in the second parenthesis, that is, "99".</p>
--	--

Replace Rule

Replace rule is an alternative string that replaces the numbers entered by the user. IP phones support up to 100 replace rules, which can be created either one by one or in batch using a replace rule template. For more information on how to customize a replace rule template, refer to [Customizing Replace Rule Template File](#) on page 239.

Procedure

Replace rule can be created using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	<p>Create the replace rule for the IP phone.</p> <p>Parameters:</p> <p>dialplan.replace.prefix.X</p> <p>dialplan.replace.replace.X</p> <p>dialplan.replace.line_id.X</p>
Local	Web User Interface	<p>Create the replace rule for the IP phone.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet ?p=settings-dialplan&q=load</p> <p>For SIP VPT49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=settings-dialplan&q=load</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
dialplan.replace.prefix.X (X ranges from 1 to 100)	String within 32 characters	Blank
Description: Configures the entered number to be replaced. Example: dialplan.replace.prefix.1 = 1 Web User Interface: Settings->Dial Plan->Replace Rule->Prefix Phone User Interface: None		
dialplan.replace.replace.X (X ranges from 1 to 100)	String within 32 characters	Blank
Description: Configures the alternate number to replace the entered number. Example: dialplan.replace.prefix.1 = 1 and dialplan.replace.replace.1 = 254245 When you enter the number "1" and press the send key, the number "254245" will replace the entered number "1". Web User Interface: Settings->Dial Plan->Replace Rule->Replace Phone User Interface: None		
dialplan.replace.line_id.X (X ranges from 1 to 100)	Refer to the following content	Blank (for all lines)
Description: Configures the desired line to apply the replace rule. The digit 0 stands for all lines. If it is left blank, the replace rule will apply to all lines on the IP phone. Permitted Values: 0 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) 0 to 12 (for SIP-T42G) 0 to 6 (for SIP-T41P/T27P) 0 to 3 (for SIP-T40P/T23P/T23G) 0 to 2 (for SIP-T21(P) E2)		

Parameters	Permitted Values	Default
<p>Example:</p> <p>dialplan.replace.line_id.1 = 1,2</p> <p>Note: Multiple line IDs are separated by commas. It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>Settings->Dial Plan->Replace Rule->Account</p> <p>Phone User Interface:</p> <p>None</p>		

To create a replace rule via web user interface:

1. Click on **Settings->Dial Plan->Replace Rule**.
2. Enter the string in the **Prefix** field.
3. Enter the string in the **Replace** field.
4. Enter the desired line ID in the **Account** field or leave it blank.

If you leave this field blank or enter 0, the replace rule will apply to all accounts on the IP phone.

Yealink T236 Log Out

Status Account Network DSSKey Features **Settings** Directory Security

Preference
Time & Date
Call Display
Upgrade
Auto Provision
Configuration
Dial Plan
Voice
Ring
Tones
Softkey Layout
TR069
Voice Monitoring
SIP

Replace Rule Dial-now Area Code Block Out

Index	Prefix	Replace	Account
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			

Prefix: 1 Replace: 254245 Account: 1,2

Add Edit Del

NOTE

Replace Rule: An alternative string that replaces the entered numbers.
Dial-now: Automatically dial out the entered numbers.
Area Code: Automatically add the area code before the numbers when dialing.
Block Out: It prevents users from dialing out specific numbers.

"," represents any string.
"x" represents any character.
"-" match a range of characters within the brackets.
"|" a separator within the bracket.
"[]" a character matches any of character sets.
"()" combines two or more patterns.
"\$" followed by the sequence number of a parenthesis means the characters placed in the parenthesis.

You can click here to get more guides.

5. Click **Add** to add the replace rule.

Customizing Replace Rule Template File

The replace rule template helps with the creation of multiple replace rules.

You can ask the distributor or Yealink FAE for replace rule template. You can also obtain the replace rule template online:

<http://support.yealink.com/documentFront/forwardToDocumentFrontDisplayPage>. For more information on obtaining the replace rule template, refer to [Obtaining Configuration Files and Resource Files](#) on page 52.

When editing a replace rule template file, learn the following:

- <DialRule> indicates the start of the template file and </DialRule> indicates the end of the template file.
- When specifying the desired line(s) to apply the replace rule, the valid values are 0 and line ID. Multiple line IDs are separated by commas. It is not applicable to SIP-T19(P) E2 and CP860 IP phones.

The following table lists valid values of line ID for each phone model.

Phone Model	Values	Description
SIP VP-T49G/SIP-T48G/T46G/ T29G	0~16	0 stands for all lines 1~16 stand for line1~line16
SIP-T42G	0~12	0 stands for all lines 1~12 stand for line1~line12
SIP-T41P/T27P	0~6	0 stands for all lines 1~6 stand for line1~line6
SIP-T40P/T23P/T23G	0~3	0 stands for all lines 1~3 stand for line1~line3
SIP-T21(P) E2	0~2	0 stands for all lines 1~2 stand for line1~line2

- At most 100 replace rules can be added to the IP phone.

The expression syntax in the replace rule template is the same as that introduced in the section [Dial Plan](#) on page 236.

To customize a replace rule template:

1. Open the template file using an ASCII editor.
2. Create replace rules between <DialRule> and </DialRule>.

For example:


```
<Data Prefix="2512" Replace="05922512" LineID="1" />
```

Where:

Prefix="" specifies the numbers to be replaced.

Replace="" specifies the alternate string instead of what the user enters.

LineID="" specifies the desired line(s) for this rule. When you leave it blank or enter 0, this replace rule will apply to all lines.



If you want to change the replace rule, specify the values within double quotes.

3. Save the change and place this file to the provisioning server.
4. Specify the access URL of the replace rule template in the configuration files.

Procedure

Specify the access URL of the replace rule template using configuration files.

Configuration File	<y0000000000xx>.cfg	Specify the access URL of the replace rule template. Parameter: dialplan_replace_rule.url
--------------------	---------------------	--

Details of Configuration Parameters:

Parameters	Permitted Values	Default
dialplan_replace_rule.url	URL within 511 characters	Blank
Description: Configures the access URL of the replace rule template file. Example: dialplan_replace_rule.url = http://192.168.10.25/dialplan.xml During the auto provisioning process, the IP phone connects to the provisioning server "192.168.10.25", and downloads the replace rule file "dialplan.xml". Web User Interface: None		

Parameters	Permitted Values	Default
Phone User Interface:		
None		

Dial-now

Dial-now is a string used to match numbers entered by the user. When entered numbers match the predefined dial-now rule, the IP phone will automatically dial out the numbers without pressing the send key. IP phones support up to 100 dial-now rules, which can be created either one by one or in batch using a dial-now rule template. For more information on how to customize a dial-now template, refer to [Customizing Dial-now Template File](#) on page 246.

Delay Time for Dial-now Rule

The IP phone will automatically dial out the entered number, which matches the dial-now rule, after a specified period of time.

Procedure

Dial-now rule can be created using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Create the dial-now rule for the IP phone. Parameters: dialplan.dialnow.rule.X dialplan.dialnow.line_id.X
		Configure the delay time for the dial-now rule. Parameters: phone_setting.dialnow_delay

Local	Web User Interface	<p>Create the dial-now rule for the IP phone.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>http://<phoneIPAddress>/servlet ?p=settings-dialnow&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet ?m=mod_data&p=settings-dialplan&q=load&dial_page=dial-now</p>
		<p>Configure the delay time for the dial-now rule.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>http://<phoneIPAddress>/servlet ?p=features-general&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet ?m=mod_data&p=features-general&q=load</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
dialplan.dialnow.rule.X (X ranges from 1 to 100)	String within 511 characters	Blank
<p>Description:</p> <p>Configures the dial-now rule (the string used to match the numbers entered by the user).</p> <p>When entered numbers match the predefined dial-now rule, the IP phone will automatically dial out the numbers without pressing the send key.</p> <p>Example:</p>		

Parameters	Permitted Values	Default
<p>dialplan.dialnow.rule.1 = 123</p> <p>Web User Interface: Settings->Dial Plan->Dial-now->Rule</p> <p>Phone User Interface: None</p>		
<p>dialplan.dialnow.line_id.X (X ranges from 1 to 100)</p>	Refer to the following content	Blank (for all lines)
<p>Description: Configures the desired line to apply the dial-now rule. The digit 0 stands for all lines. If it is left blank, the dial-now rule will apply to all lines on the IP phone.</p> <p>Permitted Values: 0 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) 0 to 12 (for SIP-T42G) 0 to 6 (for SIP-T41P/T27P) 0 to 3 (for SIP-T40P/T23P/T23G) 0 to 2 (for SIP-T21(P) E2)</p> <p>Example: dialplan.dialnow.line_id.1 = 1,2</p> <p>Note: Multiple line IDs are separated by commas. It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface: Settings->Dial Plan->Dial-now->Account</p> <p>Phone User Interface: None</p>		
<p>phone_setting.dialnow_delay</p>	Integer from 0 to 14	1
<p>Description: Configures the delay time (in seconds) for the dial-now rule. When entered numbers match the predefined dial-now rule, the IP phone will automatically dial out the entered number after the designated delay time. If it is set to 0, the IP phone will automatically dial out the entered number immediately.</p> <p>Web User Interface: Features->General Information->Time-Out for Dial-Now Rule</p> <p>Phone User Interface:</p>		

Parameters	Permitted Values	Default
None		

To create a dial-now rule via web user interface:

1. Click on **Settings->Dial Plan->Dial-now**.
2. Enter the desired value in the **Rule** field.
3. Enter the desired line ID in the **Account** field or leave it blank.

If you leave this field blank or enter 0, the dial-now rule will apply to all accounts on the IP phone.

Yealink T236 Log Out

Status Account Network DSSKey Features **Settings** Directory Security

Preference
Time & Date
Call Display
Upgrade
Auto Provision
Configuration
Dial Plan
Voice
Ring
Tones
Softkey Layout
TR069
Voice Monitoring

Replace Rule **Dial-now** **Area Code** **Block Out**

Index	Dial-now Rule	Account	
1			<input type="checkbox"/>
2			<input type="checkbox"/>
3			<input type="checkbox"/>
4			<input type="checkbox"/>
5			<input type="checkbox"/>
6			<input type="checkbox"/>
7			<input type="checkbox"/>
8			<input type="checkbox"/>
9			<input type="checkbox"/>
10			<input type="checkbox"/>

Rule: 123 Account: 1,2

Add Edit Del

NOTE

Replace Rule: An alternative string that replaces the entered numbers.
Dial-now: Automatically dial out the entered numbers.
Area Code: Automatically add the area code before the numbers when dialing.
Block Out: It prevents users from dialing out specific numbers.

"," represents any string.
"x" represents any character.
"[]" match a range of characters within the brackets.
"|" a separator within the bracket.
"[]" a character matches any of character sets.
"()" combines two or more patterns.
"s" followed by the sequence number of a parenthesis means the characters placed in the parenthesis.

You can click here to get more guides.

4. Click **Add** to add the dial-now rule.

To configure the delay time for the dial-now rule via web user interface:

1. Click on **Features->General Information**.

- Enter the desired time within 0-14 (in seconds) in the **Time-Out for Dial-Now Rule** field.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected. On the left, a sidebar lists various features: Forward&DND, General Information, Audio, Intercom, Transfer, Call Pickup, Remote Control, Phone Lock, ACD, SMS, Action URL, Power LED, and Notification Popups. The 'General Information' section is active, displaying a list of settings. The 'Time-Out for Dial-Now Rule' field at the bottom is highlighted with a red rectangular box and contains the value '1'. Other settings include Call Waiting (Enabled), Auto Redial (Disabled), and various call codes and delays.

Setting	Value
Call Waiting	Enabled
Call Waiting On Code	
Call Waiting Off Code	
Auto Redial	Disabled
Auto Redial Interval (1~300s)	10
Auto Redial Times (1~300)	10
Key As Send	#
Reserve # in User Name	Enabled
Hotline Number	
Hotline Delay(0~10s)	4
Busy Tone Delay (Seconds)	0
Return Code When Refuse	486 (Busy Here)
Return Code When DND	480 (Temporarily Unavailable)
Call Completion	Disabled
Feature Key Synchronization	Disabled
Time-Out for Dial-Now Rule	1

- Click **Confirm** to accept the change.

Customizing Dial-now Template File

The dial-now template helps with the creation of multiple dial-now rules. After setup, place the dial-now template to the provisioning server and specify the access URL in the configuration files.

You can ask the distributor or Yealink FAE for dial-now template. You can also obtain the dial-now template online:

<http://support.yealink.com/documentFront/forwardToDocumentFrontDisplayPage>. For more information on obtaining the dial-now template, refer to [Obtaining Configuration Files and Resource Files](#) on page 52.

When editing a dial-now template, learn the following:

- <DialNow> indicates the start of a template and </DialNow> indicates the end of a template.
- When specifying the desired line(s) for the dial-now rule, the valid values are 0 and line ID. Multiple line IDs are separated by commas. It is not applicable to SIP-T19(P) E2 and CP860 IP phones.

The following table lists valid values of line ID for each phone model.

Phone Model	Values	Description
SIP VP-T49G/SIP-T48G/T46G/ T29G	0~16	0 stands for all lines 1~16 stand for line1~line16
SIP-T42G	0~12	0 stands for all lines 1~12 stand for line1~line12
SIP-T41P/T27P	0~6	0 stands for all lines 1~6 stand for line1~line6
SIP-T40P/T23P/T23G	0~3	0 stands for all lines 1~3 stand for line1~line3
SIPT21(P) E2	0~2	0 stands for all lines 1~2 stand for line1~line2

- At most 100 rules can be added to the IP phone.

The expression syntax in the dial-now rule template is the same as that introduced in the section [Dial Plan](#) on page 236.

To customize a dial-now template:

- Open the template file using an ASCII editor.
- Create dial-now rules between <DialNow> and </DialNow>.


For example:

```
<Data DialNowRule="1001" LineID="0" />
```

Where:

DialNowRule="" specifies the dial-now rule.

LineID="" specifies the desired line(s) for this rule. When you leave it blank or enter 0, this dial-now rule will apply to all lines.



If you want to change the dial-now rule, specify the values within double quotes.

- Save the change and place this file to the provisioning server.
- Specify the access URL of the dial-now template.

Procedure

Specify the access URL of the dial-now template using configuration files.

Configuration File	<y0000000000xx>.cfg	Configure the access URL of the dial-now template. Parameter: dialplan_dialnow.url
---------------------------	---------------------	---

Details of Configuration Parameters:

Parameters	Permitted Values	Default
dialplan_dialnow.url	URL within 511 characters	Blank
Description: Configures the access URL of the dial-now rule template file. Example: dialplan_dialnow.url = http://192.168.10.25/dialnow.xml During the auto provisioning process, the IP phone connects to the provisioning server "192.168.10.25", and downloads the dial-now rule file "dialnow.xml". Web User Interface: None Phone User Interface: None		

Area Code

Area codes are also known as Numbering Plan Areas (NPAs). They usually indicate geographical areas in one country. When entered numbers match the predefined area code rule, the IP phone will automatically add the area code before the numbers when dialing out them. IP phones only support one area code rule.

Procedure

Area code rule can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Create the area code rule and specify the maximum and minimum lengths of entered numbers. Parameters: dialplan.area_code.code
---------------------------	---------------------	--

		dialplan.area_code.min_len dialplan.area_code.max_len dialplan.area_code.line_id
Local	Web User Interface	<p>Create the area code rule and specify the maximum and minimum lengths of entered numbers.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>http://<phoneIPAddress>/servlet ?p=settings-areacode&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet ?m=mod_data&p=settings-dialp lan&q=load&dial_page=area-c ode</p>

Details of Configuration Parameters:


Parameters	Permitted Values	Default
dialplan.area_code.code	String within 16 characters	Blank
<p>Description:</p> <p>Configures the area code to be added before the entered numbers when dialing out.</p> <p>Example:</p> <p>dialplan.area_code.code = 0592</p> <p>Note: The length of the entered number must be between the minimum length configured by the parameter "dialplan.area_code.min_len" and the maximum length configured by the parameter "dialplan.area_code.max_len".</p> <p>Web User Interface:</p> <p>Settings->Dial Plan->Area Code->Code</p> <p>Phone User Interface:</p> <p>None</p>		
dialplan.area_code.min_len	Integer from 1 to 15	1

Parameters	Permitted Values	Default
Description: Configures the minimum length of the entered numbers. Web User Interface: Settings->Dial Plan->Area Code->Min Length (1-15) Phone User Interface: None		
dialplan.area_code.max_len	Integer from 1 to 15	15
Description: Configures the maximum length of the entered numbers. Note: The value must be larger than the minimum length. Web User Interface: Settings->Dial Plan->Area Code->Max Length (1-15) Phone User Interface: None		
dialplan.area_code.line_id	Refer to the following content	Blank (for all lines)
Description: Configures the desired line to apply the area code rule. The digit 0 stands for all lines. If it is left blank, the area code rule will apply to all lines on the IP phone. Permitted Values: 0 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) 0 to 12 (for SIP-T42G) 0 to 6 (for SIP-T41P/T27P) 0 to 3 (for SIP-T40P/T23P/T23G) 0 to 2 (for SIP-T21(P) E2) Example: dialplan.area_code.line_id = 1 Note: Multiple line IDs are separated by commas. It is not applicable to SIP-T19(P) E2 and CP860 IP phones. Web User Interface: Settings->Dial Plan->Area Code->Account Phone User Interface: None		

To configure an area code rule via web user interface:

- 1. Click on **Settings->Dial Plan->Area Code**.
- 2. Enter the desired values in the **Code**, **Min Length (1-15)** and **Max Length (1-15)** fields.
- 3. Enter the desired line ID in the **Account** field or leave it blank.

If you leave this field blank or enter 0, the area code rule will apply to all accounts on the IP phone.



- 4. Click **Confirm** to accept the change.

Block Out

Block out rule prevents users from dialing out specific numbers. When entered numbers match the predefined block out rule, the LCD screen prompts “Forbidden Number”. IP phones support up to 10 block out rules.

Procedure

Block out rule can be created using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Create the block out rule for the IP phone. Parameters: dialplan.block_out.number.X dialplan.block_out.line_id.X
Local	Web User Interface	Create the block out rule for the IP phone. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet

		<p>?p=settings-blackout&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet</p> <p>?m=mod_data&p=settings-dialplan&q=load&dial_page=block-out</p>
--	--	---

Details of Configuration Parameters:

Parameters	Permitted Values	Default
dialplan.block_out.number.X (X ranges from 1 to 10)	String within 32 characters	Blank
<p>Description:</p> <p>Configures the block out numbers.</p> <p>Example:</p> <p>dialplan.block_out.number.1 = 4321</p> <p>When you dial the number "4321" on your phone, the dialing will fail and the LCD screen will prompt "Forbidden Number".</p> <p>Web User Interface:</p> <p>Settings->Dial Plan->Block Out->BlockOut NumberX</p> <p>Phone User Interface:</p> <p>None</p>		
dialplan.block_out.line_id.X (X ranges from 1 to 10)	Refer to the following content	Blank (for all lines)
<p>Description:</p> <p>Configures the desired line to apply the block out rule. The digit 0 stands for all lines. If it is left blank, the block out rule will apply to all lines on the IP phone.</p> <p>Permitted Values:</p> <p>0 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>0 to 12 (for SIP-T42G)</p> <p>0 to 6 (for SIP-T41P/T27P)</p> <p>0 to 3 (for SIP-T40P/T23P/T23G)</p> <p>0 to 2 (for SIP-T21(P) E2)</p> <p>Example:</p> <p>dialplan.block_out.line_id.1 = 1,2,3</p> <p>Note: Multiple line IDs are separated by commas. It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p>		

Parameters	Permitted Values	Default
Settings->Dial Plan->Block Out->Account		
Phone User Interface:		
None		

To create a block out rule via web user interface:

1. Click on **Settings->Dial Plan->Block Out**.
2. Enter the desired value in the **BlockOut NumberX** field.
3. Enter the desired line ID in the **Account** field or leave it blank.

If you leave this field blank or enter 0, the block out rule will apply to all accounts on the IP phone.

4. Click **Confirm** to add the block out rule.

Hotline

Hotline is a point-to-point communication link in which a call is automatically directed to the preset hotline number. The IP phone automatically dials out the hotline number using the first available line after a specified time interval when off-hook. IP phones only support one hotline number.

Procedure

Hotline can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the hotline number. Parameter: features.hotline_number
---------------------------	---------------------	---

		<p>Specify the time (in seconds) the IP phone waits before automatically dialing out the hotline number.</p> <p>Parameter: features.hotline_delay</p>
Local	Web User Interface	<p>Configure the hotline number.</p> <p>Specify the time (in seconds) the IP phone waits before automatically dial out the hotline number.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>http://<phoneIPAddress>/servlet?p=features-general&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load</p>
	Phone User Interface	<p>Configure the hotline number.</p> <p>Specify the time (in seconds) the IP phone waits before automatically dialing out the hotline number.</p>

Details of Configuration Parameters:

Parameter	Permitted Values	Default
features.hotline_number	String within 32 characters	Blank
<p>Description:</p> <p>Configures the hotline number that the IP phone automatically dials out when you lift the handset, press the Speakerphone/off-hook key or the line key.</p> <p>Leaving it blank disables hotline feature.</p> <p>Example:</p> <p>features.hotline_number = 1234</p>		

Parameter	Permitted Values	Default
<p>Note: Line key is not applicable to SIP-T19(P) E2 and CP860 IP phones; handset and Speakerphone key are not applicable to CP860 IP phones; off-hook key is only applicable to CP860 IP phones.</p> <p>Web User Interface: Features->General Information->Hotline Number</p> <p>Phone User Interface: Menu->Features->Hot Line->Hot Number</p>		
features.hotline_delay	Integer from 0 to 10	4
<p>Description: Configures the waiting time (in seconds) for the IP phone to automatically dial out the hotline number.</p> <p>If it is set to 0 (0s), the IP phone will immediately dial out the preconfigured hotline number when you lift the handset, press the Speakerphone/off-hook key or press the line key.</p> <p>If it is set to a value greater than 0, the IP phone will wait the designated seconds before dialing out the predefined hotline number when you lift the handset, press the Speakerphone/off-hook key or press the line key.</p> <p>Note: Line key is not applicable to SIP-T19(P) E2 and CP860 IP phones; handset and Speakerphone key are not applicable to CP860 IP phones; off-hook key is only applicable to CP860 IP phones.</p> <p>Web User Interface: Features->General Information->Hotline Delay(0~10s)</p> <p>Phone User Interface: Menu->Features->Hot Line->Hotline Delay</p>		

To configure hotline via web user interface:

1. Click on **Features->General Information**.
2. Enter the hotline number in the **Hotline Number** field.

- Enter the delay time in the **Hotline Delay(0~10s)** field.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected. Under 'General Information', the 'Hotline Delay(0~10s)' field is highlighted with a red box and contains the value '4'. Other fields in the same section include 'Hotline Number' (1234), 'Call Waiting' (Enabled), 'Auto Redial' (Disabled), 'Auto Redial Interval (1~300s)' (10), 'Auto Redial Times (1~300)' (10), 'Key As Send' (#), 'Reserve # in User Name' (Enabled), 'Busy Tone Delay (Seconds)' (0), 'Return Code When Refuse' (486 (Busy Here)), 'Return Code When DND' (480 (Temporarily Unavailable)), 'Call Completion' (Disabled), 'Feature Key Synchronization' (Disabled), and 'Time-Out for Dial-Now Rule' (1). A 'NOTE' section on the right provides details about various features like Call Waiting, Auto Redial, Key As Send, Hotline, and Call Completion.

- Click **Confirm** to accept the change.

To configure hotline via phone user interface:

- Press **Menu->Features->Hot Line**.
- Enter the hotline number in the **Hot Number** field.
- Enter the waiting time (in seconds) in the **Hotline Delay** field.
- Press the **Save** soft key to accept the change.

Off Hook Hot Line Dialing

For security reasons, IP phones support off hook hot line dialing feature, which allows the phone to first dial out the pre-configured number when the user lifts the handset, presses the Speakerphone key/off-hook key or desired line key, dials out a call using the account with this feature enabled. The SIP server may then prompt the user to enter an activation code for call service. Only if the user enters a valid activation code, the IP phone will use this account to dial out a call successfully.

Off hook hot line dialing feature is configurable on a per-line basis and depends on support from a SIP server.

Note

Off hook hot line dialing feature limits the call-out permission of this account and disables the hotline feature. For example, when the phone goes off hook using the account with this feature enabled, the configured hotline number will not be dialed out automatically.

The server actions may vary from different servers.

It is also applicable to the IP call and intercom call.

Procedure

Off hook hot line dialing can be configured using the configuration files.

Configuration File	<y000000000xx>.cfg	Configure off hook hot line dialing feature. Parameter: account.X.auto_dial_enable
		Specify the number that the phone first dials out. Parameter: account.X.auto_dial_num

Details of Configuration Parameters:

Parameter	Permitted Values	Default
account.X.auto_dial_enable	0 or 1	0
<p>Description:</p> <p>Enables or disables the IP phone to first dial out a pre-configured number when a user lifts the handset, presses the Speakerphone/off-hook key or desired line key or dials out a call using account X.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 1 (Enabled), the phone will first dial out the pre-configured number (configured by the parameter "account.X.auto_dial_num") when a user lifts the handset, presses the Speakerphone/off-hook key or desired line key, dials out a call using account X.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIPT42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIPT40P/T23P/T23G) X ranges from 1 to 2 (for SIPT21(P) E2) X is equal to 1 (for SIPT19(P) E2/CP860)</p> <p>Note: Line key is not applicable to SIP-T19(P) E2 and CP860 IP phones; handset and Speakerphone key are not applicable to CP860 IP phones; off-hook key is only applicable to CP860 IP phones.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p>		

Parameter	Permitted Values	Default
None		
account.X.auto_dial_num	String within 32 characters	Blank
<p>Description:</p> <p>Configures the number that the IP phone first dials out when a user lifts the handset, presses the Speakerphone/off-hook key or desired line key, dials out a call using account X.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIPT42G)</p> <p>X ranges from 1 to 6 (for SIPT41P/T27P)</p> <p>X ranges from 1 to 3 (for SIPT40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Note: It works only if the value of the parameter "account.X.auto_dial_enable" is set to 1 (Enabled). Line key is not applicable to SIP-T19(P) E2 and CP860 IP phones; handset and Speakerphone key are not applicable to CP860 IP phones; off-hook key is only applicable to CP860 IP phones.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		

Directory

Directory provides easy access to frequently used lists. Users can access lists by pressing the **Dir** soft key when the IP phone is idle. The lists can be Local Directory, History, Remote Phone Book and LDAP. The desired lists can be added to Directory using a directory file (favorite_setting.xml). Directory file is not applicable to SIP VPT49G IP phones.

Customizing a Directory Template File

You can ask the distributor or Yealink FAE for directory template. You can also obtain the directory template online:

<http://support.yealink.com/documentFront/forwardToDocumentFrontDisplayPage>. For more information on obtaining the directory template, refer to [Obtaining Configuration Files and Resource Files](#) on page 52.

The following table lists meaning of each variable in the directory template file:

Element	Attribute	Values	Description
root_favorite_set	No	No	File root element
item	id_name	localdirectory history networkcallog remotedirectory ldap networkdirectory	The existing directory list (For example, "localdirectory" for the local directory list). Note: Do not edit this field.
		Local Directory History Network CallLog Remote Phone Book LDAP Network Directories	The display name of the directory list. Note: We recommend you do not edit this field.
		1, 2, 3, 4, 5 and 6. 1 is the highest priority, 6 is the lowest.	The display priority of the directory list.
		0/1, 0: Disabled 1: Enabled.	Directory list whether to display on the IP phone LCD screen.

Customizing a directory template:

1. Open the template file using an ASCII editor.
2. For each directory list that you want to configure, edit the corresponding string in the file. For example, configure the local directory list, edit the values within double quotes in the following strings:

```
<item id_name="localdirectory" display_name="Local Directory" priority="1"
enable="1"/>
```

```
favorite_setting.xml x
1 <root_favorite_set>
2   <item id_name="localdirectory" display_name="Local Directory" priority="1" enable="1" />
3   <item id_name="history" display_name="History" priority="2" enable="0" />
4   <item id_name="remotedirectory" display_name="Remote Phone Book" priority="3" enable="0" />
5   <item id_name="ldap" display_name="LDAP" priority="4" enable="0" />
6   <!--T19 doesn't support LDAP feature-->
7 </root_favorite_set>
```

3. Save the change and place this file to the provisioning server (e.g., 192.168.1.20).
4. Specify the access URL of the custom directory template file in the configuration files (e.g., directory_setting.url = http://192.168.1.20/favorite_setting.xml).

Procedure



Directory can be configured using the configuration files or locally.



Configuration File	<y0000000000xx>.cfg	Specify the access URL of the directory template file. Parameter: directory_setting.url
Local	Web User Interface	Configure the Directory. Navigate to: http://<phoneIPAddress>/servlet ?p=contacts-favorite&q=load


Details of the Configuration Parameter:

Parameter	Permitted Values	Default
directory_setting.url	URL within 511 characters	Blank
<p>Description: Configures the access URL of the directory template file.</p> <p>Example: directory_setting.url = http://192.168.1.20/favorite_setting.xml</p> <p>During the auto provisioning process, the IP phone connects to the provisioning server "192.168.1.20", and downloads the directory file "favorite_setting.xml".</p> <p>Note: It is not applicable to SIP VP-T49G IP phones.</p> <p>Web User Interface: Directory->Setting->Directory</p> <p>Phone User Interface: None</p>		

To configure the directory via web user interface:

1. Click on **Directory->Setting**.
2. In the **Directory** block, select the desired list from the **Disabled** column and then click  .
The selected list appears in the **Enabled** column.
3. Repeat the step 2 to add more lists to the **Enabled** column.
4. To remove a list from the **Enabled** column, select the desired list and then click  .

5. To adjust the display order of list, select the desired list and then click  or .



6. Click **Confirm** to accept the change.

The IP phone LCD screen will display the enabled list(s) in the adjusted order.

Search Source in Dialing

Search source list in dialing allows the IP phone to automatically search entries from the search source list based on the entered string, and display results on the dialing screen. The user can select the desired entry to dial out quickly. The search source list can be Local Directory, History, Remote Phone Book and LDAP. The search source list can be configured using a supplied super search template file (super_search.xml).

Customizing a Super Search Template File

You can ask the distributor or Yealink FAE for super search template. You can also obtain the super search template online:

<http://support.yealink.com/documentFront/forwardToDocumentFrontDisplayPage>. For more information on obtaining the super search template, refer to [Obtaining Configuration Files and Resource Files](#) on page 52.

The following table lists meaning of each variable in the super search template file:

Element	Attribute	Values	Description
root_super_search	No	No	File root element
Item	id_name	local_directory_search calllog_search remote_directory_search ldap_search Network_directory_search	The directory list (For example, "local_directory_search" for the local directory list). Note: Do not edit this field.
	display_name	Local Contacts History	The display name of the directory list.

Element	Attribute	Values	Description
		Remote Phone Book LDAP Network Directories	Note: We recommend you do not edit this field.
	Priority	1, 2, 3, 4 and 5. 1 is the highest priority, 5 is the lowest.	The priority of the search results.
	Enable	0/1, 0: Disabled 1: Enabled	Enable or disable the IP phone to search the desired directory list.

Customizing a super search template:

1. Open the template file using an ASCII editor.
2. For each directory list that you want to configure, edit the corresponding string in the file. For example, configure the local directory list, edit the values within double quotes in the following strings:

```
<item id_name="local_directory_search" display_name="Local Contacts"
priority="1" enable="1"/>
```

```

1 <root_super_search>
2   <item id_name="local_directory_search" display_name="Local Contacts" priority="1" enable="1" />
3   <item id_name="calllog_search" display_name="History" priority="2" enable="1" />
4   <item id_name="remote_directory_search" display_name="Remote Phone book" priority="3" enable="0" />
5   <item id_name="ldap_search" display_name="LDAP" priority="4" enable="0" />
6 </root_super_search>
7

```

3. Save the change and place this file to the provisioning server (e.g., 192.168.1.20).
4. Specify the access URL of the custom super search template file in the configuration files (e.g., super_search.url = http://192.168.1.20/super_search.xml).

Procedure

Search source list in dialing can be configured using the configuration files or locally.





Configuration File	<y0000000000xx>.cfg	Specify the access URL of the super search template file. Parameter: super_search.url
Local	Web User Interface	Configure the search source list in dialing. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:

		http://<phoneIPAddress>/servlet ?p=contacts-favorite&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=contacts-favo rite&q=load
--	--	---


Details of the Configuration Parameter:

Parameter	Permitted Values	Default
super_search.url	URL within 511 characters	Blank
<p>Description: Configures the access URL of the super search template file.</p> <p>Example: super_search.url = http://192.168.1.20/super_search.xml</p> <p>During the auto provisioning process, the IP phone connects to the provisioning server "192.168.1.20", and downloads the super search template file "super_search.xml".</p> <p>Web User Interface: Directory->Setting->Search Source List In Dialing</p> <p>Phone User Interface: None</p>		

To configure search source list in dialing via web user interface:

1. Click on **Directory->Setting**.
2. In the **Search Source List In Dialing** block, select the desired list from the **Disabled** column and then click  .
The selected list appears in the **Enabled** column.
3. Repeat the step 2 to add more lists to the **Enabled** column.
4. To remove a list from the **Enabled** column, select the desired list and then click  .
5. To adjust the display order of search results, select the desired list and then click  or  .

The LCD screen displays the search results in the adjusted order.



- Click **Confirm** to accept the change.

Save Call Log

Call log contains call information such as remote party identification, time and date, and call duration. It can be used to redial previous outgoing calls, return incoming calls, and save contact information from call log lists to the contact directory.

IP phones maintain a local call log. Call log consists of four lists: Missed Calls, Placed Calls, Received Calls, and Forwarded Calls. Each call log list supports up to 100 entries. To store call information, you must enable save call log feature in advance. You can access the call history information via web user interface: **Directory->Phone Call Info**.

Procedure

Call log can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure call log feature. Parameter: features.save_call_history
Local	Web User Interface	Configure call log feature. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:

		<a href="http://<phoneIPAddress>/servlet?p=features-general&q=load">http://<phoneIPAddress>/servlet?p=features-general&q=load For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?p=m=mod_data&p=features-general&q=load">http://<phoneIPAddress>/servlet?p=m=mod_data&p=features-general&q=load
	Phone User Interface	Configure call log feature.

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
features.save_call_history	0 or 1	1
Description: Enables or disables the IP phone to save the call log. 0-Disabled 1-Enabled If it is set to 0 (Disabled), the IP phone cannot log the missed calls, placed calls, received calls and the forwarded calls in the call log lists. Web User Interface: Features->General Information->Save Call Log Phone User Interface: Menu->Features->History Setting		

To configure call log feature via web user interface:

1. Click on **Features->General Information**.

- Select the desired value from the pull-down list of **Save Call Log**.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected. Under 'General Information', the 'Save Call Log' option is highlighted with a red box. The dropdown menu for 'Save Call Log' is set to 'Enabled'. Other options include 'Call Waiting' (Enabled), 'Auto Redial' (Disabled), 'Auto Redial Interval' (10), 'Auto Redial Times' (10), and 'Key As Send' (#). A 'NOTE' section on the right provides additional information about call waiting and key settings.

- Click **Confirm** to accept the change.

To configure call log feature via phone user interface:

- Press **Menu->Features->History Setting**.
- Press **◀** or **▶**, or the **Switch** soft key to select the desired value from the **History Record** field.
- Press the **Save** soft key to accept the change.

Call List Show Number

Call list show number allows the IP phone to show the phone number instead of the name in the call log list. To use this feature, make sure the save call log feature is enabled. For more information on save call log, refer to [Save Call Log](#) on page 264.

Procedure

Call list show number can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure call list show number. Parameter: features.call_log_show_num
Local	Web User Interface	Configure call list show number. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T2

		9G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet ?p=features-general&q=load For SIP VPT49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=features-gene ral&q=load
--	--	---

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
features.call_log_show_num	0 or 1	0
<p>Description:</p> <p>Enables or disables the IP phone to show the other party's phone number instead of the name in the call log lists.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 0 (Disabled), the IP phone will show the other party's name in the call log lists.</p> <p>If it is set to 1 (Enabled), the IP phone will show the other party's phone number in the call log lists.</p> <p>Note: It works only if the value of the parameter "features.save_call_history" is set to 1 (Enabled).</p> <p>Web User Interface:</p> <p>Features->General Information->Call List Show Number</p> <p>Phone User Interface:</p> <p>None</p>		

To configure call list show number via web user interface:

1. Click on **Features->General Information**.

2. Select the desired value from the pull-down list of **Call List Show Number**.

3. Click **Confirm** to accept the change.

Missed Call Log

Missed call log allows the IP phone to display the number of missed calls with an indicator icon on the idle screen, and to log missed calls in the Missed Calls list when the IP phone misses calls. It is configurable on a per-line basis. Once the user accesses the Missed Calls list, the prompt message and indicator icon on the idle screen disappear.

Procedure

Missed call log can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure missed call log feature. Parameter: account.X.missed_callog
Local	Web User Interface	Configure missed call log feature. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet? p=account-basic&q=load&acc=0 For SIP VP-T49G:

		http://<phoneIPAddress>/servlet ?m=mod_data&p=account-basic &q=load&acc=0
--	--	---

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
account.X.missed_callog	0 or 1	1
<p>Description: Enables or disables the IP phone to indicate and record missed calls for account X.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 0 (Disabled), the IP phone does not display indicator on the idle screen and log the missed call in the Missed Calls list when missed calls.</p> <p>If it is set to 1 (Enabled), the IP phone displays a message on the idle screen and logs the missed call in the Missed Calls list when missed calls.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Note: It works only if the value of the parameter "features.save_call_history" is set to 1 (Enabled).</p> <p>Web User Interface: Account->Basic->Missed Call Log</p> <p>Phone User Interface: None</p>		

To configure missed call log via web user interface:

1. Click on **Account->Basic**.
2. Select the desired account from the pull-down list of **Account**.

3. Select the desired value from the pull-down list of **Missed Call Log**.

The screenshot shows the Yealink T236 web interface. The 'Account' tab is selected. The 'Missed Call Log' option is highlighted with a red box, showing it is set to 'Enabled'. Other settings include Proxy Require, Local Anonymous, Local Anonymous Rejection, Send Anonymous Code, On Code, Off Code, Send Anonymous Rejection Code, Auto Answer, and Ring Type. A 'NOTE' section on the right explains 'Anonymous Call' and 'Anonymous Call Rejection'.

4. Click Confirm to accept the change.

Local Directory

IP phones maintain a local directory. The local directory can store up to 1000 contacts and 48 groups. When adding a contact to the local directory, in addition to name and phone numbers, you can also specify the account, ring tone and group for the contact. Contacts and groups can be added either one by one or in batch using a local contact file. Yealink IP phones support both *.xml and *.csv format contact files, but only support *.xml format download for local contact file.

Customizing a Local Contact File

You can add contacts one by one on the IP phone directly. You can also add multiple contacts at a time and/or share contacts between IP phones using the local contact template file. After setup, place the template file to the provisioning server and specify the access URL of the template file in the configuration files. The existing local contacts on the IP phones will be overridden by the downloaded local contacts.

You can ask the distributor or Yealink FAE for local contact template. You can also obtain the local contact template online:

<http://support.yealink.com/documentFront/forwardToDocumentFrontDisplayPage>. For more information on obtaining the local contact file, refer to [Obtaining Configuration Files and Resource Files](#) on page 52.

The following table lists meaning of each variable in the local contact template file:

Element	Values	Description
root_group	no	Group list's root element.

Element	Values	Description
group	no	Group's root element.
display_name	All Contacts Blacklist	An element of group. Group name.
ring	Format of the value: System ring tone: Auto Resource:Silent.wav Resource:Splash.wav Resource:RingN.wav (integer N ranges from 1 to 8) Custom ring tone: Custom:Name.wav	An element of group. Group ring tone.
root_contact	no	Contact list's root element.
contact	no	Contact's root element.
display_name	String	An element of contact. Contact name. Note: This value cannot be blank or duplicated.
office_number	String	Office number of the contact.
mobile_number	String	Mobile number of the contact.
other_number	String	Other number of the contact.
line	-1~15; Multiple line IDs are separated by commas.	The desired line you want to add the contact to. Note: This is not applicable to SIP-T19(P) E2 and CP860 IP phones.
ring	Format of the value: System ring tone: Auto Resource:Silent.wav Resource:Splash.wav Resource:RingN.wav (integer N ranges from 1 to 8) Custom ring tone: Custom:Name.wav	An element of contact. Contact ring tone.
group_id_name	Valid Value: built-in: All Contacts, Blacklist custom:	Group name of a contact.

Element	Values	Description
	XXX (e.g., Friend)	
default_photo	Format of the value: Resource: avatar name (the built-in avatar) Config: avatar name (the custom avatar)	Contact avatar. Note: It is only applicable to SIP VP-T49G, SIP-T48G, SIP-T46G and SIP-T29G IP phones.

The following table lists valid values of line for each phone model.

Phone Model	Values	Description
SIP VP-T49G/SIP-T48G/T46G/T29G	-1~15	-1 stands for Auto (the first registered line) 0~15 stand for line1~line16
SIP-T42G	-1~11	-1 stands for Auto (the first registered line) 0~11 stand for line1~line12
SIP-T41P/T27P	-1~5	-1 stands for Auto (the first registered line) 0~5 stand for line1~line6
SIP-T40P/T23P/T23G	-1~2	-1 stands for Auto (the first registered line) 0~2 stand for line1~line3
SIP-T21(P) E2	-1~1	-1 stands for Auto (the first registered line) 0~1 stand for line1~line2

The contact avatar format must meet the following:

Phone Model	Format	Resolution	Single File Size	Total File Size
SIP VP-T49G	.jpg/.png/.bmp	<=138*138	<=2MB	<=20MB
SIP-T48G	.jpg/.png/.bmp	<=104*104	<=5MB	<=20MB
SIP-T46G/T29G	.jpg/.png/.bmp	<=110*110	<=5MB	<=20MB

The contact icon format must meet the following:

Phone Model	Format	Resolution
SIP VP-T49G	.jpg/.png/.bmp	<=58*58
SIP-T48G	.jpg/.png/.bmp	<=41*41

Customizing a Local Contact File (Black-and-white Screen Phones)

The following shows the procedure of customizing a local contact file for SIP-T42G/T41P/T40P/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860 IP phones:

To customize a local contact file:

1. Open the template file using an ASCII editor.
2. For each group that you want to add, add the following string to the file. Each starts on a separate line:

```
<group display_name="" ring="" />
```

3. For each contact that you want to add, add the following string to the file. Each starts on a separate line:


```
<contact display_name="" office_number="" mobile_number="" other_number=""
line="" ring="" group_id_name="" />
```

4. Specify the values within double quotes.

For example:

```
<group display_name="Friend" ring="Resource:Splash.wav"/>
```

```
<contact display_name="Lily" office_number="1020" mobile_number="1021"
other_number="1112" line="1,2" ring="Resource:Ring1.wav"
group_id_name="Friend"/>
```



5. Save the change and place this file to the provisioning server.
6. Specify the access URL of the custom local contact template in the configuration files.

For example:

```
local_contact.data.url = tftp://192.168.10.25/contact.xml
```

During the auto provisioning process, the IP phone connects to the provisioning server "192.168.10.25", and downloads the contact file "contact.xml".

Customizing a Local Contact File (Color Screen Phones)

The following shows the procedure of customizing a local contact file for SIP VPT49G/SIP-T48G/T46G/T29G IP phones:

Scenario A - Using the Built-in Avatar for Contact

This scenario is applicable to SIP VPT49G/SIP-T48G/T46G/T29G IP phones.

To customize a local contact file:

1. Open the template file using an ASCII editor.

- For each group that you want to add, add the following string to the file. Each starts on a separate line:

```
<group display_name="" ring="" />
```

- For each contact that you want to add, add the following string to the file. Each starts on a separate line:


```
<contact display_name="" office_number="" mobile_number="" other_number=""
line="" ring="" group_id_name="" default_photo="" />
```

- Specify the values within double quotes.

For example:

```
<group display_name="Friend" ring="Resource:Splash.wav" />
```

```
<contact display_name="Lily" office_number="1020" mobile_number="1021"
other_number="1112" line="1,2" ring="Resource:Ring1.wav"
group_id_name="Friend" default_photo="Resource:icon_family_b.png" />
```



- Save the change and place this file to the provisioning server.
- Specify the access URL of the custom local contact template in the configuration files.

For example:

```
local_contact.data.url = tftp://192.168.10.25/contact.xml
```

During the auto provisioning process, the IP phone connects to the provisioning server "192.168.10.25", and downloads the contact file "contact.xml".

Scenario B - Using the Custom Avatar for Contact

This scenario is applicable to SIP VP-T49G/SIP-T48G/T46G/T29G IP phones.


To specify custom avatars for contacts, you need to upload the custom avatars to the provisioning server in advance. In addition, you can also compress all the avatars as a tar formatted file, and then upload the tar formatted file to the provisioning server.

Preparing the Tar Formatted File

You can package the tar formatted file using the tool 7-Zip or GnuWin32. You can download 7-Zip online: <http://www.7-zip.org/> and GnuWin32 online: <http://gnuwin32.sourceforge.net/packages/gtar.htm>. This section provides you on how to package the tar file using 7-Zip.


To package a tar formatted file using the tool 7-Zip on the Windows platform:

1. Download and install 7-Zip on the local system.
2. Create a folder (e.g., photo) on the local system (e.g., C:\Program Files) and place the file that will be compressed (e.g., cutom1.jpg, cutom2.png) to this folder.
3. Start the 7-Zip file manager application (7zFM.exe).
4. Locate the photo folder from the local system (C:\Program Files\photo\).



5. Select the desired photos that will be compressed.
6. Click the **Add** button.

7. Select **tar** from the pull-down list of **Archive format**.



8. Click the **OK** button.
A photo.tar file is generated in the directory C:\Program Files\photo.
9. Place this file to the provisioning server (e.g., 192.168.10.25).

Customizing a Local Contact File


To customize a local contact file:

1. Open the template file using an ASCII editor.
2. For each group that you want to add, add the following string to the file. Each starts on a separate line:
`<group display_name="" ring=""/>`
3. For each contact that you want to add, add the following string to the file. Each starts on a separate line:
`<contact display_name="" office_number="" mobile_number="" other_number="" line="" ring="" group_id_name="" default_photo=""/>`
4. Specify the values within double quotes.
For example:
`<group display_name="Friend" ring="Resource: Splash.wav"/>`
`<contact display_name="Lily" office_number="1020" mobile_number="1021"`


```

other_number="1112" line="1,2" ring="Resource:Ring1.wav"
group_id_name="Friend" default_photo="Config:cutom1.jpg"/>
<contact display_name="Tom" office_number="2020" mobile_number="2021"
other_number="2112" line="2" ring="Resource:Ring1.wav"
group_id_name="Friend" default_photo="Config:cutom2.png"/>

```



5. Save the change and place this file to the provisioning server.
6. Specify the access URL of the custom local contact template in the configuration files.

There are three methods to specify custom avatar for contacts:

Method 1:

```
local_contact.data.url = tftp://192.168.10.25/contact.xml
```

```
local_contact.photo.url = tftp://192.168.10.25/cutom1.jpg
```

```
local_contact.photo.url = tftp://192.168.10.25/cutom2.png
```

During the auto provisioning process, the IP phone connects to the provisioning server "192.168.10.25", and downloads the contact file "contact.xml" and avatar pictures ("cutom1.jpg" and "cutom2.png").

Method 2:

```
local_contact.data.url = tftp://192.168.10.25/contact.xml
```

```
local_contact.image.url = tftp://192.168.10.25/photo.tar
```

For more information on generating a contact avatar file "photo.tar", refer to [Preparing the Tar Formatted File](#) on page 274.

During the auto provisioning process, the IP phone connects to the provisioning server "192.168.10.25", and downloads the contact file "contact.xml" and avatar file "photo.tar".

Method 3:

If the local contact file (contact.xml) and custom avatars (photo.tar) are compressed as a tar formatted file (e.g., Contact.tar), you can only configure the following parameter to upload contacts and avatars:

```
local_contact.data_photo_tar.url = tftp://192.168.10.25/Contact.tar
```

For more information on generating "photo.tar" and "Contact.tar", refer to [Preparing the Tar Formatted File](#) on page 274.

During the auto provisioning process, the IP phone connects to the provisioning server "192.168.10.25", and downloads the file "Contact.tar".

Scenario C - Using the Custom Avatar and Custom Icon for Contact

This scenario is only applicable to SIP VP-T49G and SIP-T48G IP phones.

Scenario Conditions I (only applicable to SIP VP-T49G IP phones):

- Provisioning server URL: tftp://192.168.10.25.
- The custom avatars and icons: "cutom1.jpg" and "cutom2.png". They are all uploaded to the provisioning server in advance.

Scenario Conditions II:

- Provisioning server URL: tftp://192.168.10.25.
- The custom avatars: "cutom1.jpg" and "cutom2.png". They are compressed as a tar formatted file (photo1.tar).
- The custom icons: "cutom1.jpg" and "cutom2.png". They are compressed as a tar formatted file (photo2.tar).

For more information on generating a tar formatted file, refer to [Preparing the Tar Formatted File](#) on page 274.

Note

The custom avatar and icon can be different, but make sure the icon name is the same as avatar name.

To customize a local contact file:

1. Open the template file using an ASCII editor.
2. For each group that you want to add, add the following string to the file. Each starts on a separate line:

```
<group display_name="" ring=""/>
```

3. For each contact that you want to add, add the following string to the file. Each starts on a separate line:

```
<contact display_name="" office_number="" mobile_number="" other_number=""  
line="" ring="" group_id_name="" default_photo=""/>
```


4. Specify the values within double quotes.

For example:

```
<group display_name="Friend" ring="Resource:Splash.wav"/>
```

```
<contact display_name="Lily" office_number="1020" mobile_number="1021"  
other_number="1112" line="1,2" ring="Resource:Ring1.wav"  
group_id_name="Friend" default_photo="Config:cutom1.jpg"/>
```

```
<contact display_name="Tom" office_number="2020" mobile_number="2021"
other_number="2112" line="2" ring="Resource:Ring1.wav"
group_id_name="Friend" default_photo="Config:cutom2.png"/>
```



5. Save the change and place this file to the provisioning server.
6. Specify the access URL of the custom local contact template file in the configuration files.

There are two methods to specify custom avatar and icon for contacts:

Method 1 (only applicable to SIP VPT49G IP phones):

```
local_contact.photo.url = tftp://192.168.10.25/cutom1.jpg
local_contact.photo.url = tftp://192.168.10.25/cutom2.png
local_contact.data.url = tftp://192.168.10.25/contact.xml
local_contact.icon_image.url = tftp://192.168.10.25/cutom1.jpg
local_contact.icon_image.url = tftp://192.168.10.25/cutom2.png
```


During the auto provisioning process, the IP phone connects to the provisioning server "192.168.10.25", and downloads the avatars (cutom1.jpg and cutom2.png), icons (cutom1.jpg and cutom2.png) and the contact file "contact.xml".

Method 2:


```
local_contact.image.url = tftp://192.168.10.25/photo1.tar
local_contact.data.url = tftp://192.168.10.25/contact.xml
local_contact.icon.url = tftp://192.168.10.25/photo2.tar
```

During the auto provisioning process, the IP phone connects to the provisioning server "192.168.10.25", and downloads the avatar file "photo1.tar", icon file "photo2.tar" and the contact file "contact.xml".

The following shows the custom avatars downloaded from the provisioning server:



The following shows the custom icons downloaded from the provisioning server:



Procedure

Local directory be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Specify the access URL of the local contact file (*.xml). Parameter: local_contact.data.url
		Specify the access URL of a contact avatar file. Parameter: local_contact.photo.url

		Specify the access URL of a contact icon file. Parameter: local_contact.icon_image.url
		Specify the access URL of a TAR contact avatar file. Parameter: local_contact.image.url
		Specify the access URL of the compressed TAR file consisting of the avatars TAR file and contact XML file. Parameter: local_contact.data_photo_tar.url
		Specify the access URL of a TAR contact icon file. Parameter: local_contact.icon.url
Local	Web User Interface	<p>Add a new group and a contact to the local directory.</p> <p>To import or export the local contact file.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p=contactsbasic&q=load&num=1&group=</p> <p>For SIP VP-T49G: http://<phoneIPAddress>/servlet?m=mod_data&p=contactsbasic&q=load&group=0&page=1</p>
	Phone User Interface	Add a new group and a contact to the local directory.

Details of the Configuration Parameter:


Parameter	Permitted Values	Default
local_contact.data.url	URL within 511 characters	Blank
Description: Configures the access URL of the local contact file (*.xml). Example: local_contact.data.url = http://192.168.10.25/contact.xml Web User Interface: Directory->Local Directory->Import Local Directory File Phone User Interface: None		
local_contact.photo.url	URL within 511 characters	Blank
Description: Configures the access URL of a contact avatar file. The format of the contact avatar must be *.png, *.jpg, *.bmp. The contact avatar file should be uploaded to the provisioning server in advance. Example: local_contact.photo.url = tftp://192.168.10.25/Photo.jpg Note: It is only applicable to SIP VP-T49G IP phones. If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: None Phone User Interface: None		
local_contact.icon_image.url	URL within 511 characters	Blank
Description: Configures the access URL of a contact icon file. The format of the contact icon must be *.png, *.jpg, *.bmp. The contact icon file should be uploaded to the provisioning server in advance. Example: local_contact.icon_image.url = tftp://192.168.10.25/Photo.jpg Note: It is only applicable to SIP VP-T49G IP phones. If you change this parameter, the IP phone will reboot to make the change take effect.		

Parameter	Permitted Values	Default
Web User Interface: None Phone User Interface: None		
local_contact.image.url	URL within 511 characters	Blank
Description: Configures the access URL of a TAR contact avatar file. The format of the contact avatar must be *.png, *.jpg, *.bmp. The contact avatar file should be compressed as a TAR file in advance and then place it to the provisioning server. Example: local_contact.image.url = tftp://192.168.10.25/photo.tar Note: It is only applicable to SIP VP-T49G/SIPT48G/T46G/T29G IP phones. For SIP VP-T49G IP phones, if you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: None Phone User Interface: None		
local_contact.data_photo_tar.url	URL within 511 characters	Blank
Description: Configures the access URL of the compressed TAR file consisting of the avatars TAR file and contact XML file. All avatars needed for contacts should be compressed as a TAR file in advance. Example: local_contact.data_photo_tar.url = tftp://192.168.10.25/Contact.tar Note: It is only applicable to SIP VP-T49G/SIPT48G/T46G/T29G IP phones. For SIP VP-T49G IP phones, if you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: None Phone User Interface: None		

Parameter	Permitted Values	Default
local_contact.icon.url	URL within 511 characters	Blank
<p>Description:</p> <p>Configures the access URL of a TAR contact icon file.</p> <p>The format of the contact icon must be *.png, *.jpg, *.bmp.</p> <p>The contact icon file should be compressed as a TAR file in advance and then place it to the provisioning server.</p> <p>Example:</p> <p>local_contact.icon.url = tftp://192.168.10.25/photo2.tar</p> <p>Note: It is only applicable to SIP VP-T49G/SIPT48G IP phones. For SIP VP-T49G IP phones, if you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		

To add a group to the local directory via web user interface:

1. Click on **Directory->Local Directory**.
2. In the **Group Setting** block, enter the desired group name in the **Group** field.
3. Select the desired ring tone from the pull-down list of **Ring**.



4. Click **Add** to add the group.

To add a contact to the local directory via web user interface:

1. Click on **Directory->Local Directory**.

2. In the **Directory** block, enter the name and the office, mobile or other numbers in the corresponding fields.
3. Select the desired ring tone from the pull-down list of **Ring Tone**.
4. Select the desired group from the pull-down list of **Group**.
5. Select the desired account from the pull-down list of **Account**.

If **Auto** is selected, the IP phone will use the default account when placing calls to the contact from the local directory.

The screenshot shows the Yealink T236 web interface. The top navigation bar includes 'Status', 'Account', 'Network', 'DSSKey', 'Features', 'Settings', 'Directory', and 'Security'. The 'Directory' tab is active. On the left sidebar, 'Local Directory' is selected. The main content area displays a table of contacts with columns: Index, Name, Office Number, Mobile Number, Other Number, and a dropdown menu set to 'All Contacts'. Below the table are buttons for 'Page 1', 'Prev', 'Next', 'Hang Up', 'Delete All', 'Delete', 'Move To', and 'All Contac'. A red box highlights the 'Add' button in the 'Directory' section. To the right of the 'Add' button is the 'Group Setting' section, which includes fields for 'Group', 'Ring' (set to 'Auto'), and buttons for 'Add', 'Edit', 'Delete', and 'Delete All'. Below this is the 'Import Local Directory File' section, which has two 'Browse' buttons and buttons for 'Import XML', 'Export XML', 'Import CSV', and 'Export CSV'. A 'Show Title' checkbox is also present. On the far right, a 'NOTE' section provides information about the local directory and includes a link to get more guides.

6. Click **Add** to add the contact.

To add a group to the local directory via phone user interface:

1. Press **Menu->Directory->Local Directory**.
2. Press the **AddGr** soft key.
3. Enter the desired group name in the **Name** field.
4. Press **◀** or **▶**, or the **Switch** soft key to select the desired group ring tone from the **Ring** field.
5. Press the **Add** soft key to accept the change.

To import an XML contact list file via web user interface:

1. Click on **Directory->Local Directory**.

- Click **Browse** to locate a contact list file (the file format must be *.xml) from your local system.

The screenshot shows the Yealink T236 web interface. The top navigation bar includes tabs for Status, Account, Network, DSSKey, Features, Settings, Directory, and Security. The left sidebar lists options: Local Directory, Remote Phone Book, Phone Call Info, LDAP, Multicast IP, and Setting. The main content area is titled 'Local Directory' and contains a table with columns: Index, Name, Office Number, Mobile Number, Other Number, and All Contacts. Below the table are pagination controls (Page 1, Prev, Next, Hang Up, Delete All, Delete, Move To, All Contac). The 'Directory' section has input fields for Name (Joy), Office Number (1234), Mobile Number (1235), Other Number (1236), Ring Tone (Auto), Group (All Contacts), and Account (Auto). The 'Group Setting' section has a Group input field and a Ring dropdown menu (Auto). Below these are buttons for Add, Edit, Delete, and Delete All. The 'Import Local Directory File' section is highlighted with a red box and contains a 'Browse...' button, 'Import XML', and 'Export XML' buttons. A 'NOTE' box on the right explains the local directory functionality and provides a link to more guides.

- Click **Import XML** to import the contact list.
The web user interface prompts "The original contact will be covered, Continue?".
- Click **OK** to complete importing the contact list.

To import a CSV contact list file via web user interface:

- Click on **Directory->Local Directory**.
- Click **Browse** to locate a contact list file (the file format must be *.csv) from your local system.
- (Optional.) Check the **Show Title** checkbox.
It will prevent importing the title of the contact information which is located in the first line of the CSV file.
- Click **Import CSV** to import the contact list.
- (Optional.) Mark the **On** radio box in the **Delete Old Contacts** field.
It will delete all existing contacts while importing the contact list.
- Select the contact information you want to import into the local directory from the pull-down list of **Index**.

At least one item should be selected to be imported into the local directory.

Yealink T236 Log Out

Status Account Network DSSKey Features Settings Directory Security

Delete Old Contacts ☒ On ☐ Off

Preview

Index	Display Name	Office Number	Mobile Number	Other Number	Line
1	Bob	1000			-1
2	Joy	1234			
3	Linda	1010			

NOTE

contacts-preview-note

You can click here to get more help through download Administrator Guide!

Import

- Click **Import** to complete importing the contact list.

To export a contact list via web user interface:

- Click on **Directory->Local Directory**.
- Click **Export XML** (or **Export CSV**).
- Click **Save** to save the contact list to your local system.

To add a contact to the local directory via phone user interface:

- Press **Menu->Directory->Local Directory**.
- Select the desired contact group and then press the **Enter** soft key.
- Press the **Add** soft key.
- Enter the name and the office, mobile or other numbers in the corresponding fields.
- Press **◀** or **▶**, or the **Switch** soft key to select the desired account from the **Account** field.
If **Auto** is selected, the IP phone will use the default account when placing calls to the contact from the local directory.
- Press **◀** or **▶**, or the **Switch** soft key to select the desired ring tone from the **Ring** field.
- Press the **Save** soft key to accept the change.

Live Dialpad

Live dialpad allows IP phones to automatically dial out the entered phone number after a specified period of time.

Procedure

Live dialpad can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure live dialpad. Parameters: phone_setting.predial_autodial phone_setting.inter_digit_time
Local	Web User Interface	Configure live dialpad. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet ?p=settings-preference&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=settings-preference&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
phone_setting.predial_autodial	0 or 1	0
Description: Enables or disables the live dialpad feature. 0-Disabled 1-Enabled If it is set to 1 (Enabled), the IP phone will automatically dial out the entered phone number on the dialing screen without pressing a send key. Web User Interface: Settings->Preference->Live Dialpad Phone User Interface: None		
phone_setting.inter_digit_time	Integer from 1 to 14	4

Parameters	Permitted Values	Default
<p>Description:</p> <p>Configures the delay time (in seconds) for the IP phone to automatically dial out the entered digits without pressing a send key.</p> <p>Note: It works only if the value of the parameter “phone_setting.predial_autodial” is set to 1 (Enabled).</p> <p>Web User Interface:</p> <p>Settings->Preference->Inter Digit Time(1~14s)</p> <p>Phone User Interface:</p> <p>None</p>		

To configure live dialpad via web user interface:

1. Click on **Settings->Preference**.
2. Select the desired value from the pull-down list of **Live Dialpad**.
3. Enter the desired delay time in the **Inter Digit Time(1~14s)** field.

The screenshot shows the Yealink T236 web interface. The 'Settings' tab is selected, and the 'Preference' sub-tab is active. The 'Live Dialpad' dropdown menu is set to 'Enabled', and the 'Inter Digit Time(1~14s)' field is set to '4'. A red box highlights these two settings. The 'Confirm' button is visible at the bottom of the form. On the right side, there is a 'NOTE' section with information about the 'Live Dialpad' feature.

4. Click **Confirm** to accept the change.

Call Waiting

Call waiting allows IP phones to receive a new incoming call when there is already an active call. The new incoming call is presented to the user visually on the LCD screen. Call waiting tone allows the IP phone to play a short tone, to remind the user audibly of a new incoming call during conversation. Call waiting tone works only if call waiting is enabled. You can customize call waiting tone or select specialized tone sets (vary from country to country) for your IP phone. For more information, refer to [Tones](#) on page 768.

The call waiting on code and call waiting off code configured on IP phones are used to activate/deactivate the server-side call waiting feature. They may vary on different servers.

Procedure

Call waiting and call waiting tone can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	<p>Configure call waiting and call waiting tone.</p> <p>Parameters:</p> <p>call_waiting.enable</p> <p>call_waiting.tone</p> <p>call_waiting.on_code</p> <p>call_waiting.off_code</p>
Local	Web User Interface	<p>Configure call waiting.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>http://<phoneIPAddress>/servlet ?p=features-general&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet ?m=mod_data&p=features-general&q=load</p>
		<p>Configure call waiting tone.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>http://<phoneIPAddress>/servlet ?p=features-audio&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet ?m=mod_data&p=features-audio&q=load</p>
	Phone User Interface	Configure call waiting and call waiting tone.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
call_waiting.enable	0 or 1	1
<p>Description: Enables or disables call waiting feature.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 0 (Disabled), a new incoming call is automatically rejected by the IP phone with a busy message while during a call.</p> <p>If it is set to 1 (Enabled), the LCD screen will present a new incoming call while during a call.</p> <p>Web User Interface: Features->General Information->Call Waiting</p> <p>Phone User Interface: Menu->Features->Call Waiting->Call Waiting</p>		
call_waiting.tone	0 or 1	1
<p>Description: Enables or disables the IP phone to play the call waiting tone when the IP phone receives an incoming call during a call.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 1 (Enabled), the IP phone will perform an audible indicator when receiving a new incoming call during a call.</p> <p>Note: It works only if the value of the parameter “call_waiting.enable” is set to 1 (Enabled).</p> <p>Web User Interface: Features->Audio->Call Waiting Tone</p> <p>Phone User Interface: Menu->Features->Call Waiting->Play Tone</p>		
call_waiting.on_code	String within 32 characters	Blank

Parameters	Permitted Values	Default
<p>Description:</p> <p>Configures the call waiting on code to activate the server-side call waiting feature. The IP phone will send the call waiting on code to the server when you activate call waiting feature on the IP phone.</p> <p>Example:</p> <p>call_waiting.on_code = *71</p> <p>Web User Interface:</p> <p>Features->General Information->Call Waiting On Code</p> <p>Phone User Interface:</p> <p>Menu->Features->Call Waiting->On Code</p>		
call_waiting.off_code	String within 32 characters	Blank
<p>Description:</p> <p>Configures the call waiting off code to deactivate the server-side call waiting feature. The IP phone will send the call waiting off code to the server when you deactivate call waiting feature on the IP phone.</p> <p>Example:</p> <p>call_waiting.off_code = *72</p> <p>Web User Interface:</p> <p>Features->General Information->Call Waiting Off Code</p> <p>Phone User Interface:</p> <p>Menu->Features->Call Waiting->Off Code</p>		

To configure call waiting via web user interface:


1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Call Waiting**.
3. (Optional.) Enter the call waiting on code in the **Call Waiting On Code** field.
4. (Optional.) Enter the call waiting off code in the **Call Waiting Off Code** field.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected, and the 'General Information' sub-tab is active. A red box highlights the 'Call Waiting' section, which includes a dropdown menu set to 'Enabled', and two text input fields: 'Call Waiting On Code' with the value '*71' and 'Call Waiting Off Code' with the value '*72'. Below these are fields for 'Auto Redial' (set to 'Disabled'), 'Auto Redial Interval' (10), 'Auto Redial Times' (10), and 'Key As Send' (set to '#'). On the right side, a 'NOTE' box provides additional information about the 'Call Waiting' and 'Auto Redial' features.

- 5. Click **Confirm** to accept the change.

To configure call waiting tone via web user interface:

- 1. Click on **Features->Audio**.
- 2. Select the desired value from the pull-down list of **Call Waiting Tone**.



- 3. Click **Confirm** to accept the change.

To configure call waiting and call waiting tone via phone user interface:

- 1. Press **Menu->Features->Call Waiting**.
- 2. Press **◀** or **▶** , or the **Switch** soft key to select the desired value from the **Call Waiting** field.
- 3. Press **◀** or **▶** , or the **Switch** soft key to select the desired value from the **Play Tone** field.
- 4. (Optional.) Enter the call waiting on code in the **On Code** field.
- 5. (Optional.) Enter the call waiting off code in the **Off Code** field.
- 6. Press the **Save** soft key to accept the change.

Redial Tone

Redial tone allows IP phones to continue to play the dial tone after inputting the preset numbers on the dialing screen.

Procedure

Redial tone can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure redial tone feature. Parameters: features.redial_tone
Local	Web User Interface	Configure redial tone feature. Navigate to: For

		SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet ?p=features-audio&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=features-audio&q=load
--	--	---

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.redial_tone	Integer within 6 digits	Blank
<p>Description: Configures the IP phone to continue to play the dial tone after inputting the preset numbers on the dialing screen.</p> <p>Example: features.redial_tone = 123 The IP phone will continue to play the dial tone after inputting "123" on the dialing screen. If it is left blank, the IP phone will not play the dial tone after inputting numbers on the dialing screen.</p> <p>Web User Interface: Features->Audio->Redial Tone</p> <p>Phone User Interface: None</p>		

To configure redial tone via web user interface:

1. Click on **Features->Audio**.

2. Enter the desired value in the **Redial Tone** field.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected, and the 'Audio Settings' page is displayed. The 'Redial Tone' field is highlighted with a red box and contains the value '123'. Other settings include Call Waiting Tone, Key Tone, Send Tone, Headset Send Volume, Handset Send Volume, Handfree Send Volume, and Ringer Device for Headset. A 'NOTE' section on the right explains the Redial Tone and Ringer Device for Headset features.

3. Click **Confirm** to accept the change.

Ringer Device for Headset

The IP phones support either or both speaker and headset ringer devices. Ringer Device for Headset feature allows users to configure which ringer device to be used when receiving an incoming call. For example, if the ringer device is set to Headset, ring tone will be played through your headset.

If the ringer device is set to Headset or Headset&Speaker, the headset (either a wired headset or Bluetooth headset) should be connected to the IP phone and the headset mode also should be activated in advance. You can press the HEADSET key to activate the headset mode. For more information, refer to the [Yealink phone-specific user guide](#).

Note It is not applicable to CP860 IP phones.

Procedure

Ringer device for headset can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the ringer device for the IP phone. Parameters: features.ringer_device.is_use_headset
Local	Web User Interface	Configure the ringer device for the IP phone. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T2

		9G/T27P/T23P/T23G/T21(P) E2/T19(P) E2: http://<phoneIPAddress>/servlet ?p=features-audio&q=load For SIP VPT49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=features-audio&q=load
--	--	---

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.ringer_device.is_use_headset	0, 1 or 2	0
Description: Configures the ringer device for the IP phone. 0 -Use Speaker 1 -Use Headset 2 -Use Headset & Speaker If the ringer device is set to Headset or Headset&Speaker, the headset should be connected to the IP phone and the headset mode also should be activated in advance. Note: It is not applicable to CP860 IP phones. Web User Interface: Features->Audio->Ringer Device for Headset Phone User Interface: None		

To configure ringer device for headset via web user interface:

1. Click on **Features->Audio**.

2. Select the desired value from the pull-down list of **Ringer Device for Headset**.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected in the top navigation bar. On the left sidebar, the 'Audio' option is highlighted. The main content area displays 'Audio Settings'. The 'Ringer Device for Headset' dropdown menu is highlighted with a red box, showing 'Use Speaker' as the selected option. The interface includes a sidebar with navigation links like Forward&DND, General Information, Audio, Intercom, Transfer, Call Pickup, Remote Control, and Phone Lock. The main content area shows various audio settings like Call Waiting Tone, Key Tone, Send Tone, Redial Tone, and headset/handfree volumes. A 'NOTE' section on the right explains the 'Ringer Device for Headset' setting.

3. Click **Confirm** to accept the change.

Auto Redial

Auto redial allows IP phones to redial a busy number after the first attempt. Both the number of attempts and waiting time between redials are configurable.

Procedure

Auto redial can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure auto redial feature. Parameters: auto_redial.enable auto_redial.interval auto_redial.times
Local	Web User Interface	Configure auto redial feature. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T2 9G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet ?p=features-general&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=features-gene ral&q=load
	Phone User Interface	Configure auto redial feature.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
auto_redial.enable	0 or 1	0
Description: Enables or disables the IP phone to automatically redial the dialed number when the callee is temporarily unavailable. 0-Disabled 1-Enabled If it is set to 1 (Enabled), the IP phone will dial the previous dialed out number automatically when the dialed number is temporarily unavailable. Web User Interface: Features->General Information->Auto Redial Phone User Interface: Menu->Features->Auto Redial->Auto Redial		
auto_redial.interval	Integer from 1 to 300	10
Description: Configures the interval (in seconds) for the IP phone to wait between redials. The IP phone redials the dialed number at regular intervals till the callee answers the call. Web User Interface: Features->General Information->Auto Redial Interval (1~300s) Phone User Interface: Menu->Features->Auto Redial->Redial Interval		
auto_redial.times	Integer from 1 to 300	10
Description: Configures the auto redial times when the callee is temporarily unavailable. The IP phone tries to redial the dialed number as many times as configured till the callee answers the call. Web User Interface: Features->General Information->Auto Redial Times (1~300) Phone User Interface: Menu->Features->Auto Redial->Redial Times		

To configure auto redial via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Auto Redial**.
3. Enter the waiting time in the **Auto Redial Interval (1~300s)** field.
The default waiting time is 10s.
4. Enter the desired times in the **Auto Redial Times (1~300)** field.
The default value is 10.

The screenshot shows the Yealink T23G web interface. The 'Features' tab is selected, and the 'General Information' sub-tab is active. A red box highlights the 'Auto Redial' configuration area, which includes a dropdown menu set to 'Enabled', and two input fields: 'Auto Redial Interval (1~300s)' with the value '10' and 'Auto Redial Times (1~300)' with the value '10'. To the right, a 'NOTE' section provides details about 'Call Waiting', 'Auto Redial', 'Key As Send', and 'Hotline' features.

5. Click **Confirm** to accept the change.

To configure auto redial via phone user interface:

1. Press **Menu->Features->Auto Redial**.
2. Press or , or the **Switch** soft key to select the desired value from the **Auto Redial** field.
3. Enter the waiting time (in seconds) in the **Redial Interval** field.
4. Enter the desired times in the **Redial Times** field.
5. Press the **Save** soft key to accept the change.

Auto Answer

Auto answer allows IP phones to automatically answer an incoming call. IP phones will not automatically answer the incoming call during a call even if auto answer is enabled. Auto answer is configurable on a per-line basis. Auto-Answer delay defines a period of delay time before the IP phone automatically answers incoming calls.

Auto Answer Tone

Auto answer tone allows the IP phone to play a tone when an incoming call is automatically answered. You can customize the auto answer tone or select specialized tone sets (vary from country to country) for your IP phone. For more information, refer to [Tones](#) on page 768.

Auto Answer Mute

Auto answer mute allows IP phones to mute the local microphone when an incoming call is automatically answered. It is only applicable to CP860 IP phones.

Note

Auto answer is not applicable to automatically answer an IP address call. Automatically answering an IP address call works only if IP direct auto answer feature is enabled. For more information, refer to [IP Direct Auto Answer](#) on page 306.

Procedure

Auto answer can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure auto answer. Parameter: account.X.auto_answer
		Configure auto answer mute. Parameter: account.X.auto_answer_mute_enable
	<y0000000000xx>.cfg	Specify a period of delay time for auto answer. Parameter: features.auto_answer_delay
		Configure auto answer tone. Parameter: features.auto_answer_tone.enable
Local	Web User Interface	Configure auto answer. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <code>http://<phoneIPAddress>/servlet?parameter=account-basic&q=load&acc=0</code> For SIP VP-T49G: <code>http://<phoneIPAddress>/servlet?method=mod_data&p=account-basic&q=load&acc=0</code>

		<p>Specify a period of delay time for auto answer.</p> <p>Configure auto answer tone.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>http://<phoneIPAddress>servlet?parameters=features-general&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet?parameters=mod_data&p=features-general&q=load</p>
		<p>Configure auto answer mute.</p> <p>Navigate to:</p> <p>For CP860:</p> <p>http://<phoneIPAddress>/servlet?parameters=account-basic&q=load&acc=0</p>
	Phone User Interface	<p>Configure auto answer.</p> <p>Configure auto answer mute.</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
account.X.auto_answer	0 or 1	0
<p>Description:</p> <p>Enables or disables auto answer feature for account X.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>If it is set to 1 (Enabled), the IP phone can automatically answer an incoming call.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p>		

Parameters	Permitted Values	Default
<p>Note: The IP phone cannot automatically answer the incoming call during a call even if auto answer is enabled.</p> <p>Web User Interface: Account->Basic->Auto Answer</p> <p>Phone User Interface: For SIP-T42G/T41P/T40P/T27P/T23P/T23G/T21(P) E2/T19(P) E2: Menu->Features->Auto Answer->Status</p> <p>For SIP-T46G/T29G: Menu->Features->Auto Answer->Line X->Auto Answer</p> <p>For SIP VP-T49G/SIP-T48G: Menu->Features->Auto Answer->Line X->On/Off</p> <p>For CP860: Menu->Features->Auto Answer->Auto Answer</p>		
account.X.auto_answer_mute_enable (X is equal to 1)	0 or 1	0
<p>Description: Enables or disables auto answer mute feature for account X.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 1 (Enabled), the IP phone will mute the microphone when an incoming call is automatically answered, and then the other party cannot hear you.</p> <p>Note: It is only applicable to CP860 IP phones. It works only if the values of parameters "account.X.auto_answer" and "features.allow_mute" are set to 1 (Enabled).</p> <p>Web User Interface: Account->Basic->Auto Answer Mute</p> <p>Phone User Interface: Menu->Features->Auto Answer->Auto Answer Mute</p>		
features.auto_answer_delay	Integer from 1 to 4	1
<p>Description: Configures the delay time (in seconds) before the IP phone automatically answers an incoming call.</p> <p>Note: It works only if the value of the parameter "account.X.auto_answer" is set to 1 (Enabled).</p>		

Parameters	Permitted Values	Default
Web User Interface: Features->General Information->Auto-Answer Delay(1~4s) Phone User Interface: None		
features.auto_answer_tone.enable	0 or 1	1
Description: Enables or disables the phone to play a warning tone when an incoming call is automatically answered. 0-Disabled 1-Enabled Note: For the call coming from a SIP account, it works only if the value of the parameter "account.X.auto_answer" is set to 1 (Enabled). It is also applicable to IP calls. Web User Interface: Features->General Information->Enable auto answer tone Phone User Interface: None		

To configure auto answer via web user interface (take SIP-T23G IP phones for example):

1. Click on **Account->Basic**.
2. Select the desired account from the pull-down list of **Account**.
3. Select the desired value from the pull-down list of **Auto Answer**.

The screenshot shows the Yealink T23G web interface. The top navigation bar includes 'Status', 'Account', 'Network', 'DSSKey', 'Features', 'Settings', 'Directory', and 'Security'. The 'Account' tab is selected. On the left, there is a sidebar with 'Register', 'Basic', 'Codec', and 'Advanced' options. The main content area shows the 'Account' configuration for 'Account 1'. The 'Auto Answer' option is highlighted with a red box and is set to 'Enabled'. Other options include 'Proxy Require', 'Local Anonymous', 'Local Anonymous Rejection', 'Send Anonymous Code', 'On Code', 'Off Code', 'Send Anonymous Rejection Code', 'Missed Call Log', and 'Ring Type'. A 'NOTE' section on the right provides information about 'Anonymous Call' and 'Anonymous Call Rejection'. At the bottom, there are 'Confirm' and 'Cancel' buttons.

4. Click **Confirm** to accept the change.

To configure auto answer and auto answer mute via web user interface (take CP860 IP phones for example):

1. Click on **Account->Basic**.
2. Select the desired value from the pull-down list of **Auto Answer**.
3. Select the desired value from the pull-down list of **Auto Answer Mute**.

The screenshot shows the Yealink CP860 web interface. The top navigation bar includes 'Status', 'Account', 'Network', 'DSSKey', 'Features', 'Settings', 'Directory', and 'Security'. The left sidebar has 'Register', 'Basic', 'Codec', and 'Advanced'. The main content area is under 'Account > Basic'. It contains several configuration fields: Proxy Require, Local Anonymous, Local Anonymous Rejection, Send Anonymous Code, On Code, Off Code, Send Anonymous Rejection Code, On Code, Off Code, Missed Call Log, Auto Answer, Auto Answer Mute, and Ring Type. The 'Auto Answer' and 'Auto Answer Mute' dropdown menus are highlighted with a red box, both set to 'Enabled'. There are 'Confirm' and 'Cancel' buttons at the bottom.

4. Click **Confirm** to accept the change.

To configure a period of delay time for auto answer via web user interface:

1. Click on **Features->General Information**.
2. Enter the desired time in the **Auto-Answer Delay(1~4s)** field.

The screenshot shows the Yealink T236 web interface. The top navigation bar includes 'Status', 'Account', 'Network', 'DSSKey', 'Features', 'Settings', 'Directory', and 'Security'. The left sidebar has 'Forward&DND', 'General Information', 'Audio', 'Intercom', 'Transfer', 'Call Pickup', 'Remote Control', 'Phone Lock', 'ACD', 'SMS', 'Action URL', 'Power LED', and 'Notification Popups'. The main content area is under 'Features > General Information'. It contains several configuration fields: Call Waiting, Call Waiting On Code, Call Waiting Off Code, Auto Redial, Auto Redial Interval (1~300s), Auto Redial Times (1~300), Dual-Headset, Auto-Answer Delay(1~4s), Enable auto answer tone, Headset Prior, Voice Mail Tone, and Auto Linekeys. The 'Auto-Answer Delay(1~4s)' field is highlighted with a red box and set to '1'. There are 'Confirm' and 'Cancel' buttons at the bottom.

3. Click **Confirm** to accept the change.

To configure auto answer tone via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value in the pull-down list of **Enable auto answer tone**.

The screenshot shows the Yealink T23G web interface. The 'Features' tab is selected, and the 'General Information' sub-tab is active. In the 'General Information' section, the 'Enable auto answer tone' dropdown menu is highlighted with a red box and is currently set to 'Enabled'. Other settings visible include 'Call Waiting' (Enabled), 'Auto Redial' (Disabled), 'Auto Answer Delay' (1), and 'Auto Linekeys' (Disabled). A 'NOTE' section on the right provides details about various features: 'Call Waiting' (allows IP phones to receive a new incoming call when there is already an active call), 'Auto Redial' (allows IP phones to automatically redial a busy number after the first attempt), 'Key As Send' (Assigns '#' or '*' as the send key), 'Hotline' (IP phone will automatically dial out the hotline number when lifting the handset, pressing the speakerphone key or the line key), and 'Call Completion' (allows users to monitor the busy party and establish a call when the busy party becomes available to receive a call). At the bottom of the settings area, there are 'Confirm' and 'Cancel' buttons.

3. Click **Confirm** to accept the change.

To configure auto answer via phone user interface (take SIP-T23G IP phones for example):

1. Press **Menu->Features->Auto Answer**.
2. Press or , or the **Switch** soft key to select the desired value from the **Line ID** field.
3. Press or , or the **Switch** soft key to select the desired value from the **Status** field.
4. Press the **Save** soft key to accept the change.

To configure auto answer via phone user interface (take SIP-T46G IP phones for example):

1. Press **Menu->Features->Auto Answer**.
2. Select the desired line.
3. Press or , or the **Switch** soft key to select the desired value from the **Auto Answer** field.
4. Press the **Save** soft key to accept the change.

To configure auto answer via phone user interface (take SIP-T48G IP phones for example):

1. Tap -> **Features->Auto Answer**.
2. Tap the **On** radio box in the desired line.
3. Tap the **Save** soft key to accept the change.

To configure auto answer and auto answer mute via phone user interface (take CP860 IP phones for example):

1. Press **Menu->Features->Auto Answer**.
2. Press the ◀ or ▶ soft key to select **Enabled** from the **Auto Answer** field.
3. Press the ◀ or ▶ soft key to select **Enabled** from the **Auto Answer Mute** field.
4. Press the **Save** soft key to accept the change.

IP Direct Auto Answer

IP direct auto answer allows IP phones to automatically answer an IP address call. IP direct auto answer works only if allow IP call is enabled. For more information on allow IP call, refer to [Allow IP Call](#) on page 307.

Procedure

IP direct auto answer can only be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure IP direct auto answer feature. Parameter: features.ip_call_auto_answer.enable
Local	Web User Interface	Configure IP direct auto answer feature. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p=features-general&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.ip_call_auto_answer.enable	0 or 1	0

Parameters	Permitted Values	Default
<p>Description:</p> <p>Enables or disables the auto answer feature for IP call.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>If it is set to 1 (Enabled), the IP phone can automatically answer IP call.</p> <p>Note: It works only if the value of the parameter "features.direct_ip_call_enable" is set to 1 (Enabled). The IP phone cannot automatically answer the incoming IP call during a call even if IP call auto answer is enabled.</p> <p>Web User Interface:</p> <p>Feature->General Information->IP Direct Auto Answer</p> <p>Phone User Interface:</p> <p>None</p>		

To configure IP direct auto answer via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **IP Direct Auto Answer**.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected, and the 'General Information' sub-tab is active. In the 'General Information' section, the 'IP Direct Auto Answer' dropdown menu is highlighted with a red rectangle and is currently set to 'Enabled'. Other settings in this section include 'Call Waiting' (Enabled), 'Call Waiting On Code' (empty), 'Call Waiting Off Code' (empty), 'Auto Redial' (Disabled), 'Auto Redial Interval (1~300s)' (10), 'Auto Redial Times (1~300)' (10), 'Accept SIP Trust Server Only' (Enabled), 'Allow IP Call' (Enabled), 'Call List Show Number' (Enabled), 'Voice Mail Tone' (Enabled), and 'Auto Linekeys' (Disabled). A 'NOTE' panel on the right provides details for 'Call Waiting', 'Auto Redial', 'Key As Send', 'Hotline', and 'Call Completion'. At the bottom, there are 'Confirm' and 'Cancel' buttons.

3. Click **Confirm** to accept the change.

Allow IP Call

Allow IP Call feature allow IP phones to receive or place an IP address call. You can neither receive nor place an IP address call if allow IP call feature is disabled.

Procedure

Allow IP call can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure allow IP call. Parameter: features.direct_ip_call_enable
Local	Web User Interface	Configure allow IP call. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet ?p=features-general&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=features-gene ral&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.direct_ip_call_enable	0 or 1	1
Description: Enables or disables allow IP address call. 0 -Disabled 1 -Enabled Note: If you want to receive an IP address call, make sure the value of the parameter "sip.trust_ctrl" is set to 0 (Disabled). Web User Interface: Features->General Information->Allow IP Call Phone User Interface: None		

To configure allow IP call feature via web user interface:

1. Click on **Features->General Information**.

2. Select the desired value from the pull-down list of **Allow IP Call**.

The screenshot shows the Yealink T23G web interface. The 'Features' tab is selected. In the 'General Information' section, the 'Allow IP Call' dropdown menu is highlighted with a red box and is set to 'Enabled'. Other settings include 'Call Waiting' (Enabled), 'Auto Redial' (Disabled), and 'Accept SIP Trust Server Only' (Enabled). A 'NOTE' section on the right provides additional information about various features like Call Waiting, Auto Redial, Key As Send, Hotline, and Call Completion.

3. Click **Confirm** to accept the change.

Accept SIP Trust Server Only

Accept SIP trust server only enables the IP phones to only accept the SIP message from your SIP server and outbound proxy server. It can prevent the phone receiving ghost calls from random numbers like 100, 1000, etc. To stop this from happening, you also need to disable allow IP call feature. For more information on allow IP call, refer to [Allow IP Call](#) on page 307.

Procedure

Accept SIP trust server can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure accept SIP trust server. Parameter: sip.trust_ctrl
Local	Web User Interface	Configure accept SIP trust server. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T2 9G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet ?p=features-general&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet


		?m=mod_data&p=features-general&q=load
--	--	---------------------------------------

Details of Configuration Parameters:

Parameters	Permitted Values	Default
sip.trust_ctrl	0 or 1	0
<p>Description:</p> <p>Enables or disables the IP phone to only accept the SIP message from the SIP and outbound proxy server.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>Web User Interface:</p> <p>Features->General Information->Accept SIP Trust Server Only</p> <p>Phone User Interface:</p> <p>None</p>		

To configure accept SIP trust server only feature via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Accept SIP Trust Server Only**.



3. Click **Confirm** to accept the change.

Call Completion

Call completion allows users to monitor the busy party and establish a call when the

busy party becomes available to receive a call. Two factors commonly prevent a call from connecting successfully:

- Callee does not answer
- Callee actively rejects the incoming call before answering

IP phones support call completion using the SUBSCRIBE/NOTIFY method, which is specified in draft-poetzl-sipping-call-completion-00, to subscribe to the busy party and receive notifications of their status changes.

The caller subscribes for update notifications of the dialog event from the busy party.

Example of a SUBSCRIBE message:

```
SUBSCRIBE sip:1000@10.10.20.34:5060 SIP/2.0
Via: SIP/2.0/UDP 10.10.20.32:5060;branch=z9hG4bK2880274891
From: "10111" <sip:10111@10.2.1.48:5060>;tag=8643512
To: <sip:1000@10.2.1.48:5060>;tag=4025601441
Call-ID: 4_2103527761@10.10.20.32
CSeq: 2 SUBSCRIBE
Contact: <sip:10111@10.10.20.32:5060>
Accept: application/dialog-info+xml
Max-Forwards: 70
User-Agent: Yealink SIP-T23G 44.80.0.60
Expires: 60
Event: dialog
Content-Length: 0
```

Example of a NOTIFY message (The subscription (SUBSCRIBE message) of the dialog event "Call Completion" is confirmed by the busy party):

```
NOTIFY sip:10111@10.10.20.32:5060 SIP/2.0
Via: SIP/2.0/UDP 10.10.20.31:5060;branch=z9hG4bK1830418099
From: <sip:1000@10.2.1.48:5060>;tag=1032948194
To: "10111" <sip:10111@10.2.1.48:5060>;tag=722495580
Call-ID: 0_160090766@10.10.20.32
CSeq: 2 NOTIFY
Contact: <sip:1000@10.10.20.31:5060>
Content-Type: application/dialog-info+xml
Max-Forwards: 70
User-Agent: Yealink SIP-T23G 44.80.0.60
Subscription-State: active;expires=60
Event: dialog
Content-Length: 584

<?xml version="1.0"?>
<dialog-info xmlns="urn:ietf:params:xml:ns:dialog-info" version="1" state="full"
entity="sip:1000@10.2.1.48:5060">
```

```

<dialog id="65626" call-id="0_3138198645@10.10.20.31" local-tag="2331766736"
remote-tag="1786911541" direction="initiator">
<state>confirmed</state>
<local>
<identity>sip:1000@10.2.1.48:5060</identity>
<target uri="sip:1000@10.2.1.48:5060"/>
</local>
<remote>
<identity>sip:1@10.2.1.48:5060</identity>
<target uri="sip:1@10.2.1.48:5060"/>
</remote>
</dialog>
<dialog id="65622">
<state>terminated</state>
</dialog>
</dialog-info>

```

Example of a NOTIFY message (The busy party has finished the call and is available again. A new notification update from the busy party is received by the caller):

```

NOTIFY sip:10111@10.10.20.32:5060 SIP/2.0
Via: SIP/2.0/UDP 10.10.20.31:5060;branch=z9hG4bK3431394016
From: <sip:1000@10.2.1.48:5060>;tag=1558968605
To: "10111" <sip:10111@10.2.1.48:5060>;tag=140677866
Call-ID: 0_2584152566@10.10.20.32
CSeq: 5 NOTIFY
Contact: <sip:1000@10.10.20.31:5060>
Content-Type: application/dialog-info+xml
Max-Forwards: 70
User-Agent: Yealink SIP-T23G 44.80.0.60
Subscription-State: active;expires=48
Event: dialog
Content-Length: 217

<?xml version="1.0"?>
<dialog-info xmlns="urn:ietf:params:xml:ns:dialog-info" version="4" state="partial"
entity="sip:1000@10.2.1.48:5060">
<dialog id="65644">
<state>terminated</state>
</dialog>
</dialog-info>

```

Procedure

Call completion can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure call completion. Parameter: features.call_completion_enable
Local	Web User Interface	Configure call completion. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet ?p=features-general&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=features-general&q=load
	Phone User Interface	Configure call completion.

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
features.call_completion_enable	0 or 1	0
Description: Enables or disables call completion feature. If a user places a call and the callee is temporarily unavailable to answer the call, call completion feature allows notifying the user when the callee becomes available to receive a call. 0-Disabled 1-Enabled If it is set to 1 (Enabled), the caller is notified when the callee becomes available to receive a call. Web User Interface: Features->General Information->Call Completion Phone User Interface: Menu->Features->Call Completion->Call Completion		

To configure call completion via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Call Completion**.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected, and the 'General Information' sub-tab is active. In the 'General Information' section, the 'Call Completion' dropdown menu is highlighted with a red box and set to 'Enabled'. Other settings include 'Call Waiting' (Enabled), 'Auto Redial' (Disabled), 'Auto Redial Interval' (10), 'Auto Redial Times' (10), 'Key As Send' (#), 'Reserve # in User Name' (Enabled), 'Hotline Number', 'Hotline Delay' (4), 'Busy Tone Delay' (0), 'Return Code When Refuse' (486 (Busy Here)), 'Return Code When DND' (480 (Temporarily Unavailable)), 'Feature Key Synchronization' (Disabled), and 'Time-Out for Dial-Now Rule' (1). A 'NOTE' section on the right provides additional information about various features.

3. Click **Confirm** to accept the change.

To configure call completion via phone user interface:

1. Press **Menu->Features->Call Completion**.
2. Press **◀** or **▶**, or the **Switch** soft key to select the desired value from the **Call Completion** field.
3. Press the **Save** soft key to accept the change.

Anonymous Call

Anonymous call allows the caller to conceal the identity information displayed on the callee's screen. The callee's phone LCD screen prompts an incoming call from anonymity. Anonymous call is configurable on a per-line basis.

Example of anonymous SIP header:

```
Via: SIP/2.0/UDP 10.3.20.14:5060;branch=z9hG4bK3074920774
From: "Anonymous" <sip:anonymous@anonymous.invalid>;tag=131654239
To: <sip:1006@10.2.1.48:5060>
Call-ID: 0_288363101@10.3.20.14
CSeq: 1 INVITE
Contact: <sip:1009@10.3.20.14:5060>
Content-Type: application/sdp
Allow: INVITE, INFO, PRACK, ACK, BYE, CANCEL, OPTIONS, NOTIFY, REGISTER, SUBSCRIBE, REFER,
```

```

PUBLISH, UPDATE, MESSAGE
Max-Forwards: 70
User-Agent: Yealink SIP-T23G 44.80.0.60
Allow-Events: talk,hold,conference,refer,check-sync
P-Preferred-Identity: <sip:1009@10.2.1.48>
Privacy: id
Content-Length: 302

```

The anonymous call on code and anonymous call off code configured on IP phones are used to activate/deactivate the server-side anonymous call feature. They may vary on different servers. Send Anonymous Code feature allows IP phones to send anonymous on/off code to the server.

Procedure

Anonymous call can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure anonymous call. Parameters: account.X.anonymous_call account.X.send_anonymous_code account.X.anonymous_call_oncode account.X.anonymous_call_offcode
Local	Web User Interface	Configure anonymous call. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/ T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p= account-basic&q=load&acc=0 For SIP VP-T49G: http://<phoneIPAddress>/servlet?m =mod_data&p=account-basic&q=lo ad&acc=0
	Phone User Interface	Configure anonymous call.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
account.X.anonymous_call	0 or 1	0

Parameters	Permitted Values	Default
Description: Triggers the anonymous call feature to on or off for account X. 0-Off 1-On If it is set to 1 (On), the IP phone will block its identity from showing up to the callee when placing a call. The callee's phone LCD screen presents anonymous instead of the caller's identity. X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Web User Interface: Account->Basic->Local Anonymous Phone User Interface: Menu->Features->Anonymous Call->Local Anonymous		
account.X.send_anonymous_code	0 or 1	0
Description: Configures the IP phone to send anonymous on/off code to activate/deactivate the server-side anonymous call feature for account X. 0-Off Code 1-On Code If it is set to 0 (Off Code), the IP phone will send anonymous off code to the server when you deactivate the anonymous call feature. If it is set to 1 (On Code), the IP phone will send anonymous on code to the server when you activate the anonymous call feature. X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Web User Interface:		

Parameters	Permitted Values	Default
Account->Basic->Send Anonymous Code Phone User Interface: Menu->Features->Anonymous Call->Send Anony Code		
account.X.anonymous_call_oncode	String within 32 characters	Blank
Description: Configures the anonymous call on code to activate the server-side anonymous call feature for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Example: account.1.anonymous_call_oncode = *72 Note: It works only if the value of the parameter "account.X.send_anonymous_code" is set to 1 (On Code). Web User Interface: Account->Basic->Send Anonymous Code->On Code Phone User Interface: Menu->Features->Anonymous Call->On Code		
account.X.anonymous_call_offcode	String within 32 characters	Blank
Description: Configures the anonymous call off code to deactivate the server-side anonymous call feature for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Example: account.1.anonymous_call_offcode = *73		

Parameters	Permitted Values	Default
<p>Note: It works only if the value of the parameter "account.X.send_anonymous_code" is set to 0 (Off Code).</p> <p>Web User Interface: Account->Basic->Send Anonymous Code->Off Code</p> <p>Phone User Interface: Menu->Features->Anonymous Call->Off Code</p>		

To configure anonymous call via web user interface:

1. Click on **Account->Basic**.
2. Select the desired account from the pull-down list of **Account**.
3. Select the desired value from the pull-down list of **Local Anonymous**.
4. Select the desired value from the pull-down list of **Send Anonymous Code**.
5. (Optional.) Enter the anonymous call on code in the **On Code** field.
6. (Optional.) Enter the anonymous call off code in the **Off Code** field.

The screenshot shows the Yealink T236 web interface. The 'Account' tab is selected, and the 'Basic' sub-tab is active. The 'Account' dropdown is set to 'Account 1'. The 'Local Anonymous' dropdown is set to 'On', and the 'Send Anonymous Code' dropdown is set to 'On Code'. The 'On Code' field contains '*72' and the 'Off Code' field contains '*73'. A 'NOTE' box on the right explains the 'Anonymous Call' and 'Anonymous Call Rejection' features.

7. Click **Confirm** to accept the change.

To configure the anonymous call via phone user interface:

1. Press **Menu->Features->Anonymous Call**.
2. Press **Left Arrow** or **Right Arrow**, or the **Switch** soft key to select the desired line from the **Line ID** field.
3. Press **Left Arrow** or **Right Arrow**, or the **Switch** soft key to select the desired value from the **Local Anonymous** field.
4. (Optional.) Press **Left Arrow** or **Right Arrow**, or the **Switch** soft key to select the desired value from the **Send Anony Code** field.
5. (Optional.) Enter the anonymous call on code in the **On Code** field.

6. (Optional.) Enter the anonymous call off code in the **Off Code** field.
7. Press the **Save** soft key to accept the change.

Anonymous Call Rejection

Anonymous call rejection allows IP phones to automatically reject incoming calls from callers whose identity has been deliberately concealed. The anonymous caller's phone LCD screen presents "Anonymity Disallowed". Anonymous call rejection is configurable on a per-line basis.

Example of anonymous call rejection SIP header:

```
SIP/2.0 433 Anonymity Disallowed
Via: SIP/2.0/UDP 10.10.20.32:5060;branch=z9hG4bK2816884590
From: "Anonymous" <sip:anonymous@anonymous.invalid>;tag=2625078618
To: <sip:1058@10.2.1.48:5060>;tag=2781829106
Call-ID: 4_510565349@10.10.20.32
CSeq: 1 INVITE
Allow: INVITE, INFO, PRACK, ACK, BYE, CANCEL, OPTIONS, NOTIFY, REGISTER, SUBSCRIBE, REFER,
PUBLISH, UPDATE, MESSAGE
User-Agent: Yealink SIP-T23G 44.80.0.60
Allow-Events: talk, hold, conference, refer, check-sync
Content-Length: 0
```

The anonymous call rejection on code and anonymous call rejection off code configured on IP phones are used to activate/deactivate the server-side anonymous call rejection feature. They may vary on different servers. Send Anonymous Rejection Code feature allows IP phones to send anonymous call rejection on/off code to the server.

Procedure

Anonymous call rejection can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure anonymous call rejection. Parameters: account.X.reject_anonymous_call account.X.send_anonymous_rejection_code account.X.anonymous_reject_oncode account.X.anonymous_reject_offcode
Local	Web User Interface	Configure anonymous call rejection. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P)

		<p>E2/CP860:</p> <p>http://<phoneIPAddress>/servlet?p=account-basic&q=load&acc=0</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet?m=mod_data&p=account-basic&q=load&acc=0</p>
	Phone User Interface	Configure anonymous call rejection.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
account.X.reject_anonymous_call	0 or 1	0
<p>Description:</p> <p>Triggers the anonymous call rejection feature to on or off for account X.</p> <p>0-Off</p> <p>1-On</p> <p>If it is set to 1 (On), the IP phone will automatically reject incoming calls from users enabled anonymous call feature. The anonymous user's phone LCD screen presents "Anonymity Disallowed".</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Web User Interface:</p> <p>Account->Basic->Local Anonymous Rejection</p> <p>Phone User Interface:</p> <p>Menu->Features->Anonymous Call->Anonymous Rejection</p>		
account.X.send_anonymous_rejection_code	0 or 1	0
<p>Configures the IP phone to send anonymous rejection on/off code to activate/deactivate the server-side anonymous call rejection feature for account X.</p> <p>0- Off code</p> <p>1- On code</p> <p>If it is set to 0 (Off Code), the IP phone will send anonymous rejection off code to the</p>		

Parameters	Permitted Values	Default
<p>server when you deactivate the anonymous call rejection feature.</p> <p>If it is set to 1 (On Code), the IP phone will send anonymous rejection on code to the server when you activate the anonymous call rejection feature.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIPT42G)</p> <p>X ranges from 1 to 6 (for SIPT41P/T27P)</p> <p>X ranges from 1 to 3 (for SIPT40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIPT21(P) E2)</p> <p>X is equal to 1 (for SIPT19(P) E2/CP860)</p> <p>Web User Interface:</p> <p>Account->Basic->Send Anonymous Rejection Code</p> <p>Phone User Interface:</p> <p>Menu->Features->Anonymous Call->Send Rejection Code</p>		
account.X.anonymous_reject_oncode	String within 32 characters	Blank
<p>Description:</p> <p>Configures the anonymous call rejection on code to activate the server-side anonymous call rejection feature for account X.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIPT42G)</p> <p>X ranges from 1 to 6 (for SIPT41P/T27P)</p> <p>X ranges from 1 to 3 (for SIPT40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIPT21(P) E2)</p> <p>X is equal to 1 (for SIPT19(P) E2/CP860)</p> <p>Example:</p> <p>account.1.anonymous_reject_oncode = *74</p> <p>Note: It works only if the value of the parameter "account.X.send_anonymous_rejection_code" is set to 1 (On Code).</p> <p>Web User Interface:</p> <p>Account->Basic->Send Anonymous Rejection Code->On Code</p> <p>Phone User Interface:</p> <p>Menu->Features->Anonymous Call->Reject On Code</p>		
account.X.anonymous_reject_offcode	String within 32 characters	Blank

Parameters	Permitted Values	Default
<p>Description:</p> <p>Configures the anonymous call rejection off code to deactivate the server-side anonymous call rejection feature for account X.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Example:</p> <p>account.1.anonymous_reject_offcode = *75</p> <p>Note: It works only if the value of the parameter "account.X.send_anonymous_rejection_code" is set to 0 (Off Code).</p> <p>Web User Interface:</p> <p>Account->Basic->Send Anonymous Rejection Code->Off Code</p> <p>Phone User Interface:</p> <p>Menu->Features->Anonymous Call->Reject Off Code</p>		

To configure anonymous call rejection via web user interface:

1. Click on **Account->Basic**.
2. Select the desired account from the pull-down list of **Account**.
3. Select the desired value from the pull-down list of **Local Anonymous Rejection**.
4. Select the desired value from the pull-down list of **Send Anonymous Rejection code**.
5. (Optional.) Enter the Send Anonymous Rejection on code in the **On Code** field.

- (Optional.) Enter the Send Anonymous Rejection off code in the **Off Code** field.

The screenshot shows the Yealink T236 web interface with the 'Account' tab selected. The 'Account' dropdown is set to 'Account 1'. The 'Local Anonymous Rejection' dropdown is set to 'On' and the 'Send Anonymous Rejection Code' dropdown is set to 'Off Code'. The 'On Code' field contains '*74' and the 'Off Code' field contains '*75'. A red box highlights the 'Local Anonymous Rejection' and 'Send Anonymous Rejection Code' sections. A 'NOTE' box on the right explains 'Anonymous Call' and 'Anonymous Call Rejection'.

- Click **Confirm** to accept the change.

To configure anonymous call rejection via phone user interface:

- Press **Menu->Features->Anonymous Call**.
- Press **◀** or **▶**, or the **Switch** soft key to select the desired line from the **Line ID** field.
- Press **▲** or **▼** to scroll to the **Anonymous Rejection** field.
- Press **◀** or **▶** to select **Enabled** from the **Anonymous Rejection** field.
- Press **▲** or **▼** to scroll to the **Send Rejection Code** field.
- (Optional.) Press **◀** or **▶** to select the desired value from the **Send Rejection Code** field.
- (Optional.) Enter the anonymous call rejection on code and off code respectively in the **Reject On Code** and **Reject Off Code** field.
- Press the **Save** soft key to accept the change or the **Back** soft key to cancel.

Do Not Disturb (DND)

DND allows IP phones to ignore incoming calls. DND feature can be configured on a phone or a per-line basis depending on the DND mode. Two DND modes:

- Phone** (default): DND feature is effective for the IP phone.
- Custom**: DND feature can be configured for each or all accounts.

A user can activate or deactivate DND using the DND key or DND soft key. The server-side DND feature disables the local DND and call forward settings. If the server-side DND feature is enabled on any of the IP phone's registrations, the other registrations are not affected. For more information on call forward, refer to [Call Forward](#) on page 359.

The DND on code and DND off code configured on IP phones are used to activate/deactivate the server-side DND feature. They may vary on different servers.

Return Message When DND

This feature defines the return code and the reason of the SIP response message for the rejected incoming call when DND is enabled on the IP phone. The caller's phone LCD screen displays the received return code.

DND Emergency

This feature allows users to receive the incoming calls from some authorized numbers even if the DND feature is enabled. This feature is disabled by default.

Procedure

DND can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure DND in the custom mode. Parameters: account.X.dnd.enable account.X.dnd.on_code account.X.dnd.off_code
	<y0000000000xx>.cfg	Configure the DND mode. Parameter: features.dnd_mode
		Configure DND in the phone mode. Parameters: features.dnd.enable features.dnd.on_code features.dnd.off_code
		Specify the authorized numbers when DND is enabled. Parameters: features.dnd.emergency_enable features.dnd.emergency_authorized_number

		<p>Specify the return code and the reason of the SIP response message when DND is enabled.</p> <p>Parameter:</p> <p>features.dnd_refuse_code</p>
		<p>Assign a DND key.</p> <p>Parameters:</p> <p>linekey.X.type/ programablekey.X.type/ expansion_module.X.key.Y.type linekey.X.label/ programablekey.X.label/ expansion_module.X.key.Y.label</p>
Local	Web User Interface	<p>Configure DND.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29 G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet? p=features-forward&q=load</p> <p>For SIP VP-T49G: http://<phoneIPAddress>/servlet? m=mod_data&p=features-forward d&q=load</p>

		<p>Specify the authorized numbers when DND is enabled.</p> <p>Specify the return code and the reason of the SIP response message when DND is enabled.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>http://<phoneIPAddress>/servlet?p=features-general&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load</p>
	Phone User Interface	<p>Assign a DND key.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>http://<phoneIPAddress>/servlet?p=dsskey&q=load&model=0</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet?m=mod_data&p=dsskey&q=load</p>
	Phone User Interface	<p>Configure DND.</p> <p>Assign a DND key.</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.dnd_mode	0 or 1	0
<p>Description:</p> <p>Configures the DND mode for the IP phone.</p> <p>0-Phone</p> <p>1-Custom</p>		

<p>If it is set to 0 (Phone), DND feature is effective for the IP phone.</p> <p>If it is set to 1 (Custom), you can configure DND feature for each account.</p> <p>Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>Features->Forward&DND->DND->Mode</p> <p>Phone User Interface:</p> <p>None</p>		
account.X.dnd.enable	0 or 1	0
<p>Description:</p> <p>Triggers DND feature to on or off for account X.</p> <p>0-Off</p> <p>1-On</p> <p>If it is set to 1 (On), the IP phone will reject incoming calls on account X.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>Note: It works only if the value of the parameter "features.dnd_mode" is set to 1 (Custom). It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>Features->Forward&DND->DND->DND Status</p> <p>Phone User Interface:</p> <p>Menu->Features->DND->AccountX->DND Enable.</p>		
account.X.dnd.on_code	String within 32 characters	Blank
<p>Description:</p> <p>Configures the DND on code to activate the server-side DND feature for account X. The IP phone will send the DND on code to the server when you activate DND feature for account X on the IP phone.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>Example:</p>		

<p>account.1.dnd.on_code = *73</p> <p>Note: It works only if the value of the parameter "features.dnd_mode" is set to 1 (Custom). It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>Features->Forward&DND->DND On Code</p> <p>Phone User Interface:</p> <p>Menu->Features->DND->AccountX->On Code</p>		
account.X.dnd.off_code	String within 32 characters	Blank
<p>Description:</p> <p>Configures the DND off code to deactivate the server-side DND feature for account X. The IP phone will send the DND off code to the server when you deactivate DND feature for account X on the IP phone.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>Example:</p> <p>account.1.dnd.off_code = *74</p> <p>Note: It works only if the value of the parameter "features.dnd_mode" is set to 1 (Custom). It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>Features->Forward&DND->DND Off Code</p> <p>Phone User Interface:</p> <p>Menu->Features->DND->AccountX->Off Code</p>		
features.dnd.enable	0 or 1	0
<p>Description:</p> <p>Triggers DND feature to on or off.</p> <p>0-Off</p> <p>1-On</p> <p>If it is set to 1 (On), the IP phone will reject incoming calls on all accounts.</p> <p>Note: For Yealink IP phones (except SIP-T19(P) E2 and CP860), it works only if the value of the parameter "features.dnd_model" is set to 0 (Phone).</p> <p>Web User Interface:</p> <p>Features->Forward&DND->DND->DND Status</p>		

Phone User Interface: Menu->Features->DND->DND Enable		
features.dnd.on_code	String within 32 characters	Blank
Description: Configures the DND on code to activate the server-side DND feature. The IP phone will send the DND on code to the server when you activate DND feature on the IP phone. Example: features.dnd.on_code = *71 Note: For Yealink IP phones (except SIP-T19(P) E2 and CP860), it works only if the value of the parameter "features.dnd_mode" is set to 0 (Phone). Web User Interface: Features->Forward&DND->DND->DND On Code Phone User Interface: Menu->Features->DND->On Code		
features.dnd.off_code	String within 32 characters	Blank
Description: Configures the DND off code to deactivate the server-side DND feature. The IP phone will send the DND off code to the server when you deactivate DND feature on the IP phone. Example: features.dnd.off_code = *72 Note: For Yealink IP phones (except SIP-T19(P) E2 and CP860), it works only if the value of the parameter "features.dnd_mode" is set to 0 (Phone). Web User Interface: Features->Forward&DND->DND->DND Off Code Phone User Interface: Menu->Features->DND->Off Code		
features.dnd.emergency_enable	0 or 1	0
Description: Enables or disables the IP phone to receive incoming calls from authorized numbers when DND feature is enabled. 0-Disabled 1-Enabled		

Web User Interface: Features->Forward&DND->DND->DND Emergency Phone User Interface: None		
features.dnd.emergency_authorized_number	String within 511 characters	Blank
Description: Configures the authorized numbers the IP phone can receive incoming calls from even if DND feature is enabled. Multiple numbers are separated by commas. Example: features.dnd.emergency_authorized_number = 123,124 Note: It works only if the value of the parameter "features.dnd.emergency_enable" is set to 1 (Enabled). Web User Interface: Features->Forward&DND->DND->DND Authorized Numbers Phone User Interface: None		
features.dnd_refuse_code	404, 480, 486 or 603	480
Description: Configures a return code and reason of SIP response messages when rejecting an incoming call by DND. A specific reason is displayed on the caller's phone LCD screen. 404-Not Found 480-Temporarily Unavailable 486-Busy Here 603-Denied If it is set to 486 (Busy Here), the caller's phone LCD screen will display the reason "Busy Here" when the callee enables DND. Web User Interface: Features->General Information->Return Code When DND Phone User Interface: None		

DND Key

For more information on how to configure the DSS Key, refer to [Appendix D: Configuring](#)

[DSS Key](#) on page 926.

Details of Configuration Parameters:

Parameter	Permitted Values	Default
linekey.X.type/ programablekey.X.type/ expansion_module.X.key.Y.type	5	Refer to the following content
<p>Description:</p> <p>Configures a DSS key as a DND key on the IP phone.</p> <p>The digit 5 stands for the key type DND.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G)</p> <p>X ranges from 1 to 27 (for SIPT46G/T29G)</p> <p>X ranges from 1 to 15 (for SIPT42G/T41P)</p> <p>X ranges from 1 to 21 (for SIPT27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIPT21(P) E2)</p> <p>For programable keys:</p> <p>X=1-4, 12-14 (for SIP VP-T49G)</p> <p>X=1-10, 12-14 (for SIPT48G/T46G)</p> <p>X=1-10, 13 (for SIPT42G/T41P/T40P)</p> <p>X=1-14 (for SIPT29G/T27P)</p> <p>X=1-10, 14 (for SIPT23P/T23G/T21(P) E2)</p> <p>X=1-9, 13, 14 (for SIPT19(P) E2)</p> <p>X=1-6, 9, 13 (for CP860)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Example:</p> <p>linekey.1.type = 5</p> <p>Default:</p> <p>For line keys:</p> <p>For SIP VP-T49G/SIPT48G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-29 is 0.</p> <p>For SIPT46G/T29G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-27</p>		

Parameter	Permitted Values	Default
<p>is 0.</p> <p>For SIP-T42G IP phones:</p> <p>The default value of the line key 1-12 is 15, and the default value of the line key 13-15 is 0.</p> <p>For SIP-T41P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-15 is 0.</p> <p>For SIP-T27P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-21 is 0.</p> <p>For SIP-T40P/T23P/T23G/T21(P) E2 IP phones:</p> <p>The default value is 15.</p> <p>For programable keys:</p> <p>For SIP VP-T49G IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIP-T48G/T46G IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p>		

Parameter	Permitted Values	Default
For SIP-T42G/T41P/T40P IP phones: When X=1, the default value is 28 (History). When X=2, the default value is 61 (Directory). When X=3, the default value is 5 (DND). When X=4, the default value is 30 (Menu). When X=5, the default value is 28 (History). When X=6, the default value is 61 (Directory). When X=7, the default value is 0 (NA). When X=8, the default value is 0 (NA). When X=9, the default value is 33 (Status). When X=10, the default value is 0 (NA). When X=13, the default value is 0 (NA).		
For SIP-T29G/T27P IP phones: When X=1, the default value is 28 (History). When X=2, the default value is 61 (Directory). When X=3, the default value is 5 (DND). When X=4, the default value is 30 (Menu). When X=5, the default value is 28 (History). When X=6, the default value is 61 (Directory). When X=7, the default value is 0 (NA). When X=8, the default value is 0 (NA). When X=9, the default value is 33 (Status). When X=10, the default value is 0 (NA). When X=11, the default value is 0 (NA). When X=12, the default value is 0 (NA). When X=13, the default value is 0 (NA). When X=14, the default value is 2 (Forward).		
For SIP-T23P/T23G/T21(P) E2 IP phones: When X=1, the default value is 28 (History). When X=2, the default value is 61 (Directory). When X=3, the default value is 5 (DND). When X=4, the default value is 30 (Menu). When X=5, the default value is 28 (History). When X=6, the default value is 61 (Directory). When X=7, the default value is 0 (NA).		

Parameter	Permitted Values	Default
<p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIP-T19(P) E2 IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For CP860 IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=13, the default value is 0 (NA).</p> <p>For ext keys:</p> <p>When Y=1, the default value is 37 (Switch).</p> <p>When Y= 2 to 20, 22 to 40, the default value is 0 (NA).</p> <p>Web User Interface:</p> <p>DSSKey->Line Key/Programable Key->Type</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Type</p>		
linekey.X.label/ programablekey.X.label/ expansion_module.X.key.Y.label	String within 99 characters	Blank

Parameter	Permitted Values	Default
<p>Description:</p> <p>(Optional.) Configures the label displayed on the LCD screen for each DSS key.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G)</p> <p>X ranges from 1 to 27 (for SIPT46G/T29G)</p> <p>X ranges from 1 to 15 (for SIPT42G/T41P)</p> <p>X ranges from 1 to 21 (for SIPT27P)</p> <p>X ranges from 1 to 3 (for SIPT40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIPT21(P) E2)</p> <p>For programmable keys:</p> <p>X ranges from 1 to 4.</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Web User Interface:</p> <p>DSSKey->Line Key/Programable Key->Label</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Label</p>		

To configure a DND key via web user interface:

1. Click on **DSSKey->Line Key** (or **Programable Key**).
2. In the desired DSS key field, select **DND** from the pull-down list of **Type**.
3. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.

The screenshot shows the Yealink T236 web interface. The top navigation bar includes 'Status', 'Account', 'Network', 'DSSKey', 'Features', 'Settings', 'Directory', and 'Security'. The 'DSSKey' tab is selected. On the left, 'Line Key' is highlighted under 'Programable Key'. The main table has columns: Key, Type, Value, Label, Line, and Extension. The 'Line Key2' row is highlighted with a red box, showing 'DND' in the Type column and 'N/A' in the Label column. Below the table are 'Confirm' and 'Cancel' buttons. A 'NOTE' box on the right states: 'Line Keys: Line keys allow you to quickly access features such as recall and voice mail. You can click here to get more guides.'

4. Click **Confirm** to accept the change.

To configure DND feature via web user interface:

1. Click on **Features->Forward&DND**.
2. In the **DND** block, mark the desired radio box in the **Mode** field.

- a) If you mark the **Phone** radio box:
 - 1) Mark the desired radio box in the **DND Status** field.
 - 2) (Optional.) Enter the DND on code in the **DND On Code** field.
 - 3) (Optional.) Enter the DND off code in the **DND Off Code** field.

The screenshot shows the Yealink T236 web interface with the 'Features' tab selected. The 'Forward' section is expanded, showing settings for Forward Emergency, Forward Authorized Numbers, Mode (Phone/Custom), Account (1011), Always Forward, Busy Forward, and No Answer Forward. The 'DND' section is also expanded, showing settings for DND Emergency, DND Authorized Numbers, Mode (Phone/Custom), Account (1011), DND Status (On/Off), DND On Code, and DND Off Code. A red box highlights the 'DND Status' field, which has the 'On' radio button selected. A 'NOTE' section on the right provides information about Call Forward and DND features.

- b) If you mark the **Custom** radio box:
 - 1) Select the desired account from the pull-down list of **Account**.
 - 2) Mark the desired radio box in the **DND Status** field.
 - 3) (Optional.) Enter the DND on code in the **DND On Code** field.

- 4) (Optional.) Enter the DND off code in the **DND Off Code** field.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected, and the 'Forward&DND' section is expanded. The 'Forward' section is active, showing various forwarding options. The 'DND' section is highlighted with a red box, indicating the current configuration area. The 'DND' section includes the following fields:

- DND Emergency:** Disabled (dropdown menu)
- DND Authorized Numbers:** (text input field)
- Mode:** Custom (radio button selected)
- Account:** 1011 (dropdown menu)
- DND Status:** Off (radio button selected)
- DND On Code:** (text input field)
- DND Off Code:** (text input field)

A 'NOTE' section on the right provides additional information:

- Call Forward:** It allows users to redirect an incoming call to a third party.
- Call Forward Mode:** Phone: Call forward feature is effective for the IP phone. Custom: Call forward feature can be configured for each or all accounts.
- Do Not Disturb (DND):** It allows IP phones to ignore incoming calls.
- DND Mode:** Phone: DND feature is effective for the IP phone. Custom: DND feature can be configured for each or all accounts.

At the bottom of the page, there are 'Confirm' and 'Cancel' buttons.

3. Click **Confirm** to accept the change.

To specify the authorized numbers when DND is enabled via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **DND Emergency**.
3. Enter the desired value in the **DND Authorized Numbers** field.

Multiple numbers are separated by commas.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected. Under 'Forward&DND', the 'Forward' section is expanded. The 'DND' section is highlighted with a red box. The 'DND Emergency' is set to 'Enabled' and 'DND Authorized Numbers' is set to '123,124'. The 'Mode' is set to 'Phone'. The 'Account' is set to '1011'. The 'DND Status' is set to 'On'. The 'DND On Code' and 'DND Off Code' are empty.

4. Click **Confirm** to accept the change.





To specify the return code and the reason when DND is enabled via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Return Code When DND**.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected. Under 'Forward&DND', the 'General Information' section is expanded. The 'Return Code When DND' is set to '480 (Temporarily Unavailable)'. The 'Return Code When Refuse' is set to '486 (Busy Here)'. The 'Call Completion' is set to 'Disabled'. The 'Feature Key Synchronization' is set to 'Disabled'. The 'Time-Out for Dial-Now Rule' is set to '1'.

- Click **Confirm** to accept the change.





To configure a DND key via phone user interface:

- Press **Menu->Features->DSS Keys**.
- Select the desired DSS key.
- Press  or  , or the **Switch** soft key to select **Key Event** from the **Type** field.
- Press  or  , or the **Switch** soft key to select **DND** from the **Key Type** field.
- (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.
- Press the **Save** soft key to accept the change.

To configure DND in the phone mode via phone user interface:

- Press the **DND** soft key or the DND key when the IP phone is idle.

To configure DND in the custom mode for a specific account via phone user interface:

- Press the **DND** soft key or the DND key when the IP phone is idle.
The LCD screen displays a list of accounts registered on the IP phone.
- Press  or  to select the desired account.
- Press  or  to select **Enabled** to activate DND.
You can configure DND in the custom mode for all accounts by pressing the **All On** soft key.
- Press the **Save** soft key to accept the change.

Busy Tone Delay

Busy tone is audible to the other party, indicating that the call connection has been broken when one party releases a call. Busy tone delay can define a period of time during which the busy tone is audible.

Procedure

Busy tone delay can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure busy tone delay. Parameter: features.busy_tone_delay
Local	Web User Interface	Configure busy tone delay. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T2 9G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet

		<p>?p=features-general&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet ?m=mod_data&p=features-general&q=load</p>
--	--	--

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
features.busy_tone_delay	0, 3 or 5	0
<p>Description:</p> <p>Configures the duration time (in seconds) for the busy tone.</p> <p>When one party releases the call, a busy tone is audible to the other party indicating that the call connection breaks.</p> <p>0-0s</p> <p>3-3s</p> <p>5-5s</p> <p>If it is set to 3 (3s), a busy tone is audible for 3 seconds on the IP phone.</p> <p>Web User Interface:</p> <p>Features->General Information->Busy Tone Delay (Seconds)</p> <p>Phone User Interface:</p> <p>None</p>		

To configure busy tone delay via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Busy Tone Delay (Seconds)**.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected, and the 'General Information' section is displayed. The 'Busy Tone Delay (Seconds)' parameter is highlighted with a red box, showing a value of 0. The interface includes a sidebar with navigation links like Forward&DND, General Information, Audio, Intercom, Transfer, Call Pickup, Remote Control, Phone Lock, ACD, SMS, and Action URL. A 'NOTE' section on the right provides details about Call Waiting, Auto Redial, Key As Send, Hotline, and Call Completion.

3. Click **Confirm** to accept the change.

Return Code When Refuse

Return code when refuse defines the return code and reason of the SIP response message for the refused call. The caller's phone LCD screen displays the reason according to the received return code. Available return codes and reasons are:

- 404 (Not Found)
- 480 (Temporarily Unavailable)
- 486 (Busy Here)
- 603 (Decline)

Procedure

Return code for refused call can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Specify the return code and the reason of the SIP response message when refusing a call. Parameter: features.normal_refuse_code
Local	Web User Interface	Specify the return code and the reason of the SIP response message when refusing a call. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=features-general&q=load">http://<phoneIPAddress>/servlet?p=features-general&q=load For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
features.normal_refuse_code	404, 480, 486 or 603	486

Parameter	Permitted Values	Default
<p>Description:</p> <p>Configures a return code and reason of SIP response messages when the IP phone rejects an incoming call. A specific reason is displayed on the caller's phone LCD screen.</p> <p>404-Not Found</p> <p>480-Temporarily Unavailable</p> <p>486-Busy Here</p> <p>603-Dencline</p> <p>If it is set to 486 (Busy Here), the caller's phone LCD screen will display the message "Busy Here" when the callee rejects the incoming call.</p> <p>Web User Interface:</p> <p>Features->General Information->Return Code When Refuse</p> <p>Phone User Interface:</p> <p>None</p>		

To specify the return code and the reason when refusing a call via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Return Code When Refuse**.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected, and the 'General Information' sub-tab is active. In the 'General Information' section, the 'Return Code When Refuse' dropdown menu is highlighted with a red box, and '486 (Busy Here)' is selected. Other settings visible include 'Call Waiting' (Enabled), 'Auto Redial' (Disabled), 'Auto Redial Interval' (10), 'Auto Redial Times' (10), 'Key As Send' (#), 'Reserve # in User Name' (Enabled), 'Hotline Number', 'Hotline Delay' (4), 'Busy Tone Delay' (0), 'Return Code When DND' (480 (Temporarily Unavailable)), 'Call Completion' (Disabled), 'Feature Key Synchronization' (Disabled), and 'Time-Out for Dial-Now Rule' (1). On the right side, there is a 'NOTE' section with descriptions for 'Call Waiting', 'Auto Redial', 'Key As Send', 'Hotline', and 'Call Completion'.

3. Click **Confirm** to accept the change.

Early Media

Early media refers to media (e.g., audio and video) played to the caller before a SIP

call is actually established. Current implementation supports early media through the 183 message. When the caller receives a 183 message with SDP before the call is established, a media channel is established. This channel is used to provide the early media stream for the caller.

180 Ring Workaround

180 ring workaround defines whether to deal with the 180 message received after the 183 message. When the caller receives a 183 message, it suppresses any local ringback tone and begins to play the media received. 180 ring workaround allows IP phones to resume and play the local ringback tone upon a subsequent 180 message received.

Procedure

180 ring workaround can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure 180 ring workaround. Parameter: phone_setting.is_deal180
Local	Web User Interface	Configure 180 ring workaround. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=features-general&q=load">http://<phoneIPAddress>/servlet?p=features-general&q=load For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
phone_setting.is_deal180	0 or 1	1
Description: Enables or disables the IP phone to deal with the 180 SIP message received after the 183 SIP message. 0-Disabled		

Parameter	Permitted Values	Default
1-Enabled		
If it is set to 1 (Enabled), the IP phone will resume and play the local ringback tone upon a subsequent 180 message received.		
Web User Interface:		
Features->General Information->180 Ring Workaround		
Phone User Interface:		
None		

To configure 180 ring workaround via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **180 Ring Workaround**.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected, and the 'General Information' section is expanded. The '180 Ring Workaround' option is highlighted with a red box and is set to 'Enabled'. Other settings visible include 'Call Waiting' (Enabled), 'Call Waiting On Code' (empty), 'Call Waiting Off Code' (empty), 'Auto Redial' (Disabled), 'Auto Redial Interval (1~300s)' (10), 'Auto Redial Times (1~300)' (10), 'Logon Wizard' (Enabled), 'PswPrefix' (12), 'PswLength' (3), 'PswDial' (Enabled), and 'Auto Linekeys' (Disabled). A 'NOTE' section on the right provides details about 'Call Waiting', 'Auto Redial', 'Key As Send', 'Hotline', and 'Call Completion'.

3. Click **Confirm** to accept the change.

Use Outbound Proxy in Dialog

An outbound proxy server can receive all initiating request messages and route them to the designated destination. If the IP phone is configured to use an outbound proxy server within a dialog, all SIP request messages from the IP phone will be sent to the outbound proxy server forcibly.

Note

To use this feature, make sure the outbound server has been correctly configured on the IP phone. For more information on how to configure outbound server, refer to [Account Registration](#) on page 150.

Procedure

Use outbound proxy in dialog can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Specify whether to use outbound proxy in a dialog. Parameter: sip.use_out_bound_in_dialog
Local	Web User Interface	Specify whether to use outbound proxy in a dialog. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet? p=features-general&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet? m=mod_data&p=features-general&q=load

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
sip.use_out_bound_in_dialog	0 or 1	1
Description: Enables or disables the IP phone to send all SIP requests to the outbound proxy server forcibly in a dialog. 0-Disabled 1-Enabled If it is set to 0 (Disabled), only the new SIP request messages from the IP phone will be sent to the outbound proxy server in a dialog. If it is set to 1 (Enabled), all the SIP request messages from the IP phone will be forced to send to the outbound proxy server in a dialog. Note: It works only if the value of the parameter "account.X.outbound_proxy_enable" is set to 1 (Enabled) and the outbound server address has been correctly configured on the phone. Web User Interface:		

Parameter	Permitted Values	Default
Features->General Information->Use Outbound Proxy In Dialog		
Phone User Interface:		
None		

To configure use outbound proxy in dialog via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Use Outbound Proxy In Dialog**.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected, and the 'General Information' sub-tab is active. The 'Use Outbound Proxy In Dialog' option is highlighted with a red box and is set to 'Enabled'. Other settings visible include Call Waiting (Enabled), Call Waiting On Code, Call Waiting Off Code, Auto Redial (Disabled), Auto Redial Interval (10), Auto Redial Times (10), 180 Ring Workaround (Enabled), Logon Wizard (Enabled), PswPrefix (12), PswLength (3), and Auto Linekeys (Disabled). A 'NOTE' section on the right provides details for Call Waiting, Auto Redial, Key As Send, Hotline, and Call Completion.

3. Click **Confirm** to accept the change.

SIP Session Timer

SIP session timers T1, T2 and T4 are SIP transaction layer timers defined in [RFC 3261](#). These session timers are configurable on IP phones.

Timer T1

Timer T1 is an estimate of the Round Trip Time (RTT) of transactions between a SIP client and SIP server.

Timer T2

Timer T2 represents the maximum retransmitting time of any SIP request message. The re-transmitting and doubling of T1 will continue until the retransmitting time reaches the T2 value.

Example:

The user registers a SIP account for the IP phone and then set the value of Timer T1, Timer T2 respectively (Timer T1: 0.5, Timer T2: 4). The SIP registration request message

will be re-transmitted between the IP phone and SIP server. The re-transmitting and doubling of Timer T1 (0.5) will continue until the retransmitting time reaches the Timer T2 (4). The total registration request retry time will be less than 64 times of T1 ($64 * 0.5 = 32$). The re-transmitting interval in sequence is: 0.5s, 1s, 2s, 4s, 4s, 4s, 4s, 4s, 4s and 4s.

Timer T4

Timer T4 represents the time the network will take to clear messages between the SIP client and server.

Procedure

SIP session timer can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure SIP session timer. Parameters: sip.timer_t1 sip.timer_t2 sip.timer_t4
Local	Web User Interface	Configure SIP session timer. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=settings-sip&q=load">http://<phoneIPAddress>/servlet?p=settings-sip&q=load For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=settings-sip&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=settings-sip&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
sip.timer_t1	Float from 0.5 to10	0.5

Parameters	Permitted Values	Default
Description: Configures the SIP session timer T1 (in seconds). T1 is an estimate of the Round Trip Time (RTT) of transactions between a SIP client and SIP server. Web User Interface: Settings->SIP->SIP Session Timer T1 (0.5~10s) Phone User Interface: None		
sip.timer_t2	Float from 2 to 40	4
Description: Configures the SIP session timer T2 (in seconds). Timer T2 represents the maximum retransmitting time of any SIP request message. Web User Interface: Settings->SIP->SIP Session Timer T2 (2~40s) Phone User Interface: None		
sip.timer_t4	Float from 2.5 to 60	5
Description: Configures the SIP session timer of T4 (in seconds). T4 represents the maximum duration a message will remain in the network. Web User Interface: Settings->SIP->SIP Session Timer T4 (2.5~60s) Phone User Interface: None		

To configure session timer via web user interface:

1. Click on **Settings->SIP**.
2. Enter the desired value in the **SIP Session Timer T1 (0.5~10s)** field.
The default value is 0.5.
3. Enter the desired value in the **SIP Session Timer T2 (2~40s)** field.
The default value is 4.
4. Enter the desired value in the **SIP Session Timer T4 (2.5~60s)** field.

The default value is 5.

The screenshot shows the Yealink T236 web interface. The 'SIP Config' section is active, displaying the following settings:

Parameter	Value
SIP Session Timer T1 (0.5~10s)	0.5
SIP Session Timer T2 (2~40s)	4
SIP Session Timer T4 (2.5~60s)	5
Local SIP Port	5060
TLS SIP Port	5061

Buttons: Confirm, Cancel

NOTE
SIP Session Timers
 SIP session timers T1, T2 and T4 are SIP transaction layer timers defined in RFC 3261.
 Timer T1 is an estimate of the Round Trip Time (RTT) of transactions between a SIP client and SIP server.
 Timer T2 represents the maximum retransmitting time of any SIP request message.
 Timer T4 represents the time the network will take to clear messages between the SIP client and server.
 ⓘ You can click here to get more guides.

- Click **Confirm** to accept the change.

Session Timer

Session timer allows a periodic refresh of SIP sessions through an UPDATE request, to determine whether a SIP session is still active. Session timer is specified in [RFC 4028](#). IP phones support two refresher modes: UAC and UAS. Whether the endpoint functions as a UAC or a UAS depends on the UA that initiates the SIP request. If the initiator is configured as UAC, the other client or the SIP server will function as a UAS. If the initiator is configured as UAS, the other client or the SIP server will function as a UAC. The session expiration is negotiated via the Session-Expires header in the INVITE message. The negotiated refresher is always the UAC and it will send an UPDATE or request at the negotiated session expiration. The value "refresher=uac" included in the UPDATE message means that the UAC performs the refresh.

Example of UPDATE message (UAC mode):

```
UPDATE sip:1058@10.10.20.34:5060 SIP/2.0
Via: SIP/2.0/UDP 10.10.20.32:5060;branch=z9hG4bK2104991394
From: "10111" <sip:10111@10.2.1.48:5060>;tag=2170397024
To: <sip:1058@10.2.1.48:5060>;tag=200382096
Call-ID: 4_1556494084@10.10.20.32
CSeq: 2 UPDATE
Contact: <sip:10111@10.10.20.32:5060>
Max-Forwards: 70
User-Agent: Yealink SIPT23G 44.80.0.60
Session-Expires: 90;refresher=uac
Supported: timer
```

Content-Length: 0

Procedure

Session timer can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure session timer. Parameters: account.X.session_timer.enable account.X.session_timer.expires account.X.session_timer.refresher
Local	Web User Interface	Configure session timer. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29 G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p =account-adv&q=load&acc=0 For SIP VP-T49G: http://<phoneIPAddress>/servlet? m=mod_data&p=account-adv&q =load&acc=0

Details of Configuration Parameters:

Parameters	Permitted Values	Default
account.X.session_timer.enable	0 or 1	0
Description: Enables or disables the session timer for account X. 0-Disabled 1-Enabled If it is set to 1 (Enabled), IP phone will send periodic UPDATE requests to refresh the session during a call. X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2)		

Parameters	Permitted Values	Default
X is equal to 1 (for SIP-T19(P) E2/CP860) Web User Interface: Account->Advanced->Session Timer Phone User Interface: None		
account.X.session_timer.expires	Integer from 30 to 7200	1800
Description: Configures the interval (in seconds) for refreshing the SIP session during a call for account X. For example, an UPDATE will be sent after 50% of its value has elapsed. If it is set to 1800 (1800s), the IP phone will refresh the session during a call before 900 seconds. X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Example: account.1.session_timer.expires = 1800 Note: It works only if the value of the parameter "account.X.session_timer.enable" is set to 1 (Enabled). Web User Interface: Account->Advanced->Session Expires(30~7200s) Phone User Interface: None		
account.X.session_timer.refresher	0 or 1	0
Description: Configures the function of the endpoint who initiates the SIP request for account X. 0-UAC 1-UAS X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P)		

Parameters	Permitted Values	Default
<p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Note: It works only if the value of the parameter "account.X.session_timer.enable" is set to 1 (Enabled).</p> <p>Web User Interface:</p> <p>Account->Advanced->Session Refresher</p> <p>Phone User Interface:</p> <p>None</p>		

To configure session timer via web user interface:

1. Click on **Account->Advanced**.
2. Select the desired account from the pull-down list of **Account**.
3. Select the desired value from the pull-down list of **Session Timer**.
4. Enter the desired time interval in the **Session Expires(30~7200s)** field.
5. Select the desired refresher from the pull-down list of **Session Refresher**.

The screenshot shows the Yealink T236 web interface. The 'Account' tab is selected, and the 'Advanced' sub-tab is active. The 'Session Timer' section is highlighted with a red box. The 'Session Timer' is set to 'Enabled', 'Session Expires(30~7200s)' is set to '1800', and 'Session Refresher' is set to 'UAC'. A 'NOTE' section on the right provides additional information about DTMF, Session Timer, Busy Lamp Field/BLF List, Shared Call Appearance (SCA)/ Bridge Line Appearance (BLA), and Network Conference.

6. Click **Confirm** to accept the change.

Call Hold

Call hold provides a service of placing an active call on hold. When a call is placed on hold, the IP phones send an INVITE request with HOLD SDP to request remote parties to

stop sending media and to inform them that they are being held. IP phones support two call hold methods, one is RFC 3264, which sets the “a” (media attribute) in the SDP to sendonly, recvonly or inactive (e.g., a=sendonly). The other is RFC 2543, which sets the “c” (connection addresses for the media streams) in the SDP to zero (e.g., c=0.0.0.0). Call hold tone allows IP phones to play a warning tone at regular intervals when there is a call on hold. The warning tone is played through the speakerphone.

Procedure

Call hold can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the call hold tone and call hold tone delay. Parameters: features.play_hold_tone.enable features.play_hold_tone.delay
		Specify whether RFC 2543 (c=0.0.0.0) outgoing hold signaling is used. Parameter: sip.rfc2543_hold
Local	Web User Interface	Configure the call hold tone and call hold tone delay. Specify whether RFC 2543 (c=0.0.0.0) outgoing hold signaling is used. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=features-general&q=load">http://<phoneIPAddress>/servlet?p=features-general&q=load For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.play_hold_tone.enable	0 or 1	1
Description: Enables or disables the IP phone to play a warning tone when there is a call on hold. 0 -Disabled 1 -Enabled Web User Interface: Features->General Information->Play Hold Tone Phone User Interface: None		
features.play_hold_tone.delay	Integer from 3 to 3600	30
Description: Configures the interval (in seconds) at which the IP phone play a warning tone when there is a call on hold. If it is set to 30 (30s), the IP phone will play a warning tone every 30 seconds when there is a call on hold. Note: It works only if the value of the parameter "features.play_hold_tone.enable" is set to 1 (Enabled). Web User Interface: Features->General Information->Play Hold Tone Delay Phone User Interface: None		
sip.rfc2543_hold	0 or 1	0
Description: Enables or disables the IP phone to use RFC 2543 (c=0.0.0.0) outgoing hold signaling. 0 -Disabled 1 -Enabled If it is set to 0 (Disabled), SDP media direction attributes (such as a=sendonly) per RFC 3264 is used when placing a call on hold. If it is set to 1 (Enabled), SDP media connection address c=0.0.0.0 per RFC 2543 is used when placing a call on hold.		

Parameters	Permitted Values	Default
Web User Interface: Features->General Information->RFC 2543 Hold Phone User Interface: None		

To configure call hold tone and call hold tone delay via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Play Hold Tone**.
3. Enter the desired time in the **Play Hold Tone Delay** field.

The screenshot displays the Yealink T236 web interface. The top navigation bar includes 'Status', 'Account', 'Network', 'DSSKey', 'Features', 'Settings', 'Directory', and 'Security'. The 'Features' tab is selected, leading to the 'General Information' configuration page. On the left, a sidebar lists various features: Forward&DND, General Information, Audio, Intercom, Transfer, Call Pickup, Remote Control, Phone Lock, ACD, SMS, Action URL, Power LED, and Notification Popups. The 'General Information' section contains several settings: Call Waiting (Enabled), Call Waiting On Code, Call Waiting Off Code, Auto Redial (Disabled), Auto Redial Interval (1~300s) (10), Auto Redial Times (1~300) (10), Play Hold Tone (Enabled), Play Hold Tone Delay (30), Allow Mute (Enabled), Dual-Headset (Disabled), Auto-Answer Delay(1~4s) (1), and Auto Linekeys (Disabled). The 'Play Hold Tone' dropdown and the 'Play Hold Tone Delay' text field are highlighted with a red rectangle. At the bottom of the configuration area are 'Confirm' and 'Cancel' buttons. On the right, a 'NOTE' section provides additional information about various features like Call Waiting, Auto Redial, Key As Send, Hotline, and Call Completion.

4. Click **Confirm** to accept the change.

To configure call hold method via web user interface:

1. Click on **Features->General Information**.

2. Select the desired value from the pull-down list of **RFC 2543 Hold**.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected. In the 'General Information' section, the 'RFC 2543 Hold' option is highlighted with a red box and is set to 'Enabled'. Other options include 'Call Waiting' (Enabled), 'Auto Redial' (Disabled), 'Time-Out for Dial-Now Rule' (1), 'Use Outbound Proxy In Dialog' (Enabled), 'Dual-Headset' (Disabled), 'Auto-Answer Delay(1~4s)' (1), and 'Auto Linekeys' (Disabled). A 'NOTE' section on the right provides details about various features: Call Waiting, Auto Redial, Key As Send, Hotline, and Call Completion.

3. Click **Confirm** to accept the change.

Music on Hold

Music on Hold (MoH) is the business practice of playing recorded music to fill the silence that would be heard by the party who has been placed on hold. To use this feature, specify a SIP URI pointing to a MoH server account. When a call is placed on hold, the IP phone will send an INVITE message to the specified MoH server account according to the SIP URI. The MoH server account automatically responds to the INVITE message and immediately plays audio from some source located anywhere (LAN, Internet) to the held party.

Note

Music on Hold is not available on all servers. It is no need to specify the SIP URI if the MoH feature is enabled by default on the server and the server can play audio to the held party. For more information, contact your server administrator.

Procedure

Music on hold can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure music on hold on a per-line basis. Parameter: account.X.music_server_uri
		Configure the way on how the IP phone processes music on hold when placing an active call on

		hold. Parameter: account.X.music_on_hold_type
Local	Web User Interface	<p>Configure music on hold on a per-line basis.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet? p=account-adv&q=load&acc=0</p> <p>For SIP VP-T49G: http://<phoneIPAddress>/servlet? m=mod_data&p=account-adv &q=load&acc=0</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
account.X.music_server_uri	SIP URI within 256 characters	Blank
<p>Description:</p> <p>Configures the address of the Music On Hold server for account X.</p> <p>Examples for valid values: <10.1.3.165>, 10.1.3.165, sip:moh@sip.com, <sip:moh@sip.com>, <yealink.com> or yealink.com.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Example:</p> <p>account.1.music_server_uri = sip:moh@sip.com</p> <p>Note: The DNS query in this parameter only supports A query.</p> <p>Web User Interface:</p> <p>Account->Advanced->Music Server URI</p>		

Parameters	Permitted Values	Default
Phone User Interface: None		
account.X.music_on_hold_type	0 or 1	0
Description: Configures the way to process Music On Hold when placing an active call on hold for account X. 0 -Calling the Music On Hold server before holding 1 -Calling the Music On Hold server after holding X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Web User Interface: None Phone User Interface: None		

To configure MoH via web user interface:

1. Click on **Account->Advanced**.
2. Select the desired account from the pull-down list of **Account**.

3. Enter the SIP URI (e.g., sip:moh@sip.com) in the **Music Server URI** field.

The screenshot shows the Yealink T23G web interface. The 'Account' tab is selected, and the 'Account 1' configuration page is displayed. The 'Music Server URI' field is highlighted with a red box and contains the value 'sip:moh@sip.com'. Other fields include 'Keep Alive Type' (Default), 'Keep Alive Interval(Seconds)' (30), 'RPort' (Disabled), 'Subscribe Period(Seconds)' (1800), 'Early Media' (Disabled), 'SIP Server Type' (Default), 'Directed Call Pickup Code' (*97), 'Group Call Pickup Code' (*98), 'Distinctive Ring Tones' (Enabled), 'Unregister When Reboot' (Enabled), 'Out Dialog BLF' (Enabled), 'VQ RTPC-XR Collector name' (collector), 'VQ RTPC-XR Collector address' (10.2.1.98), and 'VQ RTPC-XR Collector port' (5060). A 'NOTE' section on the right provides additional information about various features.

4. Click **Confirm** to accept the change.

Call Forward

Call forward allows users to redirect an incoming call to a third party. IP phones redirect an incoming INVITE message by responding with a 302 Moved Temporarily message, which contains a Contact header with a new URI that should be tried. Three types of call forward:

- **Always Forward** -- Forward the incoming call immediately.
- **Busy Forward** -- Forward the incoming call when the IP phone or the specified account is busy.
- **No Answer Forward** -- Forward the incoming call after a period of ring time.

Call forward can be configured on a phone or a per-line basis depending on the call forward mode. The following describes the call forward modes:

- **Phone** (default): Call forward feature is effective for the IP phone.
- **Custom**: Call forward feature can be configured for each or all accounts.

The server-side call forward settings disable the local call forward settings. If the server-side call forward feature is enabled on any of the IP phone's registrations, the other registrations are not affected. DND activated on the IP phone disables the local no answer forward settings.

The call forward on code and call forward off code configured on IP phones are used to activate/deactivate the server-side call forward feature. They may vary on different

servers.

Diversion/History-Info

IP phones support the redirected call information sent by the SIP server with Diversion header, per draft-levy-sip-diversion-08, or History-info header, per RFC 4244. The Diversion/History-info header is used to inform the IP phone of a call's history. For example, when a phone has been set to enable call forward, the Diversion/History-info header allows the receiving phone to indicate who the call was from, and from which phone number it was forwarded.

Forward International

Forward international allows users to forward an incoming call to an international telephone number (the prefix is 00). This feature is enabled by default.

Forward Emergency

Forward emergency allows the incoming calls from some authorized numbers not to be forwarded when the call forward feature is enabled. The incoming call will not be logged in the Forwarded Calls list. This feature is disabled by default.

Procedure

Call forward can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	<p>Configure call forward in custom mode.</p> <p>Parameters:</p> <p>account.X.always_fwd.enable account.X.always_fwd.target account.X.always_fwd.on_code account.X.always_fwd.off_code account.X.busy_fwd.enable account.X.busy_fwd.target account.X.busy_fwd.on_code account.X.busy_fwd.off_code account.X.timeout_fwd.enable account.X.timeout_fwd.target account.X.timeout_fwd.timeout account.X.timeout_fwd.on_code account.X.timeout_fwd.off_code</p>
---------------------------	-----------	---

	<y0000000000xx>.cfg	Specify the authorized numbers when call forward is enabled. Parameters: features.forward.emergency.enable features.forward.emergency.authorized_number
		Configure the call forward mode. Parameter: features.fwd_mode
		Configure call forward in phone mode. Parameters: forward.always.enable forward.always.target forward.always.on_code forward.always.off_code forward.busy.enable forward.busy.target forward.busy.on_code forward.busy.off_code forward.no_answer.enable forward.no_answer.target forward.no_answer.timeout forward.no_answer.on_code forward.no_answer.off_code
		Configure diversion/history-info feature. Parameter: features.fwd_diversion_enable
		Configure forward international. Parameter: forward.international.enable

Local	Web User Interface	<p>Specify the authorized numbers when call forward is enabled.</p> <p>Configure call forward.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p><a href="http://<phoneIPAddress>/servlet?p=features-forward&q=load">http://<phoneIPAddress>/servlet?p=features-forward&q=load</p> <p>For SIP VP-T49G:</p> <p><a href="http://<phoneIPAddress>/servlet?m=mod_data&p=features-forward&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=features-forward&q=load</p>
		<p>Configure diversion/history-info feature.</p> <p>Configure forward international.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p><a href="http://<phoneIPAddress>/servlet?p=features-general&q=load">http://<phoneIPAddress>/servlet?p=features-general&q=load</p> <p>For SIP VP-T49G:</p> <p><a href="http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load</p>
	Phone User Interface	<p>Configure call forward.</p> <p>Configure forward international.</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.fwd_mode	0 or 1	0
<p>Description:</p> <p>Configures the call forward mode for the IP phone.</p> <p>0-Phone</p>		

Parameters	Permitted Values	Default
1-Custom If it is set to 0 (Phone), call forward feature is effective for the IP phone. If it is set to 1 (Custom), you can configure call forward feature for each account. Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones. Web User Interface: Features->Forward&DND->Forward->Mode Phone User Interface: None		
account.X.always_fwd.enable	0 or 1	0
Description: Triggers always forward feature to on or off for account X. 0-Off 1-On If it is set to 1 (On), incoming calls to the account X are forwarded to the destination number immediately. X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIPT42G) X ranges from 1 to 6 (for SIPT41P/T27P) X ranges from 1 to 3 (for SIPT40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) Note: It works only if the value of the parameter "features.fwd_mode" is set to 1 (Custom). It is not applicable to SIP-T19(P) E2 and CP860 IP phones. Web User Interface: Features->Forward&DND->Forward->Always Forward->On/Off Phone User Interface: Menu->Features->Call Forward->Always Forward->Always Forward		
account.X.always_fwd.target	String within 32 characters	Blank
Description: Configures the destination number of the always forward for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIPT42G) X ranges from 1 to 6 (for SIPT41P/T27P) X ranges from 1 to 3 (for SIPT40P/T23P/T23G)		

Parameters	Permitted Values	Default
<p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>Note: It works only if the value of the parameter "features.fwd_mode" is set to 1 (Custom). It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Example:</p> <p>account.1.always_fwd.target = 1003</p> <p>Web User Interface:</p> <p>Features->Forward&DND->Forward->Always Forward->Target</p> <p>Phone User Interface:</p> <p>Menu->Features->Call Forward->Always Forward->Forward to</p>		
account.X.always_fwd.on_code	String within 32 characters	Blank
<p>Description:</p> <p>Configures the always forward on code to activate the server-side always forward feature for account X. The IP phone will send the always forward on code and the pre-configured destination number to the server when you activate always forward feature for account X on the IP phone.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>Example:</p> <p>account.1.always_fwd.on_code = *72</p> <p>Note: It works only if the value of the parameter "features.fwd_mode" is set to 1 (Custom). It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>Features->Forward&DND->Forward->Always Forward->On Code</p> <p>Phone User Interface:</p> <p>Menu->Features->Call Forward->Always Forward->On Code</p>		
account.X.always_fwd.off_code	String within 32 characters	Blank
<p>Description:</p> <p>Configures the always forward off code to deactivate the server-side always forward feature for account X. The IP phone will send the always forward off code to the server when you deactivate always forward feature for account X on the IP</p>		

Parameters	Permitted Values	Default
<p>phone.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>Example:</p> <p>account.1.always_fwd.off_code = *73</p> <p>Note: It works only if the value of the parameter "features.fwd_mode" is set to 1 (Custom). It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>Features->Forward&DND->Forward->Always Forward->Off Code</p> <p>Phone User Interface:</p> <p>Menu->Features->Call Forward->Always Forward->Off Code</p>		
account.X.busy_fwd.enable	0 or 1	0
<p>Description:</p> <p>Triggers busy forward feature to on or off for account X.</p> <p>0-Off</p> <p>1-On</p> <p>If it is set to 1 (On), incoming calls to the account X are forwarded to the destination number when the callee is busy.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>Note: It works only if the value of the parameter "features.fwd_mode" is set to 1 (Custom). It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>Features->Forward&DND->Forward->Busy Forward->On/Off</p> <p>Phone User Interface:</p> <p>Menu->Features->Call Forward->Busy Forward->Busy Forward</p>		
account.X.busy_fwd.target	String within 32 characters	Blank

Parameters	Permitted Values	Default
<p>Description:</p> <p>Configures the destination number of the busy forward for account X.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>Example:</p> <p>account.1.busy_fwd.target = 3602</p> <p>Note: It works only if the value of the parameter "features.fwd_mode" is set to 1 (Custom). It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>Features->Forward&DND->Forward->Busy Forward->Target</p> <p>Phone User Interface:</p> <p>Menu->Features->Call Forward->Busy Forward->Forward to</p>		
account.X.busy_fwd.on_code	String within 32 characters	Blank
<p>Description:</p> <p>Configures the busy forward on code to activate the server-side busy forward feature for account X. The IP phone will send the busy forward on code and the pre-configured destination number to the server when you activate busy forward feature for account X on the IP phone.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>Example:</p> <p>account.1.busy_fwd.on_code = *74</p> <p>Note: It works only if the value of the parameter "features.fwd_mode" is set to 1 (Custom). It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>Features->Forward&DND->Forward->No Answer Forward->On Code</p> <p>Phone User Interface:</p> <p>Menu->Features->Call Forward->Busy Forward->On Code</p>		

Parameters	Permitted Values	Default
account.X.busy_fwd.off_code	String within 32 characters	Blank
<p>Description:</p> <p>Configures the busy forward off code to deactivate the server-side busy forward feature for account X. The IP phone will send the busy forward off code to the server when you deactivate busy forward feature for account X on the IP phone.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>Example:</p> <p>account.1.busy_fwd.off_code = *75</p> <p>Note: It works only if the value of the parameter "features.fwd_mode" is set to 1 (Custom). It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>Features->Forward&DND->Forward->No Answer Forward->Off Code</p> <p>Phone User Interface:</p> <p>Menu->Features->Call Forward->Busy Forward->Off Code</p>		
account.X.timeout_fwd.enable	0 or 1	0
<p>Description:</p> <p>Triggers no answer forward feature to on or off for account X.</p> <p>0-Off</p> <p>1-On</p> <p>If it is set to 1 (On), incoming calls to the account X are forwarded to the destination number after a period of ring time.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>Note: It works only if the value of the parameter "features.fwd_mode" is set to 1 (Custom). It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p>		

Parameters	Permitted Values	Default
Features->Forward&DND->Forward->No Answer Forward->On/Off Phone User Interface: Menu->Features->Call Forward->No Answer Forward->No Answer Forward		
account.X.timeout_fwd.target	String within 32 characters	Blank
Description: Configures the destination number of the no answer forward for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) Example: account.1.timeout_fwd.target = 3603 Note: It works only if the value of the parameter "features.fwd_mode" is set to 1 (Custom). It is not applicable to SIP-T19(P) E2 and CP860 IP phones. Web User Interface: Features->Forward&DND->Forward->No Answer Forward->Target Phone User Interface: Menu->Features->Call Forward->No Answer Forward->Forward to		
account.X.timeout_fwd.timeout	Integer from 0 to 20	2
Description: Configures ring times (N) to wait before forwarding incoming calls for account X. Incoming calls will be forwarded when not answered after N*6 seconds. X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) Note: It works only if the value of the parameter "features.fwd_mode" is set to 1 (Custom). It is not applicable to SIP-T19(P) E2 and CP860 IP phones. Web User Interface: Features->Forward&DND->Forward->No Answer Forward->After Ring		

Parameters	Permitted Values	Default
Time(0~120s) Phone User Interface: Menu->Features->Call Forward->No Answer Forward->After Ring Time		
account.X.timeout_fwd.on_code	String within 32 characters	Blank
Description: Configures the no answer forward on code to activate the server-side no answer forward feature for account X. The IP phone will send the no answer forward on code and the pre-configured destination number to the server when you activate no answer forward feature for account X on the IP phone. X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) Example: account.1.timeout_fwd.on_code = *76 Note: It works only if the value of the parameter "features.fwd_mode" is set to 1 (Custom). It is not applicable to SIP-T19(P) E2 and CP860 IP phones. Web User Interface: Features->Forward&DND->Forward->No Answer Forward->On Code Phone User Interface: Menu->Features->Call Forward->No Answer Forward->On Code		
account.X.timeout_fwd.off_code	String within 32 characters	Blank
Description: Configures the no answer forward off code to deactivate the server-side no answer forward feature for account X. The IP phone will send the no answer forward off code to the server when you deactivate no answer forward feature for account X on the IP phone. X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2)		

Parameters	Permitted Values	Default
Example: account.1.timeout_fwd.off_code = *77 Note: It works only if the value of the parameter "features.fwd_mode" is set to 1 (Custom). It is not applicable to SIP-T19(P) E2 and CP860 IP phones. Web User Interface: Features->Forward&DND->Forward->No Answer Forward ->Off Code Phone User Interface: Menu->Features->Call Forward->No Answer Forward->Off Code		
features.forward.emergency.enable	0 or 1	0
Description: Enables or disables the incoming calls from some authorized numbers not to be forwarded when the call forward feature is enabled. 0 -Disabled 1 -Enabled Web User Interface: Features->Forward&DND->Forward->Forward Emergency Phone User Interface: None		
features.forward.emergency.authorized_number	String within 511 characters	Blank
Description: Configures the authorized numbers not to be forwarded even if call forward feature is enabled. Multiple numbers are separated by commas. Example: features.forward.emergency.authorized_number = 123,124 Note: It works only if the value of the parameter "features.forward.emergency.enable" is set to 1 (Enabled). Web User Interface: Features->Forward&DND->Forward->Forward Authorized Numbers Phone User Interface: None		
forward.always.enable	0 or 1	0

Parameters	Permitted Values	Default
<p>Description: Triggers the always forward feature to on or off.</p> <p>0-Off 1-On</p> <p>If it is set to 1 (On), incoming calls are forwarded to the destination number immediately.</p> <p>Note: For Yealink IP phones (except SIP-T19(P) E2 and CP860), it works only if the value of the parameter "features.fwd_mode" is set to 0 (Phone).</p> <p>Web User Interface: Features->Forward&DND->Forward->Always Forward->On/Off</p> <p>Phone User Interface: Menu->Features->Call Forward->Always Forward->Always Forward</p>		
forward.always.target	String within 32 characters	Blank
<p>Description: Configures the destination number of the always forward for the IP phone.</p> <p>Note: For Yealink IP phones (except SIP-T19(P) E2 and CP860), it works only if the value of the parameter "features.fwd_mode" is set to 0 (Phone).</p> <p>Web User Interface: Features->Forward&DND->Forward->Always Forward->Target</p> <p>Phone User Interface: Menu->Features->Call Forward->Always Forward->Forward to</p>		
forward.always.on_code	String within 32 characters	Blank
<p>Description: Configures the always forward on code to activate the server-side always forward feature. The IP phone will send the always forward on code and the pre-configured destination number to the server when you activate always forward feature on the IP phone.</p> <p>Example: forward.always.on_code = *72</p> <p>Note: For Yealink IP phones (except SIP-T19(P) E2 and CP860), it works only if the value of the parameter "features.fwd_mode" is set to 0 (Phone).</p> <p>Web User Interface: Features->Forward&DND->Forward->Always Forward->On Code</p>		

Parameters	Permitted Values	Default
Phone User Interface: Menu->Features->Call Forward->Always Forward->On Code		
forward.always.off_code	String within 32 characters	Blank
Description: Configures the always forward off code to deactivate the server-side always forward feature. The IP phone will send the always forward off code to the server when you deactivate always forward feature on the IP phone. Example: forward.always.off_code = *73 Note: For Yealink IP phones (except SIP-T19(P) E2 and CP860), it works only if the value of the parameter "features.fwd_mode" is set to 0 (Phone). Web User Interface: Features->Forward&DND->Forward->Always Forward->Off Code Phone User Interface: Menu->Features->Call Forward->Always Forward->Off Code		
forward.busy.enable	0 or 1	0
Description: Triggers the busy forward feature to on or off. 0-Off 1-On If it is set to 1 (On), incoming calls are forwarded to the destination number when the callee is busy. Note: For Yealink IP phones (except SIP-T19(P) E2 and CP860), it works only if the value of the parameter "features.fwd_mode" is set to 0 (Phone). Web User Interface: Features->Forward&DND->Forward->Busy Forward->On/Off Phone User Interface: Menu->Features->Call Forward->Busy Forward->Busy Forward		
forward.busy.target	String within 32 characters	Blank

Parameters	Permitted Values	Default
<p>Description: Configures the destination number of the busy forward for the IP phone.</p> <p>Example: forward.busy.target = 3602</p> <p>Note: For Yealink IP phones (except SIP-T19(P) E2 and CP860), it works only if the value of the parameter "features.fwd_mode" is set to 0 (Phone).</p> <p>Web User Interface: Features->Forward&DND->Forward->Busy Forward->Target</p> <p>Phone User Interface: Menu->Features->Call Forward-> Busy Forward->Forward to</p>		
forward.busy.on_code	String within 32 characters	Blank
<p>Description: Configures the busy forward on code to activate the server-side busy forward feature. The IP phone will send the busy forward on code and the pre-configured destination number to the server when you activate busy forward feature on the IP phone.</p> <p>Example: forward.busy.on_code = *74</p> <p>Note: For Yealink IP phones (except SIP-T19(P) E2 and CP860), it works only if the value of the parameter "features.fwd_mode" is set to 0 (Phone).</p> <p>Web User Interface: Features->Forward&DND->Forward->Busy Forward->On Code</p> <p>Phone User Interface: Menu->Features->Call Forward->Busy Forward->On Code</p>		
forward.busy.off_code	String within 32 characters	Blank
<p>Description: Configures the busy forward off code to deactivate the server-side busy forward feature. The IP phone will send the busy forward off code to the server when you deactivate busy forward feature on the IP phone.</p> <p>Example: forward.busy.off_code = *75</p> <p>Note: For Yealink IP phones (except SIP-T19(P) E2 and CP860), it works only if the value of the parameter "features.fwd_mode" is set to 0 (Phone).</p>		

Parameters	Permitted Values	Default
Web User Interface: Features->Forward&DND->Forward->Busy Forward->Off Code Phone User Interface: Menu->Features->Call Forward->Busy Forward->Off Code		
forward.no_answer.enable	0 or 1	0
Description: Triggers the no answer forward feature to on or off. 0 -Off 1 -On If it is set to 1 (On), incoming calls are forwarded to the destination number after a period of ring time. Note: For Yealink IP phones (except SIP-T19(P) E2 and CP860), it works only if the value of the parameter "features.fwd_mode" is set to 0 (Phone). Web User Interface: Features->Forward&DND->Forward->No Answer Forward->On/Off Phone User Interface: Menu->Features->Call Forward->No Answer Forward->No Answer Forward		
forward.no_answer.target	String within 32 characters	Blank
Description: Configures the destination number of the no answer forward for the IP phone. Example: forward.no_answer.target = 3603 Note: For Yealink IP phones (except SIP-T19(P) E2 and CP860), it works only if the value of the parameter "features.fwd_mode" is set to 0 (Phone). Web User Interface: Features->Forward&DND->Forward->No Answer Forward->Target Phone User Interface: Menu->Features->Call Forward->No Answer Forward->Forward to		
forward.no_answer.timeout	Integer from 0 to 20	2

Parameters	Permitted Values	Default
<p>Description:</p> <p>Configures ring times (N) to wait before forwarding incoming calls.</p> <p>Incoming calls will be forwarded when not answered after N*6 seconds.</p> <p>Note: For Yealink IP phones (except SIP-T19(P) E2 and CP860), it works only if the value of the parameter "features.fwd_mode" is set to 0 (Phone).</p> <p>Web User Interface:</p> <p>Features->Forward&DND->Forward->No Answer Forward->After Ring Time (0~120s)</p> <p>Phone User Interface:</p> <p>Menu->Features->Call Forward->No Answer Forward->After Ring Time</p>		
forward.no_answer.on_code	String within 32 characters	Blank
<p>Description:</p> <p>Configures the no answer forward on code to activate the server-side no answer forward feature. The IP phone will send the no answer forward on code and the pre-configured destination number to the server when you activate no answer forward feature on the IP phone.</p> <p>Example:</p> <p>forward.no_answer.on_code = *76</p> <p>Note: For Yealink IP phones (except SIP-T19(P) E2 and CP860), it works only if the value of the parameter "features.fwd_mode" is set to 0 (Phone).</p> <p>Web User Interface:</p> <p>Features->Forward&DND->Forward->No Answer Forward->On Code</p> <p>Phone User Interface:</p> <p>Menu->Features->Call Forward->No Answer Forward->On Code</p>		
forward.no_answer.off_code	String within 32 characters	Blank
<p>Description:</p> <p>Configures the no answer forward off code to deactivate the server-side no answer forward feature. The IP phone will send the no answer forward off code to the server when you deactivate no answer forward feature on the IP phone.</p> <p>Example:</p> <p>forward.no_answer.off_code = *77</p> <p>Note: For Yealink IP phones (except SIP-T19(P) E2 and CP860), it works only if the value of the parameter "features.fwd_mode" is set to 0 (Phone).</p>		

Parameters	Permitted Values	Default
Web User Interface: Features->Forward&DND->Forward->No Answer Forward->Off Code Phone User Interface: Menu->Features->Call Forward->No Answer Forward->Off Code		
features.fwd_diversion_enable	0 or 1	1
Description: Enables or disables the IP phone to present the diversion information when an incoming call is forwarded to your IP phone. 0 -Disabled 1 -Enabled Web User Interface: Features->General Information->Diversion/History-Info Phone User Interface: None		
forward.international.enable	0 or 1	1
Description: Enables or disables the IP phone to forward incoming calls to international numbers (the prefix is 00). 0 -Disabled 1 -Enabled Web User Interface: Features->General Information->Fwd International Phone User Interface: Menu->Settings->Advanced Settings (default password: admin)->FWD International->FWD International		

To specify the authorized numbers when call forward is enabled via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Forward Emergency**.
3. Enter the desired value in the **Forward Authorized Numbers** field.

Multiple numbers are separated by commas.

4. Click **Confirm** to accept the change.

To configure call forward via web user interface:

1. Click on **Features->Forward&DND**.
2. In the **Forward** block, mark the desired radio box in the **Mode** field.
 - a) If you mark the **Phone** radio box:
 - 1) Mark the desired radio box in the **Always/Busy/No Answer Forward** field.
 - 2) Enter the destination number you want to forward in the **Target** field.
 - 3) (Optional.) Enter the on code and off code in the **On Code** and **Off Code** fields.
 - 4) Select the ring time to wait before forwarding from the pull-down list of **After Ring Time(0~120s)** (only for the no answer forward).

- b) If you mark the **Custom** radio box:
 - 1) Select the desired account from the pull-down list of **Account**.
 - 2) Mark the desired radio box in the **Always/Busy/No Answer Forward** field.
 - 3) Enter the destination number you want to forward in the **Target** field.
 - 4) Enter the on code and off code in the **On Code** and **Off Code** fields.
 - 5) Select the ring time to wait before forwarding from the pull-down list of

After Ring Time(0~120s) (only for the no answer forward).

Forward

Forward Emergency: Enabled

Forward Authorized Numbers: 1014

Mode: ☐ Phone ☒ Custom

Account: 1011

Always Forward: ☒ On ☐ Off

Target: 1003

On Code: *72

Off Code: *73

Busy Forward: ☐ On ☒ Off

Target:

On Code:

Off Code:

NOTE

Call Forward
It allows users to redirect an incoming call to a third party.

Call Forward Mode
Phone: Call forward feature is effective for the IP phone.
Custom: Call forward feature can be configured for each or all accounts.

Do Not Disturb (DND)
It allows IP phones to ignore incoming calls.

DND Mode
Phone: DND feature is effective for the IP phone.
Custom: DND feature can be configured for each or all accounts.

You can click here to get more guides.

3. Click **Confirm** to accept the change.

To configure Diversion/History-Info feature via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Diversion/History-Info**.

General Information

Call Waiting: Enabled

Call Waiting On Code:

Call Waiting Off Code:

Auto Redial: Disabled

Auto Redial Interval (1~300s): 10

Auto Redial Times (1~300): 10

...

Diversion/History-Info: Enabled

Allow Trans Exist Call: Enabled

BLF LED Mode: 0

Auto-Logout Time(1~1000min): 5

Call Number Filter: ,-

Auto Linekeys: Disabled

NOTE

Call Waiting
It allows IP phones to receive a new incoming call when there is already an active call.

Auto Redial
It allows IP phones to automatically redial a busy number after the first attempt.

Key As Send
Assigns "#" or "*" as the send key.

Hotline
IP phone will automatically dial out the hotline number when lifting the handset, pressing the speakerphone key or the line key.

Call Completion
It allows users to monitor the busy party and establish a call when the busy party becomes available to receive a call.

You can click here to get more guides.

3. Click **Confirm** to accept the change.

To configure forward international via web user interface:

1. Click on **Features->General Information**.

2. Select the desired value from the pull-down list of **Fwd International**.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected. In the 'General Information' section, the 'Fwd International' dropdown menu is highlighted with a red box and set to 'Enabled'. Other settings visible include 'Call Waiting' (Enabled), 'Auto Redial' (Disabled), and 'Auto Redial Interval' (10). A 'NOTE' section on the right explains features like 'Call Waiting', 'Auto Redial', 'Key As Send', 'Hotline', and 'Call Completion'.

3. Click **Confirm** to accept the change.

To configure call forward in phone mode via phone user interface:

1. Press **Menu->Features->Call Forward**.
2. Press \uparrow or \downarrow to select the desired forwarding type, and then press the **Enter** soft key.
3. Depending on your selection:
 - a) If you select **Always Forward**:
 - 1) Press \leftarrow or \rightarrow , or the **Switch** soft key to select the desired value from the **Always Forward** field.
 - 2) Enter the destination number you want to forward all incoming calls to in the **Forward to** field.
 - 3) (Optional.) Enter the always forward on code and off code respectively in the **On Code** and **Off Code** field.
 - b) If you select **Busy Forward**:
 - 1) Press \leftarrow or \rightarrow , or the **Switch** soft key to select the desired value from the **Busy Forward** field.
 - 2) Enter the destination number you want to forward all incoming calls to when the IP phone is busy in the **Forward to** field.
 - 3) (Optional.) Enter the busy forward on code and off code respectively in the **On Code** and **Off Code** field.
 - c) If you select **No Answer Forward**:
 - 1) Press \leftarrow or \rightarrow , or the **Switch** soft key to select the desired value from the **No Answer Forward** field.
 - 2) Enter the destination number you want to forward all unanswered incoming calls to in the **Forward to** field.

3) (Optional.) Enter the no answer forward on code and off code respectively in the **On Code** and **Off Code** field.

4) Press  or  , or the **Switch** soft key to select the ring time to wait before forwarding from the **After Ring Time** field.



The default ring time is 12 seconds.

4. Press the **Save** soft key to accept the change.

To configure call forward in custom mode via phone user interface:



1. Press **Menu->Features->Call Forward**.

2. Press  or  to select the desired account, and then press the **Enter** soft key.

3. Press  or  to select the desired forwarding type, and then press the **Enter** soft key.

4. Depending on your selection:

a) If you select **Always Forward**, you can configure it for a specific account.

1) Press  or  , or the **Switch** soft key to select the desired value from the **Always Forward** field.

2) Enter the destination number you want to forward all incoming calls to in the **Forward to** field.

3) (Optional.) Enter the always forward on code and off code respectively in the **On Code** and **Off Code** field.

You can also configure the always forward for all accounts. After the always forward was configured for a specific account, do the following:



1) Press  or  to highlight the **Always Forward** field.

2) Press the **All Lines** soft key.

The LCD screen prompts "Copy to all lines?".

3) Press the **OK** soft key to accept the change.

b) If you select **Busy Forward**, you can configure it for a specific account.

1) Press  or  , or the **Switch** soft key to select the desired value from the **Busy Forward** field.

2) Enter the destination number you want to forward all incoming calls to when the IP phone is busy in the **Forward to** field.

3) (Optional.) Enter the busy forward on code and off code respectively in the **On Code** and **Off Code** field.



You can also configure the busy forward for all accounts. After the busy forward was configured for a specific account, do the following:

1) Press  or  to highlight the **Busy Forward** field.

2) Press the **All Lines** soft key.

The LCD screen prompts "Copy to all lines?".

3) Press the **OK** soft key to accept the change.

- c) If you select **No Answer Forward**, you can configure it for a specific account.
- 1) Press  or  , or the **Switch** soft key to select the desired value from the **No Answer Forward** field.



- 2) Enter the destination number you want to forward all unanswered incoming calls to in the **Forward to** field.

- 3) Press  or  , or the **Switch** soft key to select the ring time to wait before forwarding from the **After Ring Time** field.

The default ring time is 12 seconds.

- 4) (Optional.) Enter the no answer forward on code and off code respectively in the **On Code** and **Off Code** field.

You can also configure the no answer forward for all accounts. After the no answer forward was configured for a specific account, do the following:



- 1) Press  or  to highlight the **No Answer Forward** field.
- 2) Press the **All Lines** soft key.

The LCD screen prompts "Copy to all lines?".

- 3) Press the **OK** soft key to accept the change.

5. Press the **Save** soft key to accept the change.

To configure forward international via phone user interface:

1. Press **Menu->Settings->Advanced Settings** (default password: admin) ->**FWD International**.
2. Press  or  , or the **Switch** soft key to select the desired value from the **FWD International** field.
3. Press the **Save** soft key to accept the change.

Call Transfer

Call transfer enables IP phones to transfer an existing call to another party. IP phones support call transfer using the REFER method specified in RFC 3515 and offer three types of transfer:

- **Blind Transfer** -- Transfer a call directly to another party without consulting. Blind transfer is implemented by a simple REFER method without Replaces in the Refer-To header.
- **Semi-attended Transfer** -- Transfer a call after hearing the ringback tone. Semi-attended transfer is implemented by a REFER method with Replaces in the Refer-To header.
- **Attended Transfer** -- Transfer a call with prior consulting. Attended transfer is implemented by a REFER method with Replaces in the Refer-To header.

Normally, call transfer is completed by pressing the transfer key. Blind transfer on hook and attended transfer on hook features allow the IP phone to complete the transfer

through on-hook.

When a user performs a semi-attended transfer, semi-attended transfer feature determines whether to display the prompt "**n New Missed Call(s)**" ("n" indicates the number of the missed calls) on the destination party's phone LCD screen.

Procedure

Call transfer can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Specify whether to complete the transfer through on-hook. Parameters: transfer.blind_tran_on_hook_enable transfer.on_hook_trans_enable
		Configure semi-attended transfer feature. Parameter: transfer.semi_attend_tran_enable
Local	Web User Interface	Specify whether to complete the transfer through on-hook. Configure semi-attended transfer feature. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/ T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p =features-transfer&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet?m =mod_data&p=features-transfer&q =load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
transfer.blind_tran_on_hook_enable	0 or 1	1
Description: Enables or disables the IP phone to complete the blind transfer through on-hook		

Parameters	Permitted Values	Default
<p>besides pressing the Tran/Transfer soft key or TRAN/TRANSFER key. (Blind transfer means transfer a call directly to another party without consulting).</p> <p>0-Disabled 1-Enabled</p> <p>Web User Interface: Features->Transfer->Blind Transfer On Hook</p> <p>Phone User Interface: None</p>		
transfer.on_hook_trans_enable	0 or 1	1
<p>Description: Enables or disables the IP phone to complete the semi-attended/attended transfer through on-hook besides pressing the Tran/Transfer soft key or TRAN/TRANSFER key.</p> <p>0-Disabled 1-Enabled</p> <p>Web User Interface: Features->Transfer->Attended Transfer On Hook</p> <p>Phone User Interface: None</p>		
transfer.semi_attend_tran_enable	0 or 1	1
<p>Description: Enables or disables the transfer-to party's phone not to prompt a missed call on the LCD screen before displaying the caller ID when completing a semi-attended transfer.</p> <p>0-Disabled 1-Enabled</p> <p>Web User Interface: Features->Transfer->Semi-Attended Transfer</p> <p>Phone User Interface: None</p>		

To configure call transfer via web user interface:

1. Click on **Features->Transfer**.

- Select the desired values from the pull-down lists of **Semi-Attended Transfer**, **Blind Transfer on Hook** and **Attended Transfer on Hook**.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected. Under the 'Transfer' section, the following settings are visible:

- Semi-Attended Transfer: Enabled
- Blind Transfer on Hook: Enabled
- Attended Transfer on Hook: Enabled
- Transfer on Conference Hang up: Disabled
- Transfer Mode via Dskey: Blind Transfer

Buttons for 'Confirm' and 'Cancel' are at the bottom. A 'NOTE' section on the right provides details about 'Call Transfer' and 'Blind Transfer'.

- Click **Confirm** to accept the change.

Network Conference

Network conference, also known as centralized conference, provides users with flexibility of call with multiple participants (more than three). IP phones implement network conference using the REFER method specified in RFC 4579. This feature depends on support from a SIP server.

Procedure

Network conference can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure network conference. Parameters: account.X.conf_type account.X.conf_uri
Local	Web User Interface	Configure network conference. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0 For SIP VP-T49G: http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0

Details of Configuration Parameters:

Parameters	Permitted Values	Default
account.X.conf_type	0 or 2	0
<p>Description: Configures the network conference type for account X.</p> <p>0-Local Conference 2-Network Conference</p> <p>If it is set to 0 (Local Conference), conferences are set up on the IP phone locally. If it is set to 2 (Network Conference), conferences are set up by the server.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Web User Interface: Account->Advanced->Conference Type</p> <p>Phone User Interface: None</p>		
account.X.conf_uri	SIP URI within 511 characters	Blank
<p>Description: Configures the network conference URI for account X.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Example: account.1.conf_uri = conference@example.com</p> <p>Note: It works only if the value of the parameter "account.X.conf_type" is set to 2 (Network Conference).</p> <p>Web User Interface:</p>		

Parameters	Permitted Values	Default
Account->Advanced->Conference URI		
Phone User Interface:		
None		

To configure the network conference via web user interface:

1. Click on **Account->Advanced**.
2. Select the desired account from the pull-down list of **Account**.
3. Select **Network Conference** from the pull-down list of **Conference Type**.
4. Enter the conference URI in the **Conference URI** field.

The screenshot shows the Yealink T236 web interface. The 'Account' tab is active, and the 'Advanced' sub-tab is selected. The 'Account' dropdown is set to 'Account 1'. The 'Conference Type' dropdown is set to 'Network Conference', and the 'Conference URI' text field contains 'conference@example.com'. Other configuration options include 'Keep Alive Type' (Default), 'Keep Alive Interval(Seconds)' (30), 'RPort' (Disabled), 'Subscribe Period(Seconds)' (1800), 'ACD Subscribe Period(120~3600s)' (3600), 'Early Media' (Disabled), 'SIP Server Type' (Default), 'Distinctive Ring Tones' (Enabled), 'Unregister When Reboot' (Enabled), 'Out Dialog BLF' (Enabled), 'VQ RTPC-XR Collector name' (collector), 'VQ RTPC-XR Collector address' (10.2.1.98), and 'VQ RTPC-XR Collector port' (5060). A 'NOTE' section on the right provides additional context for various features.

5. Click **Confirm** to accept the change.

Feature Key Synchronization

Feature key synchronization provides the capability to synchronize the status of the following features between the IP phone and the server:

- Do Not Disturb (DND)
- Call Forwarding Always (CFA)
- Call Forwarding Busy (CFB)
- Call Forwarding No Answer (CFNA)

If feature key synchronization is enabled, a user changes the status of one of these features on the server, and then the server notifies the phone of synchronizing the status.

Conversely, if the user changes the feature status on the phone, the IP phone notifies the server of synchronizing the status.

Procedure

Feature key synchronization can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure feature key synchronization. Parameter: bw.feature_key_sync
Local	Web User Interface	Configure feature key synchronization. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet? p=features-general&q=load For SIP VPT49G: http://<phoneIPAddress>/servlet? m=mod_data&p=features-general&q=load

Details of Configuration Parameter:

Parameters	Permitted Values	Default
bw.feature_key_sync	0 or 1	0
Description: Enables or disables feature key synchronization. 0-Disabled 1-Enabled Web User Interface: Features->General Information->Feature Key Synchronization Phone User Interface: None		

To configure feature key synchronization via web user interface:

1. Click on **Features->General Information**.

2. Select **Enabled** from the pull-down list of **Feature Key Synchronization**.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected. In the 'General Information' section, the 'Feature Key Synchronization' dropdown menu is highlighted with a red box and set to 'Enabled'. Other settings include 'Call Waiting' (Enabled), 'Call Waiting On Code' (empty), 'Call Waiting Off Code' (empty), 'Auto Redial' (Disabled), 'Auto Redial Interval (1~300s)' (10), 'Auto Redial Times (1~300)' (10), 'Time-Out for Dial-How Rule' (1), 'RFC 2543 Hold' (Disabled), 'Use Outbound Proxy In Dialog' (Enabled), 'Call Number Filter' (empty), and 'Auto Linekeys' (Disabled). A 'NOTE' section on the right provides details for 'Call Waiting', 'Auto Redial', 'Key As Send', 'Hotline', and 'Call Completion'. 'Confirm' and 'Cancel' buttons are at the bottom.

3. Click **Confirm** to accept the change.

Transfer on Conference Hang Up

For a conference call, all parties drop the call when the conference initiator drops the conference call. For local conference, transfer on conference hang up allows the other two parties to remain connected when the conference initiator drops the conference call.

Procedure

Transfer on conference hang up can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the transfer on conference hang up. Parameter: transfer.tran_others_after_conf_enable
Local	Web User Interface	Configure the transfer on conference hang up. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet


		<p>?p=features-transfer&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet ?m=mod_data&p=features-transfer&q=load</p>
--	--	--

Details of the Configuration Parameter:

Parameters	Permitted Values	Default
transfer.tran_others_after_conf_enable	0 or 1	0
<p>Description:</p> <p>Enables or disables the IP phone to transfer the local conference call to the other two parties after the conference initiator drops the local conference call.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>If it is set to 1 (Enabled), the other two parties remain connected when the conference initiator drops the conference call.</p> <p>Note: It works only if the value of parameter "account.X.conf_type" is set to 0 (Local Conference).</p> <p>Web User Interface:</p> <p>Features->Transfer->Transfer on Conference Hang up</p> <p>Phone User Interface:</p> <p>None</p>		

To configure transfer on conference hang up via web user interface:

1. Click on **Features->Transfer**.
2. Select the desired value from the pull-down list of **Transfer on Conference Hang up**.



3. Click **Confirm** to accept the change.

Transfer Mode via Dsskey

Transfer mode via dsskey enables IP phones to handle the current call differently via the DSS key. IP phones support three transfer modes: New Call, Blind Transfer and Attended Transfer. For more information on Blind Transfer and Attended Transfer, refer to [Call Transfer](#) on page 376.

Note

It is not applicable to SIP-T19(P) E2 and CP860 IP phones.

The transfer mode via dsskey feature is available when the DSS key is assigned to the following features:

- Speed dial
- Transfer
- BLF/BLF List

For more information on how to configure the DSS Key, refer to [Appendix D: Configuring DSS Key](#) on page 926.

Procedure

Transfer mode via dsskey can be configured using the configuration files or locally.


Configuration File	<y0000000000xx>.cfg	Configure the transfer mode via dsskey. Parameter: transfer.dsskey_deal_type
Local	Web User Interface	Configure the transfer mode via dsskey. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2: http://<phoneIPAddress>/servlet? p=features-transfer&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet? m=mod_data&p=features-transfer&q=load

Details of the Configuration Parameter:

Parameters	Permitted Values	Default
transfer.dsskey_deal_type	0, 1 or 2	2
<p>Description:</p> <p>Configures the transfer mode when user presses the DSS key during an active call. To use this feature, you need to configure the DSS key as a speed dial, transfer or BLF/BLF List in advance.</p> <p>0-New Call</p> <p>1-Attended Transfer</p> <p>2-Blind Transfer</p> <p>Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>Features->Transfer->Transfer Mode via Dsskey</p> <p>Phone User Interface:</p> <p>None</p>		

To configure transfer mode via dsskey via web user interface:

1. Click on **Features->Transfer**.
2. Select the desired value from the pull-down list of **Transfer Mode via Dsskey**.



3. Click **Confirm** to accept the change.

Allow Trans Exist Call

Allow trans exist call feature allows users to select transfer-to party's call during multiple calls. It is convenient to transfer the active call to another existing call. It is not applicable to SIP VPT49G/SIP-T48G/T46G/T29G IP phones.

Procedure

Allow trans exist call can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure allow trans exist call. Parameters: transfer.multi_call_trans_enable
Local	Web User Interface	Configure allow trans exist call. Navigate to: http://<phoneIPAddress>/servlet?p=features-general&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
transfer.multi_call_trans_enable	0 or 1	1
<p>Description:</p> <p>Enables or disables the IP phone to select transfer-to party's call (a new call or another existing call) during multiple calls when user presses the Tran/Transfer soft key or TRAN/TRANSFER key.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>If it is set to 1 (Enabled), the user can select to transfer the active call to a new call or another existing call during multiple calls when the user presses the Tran/Transfer soft key or TRAN/TRANSFER key.</p> <p>If it is set to 0 (Disabled), the user can transfer the active call to a new call during multiple calls when the user presses the Tran/Transfer soft key or TRAN/TRANSFER key.</p> <p>Note: It is not applicable to SIP VP-T49G/SIP-T48G/T46G/T29G IP phones.</p> <p>Web User Interface:</p> <p>Features->General Information->Allow Trans Exist Call</p> <p>Phone User Interface:</p> <p>None</p>		

To configure allow trans exist call via web user interface:

1. Click on **Feature->General Information**.

2. Select the desired value from the pull-down list of **Allow Trans Exist Call**.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected. In the 'General Information' section, the 'Allow Trans Exist Call' option is highlighted with a red box and is set to 'Enabled'. Other options include 'Call Waiting' (Enabled), 'Auto Redial' (Disabled), 'Diversion/History-Info' (Enabled), 'BLF LED Mode' (0), 'Auto-Logout Time' (5), 'Call Number Filter' (.), and 'Auto Linekeys' (Disabled). A 'NOTE' sidebar on the right contains information about 'Call Waiting', 'Auto Redial', 'Key As Send', 'Hotline', and 'Call Completion'. At the bottom, there are 'Confirm' and 'Cancel' buttons.

3. Click **Confirm** to accept the change.

Directed Call Pickup

Directed call pickup is used for picking up an incoming call on a specific extension. A user can pick up the incoming call using a directed pickup key or the **DPickup** soft key. This feature depends on support from a SIP server. For many SIP servers, directed call pickup requires a directed pickup code, which can be configured on a phone or a per-line basis.

Note

It is recommended not to configure the directed call pickup key and the **DPickup** soft key simultaneously. If you do, the directed call pickup key will not be used correctly.

Procedure

Directed call pickup can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure the directed call pickup code on a per-line basis. Parameter: account.X.direct_pickup_code
--------------------	-----------	---

		<p>Configure directed call pickup features on a phone basis.</p> <p>Parameters:</p> <p>features.pickup.direct_pickup_enable</p> <p>features.pickup.direct_pickup_code</p>
	<y0000000000xx>.cfg	<p>Assign a directed call pickup key.</p> <p>Parameters:</p> <p>linekey.X.type/ programablekey.X.type/ expansion_module.X.key.Y.type linekey.X.line/ programablekey.X.line/ expansion_module.X.key.Y.line linekey.X.value/ programablekey.X.value/ expansion_module.X.key.Y.value linekey.X.label/ programablekey.X.label/ expansion_module.X.key.Y.label</p>
Local	Web User Interface	<p>Assign a directed call pickup key.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet? p=dsskey&q=load&model=0</p> <p>For SIP VP-T49G: http://<phoneIPAddress>/servlet? m=mod_data&p=dsskey&q=load</p>
		<p>Configure directed call pickup code on a per-line basis.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p>

		<p>http://<phoneIPAddress>/servlet ?p=account-adv&q=load&acc=0</p> <p>For SIP VP-T49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=account-adv &q=load&acc=0</p>
		<p>Configure directed call pickup feature on a phone basis.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>http://<phoneIPAddress>/servlet ?p=features-callpickup&q=load</p> <p>For SIP VP-T49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=features-callp ickup&q=load</p>
	Phone User Interface	Assign a directed call pickup key.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
account.X.direct_pickup_code	String within 32 characters	Blank
<p>Description:</p> <p>Configures the directed call pickup code for account X.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Example:</p> <p>account.1.direct_pickup_code = *68</p> <p>Note: The directed call pickup code configured on a per-line basis takes precedence over that configured on a phone basis.</p>		

Parameters	Permitted Values	Default
Web User Interface: Account->Advanced->Directed Call Pickup Code Phone User Interface: None		
features.pickup.direct_pickup_enable	0 or 1	0
Description: Enables or disables the IP phone to display the DPickup soft key when the IP phone is on the dialing screen. 0-Disabled 1-Enabled Web User Interface: Features->Call Pickup->Directed Call Pickup Phone User Interface: None		
features.pickup.direct_pickup_code	String within 32 characters	Blank
Description: Configures the directed call pickup code on a phone basis. Example: features.pickup.direct_pickup_code = *97 Note: The directed call pickup code configured on a per-line basis takes precedence over that configured on a phone basis. Web User Interface: Features->Call Pickup->Directed Call Pickup Code Phone User Interface:- None		

Directed Call Pickup Key

For more information on how to configure the DSS Key, refer to [Appendix D: Configuring DSS Key](#) on page 926.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
linekey.X.type/ programmablekey.X.type/ expansion_module.X.key.Y.type	9	Refer to the following content
<p>Description:</p> <p>Configures a DSS key as a directed call pickup key on the IP phone.</p> <p>The digit 9 stands for the key type Direct Pickup.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G)</p> <p>X ranges from 1 to 27 (for SIPT46G/T29G)</p> <p>X ranges from 1 to 15 (for SIPT42G/T41P)</p> <p>X ranges from 1 to 21 (for SIPT27P)</p> <p>X ranges from 1 to 3 (for SIPT40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIPT21(P) E2)</p> <p>For programmable keys:</p> <p>X=1-4, 12-14 (for SIP VP-T49G)</p> <p>X=1-10, 12-14 (for SIPT48G/T46G)</p> <p>X=1-10, 13 (for SIPT42G/T41P/T40P)</p> <p>X=1-14 (for SIPT29G/T27P)</p> <p>X=1-10, 14 (for SIPT23P/T23G/T21(P) E2)</p> <p>X=1-9, 13, 14 (for SIPT19(P) E2)</p> <p>X=1-6, 9, 13 (for CP860)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Example:</p> <p>linekey.1.type = 9</p> <p>Default:</p> <p>For line keys:</p> <p>For SIP VP-T49G/SIPT48G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-29 is 0.</p> <p>For SIPT46G/T29G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-27 is 0.</p>		

Parameters	Permitted Values	Default
<p>For SIP-T42G IP phones:</p> <p>The default value of the line key 1-12 is 15, and the default value of the line key 13-15 is 0.</p> <p>For SIP-T41P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-15 is 0.</p> <p>For SIP-T27P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-21 is 0.</p> <p>For SIP-T40P/T23P/T23G/T21(P) E2 IP phones:</p> <p>The default value is 15.</p> <p>For programmable keys:</p> <p>For SIP VP-T49G IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIP-T48G/T46G IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIP-T42G/T41P/T40P IP phones:</p>		

Parameters	Permitted Values	Default
<p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>For SIP-T29G/T27P IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=11, the default value is 0 (NA).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIP-T23P/T23G/T21(P) E2 IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p>		

Parameters	Permitted Values	Default
<p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIP-T19(P) E2 IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For CP860 IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=13, the default value is 0 (NA).</p> <p>For ext keys:</p> <p>When Y=1, the default value is 37 (Switch).</p> <p>When Y= 2 to 20, 22 to 40, the default value is 0 (NA).</p> <p>Web User Interface:</p> <p>DSSKey->Line Key/Programable Key->Type</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Type</p>		
linekey.X.line/ programablekey.X.line/ expansion_module.X.key.Y.line	Refer to the following content	1-16 for lines 1-16, 1 for programable key
Description:		

Parameters	Permitted Values	Default
<p>Configures the desired line to apply the directed call pickup key.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For programable keys:</p> <p>X=1-4, 12-14 (for SIP VP-T49G)</p> <p>X=1-10, 12-14 (for SIP-T48G/T46G)</p> <p>X=1-10, 13 (for SIP-T42G/T41P/T40P)</p> <p>X=1-14 (for SIP-T29G/T27P)</p> <p>X=1-10, 14 (for SIP-T23P/T23G/T21(P) E2)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Permitted Values:</p> <p>1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>1 to 12 (for SIP-T42G)</p> <p>1 to 6 (for SIP-T41P/T27P)</p> <p>1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>1 to 2 (for SIP-T21(P) E2)</p> <p>1-Line 1</p> <p>2-Line 2</p> <p>...</p> <p>16-Line 16</p> <p>Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Example:</p> <p>linekey.1.line = 1</p> <p>Web User Interface:</p> <p>DSSKey->Line Key/Programable Key->Line</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Account ID</p>		
linekey.X.value/ programablekey.X.value/	String within 99 characters	Blank

Parameters	Permitted Values	Default
expansion_module.X.key.Y.value		
<p>Description:</p> <p>Configures the directed call pickup feature code followed by the monitored extension.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G)</p> <p>X ranges from 1 to 27 (for SIPT46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIPT27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For programable keys:</p> <p>X=1-4, 12-14 (for SIP VP-T49G)</p> <p>X=1-10, 12-14 (for SIPT48G/T46G)</p> <p>X=1-10, 13 (for SIP-T42G/T41P/T40P)</p> <p>X=1-14 (for SIPT29G/T27P)</p> <p>X=1-10, 14 (for SIP-T23P/T23G/T21(P) E2)</p> <p>X=1-9, 13, 14 (for SIP-T19(P) E2)</p> <p>X=1-6, 9, 13 (for CP860)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Example:</p> <p>linekey.1.value = 1008</p> <p>Web User Interface:</p> <p>DSSKey->Line Key/Programable Key->Value</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Value</p>		
linekey.X.label/ programablekey.X.label/ expansion_module.X.key.Y.label	String within 99 characters	Blank
<p>Description:</p> <p>(Optional.) Configures the label displayed on the LCD screen for each DSS key.</p> <p>For line keys:</p>		

Parameters	Permitted Values	Default
<p>X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For programmable keys:</p> <p>X ranges from 1 to 4.</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Web User Interface:</p> <p>DSSKey->Line Key/Programable Key->Label</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Label</p>		

To configure a directed call pickup key via web user interface:

1. Click on **DSSKey->Line Key** (or **Programable Key**).
2. In the desired DSS key field, select **Direct Pickup** from the pull-down list of **Type**.
3. Enter the directed call pickup code followed by the specific extension in the **Value** field.
4. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.
5. Select the desired line from the pull-down list of **Line**.

6. Click **Confirm** to accept the change.

To configure the directed call pickup code on a per-line basis via web user interface:

1. Click on **Account->Advanced**.
2. Select the desired account from the pull-down list of **Account**.

3. Enter the directed call pickup code in the **Directed Call Pickup Code** field.

The screenshot shows the Yealink T236 web interface with the 'Account' tab selected. The 'Account' section is expanded, showing various configuration fields. The 'Directed Call Pickup Code' field is highlighted with a red box and contains the value '*97'. Other fields include 'Keep Alive Type', 'Keep Alive Interval(Seconds)', 'RPort', 'Subscribe Period(Seconds)', 'Early Media', 'SIP Server Type', 'Music Server URI', 'Group Call Pickup Code', 'Distinctive Ring Tones', 'Unregister When Reboot', 'Out Dialog BLF', 'VQ RTPC-XR Collector name', 'VQ RTPC-XR Collector address', and 'VQ RTPC-XR Collector port'. A 'NOTE' section on the right provides information about DTMF, Session Timer, Busy Lamp Field/BLF List, Shared Call Appearance (SCA)/ Bridge Line Appearance (BLA), and Network Conference.

4. Click **Confirm** to accept the change.

To configure directed call pickup feature on a phone basis via web user interface:







1. Click on **Features->Call Pickup**.
2. Select the desired value from the pull-down list of **Directed Call Pickup**.
3. Enter the directed call pickup code in the **Directed Call Pickup Code** field.

The screenshot shows the Yealink T236 web interface with the 'Features' tab selected. The 'Call Pickup' section is expanded, showing various configuration fields. The 'Directed Call Pickup' field is highlighted with a red box and contains the value 'Enabled'. Other fields include 'Directed Call Pickup Code', 'Group Call Pickup', 'Group Call Pickup Code', 'Visual Alert for BLF Pickup', 'Audio Alert for BLF Pickup', 'Call Park Mode', 'Call Park', 'Call Park Code', and 'Park Retrieve Code'. A 'NOTE' section on the right provides information about Directed Call Pickup, Directed Call Pickup, Visual Alert for BLF Pickup, and Audio Alert for BLF Pickup.

4. Click **Confirm** to accept the change.

To configure a directed pickup key via phone user interface:

1. Press **Menu->Features->DSS Keys**.
2. Select the desired DSS key.

3. Press  or  , or the **Switch** soft key to select **Key Event** from the **Type** field.
4. Press  or  , or the **Switch** soft key to select **DPickup** from the **Key Type** field.
5. Press  or  , or the **Switch** soft key to select the desired line from the **Account ID** field.
6. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.
7. Enter the directed call pickup code followed by the specific extension in the **Value** field.
8. Press the **Save** soft key to accept the change.

Group Call Pickup

Group call pickup is used for picking up incoming calls within a pre-defined group. If the group receives many incoming calls at once, the user will pick up the first incoming call, using a group pickup key or the **GPickup** soft key. This feature depends on support from a SIP server. For many SIP servers, group call pickup requires a group pickup code, which can be configured on a phone or a per-line basis.

Procedure

Group call pickup can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure the group call pickup code on a per-line basis. Parameters: account.X.group_pickup_code
		Configure group call pickup features on a phone basis. Parameters: features.pickup.group_pickup_enable features.pickup.group_pickup_code
	<y0000000000xx>.cfg	Assign a group call pickup key. Parameters: linekey.X.type/ programablekey.X.type/ expansion_module.X.key.Y.type linekey.X.line/ programablekey.X.line/ expansion_module.X.key.Y.line linekey.X.value/ programablekey.X.value/ expansion_module.X.key.Y.value linekey.X.label/

		<p>programablekey.X.label/ expansion_module.X.key.Y.label</p>
Local	Web User Interface	<p>Assign a group call pickup key.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=dsskey&q=load&model=0">http://<phoneIPAddress>/servlet?p=dsskey&q=load&model=0</p> <p>For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=dsskey&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=dsskey&q=load</p>
		<p>Configure the group call pickup code on a per-line basis.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0">http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0</p> <p>For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0">http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0</p>
		<p>Configure group call pickup feature on a phone basis.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=features-callpickup&q=load">http://<phoneIPAddress>/servlet?p=features-callpickup&q=load</p> <p>For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=features-callpickup&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=features-callpickup&q=load</p>

	Phone User Interface	Assign a group call pickup key.
--	----------------------	---------------------------------

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.pickup.group_pickup_enable	0 or 1	0
Description: Enables or disables the IP phone to display the GPickup soft key when the IP phone is on the dialing screen. 0 -Disabled 1 -Enabled Web User Interface: Features->Call Pickup->Group Call Pickup Phone User Interface: None		
account.X.group_pickup_code	String within 32 characters	Blank
Description: Configures the group pickup code for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIPT19(P) E2/CP860) Example: account.1.group_pickup_code = *69 Note: The group call pickup code configured on a per-line basis takes precedence over that configured on a phone basis. Web User Interface: Account->Advanced->Group Call Pickup Code Phone User Interface: None		
features.pickup.group_pickup_code	String within 32 characters	Blank
Description:		

Parameters	Permitted Values	Default
<p>Configures the group call pickup code on a phone basis.</p> <p>Example:</p> <pre>features.pickup.group_pickup_code = *98</pre> <p>Note: The group call pickup code configured on a per-line basis takes precedence over that configured on a phone basis.</p> <p>Web User Interface:</p> <p>Features->Call Pickup->Group Call Pickup Code</p> <p>Phone User Interface:</p> <p>None</p>		

Group Call Pickup Key

For more information on how to configure the DSS Key, refer to [Appendix D: Configuring DSS Key](#) on page 926.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
linekey.X.type/ programablekey.X.type/ expansion_module.X.key.Y.type	23	Refer to the following content
<p>Description:</p> <p>Configures a DSS key as a group call pickup key on the IP phone.</p> <p>The digit 23 stands for the key type Group Pickup.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For programable keys:</p> <p>X=1-4, 12-14 (for SIP VP-T49G)</p> <p>X=1-10, 12-14 (for SIP-T48G/T46G)</p> <p>X=1-10, 13 (for SIP-T42G/T41P/T40P)</p> <p>X=1-14 (for SIP-T29G/T27P)</p>		

Parameters	Permitted Values	Default
<p>X=1-10, 14 (for SIP-T23P/T23G/T21(P) E2)</p> <p>X=1-9, 13, 14 (for SIP-T19(P) E2)</p> <p>X=1-6, 9, 13 (for CP860)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Example:</p> <p>linekey.2.type = 23</p> <p>Default:</p> <p>For SIP VP-T49G/SIPT48G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-29 is 0.</p> <p>For SIPT46G/T29G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-27 is 0.</p> <p>For SIPT42G IP phones:</p> <p>The default value of the line key 1-12 is 15, and the default value of the line key 13-15 is 0.</p> <p>For SIPT41P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-15 is 0.</p> <p>For SIPT27P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-21 is 0.</p> <p>For SIPT40P/T23P/T23G/T21(P) E2 IP phones:</p> <p>The default value is 15.</p> <p>For programable keys:</p> <p>For SIP VP-T49G IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIPT48G/T46G IP phones:</p>		

Parameters	Permitted Values	Default
<p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIP-T42G/T41P/T40P IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>For SIP-T29G/T27P IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p>		

Parameters	Permitted Values	Default
<p>When X=10, the default value is 0 (NA).</p> <p>When X=11, the default value is 0 (NA).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIP-T23P/T23G/T21(P) E2 IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIP-T19(P) E2 IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For CP860 IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p>		

Parameters	Permitted Values	Default
<p>When X=6, the default value is 61 (Directory).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=13, the default value is 0 (NA).</p> <p>For ext keys:</p> <p>When Y=1, the default value is 37 (Switch).</p> <p>When Y= 2 to 20, 22 to 40, the default value is 0 (NA).</p> <p>Web User Interface:</p> <p>DSSKey->Line Key/Programable Key->Type</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Type</p>		
linekey.X.line/ programablekey.X.line/ expansion_module.X.key.Y.line	Refer to the following content	1-16 for lines 1-16, 1 for programable key
<p>Description:</p> <p>Configures the desired line to apply the group call pickup key.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G)</p> <p>X ranges from 1 to 27 (for SIPT46G/T29G)</p> <p>X ranges from 1 to 15 (for SIPT42G/T41P)</p> <p>X ranges from 1 to 21 (for SIPT27P)</p> <p>X ranges from 1 to 3 (for SIPT40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIPT21(P) E2)</p> <p>For programable keys:</p> <p>X=1-4, 12-14 (for SIP VP-T49G)</p> <p>X=1-10, 12-14 (for SIP-T48G/T46G)</p> <p>X=1-10, 13 (for SIPT42G/T41P/T40P)</p> <p>X=1-14 (for SIPT29G/T27P)</p> <p>X=1-10, 14 (for SIPT23P/T23G/T21(P) E2)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Permitted Values:</p> <p>1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G)</p> <p>1 to 12 (for SIPT42G)</p> <p>1 to 6 (for SIPT41P/T27P)</p>		

Parameters	Permitted Values	Default
1 to 3 (for SIP-T40P/T23P/T23G) 1 to 2 (for SIP-T21(P) E2) 1-Line 1 2-Line 2 ... 16-Line 16 Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones. Example: linekey.1.line = 1 Web User Interface: DSSKey->Line Key/ Programmable Key->Line Phone User Interface: Menu->Features->DSS Keys->Line Key X->Account ID		
linekey.X.value/ programablekey.X.value/ expansion_module.X.key.Y.value	String within 99 characters	Blank
Description: Configures the group call pickup feature code. For line keys: X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G) X ranges from 1 to 27 (for SIP-T46G/T29G) X ranges from 1 to 15 (for SIP-T42G/T41P) X ranges from 1 to 21 (for SIP-T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) For programmable keys: X=1-4, 12-14 (for SIP VP-T49G) X=1-10, 12-14 (for SIP-T48G/T46G) X=1-10, 13 (for SIP-T42G/T41P/T40P) X=1-14 (for SIP-T29G/T27P) X=1-10, 14 (for SIP-T23P/T23G/T21(P) E2) X=1-9, 13, 14 (for SIP-T19(P) E2) X=1-6, 9, 13 (for CP860) For ext keys: X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be		

Parameters	Permitted Values	Default
<p>configured).</p> <p>Example:</p> <p>linekey.2.value = *98</p> <p>Web User Interface:</p> <p>DSSKey->Line Key/ Programable Key->Value</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Value</p>		
linekey.X.label/ programablekey.X.label/ expansion_module.X.key.Y.label	String within 99 characters	Blank
<p>Description:</p> <p>(Optional.) Configures the label displayed on the LCD screen for each DSS key.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For programable keys:</p> <p>X ranges from 1 to 4.</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Web User Interface:</p> <p>DSSKey->Line Key/Programable Key->Label</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Label</p>		

To configure a group call pickup key via web user interface:

1. Click on **DSSKey->Line Key** (or **Programable Key**).
2. In the desired DSS key field, select **Group Pickup** from the pull-down list of **Type**.
3. Enter the group call pickup code in the **Value** field.
4. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.

5. Select the desired line from the pull-down list of **Line**.

The screenshot shows the Yealink T236 web interface. The 'DSSKey' tab is selected. Under the 'Line Key' section, 'Line Key2' is highlighted with a red box. The configuration for 'Line Key2' shows 'Type' as 'Group Pickup', 'Value' as '*98', and 'Line' as 'Line 1'. There are 'Confirm' and 'Cancel' buttons at the bottom.

6. Click **Confirm** to accept the change.

To configure the group call pickup code on a per-line basis via web user interface:

1. Click on **Account->Advanced**.
2. Select the desired account from the pull-down list of **Account**.
3. Enter the group call pickup code in the **Group Call Pickup Code** field.

The screenshot shows the Yealink T236 web interface. The 'Account' tab is selected, and the 'Advanced' sub-tab is active. The 'Account' dropdown is set to 'Account 1'. The 'Group Call Pickup Code' field is highlighted with a red box and contains the value '*98'. Other fields like 'Keep Alive Type', 'Keep Alive Interval(Seconds)', 'RPort', 'Subscribe Period(Seconds)', 'Early Media', 'SIP Server Type', 'Music Server URI', 'Directed Call Pickup Code', 'Distinctive Ring Tones', 'Unregister When Reboot', 'Out Dialog BLF', 'VQ RTPC-XR Collector name', 'VQ RTPC-XR Collector address', and 'VQ RTPC-XR Collector port' are also visible. There are 'Confirm' and 'Cancel' buttons at the bottom.

4. Click **Confirm** to accept the change.

To configure group call pickup feature on a phone basis via web user interface:

1. Click on **Features->Call Pickup**.
2. Select the desired value from the pull-down list of **Group Call Pickup**.

- Enter the group call pickup code in the **Group Call Pickup Code** field.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected. Under the 'Call Pickup' section, the 'Group Call Pickup' dropdown is set to 'Enabled' and the 'Group Call Pickup Code' text field contains '*98'. These two items are enclosed in a red rectangular box. Other settings in the 'Call Pickup' section include 'Directed Call Pickup' (Disabled), 'Directed Call Pickup Code' (empty), 'Visual Alert for BLF Pickup' (Disabled), and 'Audio Alert for BLF Pickup' (Disabled). Below this is the 'Call Park' section with 'Call Park Mode' (Transfer), 'Call Park' (Disabled), 'Call Park Code' (empty), and 'Park Retrieve Code' (empty). At the bottom are 'Confirm' and 'Cancel' buttons. A 'NOTE' sidebar on the right explains the 'Directed Call Pickup' and 'Visual Alert for BLF Pickup' features.

- Click **Confirm** to accept the change.

To configure a group pickup key via phone user interface:

- Press **Menu->Features->DSS Keys**.
- Select the desired DSS key.
- Press \leftarrow or \rightarrow , or the **Switch** soft key to select **Key Event** from the **Type** field.
- Press \leftarrow or \rightarrow , or the **Switch** soft key to select **GPickup** from the **Key Type** field.
- Press \leftarrow or \rightarrow , or the **Switch** soft key to select the desired line from the **Account ID** field.
- (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.
- Enter the group call pickup code in the **Value** field.
- Press the **Save** soft key to accept the change.

Dialog Info Call Pickup

Call pickup is implemented through SIP signals on some specific servers. When this feature is enabled, IP phones support picking up incoming calls via the INVITE message which includes a Replaces header in the message body. The value of Replaces is derived from a NOTIFY message with dialog-info event. A user can pick up an incoming call by pressing the DSS key used to monitor a specific extension (such as the BLF key). For more information on BLF, refer to [Busy Lamp Field \(BLF\)](#) on page 524.

If the visual alert for blf pickup feature is enabled, a user can also pick up an incoming call by pressing the **DPickup** soft key. For more information on visual alert for blf pickup, refer to [Visual Alert and Audio Alert for BLF Pickup](#) on page 526.

It is not applicable to SIP-T19(P) E2 and CP860 IP phones.

Note

In this way, you do not need to configure the directed call pickup code.

Example of the dialog-info carried in NOTIFY message:

```
<?xml version="1.0"?>
<dialog-info xmlns="urn:ietf:params:xml:ns:dialog-info" version="6" state="partial"
entity="sip:1011@10.2.1.48:5060">
<dialog id="65603" call-id="0_1756536024@10.10.20.34" local-tag="3408640225"
remote-tag="3779921438" direction="recipient">
<state>early</state>
<local>
<identity>sip:1011@10.2.1.48:5060</identity>
<target uri="sip:1011@10.2.1.48:5060"/>
</local>
<remote>
<identity>sip:1058@10.2.1.48:5060</identity>
<target uri="sip:1058@10.2.1.48:5060"/>
</remote>
</dialog>
</dialog-info>
```

Example of the Replaces carried in INVITE message:

```
Via: SIP/2.0/UDP 10.10.20.18:5060;branch=z9hG4bK2026058891
From: "1010" <sip:1010@10.2.1.48:5060>;tag=826048502
To: <sip:1058@10.2.1.48:5060>
Call-ID: 0_572446084@10.10.20.18
CSeq: 1 INVITE
Contact: <sip:1010@10.10.20.18:5060>
Content-Type: application/sdp
Allow: INVITE, INFO, PRACK, ACK, BYE, CANCEL, OPTIONS, NOTIFY, REGISTER, SUBSCRIBE, REFER,
PUBLISH, UPDATE, MESSAGE
Max-Forwards: 70
User-Agent: Yealink SIPT23G 44.80.0.60
Replaces: 0_1756536024@10.10.20.34;to-tag=3779921438;from-tag=3408640225
Allow-Events: talk,hold,conference,refer,check-sync
Supported: replaces
Content-Length: 304
```

Procedure

Dialog info call pickup can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure dialog info call pickup. Parameter: account.X.dialoginfo_callpickup
Local	Web User Interface	Configure dialog info call pickup. Navigate to:

		<p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2:</p> <p>http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0</p>
--	--	---

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
account.X.dialoginfo_callpickup	0 or 1	0
<p>Description:</p> <p>Enables or disables the IP phone to pick up a call according to the SIP header of dialog-info for account X.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 1 (Enabled), call pickup is implemented through SIP signals.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>Account->Advanced->Dialog Info Call Pickup</p> <p>Phone User Interface:</p> <p>None</p>		

To configure dialog info call pickup via web user interface:

1. Click on **Account->Advanced**.
2. Select the desired account from the pull-down list of **Account**.

3. Select the desired value from the pull-down list of **Dialog Info Call Pickup**.

The screenshot shows the Yealink T23G web interface. The 'Account' tab is selected. The 'Dialog Info Call Pickup' option is highlighted with a red box and set to 'Enabled'. The interface includes tabs for Status, Account, Network, DSSKey, Features, Settings, Directory, and Security. A sidebar on the left shows options like Register, Basic, Codec, and Advanced. A 'NOTE' section on the right provides information about DTMF, Session Timer, Busy Lamp Field/BLF List, Shared Call Appearance (SCA)/ Bridge Line Appearance (BLA), and Network Conference.

4. Click **Confirm** to accept the change.

Recent Call In Dialing

Recent call in dialing feature allows users to view the placed calls list when the phone is on the dialing screen.

Procedure

Recent call in dialing can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure recent call in dialing feature. Parameters: super_search.recent_call
Local	Web User Interface	Configure recent call in dialing feature. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p=contacts-favorite&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet?m=

		mod_data&p=contacts-favorite&q=load
--	--	-------------------------------------


Details of Configuration Parameters:

Parameters	Permitted Values	Default
super_search.recent_call	0 or 1	Refer to the following content
<p>Description: Enables or disables recent call in dialing feature.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 1 (Enabled), you can see the placed calls list when the IP phone is on the dialing screen.</p> <p>For SIP VP-T49G: The default value is 1.</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: The default value is 0.</p> <p>Web User Interface: Directory->Setting->Recent Call In Dialing</p> <p>Phone User Interface: None</p>		

To configure recent call in dialing via web user interface:

1. Click on **Directory->Setting**.

2. Select the desired value from the pull-down list of **Recent Call In Dialing**.



3. Click **Confirm** to accept the change.

ReCall

ReCall, also known as last call return, allows users to place a call back to the last caller. Recall is implemented on IP phones using a recall key.

Procedure

Recall key can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Assign a recall key. Parameter: linekey.X.type/ programablekey.X.type/ expansion_module.X.key.Y.type linekey.X.label/ programablekey.X.label/ expansion_module.X.key.Y.label
Local	Web User Interface	Assign a recall key. Navigate to: For SIPT48G/T46G/T42G/T41P/T40P/T2 9G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:

		http://<phoneIPAddress>/servlet ?p=dsskey&q=load&model=0 For SIP VP-T49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=dsskey&q=load
	Phone User Interface	Assign a recall key.

ReCall Key

For more information on how to configure the DSS Key, refer to [Appendix D: Configuring DSS Key](#) on page 926.

Details of Configuration Parameters:

Parameter	Permitted Values	Default
linekey.X.type/ programablekey.X.type/ expansion_module.X.key.Y.type	7	Refer to the following content
<p>Description:</p> <p>Configures a DSS key as a recall key on the IP phone.</p> <p>The digit 7 stands for the key type ReCall.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For programable keys:</p> <p>X=1-4, 12-14 (for SIP VP-T49G)</p> <p>X=1-10, 12-14 (for SIP-T48G/T46G)</p> <p>X=1-10, 13 (for SIP-T42G/T41P/T40P)</p> <p>X=1-14 (for SIP-T29G/T27P)</p> <p>X=1-10, 14 (for SIP-T23P/T23G/T21(P) E2)</p> <p>X=1-9, 13, 14 (for SIP-T19(P) E2)</p> <p>X=1-6, 9, 13 (for CP860)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be</p>		

Parameter	Permitted Values	Default
<p>configured).</p> <p>Example:</p> <p>linekey.1.type = 7</p> <p>Default:</p> <p>For SIP VP-T49G/SIPT48G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-29 is 0.</p> <p>For SIPT46G/T29G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-27 is 0.</p> <p>For SIPT42G IP phones:</p> <p>The default value of the line key 1-12 is 15, and the default value of the line key 13-15 is 0.</p> <p>For SIPT41P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-15 is 0.</p> <p>For SIPT27P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-21 is 0.</p> <p>For SIPT40P/T23P/T23G/T21(P) E2 IP phones:</p> <p>The default value is 15.</p> <p>For programmable keys:</p> <p>For SIP VP-T49G IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIPT48G/T46G IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p>		

Parameter	Permitted Values	Default
<p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIP-T42G/T41P/T40P IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>For SIP-T29G/T27P IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=11, the default value is 0 (NA).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p>		

Parameter	Permitted Values	Default
For SIP-T23P/T23G/T21(P) E2 IP phones: When X=1, the default value is 28 (History). When X=2, the default value is 61 (Directory). When X=3, the default value is 5 (DND). When X=4, the default value is 30 (Menu). When X=5, the default value is 28 (History). When X=6, the default value is 61 (Directory). When X=7, the default value is 0 (NA). When X=8, the default value is 0 (NA). When X=9, the default value is 33 (Status). When X=10, the default value is 0 (NA). When X=14, the default value is 2 (Forward). For SIP-T19(P) E2 IP phones: When X=1, the default value is 28 (History). When X=2, the default value is 61 (Directory). When X=3, the default value is 5 (DND). When X=4, the default value is 30 (Menu). When X=5, the default value is 28 (History). When X=6, the default value is 61 (Directory). When X=7, the default value is 0 (NA). When X=8, the default value is 0 (NA). When X=9, the default value is 33 (Status). When X=13, the default value is 0 (NA). When X=14, the default value is 2 (Forward). For CP860 IP phones: When X=1, the default value is 28 (History). When X=2, the default value is 61 (Directory). When X=3, the default value is 5 (DND). When X=4, the default value is 30 (Menu). When X=5, the default value is 28 (History). When X=6, the default value is 61 (Directory). When X=9, the default value is 33 (Status). When X=13, the default value is 0 (NA). For ext keys: When Y=1, the default value is 37 (Switch).		

Parameter	Permitted Values	Default
<p>When Y= 2 to 20, 22 to 40, the default value is 0 (NA).</p> <p>Web User Interface:</p> <p>DSSKey->Line Key/ Programable Key->Type</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Type</p>		
linekey.X.label/ programablekey.X.label/ expansion_module.X.key.Y.label	String within 99 characters	Blank
<p>Description:</p> <p>(Optional.) Configures the label displayed on the LCD screen for each DSS key.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For programable keys:</p> <p>X ranges from 1 to 4.</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Web User Interface:</p> <p>DSSKey->Line Key/Programable Key->Label</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Label</p>		

To configure a recall key via web user interface:

1. Click on **DSSKey->Line Key** (or **Programable Key**).
2. In the desired DSS key field, select **ReCall** from the pull-down list of **Type**.

- (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.

- Click **Confirm** to accept the change.

To configure a recall key via phone user interface:

- Press **Menu->Features->DSS Keys**.
- Select the desired DSS key.
- Press **◀** or **▶**, or the **Switch** soft key to select **Key Event** from the **Type** field.
- Press **◀** or **▶**, or the **Switch** soft key to select **ReCall** from the **Key Type** field.
- (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.
- Press the **Save** soft key to accept the change.

Call Number Filter

Call number filter feature allows IP phone to automatically filter designated characters when dialing.

Procedure

Call number filter can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the characters the IP phone filters when dialing. Parameters: features.call_num_filter
Local	Web User Interface	Configure the characters the IP phone filters when dialing. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/ T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p=features-general&q=load For SIP VP-T49G:

		http://<phoneIPAddress>/servlet?m =mod_data&p=features-general&q =load
--	--	--

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.call_num_filter	String within 99 characters	, -
<p>Description: Configures the characters the IP phone filters when dialing. If the dialed number contains configured characters, the IP phone will automatically filter these characters when dialing.</p> <p>Example: features.call_num_filter = , -12 If you dial 3-61, the IP phone will filter the characters – and 1, and then dial out 36.</p> <p>Note: If it is left blank, the IP phone will not automatically filter any characters when dialing. If you want to filter just a space, you have to set the value to " ," (a space first followed by a comma).</p> <p>Web User Interface: Features->General Information->Call Number Filter</p> <p>Phone User Interface: None</p>		

To configure the characters the IP phone will filter via web user interface:

1. Click on **Feature->General Information**.

2. Enter the desired characters in the **Call Number Filter** field.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected, and the 'General Information' section is active. The 'Call Number Filter' field is highlighted with a red box. The field contains the characters '-'. Other settings visible include 'Call Waiting' (Enabled), 'Auto Redial' (Disabled), 'Auto Redial Interval' (10), 'Auto Redial Times' (10), 'Diversion/History-Info' (Enabled), 'Allow Trans Exist Call' (Enabled), 'BLF LED Mode' (0), 'Auto-Logout Time' (5), and 'Auto Linekeys' (Disabled). A 'NOTE' section on the right provides details about 'Call Waiting', 'Auto Redial', 'Key As Send', 'Hotline', and 'Call Completion'.

3. Click **Confirm** to accept the change.

Call Park

Call park allows users to park a call on a special extension and then retrieve it on any other phone in the system. Users can park calls on the extension, known as call park orbit, by pressing a call park key or **Park** soft key. The current call is placed on hold and can be retrieved by pressing a retrieve park key or **Retrieve** soft key on another IP phone.

Yealink IP phones support call park feature under the following modes:

- FAC mode (dial the call park code to park the call to desired or local extension)
- Transfer mode (park the call to directional parking lot directly)

You need to configure the park code or retrieve code before using call park feature. This feature depends on support from a SIP server.

Note The retrieve park key is not applicable to SIP-T19(P) E2 IP phones. The FAC/Transfer mode is not applicable to SIP VP-T49G IP phones, and the SIP VP-T49G IP phones only support the call park key.

Call park feature is not applicable to CP860 IP phones.

Procedure

Call park can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the call park feature. Parameters:
---------------------------	---------------------	--

		features.call_park.park_mode call_park.enable
		Configure the call park code/call park number. Parameters: features.call_park.park_code
		Configure the park retrieve code/park retrieval number. Parameters: features.call_park.park_retrieve_code
		Assign a call park key. Assign a retrieve park key. Parameters: linekey.X.type/ expansion_module.X.key.Y.type linekey.X.line/ expansion_module.X.key.Y.line linekey.X.value/ expansion_module.X.key.Y.value linekey.X.label/ expansion_module.X.key.Y.label
Local	Web User Interface	Configure the call park feature. Configure the call park code/call park number. Configure the park retrieve code/park retrieval number. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2: <a href="http://<phoneIPAddress>/servlet?p=features-callpickup&q=load">http://<phoneIPAddress>/servlet?p=features-callpickup&q=load
		Assign a call park key. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T2

		9G/T27P/T23P/T23G/T21(P) E2: http://<phoneIPAddress>/servlet? p=dsskey&q=load&model=0 For SIP VP-T49G: http://<phoneIPAddress>/servlet? m=mod_data&p=dsskey&q=load
		Assign a retrieve park key. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T2 9G/T27P/T23P/T23G/T21(P) E2: http://<phoneIPAddress>/servlet? p=dsskey&q=load&model=0
	Phone User Interface	Assign a call park key. Assign a retrieve park key.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.call_park.park_mode	1 or 2	2
Description: Configures the call park mode. 1-FAC 2-Transfer Note: It is not applicable to SIP VP-T49G/CP860 IP phones. Web User Interface: Features->Call Pickup->Call Park Mode Phone User Interface: None		
call_park.enable	0 or 1	1
Description: Enables or disables the IP phone to display the Park soft key during a call. 0-Disabled 1-Enabled Note: If it is set to 1 (Enabled), the Retrieve soft key will also be displayed on the		

dialing screen. It is not applicable to SIP VP-T49G/CP860 IP phones. Web User Interface: Features->Call Pickup->Call Park Phone User Interface: None		
features.call_park.park_code	String within 32 characters	Blank
Description: Configures the call park code/call park number for the Park soft key. This call park code/call park number will also apply to the call park key. Note: It is not applicable to SIP VP-T49G/CP860 IP phones. Web User Interface: Features->Call Pickup->Call Park Code Phone User Interface: None		
features.call_park.park_retrieve_code	String within 32 characters	Blank
Description: Configures the park retrieve code/park retrieval number for the Retrieve soft key. This park retrieve code/park retrieval number will also apply to the retrieve park key. Note: It is not applicable to SIP VP-T49G/CP860 IP phones. Web User Interface: Features->Call Pickup->Park Retrieve Code Phone User Interface: None		

Call Park Key

For more information on how to configure the DSS Key, refer to [Appendix D: Configuring DSS Key](#) on page 926.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
linekey.X.type/ expansion_module.X.key.Y.type	10	Refer to the following content

Parameters	Permitted Values	Default
<p>Description:</p> <p>Configures a DSS key as a call park key on the IP phone.</p> <p>The digit 10 stands for the key type Call Park.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G)</p> <p>X ranges from 1 to 27 (for SIPT46G/T29G)</p> <p>X ranges from 1 to 15 (for SIPT42G/T41P)</p> <p>X ranges from 1 to 21 (for SIPT27P)</p> <p>X ranges from 1 to 3 (for SIPT40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIPT21(P) E2)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Example:</p> <p>linekey.1.type = 10</p> <p>Default:</p> <p>For SIP VP-T49G/SIPT48G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-29 is 0.</p> <p>For SIPT46G/T29G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-27 is 0.</p> <p>For SIPT42G IP phones:</p> <p>The default value of the line key 1-12 is 15, and the default value of the line key 13-15 is 0.</p> <p>For SIPT41P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-15 is 0.</p> <p>For SIPT27P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-21 is 0.</p> <p>For SIPT40P/T23P/T23G/T21(P) E2 IP phones:</p> <p>The default value is 15.</p> <p>For ext keys:</p> <p>When Y=1, the default value is 37 (Switch).</p>		

Parameters	Permitted Values	Default
<p>When Y= 2 to 20, 22 to 40, the default value is 0 (NA).</p> <p>Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface: DSSKey->Line key->Type</p> <p>Phone User Interface: Menu->Features->DSS Keys->Line Key X->Type</p>		
linekey.X.line/ expansion_module.X.key.Y.line	Refer to the following content	1-16 correspond to the lines 1-16
<p>Description:</p> <p>Configures the desired line to apply the call park key.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Permitted Values:</p> <p>1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>1 to 12 (for SIP-T42G)</p> <p>1 to 6 (for SIP-T41P/T27P)</p> <p>1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>1 to 2 (for SIP-T21(P) E2)</p> <p>1-Line 1</p> <p>2-Line 2</p> <p>...</p> <p>16-Line 16</p> <p>Example:</p> <p>linekey.1.line = 1</p> <p>Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface: DSSKey->Line key->Line</p>		

Parameters	Permitted Values	Default
Phone User Interface: Menu->Features->DSS Keys->Line Key X->Account ID		
linekey.X.value/ expansion_module.X.key.Y.value	String within 99 characters	Blank
Description: Configures the call park feature code. For line keys: X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G) X ranges from 1 to 27 (for SIP-T46G/T29G) X ranges from 1 to 15 (for SIP-T42G/T41P) X ranges from 1 to 21 (for SIP-T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) For ext keys: X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured). Example: linekey.1.value = *88 Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones. Web User Interface: DSSKey->Line key->Value Phone User Interface: Menu->Features->DSS Keys->Line Key X->Value		
linekey.X.label/ expansion_module.X.key.Y.label	String within 99 characters	Blank
Description: (Optional.) Configures the label displayed on the LCD screen for each DSS key. For line keys: X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G) X ranges from 1 to 27 (for SIP-T46G/T29G) X ranges from 1 to 15 (for SIP-T42G/T41P) X ranges from 1 to 21 (for SIP-T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2)		

Parameters	Permitted Values	Default
<p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>DSSKey->Line Key->Label</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Label</p>		

Retrieve Park Key

For more information on how to configure the DSS Key, refer to [Appendix D: Configuring DSS Key](#) on page 926.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
linekey.X.type/ expansion_module.X.key.Y.type	56	Refer to the following content
<p>Description:</p> <p>Configures a DSS key as a call park key on the IP phone.</p> <p>The digit 56 stands for the key type Retrieve Park.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G)</p> <p>X ranges from 1 to 27 (for SIPT46G/T29G)</p> <p>X ranges from 1 to 15 (for SIPT42G/T41P)</p> <p>X ranges from 1 to 21 (for SIPT27P)</p> <p>X ranges from 1 to 3 (for SIPT40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIPT21(P) E2)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Example:</p> <p>linekey.1.type = 56</p> <p>Default:</p> <p>For SIP VP-T49G/SIPT48G IP phones:</p>		

Parameters	Permitted Values	Default
<p>The default value of the line key 1-16 is 15, and the default value of the line key 17-29 is 0.</p> <p>For SIP-T46G/T29G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-27 is 0.</p> <p>For SIP-T42G IP phones:</p> <p>The default value of the line key 1-12 is 15, and the default value of the line key 13-15 is 0.</p> <p>For SIP-T41P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-15 is 0.</p> <p>For SIP-T27P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-21 is 0.</p> <p>For SIP-T40P/T23P/T23G/T21(P) E2 IP phones:</p> <p>The default value is 15.</p> <p>For ext keys:</p> <p>When Y=1, the default value is 37 (Switch).</p> <p>When Y= 2 to 20, 22 to 40, the default value is 0 (NA).</p> <p>Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>DSSKey->Line key->Type</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Type</p>		
linekey.X.line/ expansion_module.X.key.Y.line	Refer to the following content	1-16 correspond to the lines 1-16
<p>Description:</p> <p>Configures the desired line to apply the call park key.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p>		

Parameters	Permitted Values	Default
<p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Permitted Values:</p> <p>1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>1 to 12 (for SIP-T42G)</p> <p>1 to 6 (for SIP-T41P/T27P)</p> <p>1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>1 to 2 (for SIP-T21(P) E2)</p> <p>1-Line 1</p> <p>2-Line 2</p> <p>...</p> <p>16-Line 16</p> <p>Example:</p> <p>linekey.1.line = 1</p> <p>Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>DSSKey->Line key->Line</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Account ID</p>		
linekey.X.value/ expansion_module.X.key.Y.value	String within 99 characters	Blank
<p>Description:</p> <p>Configures the call park feature code.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G)</p> <p>X ranges from 1 to 27 (for SIPT46G/T29G)</p> <p>X ranges from 1 to 15 (for SIPT42G/T41P)</p> <p>X ranges from 1 to 21 (for SIPT27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Example:</p>		

Parameters	Permitted Values	Default
linekey.1.value = *88 Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones. Web User Interface: DSSKey->Line key->Value Phone User Interface: Menu->Features->DSS Keys->Line Key X->Value		
linekey.X.label/ expansion_module.X.key.Y.label	String within 99 characters	Blank
Description: (Optional.) Configures the label displayed on the LCD screen for each DSS key. For line keys: X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G) X ranges from 1 to 27 (for SIP-T46G/T29G) X ranges from 1 to 15 (for SIP-T42G/T41P) X ranges from 1 to 21 (for SIP-T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) For ext keys: X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured). Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones. Web User Interface: DSSKey->Line Key->Label Phone User Interface: Menu->Features->DSS Keys->Line Key X->Label		

To configure call park feature in FAC mode via web user interface:

1. Click on **Features->Call Pickup**.
2. Select **FAC** from the pull-down list of **Call Park Mode**.
3. Select **Enabled** from the pull-down list of **Call Park**.
4. (Optional.) Enter the call park code in the **Call Park Code** field.

- (Optional.) Enter the park retrieve code in the **Park Retrieve Code** field.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected. Under 'Call Pickup', the 'Call Park' section is highlighted with a red box. The settings are as follows:

Field	Value
Call Park Mode	FAC
Call Park	Enabled
Call Park Code	*68
Park Retrieve Code	*88

The 'Confirm' button is at the bottom of the 'Call Park' section.

- Click **Confirm** to accept the change.

To configure call park feature in transfer mode via web user interface:

- Click on **Features->Call Pickup**.
- Select **Transfer** from the pull-down list of **Call Park Mode**.
- Select **Enabled** from the pull-down list of **Call Park**.
- (Optional.) Enter the call park number in the **Call Park Code** field.
- (Optional.) Enter the park retrieval number in the **Park Retrieve Code** field.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected. Under 'Call Pickup', the 'Call Park' section is highlighted with a red box. The settings are as follows:

Field	Value
Call Park Mode	Transfer
Call Park	Enabled
Call Park Code	*01
Park Retrieve Code	*11

The 'Confirm' button is at the bottom of the 'Call Park' section.



- Click **Confirm** to accept the change.

To configure a call park key via phone user interface:

- Press **Menu->Features->DSS Keys**.
- Select the desired DSS key.
- Press **◀** or **▶**, or the **Switch** soft key to select **Key Event** from the **Type** field.
- Press **◀** or **▶**, or the **Switch** soft key to select **Call Park** from the **Key Type** field.
- Select the desired line from the **Account ID** field.

6. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.
7. (Optional.) Enter the call park code/call park number in the **Value** field.
8. Press the **Save** soft key to accept the change.

To configure a retrieve park key via phone user interface:

1. Press **Menu->Features->DSS Keys**.
2. Select the desired DSS key.
3. Press  or  , or the **Switch** soft key to select **Retrieve Park** from the **Type** field.
4. Select the desired line from the **Account ID** field.
5. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.
6. (Optional.) Enter the park retrieve code/park retrieval number in the **Value** field.
7. Press the **Save** soft key to accept the change.

Calling Line Identification Presentation

Calling Line Identification Presentation (CLIP) allows IP phones to display the caller identity, derived from a SIP header contained in the INVITE message when receiving an incoming call. IP phones support deriving caller identity from three types of SIP header: From, P-Asserted-Identity (PAI) and Remote-Party-ID (RPID). Identity presentation is based on the identity in the relevant SIP header.

Note

If the caller already exists in the local directory, the local contact name assigned to the caller should be preferentially displayed and stored in the call log.

The following sessions show the enhancements of calling line identification presentation according to the calling line identification source configured on the IP phones.

Caller ID source = FROM

- 1) The IP phone checks Privacy: id header preferentially, if there is a Privacy: id in the INVITE request, the calling line identification information will be hidden and the IP phone LCD screen presents anonymous.
- 2) If there is not any Privacy: id header in the INVITE request, the IP phone checks and presents the caller identification from the P-Preferred-Identity header.
- 3) If there is not P-Preferred-Identity header in the INVITE request, the IP phone presents the caller identification derived from the FROM header.

Caller ID source = PAI

- 1) The IP phone checks Privacy: id header preferentially, if there is a Privacy: id in the INVITE request, the caller identification information will be hidden and the IP phone

LCD screen presents anonymous.

- 2) If there is not any Privacy: id header in the INVITE request, the IP phone checks and presents the caller identification from the P-Preferred-Identity header.
- 3) If there is not P-Preferred-Identity header in the INVITE request, the IP phone checks and presents the caller identification from the P-Asserted-Identity header.

Caller ID source = PAI-FROM

- 1) The IP phone checks Privacy: id header preferentially, if there is a Privacy: id in the INVITE request, the caller identification information will be hidden and the IP phone LCD screen presents anonymous.
- 2) If there is not any Privacy: id header in the INVITE request, the IP phone checks and presents the caller identification from the P-Preferred-Identity header.
- 3) If there is not P-Preferred-Identity header in the INVITE request, the IP phone checks and presents the caller identification from the P-Asserted-Identity header.
- 4) If there is not P-Asserted-Identity header in the INVITE request, the IP phone presents the caller identification derived from the FROM header.

Caller ID source = RPID-FROM

- 1) The IP phone checks Privacy: id header preferentially, if there is a Privacy: id in the INVITE request, the caller identification information will be hidden and the IP phone LCD screen presents anonymous.
- 2) If there is not any Privacy: id header in the INVITE request, the IP phone checks and presents the caller identification from the P-Preferred-Identity header.
- 3) If there is not P-Preferred-Identity header in the INVITE request, the IP phone checks and presents the caller identification from the Remote-Party-ID header.
- 4) If there is not Remote-Party-ID header in the INVITE request, the IP phone presents the caller identification derived from the FROM header.

Caller ID source = PAI-RPID-FROM

- 1) The IP phone checks Privacy: id header preferentially, if there is a Privacy: id in the INVITE request, the caller identification information will be hidden and the IP phone LCD screen presents anonymous.
- 2) If there is not any Privacy: id header in the INVITE request, the IP phone checks and presents the caller identification from the P-Preferred-Identity header.
- 3) If there is not P-Preferred-Identity header in the INVITE request, the IP phone checks and presents the caller identification from the P-Asserted-Identity header.
- 4) If there is not P-Asserted-Identity header in the INVITE request, the IP phone checks and presents the caller identification from the Remote-Party-ID header.
- 5) If there is not Remote-Party-ID header in the INVITE request, the IP phone presents the caller identification derived from the FROM header.

Caller ID source = RPID-PAI-FROM

- 1) The IP phone checks Privacy: id header preferentially, if there is a Privacy: id in the INVITE request, the caller identification information will be hidden and the IP phone LCD screen presents anonymous.
- 2) If there is not any Privacy: id header in the INVITE request, the IP phone checks and presents the caller identification from the P-Preferred-Identity header.
- 3) If there is not P-Preferred-Identity header in the INVITE request, the IP phone checks and presents the caller identification from the Remote-Party-ID header.
- 4) If there is not Remote-Party-ID header in the INVITE request, the IP phone checks and presents the caller identification from the P-Asserted-Identity header.
- 5) If there is not P-Asserted-Identity in the INVITE request, the IP phone presents the caller identification derived from the FROM header.

For more information on calling line identification presentation, refer to [Calling and Connected Line Identification Presentation on Yealink IP Phones](#).

Procedure

CLIP can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure the presentation of the caller identity. Parameter: account.X.cid_source
		Specify whether to process Privacy header field. Parameter: account.X.cid_source_privacy
		Specify whether to process the P-Preferred-Identity (PPI) header for caller identity presentation. Parameter: account.X.cid_source_ppi
Local	Web User Interface	Configure the presentation of the caller identity. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:

		<p>http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0</p>
--	--	--

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
account.X.cid_source	0, 1, 2, 3, 4 or 5	0
<p>Description:</p> <p>Configures the presentation of the caller identity when receiving an incoming call for account X.</p> <p>0-FROM</p> <p>1-PAI</p> <p>2-PAI-FROM</p> <p>3-RPID-PAI-FROM</p> <p>4-PAI-RPID-FROM</p> <p>5-RPID-FROM</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Web User Interface:</p> <p>Account->Advanced->Caller ID Source</p> <p>Phone User Interface:</p> <p>None</p>		
account.X.cid_source_privacy	0 or 1	1
<p>Description:</p> <p>Enables or disables the IP phone to process Privacy header field in the SIP message for account X.</p> <p>0-Disabled</p>		

Parameter	Permitted Values	Default
1-Enabled X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Web User Interface: None Phone User Interface: None		
account.X.cid_source_ppi	0 or 1	1
Description: Enables or disables the IP phone to process the P-Preferred-Identity (PPI) header for caller identity presentation when receiving an incoming call for account X. 0-Disabled 1-Enabled X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Web User Interface: None Phone User Interface: None		

To configure the presentation of the caller identity via web user interface:

1. Click on **Account->Advanced**.
2. Select the desired account from the pull-down list of **Account**.

3. Select the desired value from the pull-down list of **Caller ID Source**.

The screenshot shows the Yealink T236 web interface. The 'Account' tab is selected. The 'Account' section is expanded, showing various settings. The 'Caller ID Source' dropdown is highlighted with a red box and set to 'FROM'. The 'NOTE' section on the right contains information about DTMF, Session Timer, Busy Lamp Field/BLF List, and Shared Call Appearance (SCA)/ Bridge Line Appearance (BLA).

Setting	Value
Account	Account 1
Keep Alive Type	Default
Keep Alive Interval(Seconds)	30
RPort	Disabled
Subscribe Period(Seconds)	1800
DTMF Type	RFC2833
DTMF Info Type	DTMF-Relay
DTMF Payload Type(96~127)	101
Retransmission	Disabled
Subscribe Register	Disabled
Subscribe for MWI	Disabled
MWI Subscription Period(Seconds)	3600
Subscribe MWI To Voice Mail	Disabled
Voice Mail	
Voice Mail Display	Enabled
Caller ID Source	FROM

NOTE

DTMF
It is the signal sent from the IP phone to the network, which is generated when pressing the IP phone's keypad during a call.

Session Timer
It allows a periodic refresh of SIP sessions through a re-INVITE request, to determine whether a SIP session is still active.

Busy Lamp Field/BLF List
Monitors a specific extension/a list of extensions for status changes on IP phones.

Shared Call Appearance (SCA)/ Bridge Line Appearance (BLA)
It allows users to share a SIP line on several IP phones. Any IP phone can be used to originate or receive calls on the shared line.

4. Click **Confirm** to accept the change.

Connected Line Identification Presentation

Connected Line Identification Presentation (COLP) allows IP phones to display the identity of the connected party specified for outgoing calls. IP phones can display the Dialed Digits, or the identity in a SIP header (Remote-Party-ID or P-Asserted-Identity) received, or the identity in the From header carried in the UPDATE message sent by the callee as described in RFC 4916. Connected line identification presentation is also known as Called line identification presentation. In some cases, the remote party will be different from the called line identification presentation due to call diversion.

Note

If the callee already exists in the local directory, the local contact name assigned to the callee should be preferentially displayed.

The following sessions show the enhancements of connected line identification according to the connected line identification source configured on the IP phones.

Connected Line Identification source = PAI-RPID

- 1) The IP phone checks Privacy: id header preferentially, if there is a Privacy: id in the 18X or 200OK response, the connected line identification information will be hidden and the IP phone LCD screen presents anonymous.
- 2) If there is not any Privacy: id header in the 18X or 200OK response, the IP phone checks and presents the connected line identification from the P-Asserted-Identity header.
- 3) If there is not P-Asserted-Identity header in the 18X or 200OK response, the IP phone

presents the connected line identification from the Remote-Party-ID header. If no, the IP phone presents the connected line identification according to the dialed digits.

Connected Line Identification source = Dialed digits

Yealink IP phones present the connected line identification according to the dialed digits.

Connected Line Identification source = RFC4916

Yealink IP phones support to present the connected line identification from UPDATE message following the RFC 4916.

- 1) The IP phone receives an UPDATE message during a call, the connected line identification on the LCD screen should be refreshed according the FROM SIP carried in the UPDATE message.

For more information on connected line identification presentation, refer to [Calling and Connected Line Identification Presentation on Yealink IP Phones](#).

Procedure

COLP can be configured only using the configuration files.

Configuration File	<MAC>.cfg	Configure the presentation of the callee's identity. Parameter: account.X.cp_source
		Specify whether to process Privacy header field. Parameter: account.X.cid_source_privacy

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
account.X.cp_source	0, 1 or 2	0
Description: Configures the presentation of the callee's identity for account X. 0-PAI-RPID 1-Dialed Digits 2-RFC 4916		

Parameter	Permitted Values	Default
<p>When the RFC 4916 is enabled on the IP phone, the caller sends the SIP request message which contains the from-change tag in the Supported header. The caller then receives an UPDATE message from the callee, and displays the identity in the "From" header.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIPT42G)</p> <p>X ranges from 1 to 6 (for SIPT41P/T27P)</p> <p>X ranges from 1 to 3 (for SIPT40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIPT21(P) E2)</p> <p>X is equal to 1 (for SIPT19(P) E2/CP860)</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		
account.X.cid_source_privacy	0 or 1	1
<p>Description:</p> <p>Enables or disables the IP phone to process Privacy header field in the SIP message for account X.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIPT42G)</p> <p>X ranges from 1 to 6 (for SIPT41P/T27P)</p> <p>X ranges from 1 to 3 (for SIPT40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIPT21(P) E2)</p> <p>X is equal to 1 (for SIPT19(P) E2/CP860)</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		

DTMF

DTMF (Dual Tone Multi-frequency), better known as touch-tone, is used for telecommunication signaling over analog telephone lines in the voice-frequency band.

DTMF is the signal sent from the IP phone to the network, which is generated when pressing the IP phone's keypad during a call. Each key pressed on the IP phone generates one sinusoidal tone of two frequencies. One is generated from a high frequency group and the other from a low frequency group.

The DTMF keypad is laid out in a 4×4 matrix, with each row representing a low frequency, and each column representing a high frequency. Pressing a digit key (such as '1') will generate a sinusoidal tone for each of two frequencies (697 and 1209 hertz (Hz)).

DTMF Keypad Frequencies:

	1209 Hz	1336 Hz	1477 Hz	1633 Hz
697 Hz	1	2	3	A
770 Hz	4	5	6	B
852 Hz	7	8	9	C
941 Hz	*	0	#	D

Methods of Transmitting DTMF Digit

Three methods of transmitting DTMF digits on SIP calls:

- **RFC 2833** -- DTMF digits are transmitted by RTP Events compliant to RFC 2833.
- **INBAND** -- DTMF digits are transmitted in the voice band.
- **SIP INFO** -- DTMF digits are transmitted by SIP INFO messages.

The method of transmitting DTMF digits is configurable on a per-line basis.

RFC 2833

DTMF digits are transmitted using the RTP Event packets that are sent along with the voice path. These packets use RFC 2833 format and must have a payload type that matches what the other end is listening for. The payload type for RTP Event packets is configurable. IP phones default to 101 for the payload type, which use the definition to negotiate with the other end during call establishment.

The RTP Event packet contains 4 bytes. The 4 bytes are distributed over several fields denoted as Event, End bit, R-bit, Volume and Duration. If the End bit is set to 1, the packet contains the end of the DTMF event. You can configure the sending times of the end RTP Event packet.

INBAND

DTMF digits are transmitted within the audio of the IP phone conversation. It uses the same codec as your voice and is audible to conversation partners.

SIP INFO

DTMF digits are transmitted by the SIP INFO messages when the voice stream is established after a successful SIP 200 OK-ACK message sequence. The SIP INFO message is sent along the signaling path of the call. The SIP INFO message can transmit DTMF digits in three ways: DTMF, DTMF-Relay and Telephone-Event.

Procedure

Configuration changes can be performed using the configuration files or locally.

Configuration File	<MAC>.cfg	<p>Configure the method of transmitting DTMF digit and the payload type.</p> <p>Parameters:</p> <p>account.X.dtmf.type</p> <p>account.X.dtmf.dtmf_payload</p> <p>account.X.dtmf.info_type</p>
	<y0000000000xx>.cfg	<p>Configure the number of times for the IP phone to send the end RTP Event packet.</p> <p>Parameter:</p> <p>features.dtmf.repetition</p>
		<p>Configure the duration time for DTMF.</p> <p>Parameter:</p> <p>features.dtmf.duration</p>
		<p>Configure the frequency level of DTMF digits.</p> <p>Parameter:</p> <p>features.dtmf.volume</p>
Local	Web User Interface	<p>Configure the method of transmitting DTMF digits and the payload type.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=account-adv&q=load&ac">http://<phoneIPAddress>/servlet?p=account-adv&q=load&ac</p>

		<p>c=0</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0</p>
		<p>Configure the number of times for the IP phone to send the end RTP Event packet.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>http://<phoneIPAddress>/servlet?p=features-general&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
account.X.dtmf.type	0, 1, 2 or 3	1
<p>Description:</p> <p>Configures the DTMF type for account X.</p> <p>0-INBAND</p> <p>1-RFC 2833</p> <p>2-SIP INFO</p> <p>3-RFC2833 + SIP INFO</p> <p>If it is set to 0 (INBAND), DTMF digits are transmitted in the voice band.</p> <p>If it is set to 1 (RFC 2833), DTMF digits are transmitted by RTP Events compliant to RFC 2833.</p> <p>If it is set to 2 (SIP INFO), DTMF digits are transmitted by the SIP INFO messages.</p> <p>If it is set to 3 (RFC2833 + SIP INFO), DTMF digits are transmitted by RTP Events</p>		

Parameters	Permitted Values	Default
<p>compliant to RFC 2833 and the SIP INFO messages.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIPT42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Web User Interface:</p> <p>Account->Advanced->DTMF Type</p> <p>Phone User Interface:</p> <p>None</p>		
account.X.dtmf.dtmf_payload	Integer from 96 to 127	101
<p>Description:</p> <p>Configures the value of DTMF payload for account X.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIPT42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Note: It works only if the value of parameter "account.X.dtmf.type" is set to 1 (RFC2833) or 3 (RFC2833 + SIP INFO).</p> <p>Web User Interface:</p> <p>Account->Advanced->DTMF Payload Type(96~127)</p> <p>Phone User Interface:</p> <p>None</p>		
account.X.dtmf.info_type	1, 2 or 3	1
<p>Description:</p> <p>Configures the DTMF info type.</p> <p>1-DTMF-Relay</p> <p>2-DTMF</p> <p>3-Telephone-Event</p>		

Parameters	Permitted Values	Default
<p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Note: It works only if the value of parameter “account.X.dtmf.type” is set to 2 (SIP INFO) or 3 (RFC2833 + SIP INFO).</p> <p>Web User Interface:</p> <p>Account->Advanced->DTMF Info Type</p> <p>Phone User Interface:</p> <p>None</p>		
features.dtmf.repetition	1, 2 or 3	3
<p>Description:</p> <p>Configures the repetition times for the IP phone to send the end RTP Event packet during an active call.</p> <p>Web User Interface:</p> <p>Features->General Information->DTMF Repetition</p> <p>Phone User Interface:</p> <p>None</p>		
features.dtmf.duration	Integer from 0 to 300	100
<p>Description:</p> <p>Configures the duration time (in milliseconds) for DTMF.</p> <p>Note: If the time interval to between two DTMF digits is less than this value, two or more same DTMF digits could be identified as one DTMF digit. This may cause the loss of one or more DTMF digits. For example, 2662 may be identified as 262. If so, you can modify the value of this parameter to a little lower than the default value.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		
features.dtmf.volume	Integer from -33 to 0	-10

Parameters	Permitted Values	Default
Description: Configures the frequency level of DTMF digits (in db). Web User Interface: None Phone User Interface: None		

To configure the method of transmitting DTMF digits via web user interface:

1. Click on **Account->Advanced**.
2. Select the desired account from the pull-down list of **Account**.
3. Select the desired value from the pull-down list of **DTMF Type**.
If **SIP INFO** or **RFC2833 + SIP INFO** is selected, select the desired value from the pull-down list of **DTMF Info Type**.
4. Enter the desired value in the **DTMF Payload Type(96~127)** field.

The screenshot shows the Yealink T236 web interface. The top navigation bar includes 'Status', 'Account', 'Network', 'DSSKey', 'Features', 'Settings', 'Directory', and 'Security'. The 'Account' tab is active, and the 'Advanced' sub-tab is selected. The 'Account' dropdown is set to 'Account 1'. The 'DTMF Type' is set to 'RFC2833', 'DTMF Info Type' is set to 'DTMF-Relay', and 'DTMF Payload Type(96~127)' is set to '101'. A red box highlights these three settings. The 'NOTE' section on the right contains information about DTMF, Session Timer, and Busy Lamp Field/BLF List.

5. Click **Confirm** to accept the change.

To configure the number of times to send the end RTP Event packet via web user interface:

1. Click on **Features->General Information**.

2. Select the desired value (1-3) from the pull-down list of **DTMF Repetition**.

The screenshot shows the Yealink T236 configuration page. The 'Features' tab is active. In the 'General Information' section, the 'DTMF Repetition' dropdown is highlighted with a red rectangle and shows the value '3'. Other settings include 'Call Waiting' (Enabled), 'Call Waiting On Code' (empty), 'Call Waiting Off Code' (empty), 'Auto Redial' (Disabled), 'Auto Redial Interval (1~300s)' (10), 'Auto Redial Times (1~300)' (10), 'Multicast Codec' (G722), 'Play Hold Tone' (Enabled), 'Play Hold Tone Delay' (30), 'Allow Mute' (Enabled), and 'Auto Linekeys' (Disabled). A 'NOTE' section on the right contains information about 'Call Waiting', 'Auto Redial', 'Key As Send', 'Hotline', and 'Call Completion'. At the bottom, there are 'Confirm' and 'Cancel' buttons.

3. Click **Confirm** to accept the change.

Suppress DTMF Display

Suppress DTMF display allows IP phones to suppress the display of DTMF digits during an active call. DTMF digits are displayed as “*” on the LCD screen. Suppress DTMF display delay defines whether to display the DTMF digits for a short period of time before displaying as “*”.

Procedure

Configuration changes can be performed using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure suppress DTMF display and suppress DTMF display delay. Parameters: features.dtmf.hide features.dtmf.hide_delay
Local	Web User Interface	Configure suppress DTMF display and suppress DTMF display delay. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p=features-general&q=load

		For SIP VP-T49G: http://<phoneIPAddress>/servlet? m=mod_data&p=features-general &q=load
--	--	--

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.dtmf.hide	0 or 1	0
Description: Enables or disables the IP phone to suppress the display of DTMF digits during an active call. 0 -Disabled 1 -Enabled If it is set to 1 (Enabled), the DTMF digits are displayed as asterisks. Web User Interface: Features->General Information->Suppress DTMF Display Phone User Interface: None		
features.dtmf.hide_delay	0 or 1	0
Description: Enables or disables the IP phone to display the DTMF digits for a short period before displaying asterisks during an active call. 0 -Disabled 1 -Enabled Note: It works only if the value of the parameter "features.dtmf.hide" is set to 1 (Enabled). Web User Interface: Features->General Information->Suppress DTMF Display Delay Phone User Interface: None		

To configure suppress DTMF display and suppress DTMF display delay via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Suppress DTMF Display**.

3. Select the desired value from the pull-down list of **Suppress DTMF Display Delay**.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected. Under 'General Information', the 'Suppress DTMF Display Delay' dropdown is highlighted with a red box. The dropdown is currently set to 'Enabled'. Other settings visible include 'Call Waiting' (Enabled), 'Call Waiting On Code' (empty), 'Call Waiting Off Code' (empty), 'Auto Redial' (Disabled), 'Play Local DTMF Tone' (Enabled), 'DTMF Repetition' (3), 'Multicast Codec' (G722), 'Play Hold Tone' (Enabled), 'Hide Feature Access Codes' (Enabled), 'Display Method on Dialing' (User Name), and 'Auto Linekeys' (Enabled). A 'NOTE' section on the right provides additional information about various features.

4. Click **Confirm** to accept the change.

Transfer via DTMF

Call transfer is implemented via DTMF on some traditional servers. The IP phone sends specified DTMF digits to the server for transferring calls to third parties.

Procedure

Configuration changes can be performed using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure transfer via DTMF. Parameters: features.dtmf.replace_tran features.dtmf.transfer
Local	Web User Interface	Configure transfer via DTMF. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T 29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servl et?p=features-general&q=loa d For SIP VP-T49G: http://<phoneIPAddress>/servl

		et?m=mod_data&p=features-general&q=load
--	--	---


Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.dtmf.replace_tran	0 or 1	0
<p>Description: Enables or disables the IP phone to send DTMF sequences for transfer function when pressing the Tran/Transfer soft key or TRAN/TRANSFER key.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 0 (Disabled), the IP phone will perform the transfer as normal when pressing the Tran/Transfer soft key or TRAN/TRANSFER key during a call.</p> <p>If it is set to 1 (Enabled), the IP phone will transmit the designated DTMF digits to the server for performing call transfer when pressing the Tran/Transfer soft key or TRAN/TRANSFER key during a call.</p> <p>Web User Interface: Features->General Information->DTMF Replace Tran</p> <p>Phone User Interface: None</p>		
features.dtmf.transfer	String within 32 characters	Blank
<p>Description: Configures the DTMF digits to be transmitted to perform call transfer.</p> <p>Valid values are: 0-9, *, # and A-D.</p> <p>Example: features.dtmf.transfer = 123</p> <p>Note: It works only if the value of the parameter "features.dtmf.replace_tran" is set to 1 (Enabled).</p> <p>Web User Interface: Features->General Information->Tran Send DTMF</p> <p>Phone User Interface: None</p>		

To configure transfer via DTMF via web user interface:

1. Click on **Features->General Information**.

- 2. Select the desired value from the pull-down list of **DTMF Replace Tran**.
- 3. Enter the specified DTMF digits in the **Tran Send DTMF** field.



- 4. Click **Confirm** to accept the change.

Play Local DTMF Tone

Play local DTMF tone allows IP phones to play a local DTMF tone during an active call. If this feature is enabled, you can hear the DTMF tone when pressing the IP phone’s keypad during a call.

Procedure

Configuration changes can be performed using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure play local DTMF tone. Parameters: features.play_local_dtmf_tone_enable
Local	Web User Interface	Configure play local DTMF tone. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet? p=features-general&q=load For SIP VPT49G:


		http://<phoneIPAddress>/servlet ?m=mod_data&p=features-general&q=load
--	--	--

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.play_local_dtmf_tone_enable	0 or 1	1
<p>Description:</p> <p>Enables or disables the IP phone to play a local DTMF tone.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>If it is set to 1 (Enabled), you can hear the DTMF tone when pressing the IP phone's keypad during a call.</p> <p>Web User Interface:</p> <p>Features->General Information->Play Local DTMF Tone</p> <p>Phone User Interface:</p> <p>None</p>		

To configure play local DTMF tone via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Play Local DTMF Tone**.



3. Click **Confirm** to accept the change.

Allow Mute

You can mute the microphone of the active audio device during an active call, and then the other party cannot hear you. If allow mute feature is disabled, you cannot mute an active call.

Procedure

Allow mute can be configured using the configuration files or locally.


Configuration File	<y0000000000xx>.cfg	Configure allow mute feature. Parameters: features.allow_mute
Local	Web User Interface	Configure allow mute feature. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/ T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=features-general&q=load">http://<phoneIPAddress>/servlet?p=features-general&q=load For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.allow_mute	0 or 1	1
Description: Enables or disables the IP phone to mute an active call. 0 -Disabled 1 -Enabled Web User Interface: Features->General Information->Allow Mute Phone User Interface: None		

To configure allow mute via web user interface:

- 1. Click on **Feature->General Information**.
- 2. Select the desired value from the pull-down list of **Allow Mute**.



- 3. Click **Confirm** to accept the change.

Intercom

Intercom allows establishing an audio conversation directly. The IP phone can answer intercom calls automatically. This feature depends on support from a SIP server.

Outgoing Intercom Calls

Intercom is a useful feature in office environments to quickly connect with an operator or secretary. Users can press an intercom key to automatically initiate an outgoing intercom call with a remote extension.

Note It is not applicable to SIP-T19(P) E2 IP phones.

Procedure

Intercom key can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Assign an intercom key. Parameters: linekey.X.type/ programablekey.X.type/ expansion_module.X.key.Y.type
--------------------	---------------------	---

		linekey.X.line/ expansion_module.X.key.Y.line linekey.X.value/ programablekey.X.value/ expansion_module.X.key.Y.value linekey.X.label/ programablekey.X.label/ expansion_module.X.key.Y.label
Local	Web User Interface	Assign an intercom key. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/CP860: http://<phoneIPAddress>/servlet ?p=dsskey&q=load&model=0 For SIP VP-T49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=dsskey&q=load
	Phone User Interface	Assign an intercom key.

Intercom Key

For more information on how to configure the DSS Key, refer to [Appendix D: Configuring DSS Key](#) on page 926.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
linekey.X.type/ programablekey.X.type/ expansion_module.X.key.Y.type	14	Refer to the following content
Description: Configures a DSS key as an intercom key. The digit 14 stands for the key type Intercom . For line keys: X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G) X ranges from 1 to 27 (for SIP-T46G/T29G)		

Parameters	Permitted Values	Default
<p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For programable keys:</p> <p>X=1-6, 9, 13 (for CP860)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Example:</p> <p>linekey.1.type = 14</p> <p>Default:</p> <p>For line keys:</p> <p>For SIP VPT49G/SIPT48G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-29 is 0.</p> <p>For SIPT46G/T29G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-27 is 0.</p> <p>For SIPT42G IP phones:</p> <p>The default value of the line key 1-12 is 15, and the default value of the line key 13-15 is 0.</p> <p>For SIPT41P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-15 is 0.</p> <p>For SIPT27P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-21 is 0.</p> <p>For SIPT40P/T23P/T23G/T21(P) E2 IP phones:</p> <p>The default value is 15.</p> <p>For programable keys:</p> <p>For CP860 IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p>		

Parameters	Permitted Values	Default
<p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=13, the default value is 0 (NA).</p> <p>For ext keys:</p> <p>When Y=1, the default value is 37 (Switch).</p> <p>When Y= 2 to 20, 22 to 40, the default value is 0 (NA).</p> <p>Note: It is not applicable to SIP-T19(P) E2 IP phones.</p> <p>Web User Interface:</p> <p>DSSKey->Line key/Programable Key->Type</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Type</p>		
linekey.X.line/ expansion_module.X.key.Y.line	Refer to the following content	1-16 for lines 1-16
<p>Description:</p> <p>Configures the desired line to apply the intercom key.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Permitted Values:</p> <p>1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>1 to 12 (for SIP-T42G)</p> <p>1 to 6 (for SIP-T41P/T27P)</p> <p>1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>1 to 2 (for SIP-T21(P) E2)</p> <p>1-Line 1</p> <p>2-Line 2</p> <p>...</p>		

Parameters	Permitted Values	Default
16-Line 16 Example: linekey.1.line = 1 Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones. Web User Interface: DSSKey->Line key->Line Phone User Interface: Menu->Features->DSS Keys->Line Key X->Account ID		
linekey.X.value/ programablekey.X.value/ expansion_module.X.key.Y.value	String within 99 characters	Blank
Description: Configures the intercom number. For line keys: X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G) X ranges from 1 to 27 (for SIP-T46G/T29G) X ranges from 1 to 15 (for SIP-T42G/T41P) X ranges from 1 to 21 (for SIP-T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) For programable keys: X=1-6, 9, 13 (for CP860) For ext keys: X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured). Example: linekey.1.value = 1008 Note: It is not applicable to SIP-T19(P) E2 IP phones. Web User Interface: DSSKey->Line key->Value Phone User Interface: Menu->Features->DSS Keys->Line Key X->Value		
linekey.X.label/ programablekey.X.label/ expansion_module.X.key.Y.label	String within 99 characters	Blank

Parameters	Permitted Values	Default
<p>Description:</p> <p>(Optional.) Configures the label displayed on the LCD screen for each DSS key.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G)</p> <p>X ranges from 1 to 27 (for SIPT46G/T29G)</p> <p>X ranges from 1 to 15 (for SIPT42G/T41P)</p> <p>X ranges from 1 to 21 (for SIPT27P)</p> <p>X ranges from 1 to 3 (for SIPT40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIPT21(P) E2)</p> <p>For programmable keys:</p> <p>X ranges from 1 to 4.</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Note: It is not applicable to SIP-T19(P) E2 IP phones.</p> <p>Web User Interface:</p> <p>DSSKey->Line Key->Label</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Label</p>		



To configure an intercom key via web user interface:

1. Click on **DSSKey->Line Key** (or **Programmable Key**).
2. In the desired DSS key field, select **Intercom** from the pull-down list of **Type**.
3. Enter the remote extension number in the **Value** field.
4. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.
5. Select the desired line from the pull-down list of **Line**.

The screenshot shows the Yealink T23G web interface. The 'DSSKey' tab is selected in the top navigation bar. On the left sidebar, 'Line Key' is selected. The main content area displays a table for configuring DSS keys. The table has columns: Key, Type, Value, Label, Line, and Extension. The 'Line Key2' row is highlighted with a red box, indicating it is the current configuration point. In this row, 'Intercom' is selected for Type, '1008' is entered for Value, and 'Line 1' is selected for Line. Below the table are 'Confirm' and 'Cancel' buttons. On the right side, there is a 'NOTE' section with a green header and a message about Line Keys.

6. Click **Confirm** to accept the change.

To configure an intercom key via phone user interface:

1. Press **Menu**->**Features**->**DSS Keys**.
2. Select the desired DSS key.
3. Press  or , or the **Switch** soft key to select **Intercom** from the **Type** field.
4. Select the desired line from the **Account ID** field.
5. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.
6. Enter the remote extension number in the **Value** field.
7. Press the **Save** soft key to accept the change.

Incoming Intercom Calls

The IP phone can process incoming calls differently depending on settings. There are four configuration options for incoming intercom calls:

Accept Intercom

Accept Intercom allows the IP phone to answer an incoming intercom call.

Intercom Mute

Intercom Mute allows the IP phone to mute the microphone for incoming intercom calls.

Intercom Tone

Intercom Tone allows the IP phone to play a warning tone before answering an intercom call.

Intercom Barge

Intercom Barge allows the IP phone to automatically answer an incoming intercom call while an active call is in progress. The active call will be placed on hold.

If you disable this feature, the IP phone will handle an incoming intercom call like a waiting call while there is already an active call on the IP phone.

Procedure

Incoming intercom calls can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure incoming intercom call feature. Parameters: features.intercom.allow features.intercom.mute features.intercom.tone features.intercom.barge
Local	Web User Interface	Configure incoming intercom call

		<p>feature.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T2 9G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>http://<phoneIPAddress>/servlet ?p=features-intercom&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet ?m=mod_data&p=features-inter com&q=load</p>
	Phone User Interface	Configure incoming intercom call feature.

Details of Configuration Parameters:


Parameters	Permitted Values	Default
features.intercom.allow	0 or 1	1
<p>Description:</p> <p>Enables or disables the IP phone to answer an incoming intercom call.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>If it is set to 0 (Disabled), the IP phone will reject incoming intercom calls and sends a busy signal to the caller.</p> <p>If it is set to 1 (Enabled), the IP phone will automatically answer an incoming intercom call.</p> <p>Web User Interface:</p> <p>Features->Intercom->Accept Intercom</p> <p>Phone User Interface:</p> <p>Menu->Features->Intercom->Accept Intercom</p>		
features.intercom.mute	0 or 1	0
<p>Description:</p> <p>Enables or disables the IP phone to mute the microphone when answering an intercom call.</p> <p>0-Disabled</p>		

Parameters	Permitted Values	Default
1-Enabled If it is set to 1 (Enabled), the microphone is muted for intercom calls, and then the other party cannot hear you. Note: It works only if the value of the parameter "features.intercom.allow" is set to 1 (Enabled). Web User Interface: Features->Intercom->Intercom Mute Phone User Interface: Menu->Features->Intercom->Intercom Mute		
features.intercom.tone	0 or 1	1
Description: Enables or disables the IP phone to play a warning tone when answering an intercom call. 0-Disabled 1-Enabled Note: It works only if the value of the parameter "features.intercom.allow" is set to 1 (Enabled). Web User Interface: Features->Intercom->Intercom Tone Phone User Interface: Menu->Features->Intercom->Intercom Tone		
features.intercom.barge	0 or 1	0
Description: Enables or disables the IP phone to answer an incoming intercom call while there is already an active call on the IP phone. 0-Disabled 1-Enabled If it is set to 0 (Disabled), the IP phone will handle an incoming intercom call like a waiting call while there is already an active call on the IP phone. If it is set to 1 (Enabled), the IP phone will automatically answer the intercom call while there is already an active call on the IP phone and place the active call on hold. Note: It works only if the values of parameters "features.intercom.allow" and "call_waiting.enable" are set to 1 (Enabled).		

Parameters	Permitted Values	Default
Web User Interface: Features->Intercom->Intercom Barge Phone User Interface: Menu->Features->Intercom->Intercom Barge		

To configure intercom via web user interface:

1. Click on **Features->Intercom**.
2. Select the desired values from the pull-down lists of **Accept Intercom**, **Intercom Mute**, **Intercom Tone** and **Intercom Barge**.



3. Click **Confirm** to accept the change.

To configure intercom via phone user interface:

1. Press **Menu->Features->Intercom**.
2. Press ◀ or ▶, or the **Switch** soft key to select the desired values from the **Accept Intercom**, **Intercom Mute**, **Intercom Tone** and **Intercom Barge** fields.
3. Press the **Save** soft key to accept the change.

Call Timeout

Call timeout defines a specific period of time within which the IP phone will cancel the dialing if the call is not answered.

Procedure

Call timeout can only be configured using the configuration files.

Configuration File	<y0000000000xx>.cfg	Configure the duration time (in seconds) in the ringback state. Parameters: phone_setting.ringback_timeout
---------------------------	---------------------	---

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
phone_setting.ringback_timeout	Integer from 0 to 3600	180
Description: Configures the duration time (in seconds) in the ringback state. If it is set to 180, the phone will cancel the dialing if the call is not answered within 180 seconds. Web User Interface: None Phone User Interface: None		

Ringling Timeout

Ringling timeout defines a specific period of time within which the IP phone will stop ringing if the call is not answered.

Procedure

Ringling timeout can only be configured using the configuration files.

Configuration File	<y0000000000xx>.cfg	Configure the duration time (in seconds) in the ringing state. Parameters: phone_setting.ringing_timeout
---------------------------	---------------------	---

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
phone_setting.ringing_timeout	Integer from 0 to 3600	180

Parameter	Permitted Values	Default
Description: Configures the duration time (in seconds) in the ringing state. If it is set to 180, the phone will stop ringing if the call is not answered within 180 seconds. Web User Interface: None Phone User Interface: None		

Send user=phone

When placing a call, the IP phone will send an INVITE request to the proxy server. Send user=phone feature allows adding user=phone to the SIP header of the INVITE message.

Example of a SIP INVITE message:

```

INVITE sip:101@10.2.1.48:5060;user=phone SIP/2.0
Via: SIP/2.0/UDP 10.3.20.6:5060;branch=z9hG4bK2475812834
From: "1010" <sip:1010@10.2.1.48:5060>;tag=3747068208
To: <sip:101@10.2.1.48:5060;user=phone>
Call-ID: 0_4008470062@10.3.20.6
CSeq: 1 INVITE
Contact: <sip:1010@10.3.20.6:5060>
Content-Type: application/sdp
Allow: INVITE, INFO, PRACK, ACK, BYE, CANCEL, OPTIONS, NOTIFY, REGISTER, SUBSCRIBE, REFER,
PUBLISH, UPDATE, MESSAGE
Max-Forwards: 70
User-Agent: Yealink SIP-T23G 44.80.0.60
Allow-Events: talk,hold,conference,refer,check-sync
Content-Length: 300

```

Procedure

Send user=phone can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure send user=phone feature on a per-line basis. Parameters: account.X.enable_user_equal_ph
---------------------------	-----------	--

		one
Local	Web User Interface	<p>Configure send user=phone feature on a per-line basis.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0</p>

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
account.X.enable_user_equal_phone	0 or 1	0
<p>Description:</p> <p>Enables or disables the IP phone to add "user=phone" to the SIP header of the INVITE message for account X.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Web User Interface:</p> <p>Account->Advanced->Send user=phone</p> <p>Phone User Interface:</p> <p>None</p>		

To configure send user=phone feature via web user interface:

1. Click on **Account->Advanced**.
2. Select the desired account from the pull-down list of **Account**.

3. Select the desired value from the pull-down list of **Send user=phone**.

The screenshot shows the Yealink T23G web interface. The top navigation bar includes 'Status', 'Account', 'Network', 'DSSKey', 'Features', 'Settings', 'Directory', and 'Security'. The 'Account' tab is selected. On the left, there is a sidebar with 'Register', 'Basic', 'Codec', and 'Advanced' options. The 'Advanced' option is selected. The main content area displays various settings for 'Account 1'. The 'Send user=phone' setting is highlighted with a red box and is currently set to 'Disabled'. Other settings include 'Keep Alive Type' (Default), 'Keep Alive Interval(Seconds)' (30), 'RPort' (Disabled), 'Subscribe Period(Seconds)' (1800), 'DTMF Type' (RFC2833), 'DTMF Info Type' (DTMF-Relay), 'DTMF Payload Type(96~127)' (101), 'Retransmission' (Disabled), 'Subscribe Register' (Disabled), 'Subscribe for MWI' (Disabled), 'MWI Subscription Period(Seconds)' (3600), 'Subscribe MWI To Voice Mail' (Disabled), 'Voice Mail' (empty), 'Voice Mail Display' (Enabled), 'Caller ID Source' (FROM), 'Session Timer' (Disabled), 'Session Expires(30~7200s)' (1800), 'Session Refresher' (UAC), and 'RTP Encryption(SRTP)' (Disabled). On the right, there is a 'NOTE' section with information about DTMF, Session Timer, Busy Lamp Field/BLF List, Shared Call Appearance (SCA)/ Bridge Line Appearance (BLA), Network Conference, and VQ-RTCPXR.

4. Click **Confirm** to accept the change.

SIP Send MAC

The IP phone can send the MAC address in the REGISTER message. SIP send MAC allow adding "Mac:<PhoneMACAddress>" (e.g., Mac: 00:15:65:74:b1:50) to the SIP header of the REGISTER message.

Example of a SIP REGISTER message:

```
REGISTER sip:10.2.1.48:5060 SIP/2.0
Via: SIP/2.0/UDP 10.3.20.14:5060;branch=z9hG4bK3593117201
From: "11" <sip:11@10.2.1.48:5060>;tag=2788360609
To: "11" <sip:11@10.2.1.48:5060>
Call-ID: 1_1863786852@10.3.20.14
CSeq: 2 REGISTER
Contact: <sip:11@10.3.20.14:5060;line=cc75882e976e208>
Allow: INVITE, INFO, PRACK, ACK, BYE, CANCEL, OPTIONS, NOTIFY, REGISTER, SUBSCRIBE, REFER,
PUBLISH, UPDATE, MESSAGE
Max-Forwards: 70
User-Agent: Yealink SIPT23G 44.80.0.60
Expires: 0
Allow-Events: talk,hold,conference,refer,check-sync
Mac: 00:15:65:74:b1:50
```

Content-Length: 0

Procedure

SIP send MAC can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure SIP send MAC on a per-line basis. Parameters: account.X.register_mac
Local	Web User Interface	Configure SIP send MAC on a per-line basis. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0">http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0 For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0">http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
account.X.register_mac	0 or 1	0
Description: Enables or disables the IP phone to add MAC address to the SIP header of the REGISTER message for account X. 0 -Disabled 1 -Enabled X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860)		

Parameter	Permitted Values	Default
Web User Interface: Account->Advanced->SIP Send MAC Phone User Interface: None		

To configure SIP send MAC feature via web user interface:

1. Click on **Account->Advanced**.
2. Select the desired account from the pull-down list of **Account**.
3. Select the desired value from the pull-down list of **SIP Send MAC**.

The screenshot shows the Yealink T23G web interface. The 'Account' tab is selected, and the 'Advanced' sub-tab is active. The 'Account' dropdown is set to 'Account 1'. The 'SIP Send MAC' option is highlighted with a red box and is set to 'Enabled'. Other settings include 'Keep Alive Type' (Default), 'Keep Alive Interval(Seconds)' (30), 'RPort' (Disabled), and 'Subscribe Period(Seconds)' (1800). The 'SIP Send Line' option is also set to 'Enabled'. The 'SIP Registration Retry Timer(0~1800s)' is set to 30. The 'VQ RTP-XR Collector name', 'VQ RTP-XR Collector address', and 'VQ RTP-XR Collector port' (5060) are also visible. The 'Number of line key' is set to 1. A 'NOTE' section on the right provides information about DTMF, Session Timer, Busy Lamp Field/BLF List, and Shared Call Appearance (SCA)/ Bridge Line Appearance (BLA).

4. Click **Confirm** to accept the change.

SIP Send Line

The IP phone can send the line number in the REGISTER message. SIP send line allow adding "Line:<linenumber>" (e.g., Line: 1) to the SIP header of the REGISTER message. The line number is a number between 0 and 15.

The following table lists line number values for each phone model.

Phone Model	Line Number	Description
SIP VP-T49G/SIP-T48G/T46G/T29G	0~15	0~15 stand for line1~line16
SIPT42G	0~11	0~11 stand for line1~line12
SIPT41P/T27P	0~5	0~5 stand for line1~line6
SIPT40P/T23P/T23G	0~2	0~2 stand for line1~line3

Phone Model	Line Number	Description
SIP-T21(P) E2	0~1	0~1 stand for line1~line2
SIP-T19(P) E2/CP860	0	0 stand for line1

Example of a SIP REGISTER message:

```
REGISTER sip:10.2.1.48:5060 SIP/2.0
Via: SIP/2.0/UDP 10.3.20.14:5060;branch=z9hG4bK3990593443
From: "11" <sip:11@10.2.1.48:5060>;tag=255071842
To: "11" <sip:11@10.2.1.48:5060>
Call-ID: 1_2369214377@10.3.20.14
CSeq: 2 REGISTER
Contact: <sip:11@10.3.20.14:5060;line=1da6aa8d7254654>
Allow: INVITE, INFO, PRACK, ACK, BYE, CANCEL, OPTIONS, NOTIFY, REGISTER, SUBSCRIBE, REFER,
PUBLISH, UPDATE, MESSAGE
Max-Forwards: 70
User-Agent: Yealink SIP-T23G 44.80.0.60
Expires: 0
Allow-Events: talk,hold,conference,refer,check-sync
Line: 1
Content-Length: 0
```

Procedure

SIP send line can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure SIP send line on a per-line basis. Parameters: account.X.register_line
Local	Web User Interface	Configure SIP send line on a per-line basis. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0">http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0 For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0">http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
account.X.register_line	0 or 1	0
<p>Description:</p> <p>Enables or disables the IP phone to add line number to the SIP header of the REGISTER message for account X.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIPT42G)</p> <p>X ranges from 1 to 6 (for SIPT41P/T27P)</p> <p>X ranges from 1 to 3 (for SIPT40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIPT21(P) E2)</p> <p>X is equal to 1 (for SIPT19(P) E2/CP860)</p> <p>Web User Interface:</p> <p>Account->Advanced->SIP Send Line</p> <p>Phone User Interface:</p> <p>None</p>		

To configure SIP send Line feature via web user interface:

1. Click on **Account->Advanced**.
2. Select the desired account from the pull-down list of **Account**.
3. Select the desired value from the pull-down list of **SIP Send Line**.

The screenshot displays the Yealink web user interface for configuring an account. The 'Account' tab is selected, and the 'Advanced' sub-tab is active. The 'SIP Send Line' option is highlighted with a red box and is currently set to 'Enabled'. The interface includes a sidebar with 'Register', 'Basic', 'Codec', and 'Advanced' tabs. The main area shows various configuration fields like 'Keep Alive Type', 'Keep Alive Interval', 'RPort', 'Subscribe Period', 'SIP Send MAC', 'SIP Send Line', 'SIP Registration Retry Timer', 'VQ RTP-XR Collector name', 'VQ RTP-XR Collector address', 'VQ RTP-XR Collector port', and 'Number of line key'. A 'NOTE' section on the right provides additional information about DTMF, Session Timer, Busy Lamp Field/BLF List, and Shared Call Appearance (SCA)/ Bridge Line Appearance (BLA).

4. Click **Confirm** to accept the change.

Reserve # in User Name

Reserve # in User Name feature allows IP phones to reserve “#” in user name. When Reserve # in User Name feature is disabled, “#” will be converted into “%23”. For example, the user registers an account (user name: 1010#) on the phone, the phone will send 1010%23 instead of 1010# in the REGISTER message or INVITE message to SIP server.

Example of a SIP REGISTER message:

```
INVITE sip:2@10.2.1.48:5060 SIP/2.0
Via: SIP/2.0/UDP 10.3.20.6:5060;branch=z9hG4bK1867789050
From: "1010" <sip:1010%23@10.2.1.48:5060>;tag=1945988802
To: <sip:2@10.2.1.48:5060>
Call-ID: 0_2336101648@10.3.20.6
CSeq: 1 INVITE
Contact: <sip:1010%23@10.3.20.6:5060>
Content-Type: application/sdp
Allow: INVITE, INFO, PRACK, ACK, BYE, CANCEL, OPTIONS, NOTIFY, REGISTER, SUBSCRIBE, REFER,
PUBLISH, UPDATE, MESSAGE
Max-Forwards: 70
User-Agent: Yealink SIP-T23G 44.80.0.60
Allow-Events: talk,hold,conference,refer,check-sync
Content-Length: 300
```

Procedure

Reserve # in User Name can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure reserve # in user name. Parameters: sip.use_23_as_pound
Local	Web User Interface	Configure reserve # in user name. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T2 9G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet? p=features-general&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet?


		m=mod_data&p=features-general&q=load
--	--	--------------------------------------

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
sip.use_23_as_pound	0 or 1	1
<p>Description: Enables or disables the IP phone to reserve the pound sign (#) in the user name. 0-Disabled (convert the pound sign into "%23") 1-Enabled</p> <p>Web User Interface: Features->General Information->Reserve # in User Name</p> <p>Phone User Interface: None</p>		

To configure reserve # in user name feature via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Reserve # in User Name**.



3. Click **Confirm** to accept the change.

Password Dial

Password dial feature allows the callee number to be partly displayed on the IP phone when placing a call. The hidden digits are displayed as asterisks on the LCD screen. This feature is especially useful for users always placing important and confidential calls.

Procedure

Password dial feature can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure password dial feature. Parameters: features.password_dial.enable features.password_dial.prefix features.password_dial.length
Local	Web User Interface	Configure password dial feature. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p=features-general&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
features.password_dial.enable	0 or 1	0
Description: Enables or disables password dial feature for the IP phone. 0 -Disabled 1 -Enabled Web User Interface: Features->General Information->PswDial Phone User Interface: None		
features.password_dial.prefix	String within 32 characters	Blank
Description: Configures the prefix of the password dial number.		

Parameter	Permitted Values	Default
Example: features.password_dial.prefix = 12 Web User Interface: Features->General Information->PswPrefix Phone User Interface: None		
features.password_dial.length	Integer from 0 to 99	Blank
Description: Configures the number of digits to be hidden. The hidden digits are displayed as asterisks on the LCD screen. Example: features.password_dial.length = 3 Note: If you set the prefix to 12 and the length to 3, when you want to dial the number 123456, the entered number is displayed as 12***6 on the LCD screen. Web User Interface: Features->General Information->PswLength Phone User Interface: None		

To configure password dial feature via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **PswDial**.
3. Enter the prefix of password dial in the **PswPrefix** field.

4. Enter the desired number of hidden digits in the **PswLength** field.

The screenshot shows the Yealink T236 web interface. The 'General Information' tab is selected. The 'PswLength' field is highlighted with a red box and contains the value '3'. Other fields include 'PswPrefix' (12), 'PswDial' (Enabled), and 'Auto Linekeys' (Disabled). A 'NOTE' section on the right provides details about 'Call Waiting', 'Auto Redial', 'Key As Send', 'Hotline', and 'Call Completion'.

5. Click **Confirm** to accept the change.

Unregister When Reboot

Unregister when reboot feature allows IP phones to unregister first before re-registering the account when finishing a reboot.

Procedure

Unregister when reboot can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure unregister when reboot. Parameters: account.X.unregister_on_reboot
Local	Web User Interface	Configure unregister when reboot. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0 For SIP VP-T49G: http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q

		=load&acc=0
--	--	-------------

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
account.X.unregister_on_reboot	0 or 1	0
<p>Description: Enables or disables the IP phone to unregister first before re-registering account X when finishing a reboot.</p> <p>0-Disabled 1-Enabled</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Web User Interface: Account->Advanced->Unregister When Reboot</p> <p>Phone User Interface: None</p>		

To configure unregister when reboot via web user interface:

1. Click on **Account->Advanced**.
2. Select the desired account from the pull-down list of **Account**.

3. Select the desired value from the pull-down list of **Unregister When Reboot**.

The screenshot shows the Yealink T236 web interface with the 'Account' tab selected. The 'Unregister When Reboot' option is highlighted with a red box and is set to 'Enabled'. Other visible settings include 'Keep Alive Type' (Default), 'Keep Alive Interval(Seconds)' (30), 'RPort' (Disabled), 'Subscribe Period(Seconds)' (1800), 'Early Media' (Disabled), 'SIP Server Type' (Default), 'Music Server URI' (sip:moh@sp.com), 'Directed Call Pickup Code' (*97), 'Group Call Pickup Code' (*98), 'Distinctive Ring Tones' (Enabled), 'Out Dialog BLF' (Enabled), 'VQ RTPC-XR Collector name' (collector), 'VQ RTPC-XR Collector address' (10.2.1.98), and 'VQ RTPC-XR Collector port' (5060). A 'NOTE' section on the right provides information about DTMF, Session Timer, Busy Lamp Field/BLF List, Shared Call Appearance (SCA)/ Bridge Line Appearance (BLA), and Network Conference.

4. Click **Confirm** to accept the change.

100 Reliable Retransmission

As described in [RFC 3262](#), 100rel tag is for reliability of provisional responses. When present in a Supported header, it indicates that the IP phone can send or receive reliable provisional responses. When present in a Require header in a reliable provisional response, it indicates that the response is to be sent reliably.

Example of a SIP INVITE message:

```
INVITE sip:1024@pbx.yealink.com:5060 SIP/2.0
Via: SIP/2.0/UDP 10.3.6.197:5060;branch=z9hG4bK1708689023
From: "1025" <sip:1025@pbx.yealink.com:5060>;tag=1622206783
To: <sip:1024@pbx.yealink.com:5060>
Call-ID: 0_537569052@10.3.6.197
CSeq: 2 INVITE
Contact: <sip:1025@10.3.6.197:5060>
Authorization: Digest username="1025", realm="pbx.yealink.com",
nonce="BroadWorksXi5stub71Ts2nb05BW", uri="sip:1024@pbx.yealink.com:5060",
response="f7e9d35c55af45b3f89beae95e913171", algorithm=MD5, cnonce="0a4f113b", qop=auth,
nc=00000001
Content-Type: application/sdp
Allow: INVITE, INFO, PRACK, ACK, BYE, CANCEL, OPTIONS, NOTIFY, REGISTER, SUBSCRIBE, REFER,
PUBLISH, UPDATE, MESSAGE
Max-Forwards: 70
```

```
User-Agent: Yealink SIP-T23G 44.80.0.60
Supported: 100rel
Allow-Events: talk,hold,conference,refer,check-sync
Content-Length: 302
```

Procedure

100 Reliable Retransmission can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure the 100 reliable retransmission feature. Parameters: account.X.100rel_enable
Local	Web User Interface	Configure the 100 reliable retransmission feature. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0">http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0 For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0">http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
account.X.100rel_enable	0 or 1	0
Description: Enables or disables the 100 reliable retransmission feature for account X. 0 -Disabled 1 -Enabled X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2)		

Parameter	Permitted Values	Default
X is equal to 1 (for SIP-T19(P) E2/CP860) Web User Interface: Account->Advanced->Retransmission Phone User Interface: None		

To configure 100 reliable retransmission via web user interface:

1. Click on **Account->Advanced**.
2. Select the desired account from the pull-down list of **Account**.
3. Select the desired value from the pull-down list of **Retransmission**.

4. Click **Confirm** to accept the change.

Reboot in Talking

Reboot in talking feature allows IP phones to reboot during an active call when it receives a reboot request by action URI. For more information on action URI, refer to [Action URI](#) on page 637.

IP phones do not receive and handle HTTP/HTTPS GET requests by default. To use this feature, you need to specify the trusted IP address(es) for action URI in advance. For more information, refer to [Configuring Trusted IP Address for Action URI](#) on page 642.

Procedure

Reboot in talking can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure reboot in talking. Parameter: features.reboot_in_talk_enable
---------------------------	---------------------	---

Local	Web User Interface	<p>Configure reboot in talking.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet ?p=features-general&q=load</p> <p>For SIP VP-T49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=features-general&q=load</p>
-------	--------------------	--

Details of Configuration Parameters:

Parameter	Permitted Values	Default
features.reboot_in_talk_enable	0 or 1	0
<p>Description:</p> <p>Enables or disables the phone to reboot during a call when it receives a reboot request by action URI.</p> <p>0-Disabled 1-Enabled</p> <p>Note: It works only if the value of the parameter “features.action_uri_limit_ip” is set to “any” or trusted IP address(es) and it is not the first time for the IP phone to receive HTTP/HTTPS GET request from the trusted IP address(es).</p> <p>Web User Interface:</p> <p>Features->General Information->Reboot in Talking</p> <p>Phone User Interface:</p> <p>None</p>		

To configure reboot in talking via web user interface:

1. Click on **Features->General Information**.

- Select the desired value from the pull-down list of **Reboot in Talking** field.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected. Under 'General Information', the 'Reboot in Talking' field is highlighted with a red box and set to 'Enabled'. Other settings include Call Waiting (Enabled), Auto Redial (Disabled), and Voice Mail Tone (Enabled). A 'NOTE' section on the right provides details about Call Waiting, Auto Redial, Key As Send, Hotline, and Call Completion features.

- Click **Confirm** to accept the change.

A dialog box pops up to prompt that settings will take effect after a reboot.

- Click **OK** to reboot the phone.

Answer By Hand

Answer by hand feature allows you to answer an incoming call by picking up the handset, pressing the Speakerphone key or pressing the HEADSET key directly.

If you disable answer by hand feature, you need to press the corresponding line key or the **Answer** soft key to answer an incoming call after picking up the handset, pressing the Speakerphone key or pressing the HEADSET key. It is not applicable to CP860 IP phones.

Procedure

Answer by hand can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure answer by hand. Parameter: features.off_hook_answer.enable
---------------------------	---------------------	---

Details of Configuration Parameters:

Parameter	Permitted Values	Default
features.off_hook_answer.enable	0 or 1	1

Parameter	Permitted Values	Default
<p>Description:</p> <p>Enables or disables the IP phone to answer an incoming call by picking up the handset, pressing the Speakerphone key or pressing the HEADSET key directly.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 0 (Disabled), you need to press the corresponding line key, the Answer soft key or the OK key to answer an incoming call after picking up the handset, pressing the Speakerphone key or pressing the HEADSET key.</p> <p>Note: It is not applicable to CP860 IP phones.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		

Bandwidth

The IP phone automatically detects the available bandwidth for call connection by default. You can specify the uplink and downlink bandwidths for the IP phone to achieve the best result. Uplink bandwidth is the maximum bandwidth of outgoing calls, and downlink bandwidth is the maximum bandwidth of incoming calls. It is only applicable to SIP VP-T49G IP phones.

Procedure

Bandwidth can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	<p>Specify the maximum transmitting or receiving bandwidth.</p> <p>Parameter:</p> <p>features.uplink_bandwidth features.downlink_bandwidth</p>
Local	Web User Interface	<p>Specify the maximum transmitting or receiving bandwidth.</p> <p>Navigate to:</p> <p>http://<phoneIPAddress>/servlet ?m=mod_data&p=settings-vide o&q=load</p>

	Phone User Interface	Specify the maximum transmitting or receiving bandwidth.
--	----------------------	--

Details of Configuration Parameters:


Parameter	Permitted Values	Default
features.uplink_bandwidth	0, 256, 384, 512, 640, 768, 1024, 1280, 1500, 2000, 3000 or 4000	0
<p>Description: Specifies the maximum transmitting bandwidth for the IP phone.</p> <p>0-Auto 256-256kb/s 384-384kb/s 512-512kb/s 640-640kb/s 768-768kb/s 1024-1024kb/s 1280-1280kb/s 1500-1500kb/s 2000-2000kb/s 3000-3000kb/s 4000-4000kb/s</p> <p>If it is set to 0 (Auto), the IP phone will select the appropriate transmitting bandwidth automatically.</p> <p>Note: It is only applicable to SIP VP-T49G IP phones.</p> <p>Web User Interface: Settings->Video->Uplink Bandwidth</p> <p>Phone User Interface: Menu->Basic->Video Setting->Uplink Bandwidth</p>		
features.downlink_bandwidth	0, 256, 384, 512, 640, 768, 1024, 1280, 1500, 2000, 3000 or 4000	0
<p>Description: Specifies the maximum receiving bandwidth for the IP phone.</p> <p>0-Auto</p>		

Parameter	Permitted Values	Default
<p> 256-256kb/s 384-384kb/s 512-512kb/s 640-640kb/s 768-768kb/s 1024-1024kb/s 1280-1280kb/s 1500-1500kb/s 2000-2000kb/s 3000-3000kb/s 4000-4000kb/s </p> <p>If it is set to 0 (Auto), the IP phone will select the appropriate receiving bandwidth automatically.</p> <p>Note: It is only applicable to SIP VP-T49G IP phones.</p> <p>Web User Interface: Settings->Video->Downlink Bandwidth</p> <p>Phone User Interface: Menu->Basic->Video Setting->Downlink Bandwidth</p>		

To configure bandwidth via web user interface:


1. Click on **Settings->Video**.
2. Select the desired value from the pull-down list of **Uplink Bandwidth**.

3. Select the desired value from the pull-down list of **Downlink Bandwidth**.



4. Click **Confirm** to accept the change.

To configure bandwidth via phone user interface:

1. Tap  -> **Basic**-> **Video Setting**.
2. Tap the **Uplink Bandwidth** field.
3. Tap the desired value in the pop-up dialog box.
4. Tap the **Downlink Bandwidth** field.
5. Tap the desired value in the pop-up dialog box.
6. Tap the **Save** soft key to accept the change.

Screenshot and Recording

Yealink IP phones support capturing the screenshot and recording during a call. Before capturing the screenshot and recording, ensure that the USB flash drive has been inserted into the USB port of the phone. Screenshot is only applicable to SIP VP-T49G IP phones. Recording is only applicable to SIP VP-T49G and CP860 IP phones.

Screenshot

Screenshot feature allows users to capture the screenshot to a USB flash drive which you inserted into the phone during a video call.

The screenshots are saved in *.JPG format and include a date/time stamp and the other party's number/IP address/name (or the first person's number/IP address/name you

called), for example, 20150731-1630-Mishoel.JPG was created on July 31, 2015, at 16:30 and you have a call with Mishoel. Screenshot can be viewed on either the phone itself or on a computer using an application capable of viewing *.JPG files. For more information, refer to [Yealink_SIP_VP-T49G_User_Guide](#).

Yealink IP phones also support capturing the screen display of the IP phone using the action URI. For more information, refer to [Scenario A - Capturing the Current Screen of the Phone](#) on page 645.

Note

If the call is audio-only, you cannot capture the screenshot using USB flash drive.

Procedure

Screenshot feature can be only configured using the configuration files.

Configuration File	<y0000000000xx>.cfg	Configure the screenshot feature. Parameter: features.screenshot.enable
---------------------------	---------------------	--

Details of Configuration Parameters:

Parameter	Permitted Values	Default
features.screenshot.enable	0 or 1	1
Description: Enables or disables the screenshot feature for the IP phone. 0 -Disabled 1 -Enabled If it is set to 1 (Enabled), you can capture screenshots by tapping the Screenshot soft key or pressing the MESSAGE key during a video call, and the captured screenshots will be saved to the USB flash drive. If it is set to 0 (Disabled), you can only capture screenshots by pressing the MESSAGE key during a video call. Note: It is only applicable to SIP VP-T49G IP phones. Web User Interface: None Phone User Interface: None		

Call and Conference Recording (for SIP VP-T49G IP Phones)

Recording feature allows users to record active calls (audio calls or video calls) or

conferences to a USB flash drive which you inserted into the phone during an active call.

You can record the audio or video call by tapping the **Record** soft key during a call. Yealink IP phones also support recording calls by tapping record/URL record key. For more information, refer to [Call Recording](#) on page 598.

Note

Before recording any call, especially those involving PSTN, it is necessary to know about the rules and restrictions of any governing call-recording in the place you are in. It is also very important to have the consent of the person you are calling before recording the conversation.

Recording an audio-only call

The recorded calls are saved in *.acc format and include a date & time stamp and the other party's number/IP address/name (or the first person's number/IP address/name you called), for example, 20150731-1630-Mishoel.acc was created on July 31, 2015, at 16:30 and you have a call with Mishoel. Recorded calls can be played on either the phone itself or on a computer using an application capable of playing *.acc files.

Recording a video call

The recorded calls are saved in *.mkv format and include a date & time stamp and the other party's number/IP address/name (or the first person's number/IP address/name you called), for example, 20150731-1630-Mishoel.mkv was created on July 31, 2015, at 16:30 and you have a call with Mishoel. Recorded calls can be played on either the phone itself or on a computer using an application capable of playing *.mkv files.

For more information, refer to [Yealink SIP-VPT49G User Guide](#).

Procedure

Recording feature can be only configured using the configuration files.

Configuration File	<y0000000000xx>.cfg	Configure the recording feature. Parameter: features.call_recording.enable
---------------------------	---------------------	---

Details of Configuration Parameters:

Parameter	Permitted Values	Default
features.call_recording.enable	0 or 1	1
Description: Enables or disables the recording feature for the IP phone. 0-Disabled		

Parameter	Permitted Values	Default
1-Enabled If it is set to 1 (Enabled), you can record the audio or video call by tapping the Record soft key during a call, and the recorded calls or videos will be saved to the USB flash drive. Note: It is only applicable to SIP VP-T49G IP phones. Web User Interface: None Phone User Interface: None		

Call and Conference Recording (for CP860 IP Phones)

You can record active calls and conferences on your CP860 IP phone after you insert a USB flash drive into the USB port on the phone.

The recorded calls are saved in *.wav format and include a date/time stamp, the other party's number/IP address/name (or the first person's number/IP address/name you called), duration of the call and the recording file size. For example, 20150911-1542-Bob 00:00:06(198.2KB) was created on Sep. 11, 2015, at 15:42 and you have a call with Bob, the duration of the call is 6 seconds and the size of the file is 198.2KB. Recorded calls can be played on either the phone itself or on a computer using an application capable of playing *.wav files.

For more information, refer to [Yealink_CP860_User_Guide](#).

External Monitor

External Monitor feature allows IP phone to present the video images captured from camera (both near site and far site) on one external monitor during a video call. It is helpful for the user to have a clearer view of the far-site video image. The video layout on the external monitor will be synchronous with that on the phone. If the phone is not in an active video call, the external monitor will only display a Yealink logo.

To use this feature, ensure that the external monitor has been connected to the HDMI port of the phone. It is only applicable to SIP VP-T49G IP phones.

Procedure

External monitor feature can be configured using the configuration files or locally.


Configuration File	<y0000000000xx>.cfg	Configure external monitor feature. Parameters: features.hdmi_out.enable features.hdmi_out_status
Local	Phone User Interface	Configure external monitor feature.

Details of Configuration Parameters:

Parameter	Permitted Values	Default
features.hdmi_out.enable	0 or 1	1
Description: Enables or disables the external monitor feature. 0 -Disabled 1 -Enabled If it is set to 0 (Disabled), the HDMI configuration item will disappear from phone user interface. Note: It is only applicable to SIP VP-T49G IP phones. Web User Interface: None Phone User Interface: None		
features.hdmi_out_status	0 or 1	1
Description: Enables or disables the IP phone to present the video images captured from camera (both near site and far site) on the external monitor during a video call. 0 -Disabled 1 -Enabled Note: It works only if the value of the parameter "features.hdmi_out.enable" is set to 1 (Enabled). It is only applicable to SIP VP-T49G IP phones. Web User Interface: None		

Parameter	Permitted Values	Default
Phone User Interface: Menu->Basic->HDMI->EXT Display		

To configure EXT display via phone user interface:

1. Tap  -> **Basic**->**HDMI**.
2. Tap the **EXT Display** field.
3. Tap the desired value in the pop-up dialog box.
4. Tap the **Save** soft key to accept the change.

Configuring Advanced Features

This chapter provides information for making configuration changes for the following advanced features:

- [Remote Phone Book](#)
- [LDAP](#)
- [Busy Lamp Field](#)
- [BLF List](#)
- [Hide Features Access Code](#)
- [Automatic Call Distribution \(ACD\)](#)
- [Shared Call Appearance \(SCA\)](#)
- [Bridge Lines Appearance \(BLA\)](#)
- [Message Waiting Indicator](#)
- [Short Message Service \(SMS\)](#)
- [Multicast Paging](#)
- [Call Recording](#)
- [Hot Desking](#)
- [Logon Wizard](#)
- [Action URL](#)
- [Action URI](#)
- [Server Redundancy](#)
- [Static DNS Cache](#)
- [VLAN](#)
- [VPN](#)
- [Voice Quality Monitoring](#)
- [Quality of Service](#)
- [Network Address Translation](#)
- [Real-Time Transport Protocol](#)
- [TR-069 Device Management](#)
- [IPv6 Support](#)

Remote Phone Book

Remote phone book is a centrally maintained phone book, stored on the remote server. Users only need the access URL of the remote phone book. The IP phone can establish a connection with the remote server and download the phone book, and then display the remote phone book entries on the phone user interface. IP phones support up to 5 remote phone books. Remote phone book is customizable.

Customizing Remote Phone Book Template File

You can customize the remote phone book for IP phones as required. You can also add multiple remote contacts at a time and/or share remote contacts between IP phones using the supplied template files (Menu.xml and Department.xml). The Menu.xml file defines departments of a remote phone book. The Department.xml file defines contact lists for a department, which is nested in Menu.xml file. After setup, place the files (Menu.xml and Department.xml) to the provisioning server, and specify the access URL of the file (Menu.xml) in the configuration files.

You can ask the distributor or Yealink FAE for remote XML phone book template. You can also obtain the remote XML phone book template online:

<http://support.yealink.com/documentFront/forwardToDocumentFrontDisplayPage>. For more information on obtaining the remote phone book template, refer to [Obtaining Configuration Files and Resource Files](#) on page 52.

When creating a Department.xml file, learn the following:

- `<YealinkIPPhoneDirectory>` indicates the start of a department file and `</YealinkIPPhoneDirectory>` indicates the end of a department file.
- Create contact lists for a department between `<DirectoryEntry>` and `</DirectoryEntry>`.

To customize a Department.xml file:


1. Open the template file using an ASCII editor.
2. For each contact that you want to add, add the following strings to the file. Each starts on a separate line:

<pre><Name> Test1</Name> <Telephone> 23000</Telephone></pre>
--

Where:

Specify the contact name between <Name> and </Name>.

Specify the contact number between <Telephone> and </Telephone>.



3. Save the file and place this file to the provisioning server.

When creating a Menu.xml file, learn the following:

- <YealinkIPPhoneMenu> indicates the start of a remote phone book file and </YealinkIPPhoneMenu> indicates the end of a remote phone book file.
- Create the title of a remote phone book between <Title> and </Title>.
- <Menuitem> indicates the start of specifying a department file and </Menuitem> indicates the end of specifying a department file.
- <SoftKeyItem> indicates the start of specifying an XML file and </SoftKeyItem> indicates the end of specifying an XML file.

To customize a Menu.xml file:


1. Open the template file using an ASCII editor.
2. For each department that you want to add, add the following strings to the file. Each starts on a separate line:

```

<Menuitem>
<Name>Department1</Name>


```

```
<URL> http://10.2.9.1:99/Department.xml</URL>
</MenuItem>
```



- For each XML file that you want to add, add the following strings to the file. Each starts on a separate line:

```
<SoftKeyItem>
<Name>#</Name>
<URL> http://10.2.9.1:99/Department.xml</URL>
</SoftKeyItem>
```



- Save the file and place this file to the provisioning server.
- Specify the access URL of the remote phone book (remote_phonebook.data.1.url = http://192.168.1.20/Menu.xml).

During the auto provisioning process, the IP phone connects to the provisioning server “192.168.1.20”, and downloads the remote phone book file “Menu.xml”.

Note

Yealink supplies a phonebook generation tool to generate a remote XML phone book. For more information, refer to [Yealink Phonebook Generation Tool User Guide](#).

Incoming/Outgoing Call Lookup allows IP phones to search the entry names from the remote phone book for incoming/outgoing calls. Update Time Interval specifies how often IP phones refresh the local cache of the remote phone book.

Procedure

Remote phone book can be configured using the configuration files or locally.

Configuration File	<y0000000000xx> .cfg	Specify the access URL and the display name of the remote phone book. Parameters: remote_phonebook.data.X.url remote_phonebook.data.X.name remote_phonebook.display_name
		Specify whether to query the entry name from the remote phone book for outgoing/incoming calls. Parameter: features.remote_phonebook.enable
		Specify how often the IP phone refreshes the local cache of the remote phone book. Parameter: features.remote_phonebook.flash_time
		Specify whether to refresh the local cache of the remote phone book at a time when accessing the remote phone book. Parameter: features.remote_phonebook.enter_update_enable
Local	Web User Interface	Specify the access URL and the display name of the remote phone book. Specify whether to query the entry name from the remote phone book for outgoing/incoming calls. Specify how often the IP phone refreshes

		<p>the local cache of the remote phone book.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/ T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p=contacts-remote&q=load</p> <p>For SIP VP-T49G: http://<phoneIPAddress>/servlet?m=mod_data&p=contacts-remote&q=load</p>
--	--	--

Details of Configuration Parameters:

Parameters	Permitted Values	Default
remote_phonebook.data.X.url (X ranges from 1 to 5)	URL within 511 characters	Blank
<p>Description: Configures the access URL of the remote phone book.</p> <p>Example: remote_phonebook.data.1.url = http://192.168.1.20/phonebook.xml</p> <p>Web User Interface: Directory->Remote Phone Book->Remote URL</p> <p>Phone User Interface: None</p>		
remote_phonebook.data.X.name (X ranges from 1 to 5)	String within 99 characters	Blank
<p>Description: Configures the display name of the remote phone book item.</p> <p>Example: remote_phonebook.data.1.name = Xmyl</p> <p>Web User Interface: Directory->Remote Phone Book->Display Name</p> <p>Phone User Interface: None</p>		
remote_phonebook.display_name	String within 99 characters	Blank

Parameters	Permitted Values	Default
<p>Description: Configures the display name of the remote phone book.</p> <p>Example: remote_phonebook.display_name = Friends "Friends" will be displayed on the LCD screen at the path Menu->Directory. If it is left blank, Remote Phone Book will be the display name.</p> <p>Note: It is not applicable to SIP-T42G/T41P IP phones.</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		
features.remote_phonebook.enable	0 or 1	0
<p>Description: Enables or disables the IP phone to perform a remote phone book search for an incoming or outgoing call and display the matched results on the LCD screen.</p> <p>0-Disabled 1-Enabled</p> <p>Web User Interface: Directory->Remote Phone Book->Incoming/Outgoing Call Lookup</p> <p>Phone User Interface: None</p>		
features.remote_phonebook.flash_time	0, Integer from 3600 to 1296000	21600
<p>Description: Configures how often to refresh the local cache of the remote phone book. If it is set to 3600, the IP phone will refresh the local cache of the remote phone book every 3600 seconds.</p> <p>Note: If it is set to 0, the IP phone will refresh the local cache of the remote phone book aperiodically.</p> <p>Web User Interface: Directory->Remote Phone Book->Update Time Interval(Seconds)</p> <p>Phone User Interface: None</p>		

Parameters	Permitted Values	Default
features.remote_phonebook.enter_update_enable	0 or 1	0
<p>Description:</p> <p>Enables or disables the IP phone to refresh the local cache of the remote phone book at a time when accessing the remote phone book.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		

To specify access URL of the remote phone book via web user interface:

1. Click on **Directory->Remote Phone Book**.
2. Enter the access URL in the **Remote URL** field.
3. Enter the name in the **Display Name** field.

The screenshot shows the Yealink T236 web interface. The 'Directory' tab is selected, and the 'Remote Phone Book' sub-tab is active. A table with 3 columns (Index, Remote URL, Display Name) is shown. The first row (Index 1) has 'http://192.168.1.20/phonebook.xml' in the Remote URL field and 'Xmyl' in the Display Name field. Below the table, there are two settings: 'Incoming/Outgoing Call Lookup' set to 'Disabled' and 'Update Time Interval(Seconds)' set to '21600'. A 'NOTE' box on the right states: 'Remote Phone Book It is a centrally maintained phone book, stored on the remote server. Users only need the access URL of the remote phone book. The IP phone can establish a connection with the remote server and download the phone book, and then display the remote phone book entries on the phone user interface.' There is also a link to get more guides.

4. Click **Confirm** to accept the change.

To configure incoming/outgoing call lookup and update time interval via web user interface:

1. Click on **Directory->Remote Phone Book**.
2. Select the desired value from the pull-down list of **Incoming/Outgoing Call Lookup**.

- Enter the desired time in the **Update Time Interval(Seconds)** field.

The screenshot shows the Yealink T236 web interface. The 'Directory' tab is selected. On the left, there is a sidebar with options: Local Directory, Remote Phone Book, Phone Call Info, LDAP, Multicast IP, and Setting. The main area displays a table with columns: Index, Remote URL, and Display Name. The table has 5 rows. Below the table, there are two fields: 'Incoming/Outgoing Call Lookup' (set to 'Enabled') and 'Update Time Interval(Seconds)' (set to '21600'). A red box highlights these two fields. At the bottom, there are 'Confirm' and 'Cancel' buttons. On the right, there is a 'NOTE' section titled 'Remote Phone Book' with explanatory text and a link to more guides.

- Click **Confirm** to accept the change.

LDAP

LDAP (Lightweight Directory Access Protocol) is an application protocol for accessing and maintaining information services for the distributed directory over an IP network. IP phones can be configured to interface with a corporate directory server that supports LDAP version 2 or 3. The following LDAP servers are supported:

- Microsoft Active Directory
- Sun ONE Directory Server
- Open LDAP Directory Server
- Microsoft Active Directory Application Mode (ADAM)

The biggest plus for LDAP is that users can access the central LDAP directory of the corporation using IP phones. Therefore they do not have to maintain the directory locally. Users can search and dial out from the LDAP directory, and save LDAP entries to the local directory. LDAP entries displayed on the IP phone are read only, which cannot be added, edited or deleted by users. When an LDAP server is properly configured, the IP phone can look up entries from the LDAP server in a wide variety of ways. The LDAP server indexes all the data in its entries, and “filters” can be used to select the desired entry or group, and return the desired information.

Configurations on the IP phone limit the amount of the displayed entries when querying from the LDAP server, and decide how attributes are displayed and sorted.

You can set a DSS key to be an LDAP key, and then press the LDAP key to enter the LDAP search screen when the IP phone is idle.

Note

LDAP is not applicable to SIP-T19(P) E2 IP phones.

LDAP Attributes

The following table lists the most common attributes used to configure the LDAP lookup on IP phones.

Abbreviation	Name	Description
gn	givenName	First name
cn	commonName	LDAP attribute is made up from given name joined to surname.
sn	surname	Last name or family name
dn	distinguishedName	Unique identifier for each entry
dc	dc	Domain component
-	company	Company or organization name
-	telephoneNumber	Office phone number
mobile	mobilephoneNumber	Mobile or cellular phone number
ipPhone	IPphoneNumber	Home phone number

For more information on LDAP, refer to [LDAP Phonebook on Yealink IP Phones](#).

Procedure

LDAP can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure LDAP. Parameters: ldap.enable ldap.name_filter ldap.number_filter ldap.tls_mode ldap.host ldap.port ldap.base ldap.user ldap.password ldap.max_hits ldap.name_attr ldap.numb_attr ldap.display_name ldap.version ldap.call_in_lookup
---------------------------	---------------------	---

		ldap.call_out_lookup ldap.ldap_sort ldap.incoming_call_special_search.enable
		Assign an LDAP key. Parameters: linekey.X.type/ programablekey.X.type/ expansion_module.X.key.Y.type linekey.X.label/ programablekey.X.label/ expansion_module.X.key.Y.label
	Web User Interface	Configure LDAP. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=contacts-LDAP&q=load">http://<phoneIPAddress>/servlet?p=contacts-LDAP&q=load For SIP VPT49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=contacts-LDAP&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=contacts-LDAP&q=load
		Assign an LDAP key. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=dsskey&q=load&model=0">http://<phoneIPAddress>/servlet?p=dsskey&q=load&model=0 For SIP VPT49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=dsskey&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=dsskey&q=load
Local	Phone User Interface	Assign an LDAP key.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
ldap.enable	0 or 1	0
Description: Enables or disables LDAP feature on the IP phone. 0 -Disabled 1 -Enabled Note: It is not applicable to SIP-T19(P) E2 IP phones. Web User Interface: Directory->LDAP->Enable LDAP Phone User Interface: None		
ldap.name_filter	String within 99 characters	Blank
Description: Configures the search criteria for LDAP contact names look up. The "*" symbol in the filter stands for any character. The "%" symbol in the filter stands for the name prefix entered by the user. Example: ldap.name_filter = ((cn=*)(sn=*)) When the cn or sn of the LDAP contact starts with the entered prefix, the record will be displayed on the LCD screen. Note: It is not applicable to SIP-T19(P) E2 IP phones. Web User Interface: Directory->LDAP->LDAP Name Filter Phone User Interface: None		
ldap.number_filter	String within 99 characters	Blank
Description: Configures the search criteria for LDAP contact numbers look up. The "*" symbol in the filter stands for any number. The "%" symbol in the filter stands for the number prefix entered by the user. Example:		

Parameters	Permitted Values	Default
<p>ldap.number_filter = ((telephoneNumber=%)(mobile=%)(ipPhone=%))</p> <p>When the number prefix of the telephoneNumber, mobile or ipPhone of the contact record matches the search criteria, the record will be displayed on the LCD screen.</p> <p>Note: It is not applicable to SIP-T19(P) E2 IP phones.</p> <p>Web User Interface:</p> <p>Directory->LDAP->LDAP Number Filter</p> <p>Phone User Interface:</p> <p>None</p>		
ldap.tls_mode	0, 1 or 2	0
<p>Description:</p> <p>Configures the connection mode between the LDAP server and the IP phone.</p> <p>0-LDAP—Unencrypted connection between LDAP server and the IP phone (port 389 is used by default).</p> <p>1-LDAP TLS Start—TLS/SSL connection between LDAP server and the IP phone (port 389 is used by default).</p> <p>2-LDAPs—TLS/SSL connection between LDAP server and the IP phone (port 636 is used by default).</p> <p>Note: It is not applicable to SIP-T19(P) E2 IP phones.</p> <p>Web User Interface:</p> <p>Directory->LDAP->LDAP TLS Mode</p> <p>Phone User Interface:</p> <p>None</p>		
ldap.host	IP address or domain name	Blank
<p>Description:</p> <p>Configures the IP address or domain name of the LDAP server.</p> <p>Example:</p> <p>ldap.host = 192.168.1.20</p> <p>Note: It is not applicable to SIP-T19(P) E2 IP phones.</p> <p>Web User Interface:</p> <p>Directory->LDAP->Server Address</p> <p>Phone User Interface:</p> <p>None</p>		
ldap.port	Integer from 1 to	389

Parameters	Permitted Values	Default
	65535	
<p>Description: Configures the port of the LDAP server.</p> <p>Example: ldap.port = 389</p> <p>Note: It is not applicable to SIP-T19(P) E2 IP phones.</p> <p>Web User Interface: Directory->LDAP->Port</p> <p>Phone User Interface: None</p>		
ldap.base	String within 99 characters	Blank
<p>Description: Configures the LDAP search base which corresponds to the location of the LDAP phone book from which the LDAP search request begins. The search base narrows the search scope and decreases directory search time.</p> <p>Example: ldap.base = dc=yealink,dc=cn</p> <p>Note: It is not applicable to SIP-T19(P) E2 IP phones.</p> <p>Web User Interface: Directory->LDAP->Base</p> <p>Phone User Interface: None</p>		
ldap.user	String within 99 characters	Blank
<p>Description: Configures the user name used to login the LDAP server. This parameter can be left blank in case the server allows anonymous to login. Otherwise you will need to provide the user name to login the LDAP server.</p> <p>Example: ldap.user = cn=manager,dc=yealink,dc=cn</p> <p>Note: It is not applicable to SIP-T19(P) E2 IP phones.</p> <p>Web User Interface: Directory->LDAP->Username</p>		

Parameters	Permitted Values	Default
Phone User Interface: None		
ldap.password	String within 99 characters	Blank
Description: Configures the password to login the LDAP server. This parameter can be left blank in case the server allows anonymous to login. Otherwise you will need to provide the password to login the LDAP server. Example: ldap.password = secret Note: It is not applicable to SIP-T19(P) E2 IP phones. Web User Interface: Directory->LDAP->Password Phone User Interface: None		
ldap.max_hits	Integer from 1 to 32000	50
Description: Configures the maximum number of search results to be returned by the LDAP server. If the value of the "Max.Hits" is blank, the LDAP server will return all searched results. Please note that a very large value of the "Max. Hits" will slow down the LDAP search speed, therefore it should be configured according to the available bandwidth. Example: ldap.max_hits = 50 Note: It is not applicable to SIP-T19(P) E2 IP phones. Web User Interface: Directory->LDAP->Max Hits (1~32000) Phone User Interface: None		
ldap.name_attr	String within 99 characters	Blank
Description: Configures the name attributes of each record to be returned by the LDAP server. It compresses the search results. You can configure multiple name attributes		

Parameters	Permitted Values	Default
<p>separated by spaces.</p> <p>Example:</p> <p>ldap.name_attr = cn sn</p> <p>This requires the "cn" and "sn" attributes set for each contact record on the LDAP server.</p> <p>Note: It is not applicable to SIP-T19(P) E2 IP phones.</p> <p>Web User Interface:</p> <p>Directory->LDAP->LDAP Name Attributes</p> <p>Phone User Interface:</p> <p>None</p>		
ldap.numb_attr	String within 99 characters	Blank
<p>Description:</p> <p>Configures the number attributes of each record to be returned by the LDAP server. It compresses the search results. You can configure multiple number attributes separated by spaces.</p> <p>Example:</p> <p>ldap.numb_attr = mobile ipPhone</p> <p>This requires the "mobile" and "ipPhone" attributes set for each contact record on the LDAP server.</p> <p>Note: It is not applicable to SIP-T19(P) E2 IP phones.</p> <p>Web User Interface:</p> <p>Directory->LDAP->LDAP Number Attributes</p> <p>Phone User Interface:</p> <p>None</p>		
ldap.display_name	String within 99 characters	Blank
<p>Description:</p> <p>Configures the display name of the contact record displayed on the LCD screen. The value must start with "%" symbol.</p> <p>Example:</p> <p>ldap.display_name = %cn</p> <p>The cn of the contact record is displayed on the LCD screen.</p> <p>Note: It is not applicable to SIP-T19(P) E2 IP phones.</p> <p>Web User Interface:</p>		

Parameters	Permitted Values	Default
Directory->LDAP->LDAP Display Name Phone User Interface: None		
ldap.version	2 or 3	3
Description: Configures the LDAP protocol version supported by the IP phone. Make sure the protocol value corresponds with the version assigned on the LDAP server. Note: It is not applicable to SIP-T19(P) E2 IP phones. Web User Interface: Directory->LDAP->Protocol Phone User Interface: None		
ldap.call_in_lookup	0 or 1	0
Description: Enables or disables the IP phone to perform an LDAP search when receiving an incoming call. 0 -Disabled 1 -Enabled Note: It is not applicable to SIP-T19(P) E2 IP phones. Web User Interface: Directory->LDAP->LDAP Lookup For Incoming Call Phone User Interface: None		
ldap.call_out_lookup	0 or 1	1
Description: Enables or disables the IP phone to perform an LDAP search when placing a call. 0 -Disabled 1 -Enabled Note: It is not applicable to SIP-T19(P) E2 IP phones. Web User Interface: Directory->LDAP->LDAP Lookup For Callout Phone User Interface:		

Parameters	Permitted Values	Default
None		
ldap.ldap_sort	0 or 1	0
<p>Description: Enables or disables the IP phone to sort the search results in alphabetical order or numerical order.</p> <p>0-Disabled 1-Enabled</p> <p>Note: It is not applicable to SIP-T19(P) E2 IP phones.</p> <p>Web User Interface: Directory->LDAP->LDAP Sorting Results</p> <p>Phone User Interface: None</p>		
ldap.incoming_call_special_search.enable	0 or 1	0
<p>Description: Enables or disables the IP phone to search the telephone numbers starting with "+" symbol and "00" from the LDAP server if the incoming phone number starts with "+" or "00". When completing the LDAP search, the all search results will be displayed on the LCD screen.</p> <p>0-Disabled 1-Enabled</p> <p>For example, If the phone receives an incoming call from the phone number 0044123456789, it will search 0044123456789 from the LDAP sever first, if no result found, it will search +44123456789 from the server again. The phone will display all the search results.</p> <p>Note: It works only if the value of the parameter "ldap.call_in_lookup" is set to 1 (Enabled). You may need to set the value of the parameter "ldap.name_filter" to be ((cn=*)(sn=*)(telephoneNumber=*)(mobile=*)) for searching the telephone numbers starting with "+" symbol. It is not applicable to SIP-T19(P) E2 IP phones.</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		

LDAP Key

For more information on how to configure the DSS Key, refer to [Appendix D: Configuring DSS Key](#) on page 926.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
linekey.X.type/ programablekey.X.type/ expansion_module.X.key.Y.type	38	Refer to the following content
<p>Description:</p> <p>Configures a DSS key as an LDAP key on the IP phone.</p> <p>The digit 38 stands for the key type LDAP.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G)</p> <p>X ranges from 1 to 27 (for SIPT46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For programable keys:</p> <p>X=1-4, 12-14 (for SIP VP-T49G)</p> <p>X=1-10, 12-14 (for SIPT48G/T46G)</p> <p>X=1-10, 13 (for SIPT42G/T41P/T40P)</p> <p>X=1-14 (for SIPT29G/T27P)</p> <p>X=1-10, 14 (for SIPT23P/T23G/T21(P) E2)</p> <p>X=1-6, 9, 13 (for CP860)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Example:</p> <p>linekey.1.type = 38</p> <p>Default:</p> <p>For SIP VP-T49G/SIPT48G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-29 is 0.</p> <p>For SIPT46G/T29G IP phones:</p>		

Parameters	Permitted Values	Default
<p>The default value of the line key 1-16 is 15, and the default value of the line key 17-27 is 0.</p> <p>For SIP-T42G IP phones:</p> <p>The default value of the line key 1-12 is 15, and the default value of the line key 13-15 is 0.</p> <p>For SIP-T41P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-15 is 0.</p> <p>For SIP-T27P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-21 is 0.</p> <p>For SIP-T40P/23P/T23G/T21(P) E2 IP phones:</p> <p>The default value is 15.</p> <p>For programmable keys:</p> <p>For SIP VP-T49G IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIP-T48G/T46G IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p>		

Parameters	Permitted Values	Default
<p>For SIP-T42G/T41P/T40P IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>For SIP-T29G/T27P IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=11, the default value is 0 (NA).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIP-T23P/T23G/T21(P) E2 IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p>		

Parameters	Permitted Values	Default
<p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For CP860 IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=13, the default value is 0 (NA).</p> <p>For ext keys:</p> <p>When Y=1, the default value is 37 (Switch).</p> <p>When Y= 2 to 20, 22 to 40, the default value is 0 (NA).</p> <p>Note: It is not applicable to SIP-T19(P) E2 IP phones.</p> <p>Web User Interface:</p> <p>DSSKey->Line Key/ Programmable Key->Type</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Type</p>		
linekey.X.label/ programmablekey.X.label/ expansion_module.X.key.Y.label	String within 99 characters	Blank
<p>Description:</p> <p>(Optional.) Configures the label displayed on the LCD screen for each DSS key.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G)</p> <p>X ranges from 1 to 27 (for SIPT46G/T29G)</p> <p>X ranges from 1 to 15 (for SIPT42G/T41P)</p> <p>X ranges from 1 to 21 (for SIPT27P)</p> <p>X ranges from 1 to 3 (for SIPT40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIPT21(P) E2)</p> <p>For programmable keys:</p>		

Parameters	Permitted Values	Default
<p>X ranges from 1 to 4.</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Note: It is not applicable to SIP-T19(P) E2 IP phones.</p> <p>Web User Interface:</p> <p>DSSKey->Line Key/Programable Key->Label</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Label</p>		

To configure LDAP via web user interface:

1. Click on **Directory->LDAP**.
2. Enter the values in the corresponding fields.
3. Select the desired values from the corresponding pull-down lists.

4. Click **Confirm** to accept the change.

To configure an LDAP key via web user interface:

1. Click on **DSSKey->Line Key** (or **Programable Key**).
2. In the desired DSS key field, select **LDAP** from the pull-down list of **Type**.

- (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.

Key	Type	Value	Label	Line	Extension
Line Key1	Line		1011	Line 1	
Line Key2	LDAP		N/A	Line 2	
Line Key3	Line			Line 3	

- Click **Confirm** to accept the change.

To configure an LDAP key via phone user interface:

- Press **Menu->Features->DSS Keys**.
- Select the desired DSS key.
- Press \leftarrow or \rightarrow , or the **Switch** soft key to select **Key Event** from the **Type** field.
- Press \leftarrow or \rightarrow , or the **Switch** soft key to select **LDAP** from the **Key Type** field.
- (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.
- Press the **Save** soft key to accept the change.

Busy Lamp Field (BLF)

BLF is used to monitor a specific user for status changes on IP phones. For example, you can configure a BLF key on a supervisor's phone to monitor the IP phone user status (busy or idle). When the monitored user places a call, a busy indicator on the supervisor's phone indicates that the user's phone is in use.

When the monitored user is idle, the supervisor can press the BLF key to dial out the phone number. When the monitored user receives an incoming call, the supervisor can press the BLF key to pick up the call directly. When the monitored user is in a call, the supervisor can press the BLF key to interrupt and set up a conference call.

Note

BLF is not applicable to SIP-T19(P) E2 and CP860 IP phones.

BLF Subscription

IP phones support BLF using a SUBSCRIBE/NOTIFY mechanism as specified in [RFC 3265](#). This feature depends on support from a SIP server.

When the IP phone is configured to monitor a specific user, it sends a SUBSCRIBE message to the server. A NOTIFY message which includes XML in the message body is sent to the IP phone to inform the current state of monitored user. Once status of the monitored user is changed from idle to busy or vice versa, the IP phone is notified from the server with a NOTIFY message. You can manually configure the period of the BLF

subscription.

Example of a SUBSCRIBE message:

```
SUBSCRIBE sip:1011@10.3.20.2:5060 SIP/2.0
Via: SIP/2.0/UDP 10.3.20.1:5060;branch=z9hG4bK2940676338
From: "1010" <sip:1010@10.2.1.48:5060>;tag=2493044525
To: <sip:1011@10.2.1.48:5060>;tag=2527548726
Call-ID: 0_3538292381@10.3.20.1
CSeq: 2 SUBSCRIBE
Contact: <sip:1010@10.3.20.1:5060>
Accept: application/dialog-info+xml
Max-Forwards: 70
User-Agent: Yealink SIP-T23G 44.80.0.60
Expires: 30
Event: dialog
Content-Length: 0
```

Example of a NOTIFY message (<state>confirmed</state> shows the call has been established):

```
NOTIFY sip:1010@10.3.20.1:5060 SIP/2.0
Via: SIP/2.0/UDP 10.3.20.2:5060;branch=z9hG4bK276311022
From: <sip:1011@10.2.1.48:5060>;tag=3436332841
To: "1010" <sip:1010@10.2.1.48:5060>;tag=3098567568
Call-ID: 0_4117916748@10.3.20.1
CSeq: 4 NOTIFY
Contact: <sip:1011@10.3.20.2:5060>
Content-Type: application/dialog-info+xml
Max-Forwards: 70
User-Agent: Yealink SIP-T27P 45.80.0.20
Subscription-State: active;expires=17
Event: dialog
Content-Length: 534

<?xml version="1.0"?>
<dialog-info xmlns="urn:ietf:params:xml:ns:dialog-info" version="3" state="partial"
entity="sip:1011@10.2.1.48:5060">
<dialog id="74" call-id="0_2561109579@10.3.20.1" local-tag="2778958897" remote-tag="1132018898"
direction="recipient">
<state>confirmed</state>
<local>
<identity>sip:1011@10.2.1.48:5060</identity>
<target uri="sip:1011@10.2.1.48:5060"/>
</local>
<remote>
```

```

<identity>sip:1010@10.2.1.48:5060</identity>
<target uri="sip:1010@10.2.1.48:5060"/>
</remote>
</dialog>
</dialog-info>

```

Visual Alert and Audio Alert for BLF Pickup

Visual and audio alert for BLF pickup allow the supervisor's phone to play an alert tone and display a visual prompt (e.g., "6001<-6002", 6001 is the monitored extension which receives an incoming call from 6002) when the monitored user receives an incoming call. In addition to the BLF key, visual alert for BLF pickup feature enables the supervisor to pick up the monitored user's incoming call by pressing the **DPickup** soft key. The directed call pickup code must be configured in advance. For more information on how to configure the directed call pickup code for the **DPickup** soft key, refer to [Directed Call Pickup](#) on page 391.

BLF LED Mode

BLF LED Mode provides five kinds of definition for the BLF/BLF List key LED status. As there is no hard line key on SIP VP-T49G and SIP-T48G IP phones, BLF LED mode configuration is only applicable to SIP-T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2 IP phones. BLF LED mode is also applicable to the expansion module EXP40 connected to SIP-T48G/T46G IP phones, EXP20 connected to SIP-T29G and SIP-T27P IP phones. The following table lists the LED statuses of the BLF key when BLF LED Mode is set to 0, 1, 2, 3 or 4 respectively. The default value of BLF LED mode is 0.

BLF LED mode feature is also applicable to BLF list key. For more information on BLF List key, refer to [BLF List](#) on page 537.

Line key/Expansion Module Key LED (configured as a BLF key or a BLF List key and BLF LED Mode is set to 0)

LED Status	Description
Solid green	The monitored user is idle.
Fast flashing red (200ms)	The monitored user receives an incoming call.
Solid red	The monitored user is dialing. The monitored user is talking. The monitored user's conversation is placed on hold (This LED status requires server support).
Slow flashing red (1s)	The call is parked against the monitored user's phone number.
Off	The monitored user does not exist.

Line Key/Expansion Module Key LED (configured as a BLF key or a BLF List key and BLF LED Mode is set to 1)

LED Status	Description
Fast flashing red (200ms)	The monitored user receives an incoming call.
Solid red	The monitored user is dialing. The monitored user is talking. The monitored user's conversation is placed on hold (This LED status requires server support).
Slow flashing red (1s)	The call is parked against the monitored user's phone number.
Off	The monitored user is idle. The monitored user does not exist.

Line Key/Expansion Module Key LED (configured as a BLF key or a BLF List key and BLF LED Mode is set to 2)

LED Status	Description
Fast flashing red (200ms)	The monitored user receives an incoming call.
Solid red	The monitored user is dialing. The monitored user is talking. The monitored user's conversation is placed on hold (This LED status requires server support).
Slow flashing red (1s)	The call is parked against the monitored user's phone number.
Off	The monitored user is idle. The monitored user does not exist.

Line Key/Expansion Module Key LED (configured as a BLF key or a BLF List key and BLF LED Mode is set to 3)

LED Status	Description
Fast flashing green (200ms)	The monitored user receives an incoming call.
Solid red	The monitored user is dialing. The monitored user is talking. The monitored user's conversation is placed on hold (This LED status requires server support).
Slow flashing red (1s)	The call is parked against the monitored user's phone number.
Off	The monitored user is idle. The monitored user does not exist.

Line Key/Expansion Module Key LED (configured as a BLF key or a BLF List key and BLF LED Mode is set to 4. This mode is specifically designed for the Genband server.)

LED Status	Description
Solid green	The monitored user is talking.
Slow flashing green (1s)	The monitored user does not exist.
Off	The monitored user is idle.

Procedure

BLF can be configured using the configuration files or locally.

Configuration File	y0000000000xx.cfg	Specify whether to use visual alert and audio alert for BLF pickup. Parameters: features.pickup.blf_visual_enable features.pickup.blf_audio_enable
		Assign a BLF key. Parameters: linekey.X.type/ expansion_module.X.key.Y.type linekey.X.line/ expansion_module.X.key.Y.line linekey.X.value/ expansion_module.X.key.Y.value linekey.X.pickup_value/ expansion_module.X.key.Y.pickup_value linekey.X.label/ expansion_module.X.key.Y.label
		Configure BLF LED mode. Parameter: features.blf_led_mode
	<MAC>.cfg	Configure the period of the BLF subscription. Parameter: account.X.blf.subscribe_period

		<p>Configure the event of the BLF subscription.</p> <p>Parameter: account.X.blf.subscribe_event</p>
		<p>Configure whether to handle NOTIFY messages out of the BLF dialog.</p> <p>Parameter: account.X.out_dialog_blf_enable</p>
Local	Web User Interface	<p>Assign a BLF key.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2: <a href="http://<phoneIPAddress>/servlet?p=dsskey&q=load&model=0">http://<phoneIPAddress>/servlet?p=dsskey&q=load&model=0</p> <p>For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=dsskey&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=dsskey&q=load</p>
		<p>Specify whether to use visual alert and audio alert for BLF pickup.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2: <a href="http://<phoneIPAddress>/servlet?p=features-callpickup&q=load">http://<phoneIPAddress>/servlet?p=features-callpickup&q=load</p> <p>For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=features-callpickup&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=features-callpickup&q=load</p>
		<p>Configure BLF LED mode.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2: <a href="http://<phoneIPAddress>/servlet?p=features-general&q=load">http://<phoneIPAddress>/servlet?p=features-general&q=load</p>

		<p>Configure the period of the BLF subscription.</p> <p>Configure whether to handle NOTIFY messages out of the BLF dialog.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2: <code>http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0</code></p> <p>For SIP VP-T49G: <code>http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0</code></p>
	Phone User Interface	Assign a BLF key.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.pickup.blf_visual_enable	0 or 1	0
<p>Description:</p> <p>Enables or disables the IP phone to display a visual alert when the monitored user receives an incoming call.</p> <p>0-Disabled 1-Enabled</p> <p>Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>Features->Call Pickup->Visual Alert for BLF Pickup</p> <p>Phone User Interface:</p> <p>None</p>		
features.pickup.blf_audio_enable	0 or 1	0
<p>Description:</p> <p>Enables or disables the IP phone to play an audio alert when the monitored user receives an incoming call.</p>		

Parameters	Permitted Values	Default
0-Disabled 1-Enabled Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones. Web User Interface: Features->Call Pickup->Audio Alert for BLF Pickup Phone User Interface: None		
features.blf_led_mode	0, 1, 2, 3 or 4	0
Description: Configures BLF LED mode and provides five kinds of definition for the BLF/BLF List key LED status. Note: It is not applicable to SIP VP-T49G, SIP-T19(P) E2 and CP860 IP phones. For the Genband server, you can set the value of this parameter to 4. Web User Interface: Features->General Information->BLF LED Mode Phone User Interface: None		
account.X.blf.subscribe_period	Integer from 30 to 2147483647	1800
Description: Configures the period (in seconds) of the BLF subscription for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) The IP phone is able to successfully refresh the SUBSCRIBE before expiration of the SUBSCRIBE dialog. Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones. Web User Interface: Account->Advanced->Subscribe Period(Seconds) Phone User Interface:		

Parameters	Permitted Values	Default
None		
account.X.blf.subscribe_event	0 or 1	0
<p>Description: Configures the event of the BLF subscription for account X. 0-dialog 1-presence X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		
account.X.out_dialog_blf_enable	0 or 1	0
<p>Description: Enables or disables the IP phone to handle NOTIFY messages out of the BLF dialog for account X. 0-Disabled 1-Enabled X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface: Account->Advanced->Out Dialog BLF</p> <p>Phone User Interface:</p>		

Parameters	Permitted Values	Default
None		

BLF Key

For more information on how to configure the DSS Key, refer to [Appendix D: Configuring DSS Key](#) on page 926.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
linekey.X.type/ expansion_module.X.key.Y.type	16	Refer to the following content
<p>Description: Configures a DSS key as a BLF key on the IP phone. The digit 16 stands for the key type BLF. For line keys: X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G) X ranges from 1 to 27 (for SIPT46G/T29G) X ranges from 1 to 15 (for SIPT42G/T41P) X ranges from 1 to 21 (for SIPT27P) X ranges from 1 to 3 (for SIPT40P/T23P/T23G) X ranges from 1 to 2 (for SIPT21(P) E2) For ext keys: X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured). Example: linekey.1.type = 16 Default: For line keys: For SIP VP-T49G/SIPT48G IP phones: The default value of the line key 1-16 is 15, and the default value of the line key 17-29 is 0. For SIPT46G/T29G IP phones: The default value of the line key 1-16 is 15, and the default value of the line key 17-27 is 0. For SIPT42G IP phones:</p>		

Parameters	Permitted Values	Default
<p>The default value of the line key 1-12 is 15, and the default value of the line key 13-15 is 0.</p> <p>For SIP-T41P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-15 is 0.</p> <p>For SIP-T27P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-21 is 0.</p> <p>For SIP-T40P/T23P/T23G/T21(P) E2 IP phones:</p> <p>The default value is 15.</p> <p>For ext keys:</p> <p>When Y=1, the default value is 37 (Switch).</p> <p>When Y= 2 to 20, 22 to 40, the default value is 0 (NA).</p> <p>Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>DSSKey->Line Key->Type</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Type</p>		
linekey.X.line/ expansion_module.X.key.Y.line	Refer to the following content	1-16 correspond to the lines 1-16
<p>Description:</p> <p>Configures the desired line to apply the BLF key.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Permitted Values:</p> <p>1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p>		

Parameters	Permitted Values	Default
1 to 12 (for SIP-T42G) 1 to 6 (for SIP-T41P/T27P) 1 to 3 (for SIP-T40P/T23P/T23G) 1 to 2 (for SIP-T21(P) E2) 1-Line 1 2-Line 2 ... 16-Line 16 Example: linekey.1.line = 1 Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones. Web User Interface: DSSKey->Line Key->Line Phone User Interface: Menu->Features->DSS Keys->Line Key X->Account ID		
linekey.X.value/ expansion_module.X.key.Y.value	String within 99 characters	Blank
Description: Configures the number of the monitored user. For line keys: X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G) X ranges from 1 to 27 (for SIP-T46G/T29G) X ranges from 1 to 15 (for SIP-T42G/T41P) X ranges from 1 to 21 (for SIP-T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) For ext keys: X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured). Example: linekey.1.value = 1008 Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones. Web User Interface: DSSKey->Line Key->Value		

Parameters	Permitted Values	Default
Phone User Interface: Menu->Features->DSS Keys->Line Key X->Value		
linekey.X.pickup_value/ expansion_module.X.key.Y.pickup_value	String within 256 characters	Blank
Description: Configures the pickup code for BLF feature. This parameter only applies to BLF feature. For line keys: X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G) X ranges from 1 to 27 (for SIP-T46G/T29G) X ranges from 1 to 15 (for SIP-T42G/T41P) X ranges from 1 to 21 (for SIP-T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) For ext keys: X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured). Example: line.1.pickup_value = *88 Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones. Web User Interface: DSSKey->Line Key->Extension Phone User Interface: Menu->Features->DSS Keys->Line Key X->Extension		
linekey.X.label/ expansion_module.X.key.Y.label	String within 99 characters	Blank
Description: (Optional.) Configures the label displayed on the LCD screen for each DSS key. For line keys: X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G) X ranges from 1 to 27 (for SIP-T46G/T29G) X ranges from 1 to 15 (for SIP-T42G/T41P) X ranges from 1 to 21 (for SIP-T27P)		

Parameters	Permitted Values	Default
<p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>DSSKey->Line Key->Label</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Label</p>		

To configure a BLF key via web user interface:

1. Click on **DSSKey->Line Key**.
2. In the desired DSS key field, select **BLF** from the pull-down list of **Type**.
3. Enter the phone number or extension you want to monitor in the **Value** field.
4. Select the desired line from the pull-down list of **Line**.
5. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.
6. (Optional.) Enter the directed call pickup code in the **Extension** field.

The screenshot shows the Yealink T236 web interface. The 'DSSKey' tab is selected. Under 'Line Key', there is a table for configuring programmable keys. The table has columns: Key, Type, Value, Label, Line, and Extension. Line Key2 is highlighted with a red box, showing it is configured as a BLF key with the value 1008, assigned to Line 1, with the label *88. A 'NOTE' box on the right states: 'Line Keys: Line keys allow you to quickly access features such as recall and voice mail. You can click here to get more guides.'

7. Click **Confirm** to accept the change.

To configure visual alert and audio alert for BLF pickup via web user interface:

1. Click on **Features->Call Pickup**.
2. Select the desired value from the pull-down list of **Visual Alert for BLF Pickup**.

3. Select the desired value from the pull-down list of **Audio Alert for BLF Pickup**.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected. Under the 'Call Pickup' section, the 'Audio Alert for BLF Pickup' dropdown is highlighted with a red box, showing 'Enabled' selected. The 'Visual Alert for BLF Pickup' dropdown is also highlighted with a red box, showing 'Enabled' selected. The 'Call Park' section is visible below. The 'Confirm' and 'Cancel' buttons are at the bottom.

4. Click **Confirm** to accept the change.

To configure BLF LED mode via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **BLF LED Mode**.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected. Under the 'General Information' section, the 'BLF LED Mode' dropdown is highlighted with a red box, showing '0' selected. The 'Call Waiting' section is visible above. The 'Confirm' and 'Cancel' buttons are at the bottom.

3. Click **Confirm** to accept the change.

To configure BLF subscription via web user interface:

1. Click on **Account->Advanced**.
2. Select the desired account from the pull-down list of **Account**.

3. Enter the desired period of BLF subscription in the **Subscribe Period(Seconds)** field.

The screenshot shows the Yealink T236 web interface. The 'Account' tab is selected. The 'Subscribe Period(Seconds)' field is highlighted with a red box and contains the value '1800'. Other fields include 'Keep Alive Type' (Default), 'Keep Alive Interval(Seconds)' (30), 'RPort' (Disabled), 'DTMF Type' (RFC2833), 'DTMF Info Type' (DTMF-Relay), 'DTMF Payload Type(96~127)' (101), 'Retransmission' (Disabled), 'Subscribe Register' (Disabled), and 'Subscribe for MWI' (Disabled). A sidebar on the left shows navigation options: Register, Basic, Codec, and Advanced. A 'NOTE' section on the right contains information about DTMF, Session Timer, and Busy Lamp Field/BLF List.

4. Click **Confirm** to accept the change.

To configure a BLF key via phone user interface:

1. Press **Menu->Features->DSS Keys**.
2. Select the desired DSS key.
3. Press **◀** or **▶**, or the **Switch** soft key to select **BLF** from the **Type** field.
4. Press **◀** or **▶**, or the **Switch** soft key to select the desired line from the **Account ID** field.
5. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.
6. Enter the phone number or extension you want to monitor in the **Value** field.
7. (Optional.) Enter the directed call pickup code in the **Extension** field.
8. Press the **Save** soft key to accept the change.

BLF List

Busy Lamp Field (BLF) List allows a list of specific extensions to be monitored for status changes. It enables the monitoring phone to subscribe to a list of users, and receive notifications of the status of monitored users. Different indicators on the monitoring phone show the status of monitored users. The monitoring user can also be notified about calls being parked/no longer parked against any monitored user. IP phones support BLF list using a SUBSCRIBE/NOTIFY mechanism as specified in [RFC 3265](#). This feature depends on support from a SIP server.

Note

BLF list is not applicable to SIP-T19(P) E2 and CP860 IP phones.

Procedure

BLF List can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	<p>Configure BLF List.</p> <p>Parameters:</p> <p>account.X.blf.blf_list_uri</p> <p>account.X.blf_list_code</p> <p>account.X.blf_list_barge_in_code</p> <p>account.X.blf_list_retrieve_call_parked_code</p>
	y0000000000xx.cfg	<p>Specify whether to automatically configure the BLF list keys.</p> <p>Parameter:</p> <p>phone_setting.auto_blf_list_enable</p>
		<p>Configure the order of BLF list keys assigned automatically.</p> <p>Parameter:</p> <p>phone_setting.blf_list_sequence_type</p>
		<p>Assign a BLF List key.</p> <p>Parameters:</p> <p>linekey.X.type/ expansion_module.X.key.Y.type</p> <p>linekey.X.line/ expansion_module.X.key.Y.line</p>
Local	Web User Interface	<p>Configure BLF List.</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2: <a href="http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0">http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0</p> <p>For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0">http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0</p>
		<p>Assign a BLF List key.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27</p>

		P/T23P/T23G/T21(P) E2: http://<phoneIPAddress>/servlet?p=dsskey&q=load&model=0 For SIP VP-T49G: http://<phoneIPAddress>/servlet?m=mod_data&p=dsskey&q=load
	Phone User Interface	Assign a BLF List key.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
phone_setting.auto_blf_list_enable	0 or 1	1
Description: Enables or disables the IP phone to automatically configure the BLF list keys. 0 -Disabled 1 -Enabled Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones. Web User Interface: None Phone User Interface: None		
phone_setting.blf_list_sequence_type	0 or 1	0
Description: Configures the order of BLF list keys assigned automatically. 0 -Line Key->Ext Key 1 -Ext Key->Line Key Note: It works only if the value of the parameter "phone_setting.auto_blf_list_enable" is set to 1 (Enabled). It is only applicable to SIP-T48G/T46G/T29G/T27P IP phones. Web User Interface: None Phone User Interface: None		
account.X.blf.blf_list_uri	String within 256	Blank

Parameters	Permitted Values	Default
	characters	
Description: Configures the BLF List URI to monitor a list of users for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones. Example: account.1.blf.blf_list_uri = 4609@pbx.yealink.com Phone User Interface: None		
account.X.blf_list_code	String within 32 characters	Blank
Description: Configures the feature access code for directed call pickup for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones. Example: account.1.blf_list_code = *97 Web User Interface: Account->Advanced->BLF List Pickup Code Phone User Interface: None		
account.X.blf_list_barge_in_code	String within 32 characters	Blank
Description: Configures the feature access code for directed call pickup with barge-in for account X.		

Parameters	Permitted Values	Default
<p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Example:</p> <p>account.1.blf_list_barge_in_code = *33</p> <p>Web User Interface:</p> <p>Account->Advanced->BLF List Barge In Code</p> <p>Phone User Interface:</p> <p>None</p>		
account.X.blf_list_retrieve_call_parked_code	String within 32 characters	Blank
<p>Description:</p> <p>Configures the feature access code for the call park retrieve for account X.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Example:</p> <p>account.1.blf_list_retrieve_call_parked_code = *88</p> <p>Web User Interface:</p> <p>Account->Advanced->BLF List Retrieve Call Parked Code</p> <p>Phone User Interface:</p> <p>None</p>		

BLF List Key

For more information on how to configure the DSS Key, refer to [Appendix D: Configuring DSS Key](#) on page 926.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
linekey.X.type/ expansion_module.X.key.Y.type	39	Refer to the following content
<p>Description:</p> <p>Configures a DSS key as a BLF List key on the IP phone.</p> <p>The digit 39 stands for the key type BLF List.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Example:</p> <p>linekey.1.type = 39</p> <p>Default:</p> <p>For SIP VP-T49G/SIP-T48G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-29 is 0.</p> <p>For SIP-T46G/T29G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-27 is 0.</p> <p>For SIP-T42G IP phones:</p> <p>The default value of the line key 1-12 is 15, and the default value of the line key 13-15 is 0.</p> <p>For SIP-T41P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-15 is 0.</p> <p>For SIP-T27P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-21 is 0.</p> <p>For SIP-T40P/T23P/T23G/T21(P) E2 IP phones:</p>		

Parameters	Permitted Values	Default
<p>The default value is 15.</p> <p>For ext keys:</p> <p>When Y=1, the default value is 37 (Switch).</p> <p>When Y= 2 to 20, 22 to 40, the default value is 0 (NA).</p> <p>Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>DSSKey->Line Key->Type</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Type</p>		
linekey.X.line/ expansion_module.X.key.Y.line	Refer to the following content	1-16 correspond to the lines 1-16
<p>Description:</p> <p>Configures the desired line to apply the BLF List key.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G)</p> <p>X ranges from 1 to 27 (for SIPT46G/T29G)</p> <p>X ranges from 1 to 15 (for SIPT42G/T41P)</p> <p>X ranges from 1 to 21 (for SIPT27P)</p> <p>X ranges from 1 to 3 (for SIPT40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIPT21(P) E2)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Permitted Values:</p> <p>1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G)</p> <p>1 to 12 (for SIPT42G)</p> <p>1 to 6 (for SIPT41P/T27P)</p> <p>1 to 3 (for SIPT40P/T23P/T23G)</p> <p>1 to 2 (for SIPT21(P) E2)</p> <p>1-Line 1</p> <p>2-Line 2</p> <p>...</p> <p>16-Line 16</p> <p>Example:</p> <p>linekey.1.line = 1</p>		

Parameters	Permitted Values	Default
<p>Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface: DSSKey->Line Key->Line</p> <p>Phone User Interface: Menu->Features->DSS Keys->Line Key X->Account ID</p>		

To configure the BLF List settings via web user interface:

1. Click on **Account->Advanced**.
2. Select the account (e.g., account 1) from the pull-down list of **Account**.
3. Enter the BLF List URI in the **BLF List URI** field.
4. (Optional.) Enter the directed pickup code in the **BLF List Pickup Code** field.
5. (Optional.) Enter the barge-in code in the **BLF List Barge In Code** field.
6. (Optional.) Enter the retrieve call parked code in the **BLF List Retrieve Call Parked Code** field.

The screenshot shows the Yealink T236 web interface. The 'Account' tab is selected, and the 'Advanced' sub-tab is active. The 'Account' dropdown is set to 'Account 1'. The 'BLF List' settings are highlighted with a red box:

- BLF List URI: 4609@pbx.yealink.com
- BLF List Pickup Code: *97
- BLF List Barge In Code: *33
- BLF List Retrieve Call Parked Code: *88

Other visible settings include:

- Keep Alive Type: Default
- Keep Alive Interval(Seconds): 30
- RPort: Disabled
- Subscribe Period(Seconds): 1800
- RTP Encryption(SRTP): Optional
- PTime(ms): 20
- Shared Line: Shared Call Appearance
- Call Pull Feature Access Code: *11
- Dialog Info Call Pickup: Enabled
- VQ RTPC-XR Collector name: collector
- VQ RTPC-XR Collector address: 10.2.1.98
- VQ RTPC-XR Collector port: 5060

On the right side, there is a 'NOTE' section with information about DTMF, Session Timer, Busy Lamp Field/BLF List, Shared Call Appearance (SCA)/ Bridge Line Appearance (BLA), and Network Conference.

7. Click **Confirm** to accept the change.

To configure BLF List keys manually via web user interface:

1. Click on **DSSKey->Line Key**.
2. In the desired DSS key field, select **BLF List** from the pull-down list of **Type**.

- Repeat the step 2, configure more BLF list keys.

- Click **Confirm** to accept the change.

Hide Features Access Code

Hide Features Access Code feature enables the IP phone to display the feature name instead of the dialed feature access code automatically. For example, the dialed call park code will be replaced by the identifier “Call Park” when you park an active call. The hide feature access codes feature is applicable to the following features:

- Voice Mail
- Pick up
- Group Pick up
- Barge In (not applicable to SIP-T19(P) E2 and CP860 IP phones)
- Retrieve (not applicable to SIP-T19(P) E2 and CP860 IP phones)
- Call Park (not applicable to SIP-T19(P) E2 and CP860 IP phones)
- Call Pull

Procedure

The hide feature access codes feature can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the hide feature access codes feature. Parameters: features.hide_feature_access_codes.enable
Local	Web User Interface	Configure the hide feature access codes feature. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T2

		9G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet ?p=features-general&q=load For SIP VPT49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=features-gen eral&q=load
--	--	---

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.hide_feature_access_codes.enable	0 or 1	0
Description: Enables or disables the IP phone to display feature name instead of the feature access code when dialing and in talk. 0 -Disabled 1 -Enabled Web User Interface: Features->General Information->Hide Feature Access Codes Phone User Interface: None		

To enable hide feature access codes feature via web user interface:

1. Click on **Features->General Information**.

2. Select **Enabled** from the pull-down list of **Hide Feature Access Codes**.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected. Under 'General Information', the 'Hide Feature Access Codes' dropdown is set to 'Enabled' and is highlighted with a red rectangle. Other settings include 'Call Waiting' (Enabled), 'Auto Redial' (Disabled), and 'Auto Redial Interval' (10). A 'NOTE' sidebar on the right contains information about various features like Call Waiting, Auto Redial, Key As Send, Hotline, and Call Completion.

3. Click **Confirm** to accept the change.

Automatic Call Distribution (ACD)

ACD enables organizations to manage a large number of phone calls on an individual basis. ACD enables the use of IP phones in a call-center role by automatically distributing incoming calls to available users, or agents. ACD depends on support from a SIP server. ACD is disabled on the IP phone by default. You need to enable it on a per-line basis before logging into the ACD system.

After the IP phone user logs into the ACD system, the server monitors the IP phone status and then decides whether to assign an incoming call to the user's IP phone. When the IP phone status is changed to unavailable, the server stops distributing calls to the IP phone. The IP phone will remain in the unavailable status until the user manually changes the IP phone status or the ACD auto available timer (if configured) expires. How long the IP phone remains unavailable is configurable by the auto available timer. When the timer expires, the IP phone status is automatically changed to available. ACD auto available timer feature depends on support from a SIP server.

You can configure an ACD key for the user to log into the ACD system. The ACD key on the IP phone indicates the ACD status. ACD key is not applicable to SIP-T19(P) E2 and CP860 IP phones.

Procedure

ACD can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure ACD feature on a per-line basis. Parameters:
---------------------------	-----------	--

		account.X.acd.enable account.X.acd.available account.X.subscribe_acd_expires
	<y000000000xx>.cfg	Configure ACD auto available. Parameters: acd.auto_available acd.auto_available_timer
		Assign an ACD key. Parameters: linekey.X.type/ expansion_module.X.key.Y.type linekey.X.label/ expansion_module.X.key.Y.label
Local	Web User Interface	Configure ACD auto available. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet ?p=features-acd&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=features-acd &q=load
		Assign an ACD key. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2: http://<phoneIPAddress>/servlet ?p=dsskey&q=load&model=0 For SIP VP-T49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=dsskey&q=load
	Phone User Interface	Assign an ACD key.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
account.X.acd.enable	0 or 1	0
<p>Description: Enables or disables ACD feature for account X.</p> <p>0-Disabled 1-Enabled</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		
account.X.acd.available	0 or 1	0
<p>Description: Enables or disables the IP phone to display the available and unavailable soft keys for account X after the IP phone logs into the ACD system.</p> <p>0-Disabled 1-Enabled</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Note: It works only if the value of the parameter “account.X.acd.enable” is set to 1 (Enabled).</p> <p>Web User Interface: None</p>		

Parameters	Permitted Values	Default
Phone User Interface: None		
account.X.subscribe_acd_expires	Integer from 120 to 3600	3600
Description: Configures the period (in seconds) of ACD subscription for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Note: It works only if the value of the parameter "account.X.acd.enable" is set to 1 (Enabled). Web User Interface: Account->Advanced->ACD Subscribe Period(120~3600s) Phone User Interface: None		
acd.auto_available	0 or 1	0
Description: Enables or disables the IP phone to automatically change the status of the ACD agent to available after the designated time. 0 -Disabled 1 -Enabled Note: It works only if the value of the parameter "account.X.acd.enable" is set to 1 (Enabled). Web User Interface: Features->ACD->ACD Auto Available Phone User Interface: None		
acd.auto_available_timer	Integer from 0 to 120	60
Description:		

Parameters	Permitted Values	Default
<p>Configures the interval (in seconds) for the status of the ACD agent to be automatically changed to available.</p> <p>Note: It works only if the values of parameters “account.X.acd.enable” and “acd.auto_available” are set to 1 (Enabled).</p> <p>Web User Interface: Features->ACD->ACD Auto Available Timer (0~120s)</p> <p>Phone User Interface: None</p>		

ACD Key

For more information on how to configure the DSS Key, refer to [Appendix D: Configuring DSS Key](#) on page 926.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
linekey.X.type/ expansion_module.X.key.Y.type	42	Refer to the following content
<p>Description: Configures a DSS key to be an ACD key on the IP phone.</p> <p>The digit 42 stands for the key type ACD.</p> <p>For line keys: X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G) X ranges from 1 to 27 (for SIPT46G/T29G) X ranges from 1 to 15 (for SIPT42G/T41P) X ranges from 1 to 21 (for SIPT27P) X ranges from 1 to 3 (for SIPT40P/T23P/T23G) X ranges from 1 to 2 (for SIPT21(P) E2)</p> <p>For ext keys: X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Example: linekey.2.type = 42</p> <p>Default: For SIP VP-T49G/SIPT48G IP phones:</p>		

Parameters	Permitted Values	Default
<p>The default value of the line key 1-16 is 15, and the default value of the line key 17-29 is 0.</p> <p>For SIP-T46G/T29G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-27 is 0.</p> <p>For SIP-T42G IP phones:</p> <p>The default value of the line key 1-12 is 15, and the default value of the line key 13-15 is 0.</p> <p>For SIP-T41P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-15 is 0.</p> <p>For SIP-T27P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-21 is 0.</p> <p>For SIP-T40P/T23P/T23G/T21(P) E2 IP phones:</p> <p>The default value is 15.</p> <p>For ext keys:</p> <p>When Y=1, the default value is 37 (Switch).</p> <p>When Y= 2 to 20, 22 to 40, the default value is 0 (NA).</p> <p>Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>DSSKey->Line Key->Type</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Type</p>		
linekey.X.label/ expansion_module.X.key.Y.label	String within 99 characters	Blank
<p>Description:</p> <p>(Optional.) Configures the label displayed on the LCD screen for each DSS key.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p>		

Parameters	Permitted Values	Default
<p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>DSSKey->Line Key->Label</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Label</p>		

To configure an ACD key via web user interface:

1. Click on **DSSKey->Line Key**.
2. In the desired DSS key field, select **ACD** from the pull-down list of **Type**.
3. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.

The screenshot shows the Yealink T236 web interface. The 'DSSKey' tab is selected. Under 'Line Key', 'Line Key2' is highlighted with a red box. Its 'Type' is set to 'ACD' and its 'Label' is 'N/A'. The 'Confirm' button is visible at the bottom of the form.

4. Click **Confirm** to accept the change.

To configure the ACD auto available timer feature via web user interface:

1. Click on **Features->ACD**.
2. Select the desired value from the pull-down list of **ACD Auto Available**.
3. Enter the desired timer in the **ACD Auto Available Timer(0~120s)** field.

The screenshot shows the Yealink T236 web interface with the 'Features' tab selected. The 'ACD' section is active. The 'ACD Auto Available' dropdown is set to 'Enabled', and the 'ACD Auto Available Timer(0~120s)' field is set to '60'. The 'Confirm' button is highlighted.

4. Click **Confirm** to accept the change.

To configure the ACD subscribe period via web user interface:

1. Click on **Account->Advanced**.
2. Select the desired account from the pull-down list of **Account**.
3. Enter the desired timer in the **ACD Subscribe Period(120~3600s)** field.

The screenshot shows the Yealink T236 web interface. The 'Account' tab is selected, and the 'Advanced' sub-tab is active. The 'ACD Subscribe Period(120~3600s)' field is highlighted with a red box and contains the value '3600'. Other fields include 'Keep Alive Type' (Default), 'Keep Alive Interval(Seconds)' (30), 'RPort' (Disabled), 'Subscribe Period(Seconds)' (1800), 'DTMF Type' (RFC2833), 'Conference URI' (empty), 'Early Media' (Disabled), 'Out Dialog BLF' (Disabled), 'VQ RTPC-XR Collector name' (empty), 'VQ RTPC-XR Collector address' (empty), and 'VQ RTPC-XR Collector port' (5060). A 'NOTE' section on the right contains information about DTMF, Session Timer, Busy Lamp Field/BLF List, Shared Call Appearance (SCA)/ Bridge Line Appearance (BLA), and Network Conference.

4. Click **Confirm** to accept the change.

To configure an ACD key via phone user interface:

1. Press **Menu->Features->DSS Keys**.
2. Select the desired DSS key.
3. Press **◀** or **▶**, or the **Switch** soft key to select **ACD** from the **Type** field.
4. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.
5. Press the **Save** soft key to accept the change.

Shared Call Appearance (SCA)

SCA allows users to share an extension which can be registered on two or more IP phones at the same time. For more information on how to register accounts, refer to [Account Registration](#) on page 150.

Any IP phone can be used to originate or receive calls on the shared line. An incoming call can be presented to multiple phones simultaneously. The incoming call can be answered on any IP phone but not all. A call that is active on one IP phone will be presented visually to other IP phones that share the call appearance.

IP phones support SCA using a SUBSCRIBE/NOTIFY mechanism as specified in [RFC 3265](#). The events used are:

- “call-info” for call appearance state notification
- “line-seize” for the IP phone to ask to seize the line

SCA supports the IP phones barging in an active call. In addition, SCA has the call pull capability. Call pull feature allows users to retrieve an existing call from another shared phone that is in active or public hold status.

If the call is placed on public hold, the held call is available for any shared party to retrieve. If the call is placed on private hold, the held call is only available for the hold party to retrieve. You need to configure either the private hold soft key or a private hold key before you place the call on private hold.

Procedure

SCA can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure the registration line type. Parameters: account.X.shared_line
		Configure the call pull feature access code. Parameters: account.X.shared_line_callpull_code
	<y0000000000xx>.cfg	Configure the private hold soft key. Parameters: phone_setting.custom_softkey_enable custom_softkey_talking.url
		Assign a private hold key. Parameters: linekey.X.type/ expansion_module.X.key.Y.type linekey.X.label/ expansion_module.X.key.Y.label

Local	Web User Interface	<p>Configure the registration line type.</p> <p>Configure the call pull feature access code.</p> <p>Configure the number of DSS keys to be assigned automatically.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p><a href="http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0">http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0</p> <p>For SIP VP-T49G:</p> <p><a href="http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0">http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0</p>
		<p>Configure auto linekeys.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2:</p> <p><a href="http://<phoneIPAddress>/servlet?p=features-general&q=load">http://<phoneIPAddress>/servlet?p=features-general&q=load</p> <p>For SIP VP-T49G:</p> <p><a href="http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load</p>
		<p>Configure the private hold soft key.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p><a href="http://<phoneIPAddress>/servlet?p=settings-softkey&q=load">http://<phoneIPAddress>/servlet?p=settings-softkey&q=load</p> <p>For SIP VP-T49G:</p>

		<a href="http://<phoneIPAddress>/servlet?m=mod_data&p=settings-softkey&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=settings-softkey&q=load
		Assign a private hold key. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2: <a href="http://<phoneIPAddress>/servlet?p=dsskey&q=load&model=0">http://<phoneIPAddress>/servlet?p=dsskey&q=load&model=0 For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=dsskey&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=dsskey&q=load
	Phone User Interface	Assign a private hold key.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
account.X.shared_line	0, 1 or 3	0
Description: Configures the registration line type. 0 -Disabled 1 -Shared Call Appearance 3 -Draft BLA (not applicable to SIP VP-T49G IP phones) X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Web User Interface: Account->Advanced->Shared Line Phone User Interface: None		
account.X.shared_line_callpull_code	String within 32 characters	Blank

Parameters	Permitted Values	Default
<p>Description:</p> <p>Configures the call pull feature access code to retrieve an existing call from another shared phone that is in active or public hold status for account X.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Note: It works only if the value of the parameter "account.X.shared_line" is set to 1 (Share Call Appearance).</p> <p>Web User Interface:</p> <p>Account->Advanced->Call Pull Feature Access Code</p> <p>Phone User Interface:</p> <p>None</p>		
account.X.number_of_linekey	String within 32 characters	1
<p>Description:</p> <p>Configures the number of DSS keys to be assigned with Line type automatically from the first unused one (unused one means the DSS key is configured as N/A or Line). If a DSS key is used, the IP phone will skip to the next unused DSS key.</p> <p>The order of DSS key assigned automatically is Line Key->Ext Key.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>Example:</p> <p>account.1.number_of_linekey = 2</p> <p>Note: It works only if the value of the parameter "features.auto_linekeys.enable" is set to 1 (Enabled). It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>Account->Advanced->Number of line key</p> <p>Phone User Interface:</p> <p>None</p>		

Parameters	Permitted Values	Default
features.auto_linekeys.enable	0 or 1	0
Description: Enables or disables the DSS keys to be assigned with Line type automatically. 0 -Disabled 1 -Enabled Note: The number of the DSS keys is determined by the value of the parameter "account.X.number_of_linekey". It is not applicable to SIP-T19(P) E2 and CP860 IP phones. Web User Interface: Features->General Information->Auto Linekeys Phone User Interface: None		

Private Hold Soft Key

Configuring the private hold soft key may affect the softkey layout in the Talking state. For more information, refer to [Softkey Layout](#) on page 219.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
phone_setting.custom_softkey_enable	0 or 1	0
Description: Enables or disables custom soft keys layout feature. 0 -Disabled 1 -Enabled Web User Interface: Settings->Softkey Layout->Custom Softkey Phone User Interface: None		
custom_softkey_talking.url	URL within 511 characters	Blank

Parameters	Permitted Values	Default
<p>Description:</p> <p>Configures the access URL of the custom file for the soft key presented on the LCD screen when in the Talking state.</p> <p>Example:</p> <p>custom_softkey_talking.url = http://192.168.1.20/XMLfiles/Talking.xml</p> <p>During the auto provisioning process, the IP phone connects to the provisioning server "192.168.1.20", and downloads the Talking state file from the "XMLfiles" directory.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		

Private Hold Key

For more information on how to configure the DSS Key, refer to [Appendix D: Configuring DSS Key](#) on page 926.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
linekey.X.type/ expansion_module.X.key.Y.type	20	Refer to the following content
<p>Description:</p> <p>Configures a DSS key to be a private hold key on the IP phone.</p> <p>The digit 20 stands for the key type Private Hold.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G)</p> <p>X ranges from 1 to 27 (for SIPT46G/T29G)</p> <p>X ranges from 1 to 15 (for SIPT42G/T41P)</p> <p>X ranges from 1 to 21 (for SIPT27P)</p> <p>X ranges from 1 to 3 (for SIPT40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIPT21(P) E2)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p>		

Parameters	Permitted Values	Default
<p>Example:</p> <p>linekey.2.type = 20</p> <p>Default:</p> <p>For SIP VP-T49G/SIPT48G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-29 is 0.</p> <p>For SIPT46G/T29G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-27 is 0.</p> <p>For SIPT42G IP phones:</p> <p>The default value of the line key 1-12 is 15, and the default value of the line key 13-15 is 0.</p> <p>For SIPT41P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-15 is 0.</p> <p>For SIPT27P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-21 is 0.</p> <p>For SIPT40P/T23P/T23G/T21(P) E2 IP phones:</p> <p>The default value is 15.</p> <p>For ext keys:</p> <p>When Y=1, the default value is 37 (Switch).</p> <p>When Y= 2 to 20, 22 to 40, the default value is 0 (NA).</p> <p>Note: It is not applicable to SIP-T19(P) E2, CP860 IP phones.</p> <p>Web User Interface:</p> <p>DSSKey->Line Key->Type</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Type</p>		
linekey.X.label/ expansion_module.X.key.Y.label	String within 99 characters	Blank
<p>Description:</p> <p>(Optional.) Configures the label displayed on the LCD screen for each DSS key.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G)</p> <p>X ranges from 1 to 27 (for SIPT46G/T29G)</p>		

Parameters	Permitted Values	Default
<p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Note: It is not applicable to SIP-T19(P) E2, CP860 IP phones.</p> <p>Web User Interface:</p> <p>DSSKey->Line Key->Label</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Label</p>		

To configure auto linekeys feature via web user interface:

1. Click on **Features->General Information**.
2. Select **Enabled** from the pull-down list of **Auto Linekeys**.

If **Auto LineKeys** is enabled, you can automatically assign multiple DSS keys with Line type for a registered shared line on the phone.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected. Under 'General Information', the 'Auto Linekeys' dropdown menu is set to 'Enabled' and is highlighted with a red rectangular box. Other settings visible include 'Call Waiting' (Enabled), 'Auto Redial' (Disabled), and 'Voice Mail Tone' (Enabled). A 'NOTE' section on the right provides details about 'Call Waiting', 'Auto Redial', 'Key As Send', 'Hotline', and 'Call Completion' features.

3. Click **Confirm** to accept the change.

To configure the shared line settings on the primary phone via web user interface:

1. Register the primary account (e.g., 4609).

The screenshot shows the Yealink T23G web interface with the 'Account' tab selected. The 'Register' section is expanded, showing fields for 'Line Active' (Enabled), 'Label' (4609), 'Display Name' (4609), 'Register Name' (4609), 'User Name' (4609), and 'Password' (masked). Below these are 'SIP Server 1' and 'SIP Server 2' sections. 'SIP Server 1' has 'Server Host' (pbx.yealink.com), 'Port' (5060), 'Transport' (UDP), 'Server Expires' (3600), and 'Server Retry Counts' (3). 'SIP Server 2' has similar fields. At the bottom, 'Enable Outbound Proxy Server' is set to 'Enabled', 'Outbound Proxy Server 1' is '10.1.8.11', and 'Port' is '5060'. The 'NAT' dropdown is set to 'Disabled'. A 'NOTE' section on the right provides information about Account Registration, Server Redundancy, and NAT Traversal.

2. Click on **Advanced**, select **Shared Call Appearance** from the pull-down list of **Shared Line**.

3. Enter the desired number in the **Number of line key** field.

This field appears only if **Auto Linekeys** is enabled.

The default value is 1. In this example, the value is set to 2.

Yealink T236 Log Out

Status Account Network DSSKey Features Settings Directory Security

Register Basic Codec Advanced

Account Account 1

Keep Alive Type: Default

Keep Alive Interval(Seconds): 30

RPort: Disabled

Subscribe Period(Seconds): 1800

BLF List Retrieve Call Parked Code: []

Shared Line: Shared Call Appearance

Call Pull Feature Access Code: []

Dialog Info Call Pickup: Disabled

BLA Number: []

Out Dialog BLF: Disabled

VQ RTPC-XR Collector name: []

VQ RTPC-XR Collector address: []

VQ RTPC-XR Collector port: 5060

Number of line key: 2

Confirm Cancel

NOTE

DTMF
It is the signal sent from the IP phone to the network, which is generated when pressing the IP phone's keypad during a call.

Session Timer
It allows a periodic refresh of SIP sessions through a re-INVITE request, to determine whether a SIP session is still active.

Busy Lamp Field/BLF List
Monitors a specific extension/a list of extensions for status changes on IP phones.

Shared Call Appearance (SCA)/ Bridge Line Appearance (BLA)
It allows users to share a SIP line on several IP phones. Any IP phone can be used to originate or receive calls on the shared line.

Network Conference
It allows multiple participants

- Click **Confirm** to accept the change.

To configure the shared line settings on alternate phone via web user interface:

- Register the alternate account (e.g., 4609_1).
(Enter the primary account 4609 in the **Register Name** field.)

Yealink T236 Log Out

Status Account Network DSSKey Features Settings Directory Security

Register Basic Codec Advanced

Account Account 1

Register Status: Registered

Line Active: Enabled

Label: 4609_1

Display Name: 4609_1

Register Name: 4609

User Name: 4609_1

Password: []

SIP Server 1

Server Host: pbx.yealink.com Port: 5060

Transport: UDP

Server Expires: 3600

Server Retry Counts: 3

SIP Server 2

Server Host: [] Port: 5060

Transport: UDP

Server Expires: 3600

Server Retry Counts: 3

Enable Outbound Proxy Server: Enabled

Outbound Proxy Server 1: 10.1.8.11 Port: 5060

Outbound Proxy Server 2: [] Port: 5060

Proxy Fallback Interval: 3600

NAT: Disabled

Confirm Cancel

NOTE

Account Registration
Registers account(s) for the IP phone.

Server Redundancy
It is often required in VoIP deployments to ensure continuity of phone service, for events where the server needs to be taken offline for maintenance, the server fails, or the connection between the IP phone and the server fails.

NAT Traversal
A general term for techniques that establish and maintain IP connections traversing NAT gateways. STUN is one of the NAT traversal techniques.

You can configure NAT traversal for this account.

You can click here to get more guides.

- Click on **Advanced**, select **Shared Call Appearance** from the pull-down list of **Shared Line**.
- Enter the desired number in the **Number of line key** field.
This field appears only if **Auto Linekeys** is enabled.
The default value is 1. In this example, the value is set to 2.

The screenshot shows the Yealink T23G web interface. The 'Account' tab is selected, and the 'Advanced' sub-tab is active. The 'Shared Line' dropdown menu is set to 'Shared Call Appearance', and the 'Number of line key' field is set to 2. Both fields are highlighted with red boxes. The interface includes a sidebar with 'Register', 'Basic', 'Codec', and 'Advanced' tabs. The main area has tabs for 'Status', 'Account', 'Network', 'DSSKey', 'Features', 'Settings', 'Directory', and 'Security'. A 'NOTE' section on the right provides information about DTMF, Session Timer, Busy Lamp Field/BLF List, Shared Call Appearance (SCA)/ Bridge Line Appearance (BLA), and Network Conference.

- Click **Confirm** to accept the change.

To configure the call pull feature access code via web user interface:


- Click on **Account->Advanced**.
- Select the desired account from the pull-down list of **Account**.

- Enter the call pull feature access code (e.g., *11) in the **Call Pull Feature Access Code** field.

The screenshot shows the Yealink T236 web interface. The 'Account' tab is selected. The 'Account' section is expanded, showing various settings. The 'Call Pull Feature Access Code' field is highlighted with a red box and contains the value '*11'. Other settings include 'Keep Alive Type' (Default), 'Keep Alive Interval(Seconds)' (30), 'RPort' (Disabled), 'Subscribe Period(Seconds)' (1800), 'BLF List Barge In Code', 'BLF List Retrieve Call Parked Code', 'Shared Line' (Shared Call Appearance), 'Dialog Info Call Pickup' (Disabled), 'Unregister When Reboot' (Disabled), 'Out Dialog BLF' (Disabled), 'VQ RTPC-XR Collector name', 'VQ RTPC-XR Collector address', and 'VQ RTPC-XR Collector port' (5060). A 'NOTE' section on the right provides information about DTMF, Session Timer, Busy Lamp Field/BLF List, Shared Call Appearance (SCA)/ Bridge Line Appearance (BLA), and Network Conference.

- Click **Confirm** to accept the change.

To configure the private hold soft key via web user interface:

- Click on **Settings->Softkey Layout**.
- Select **Enabled** from the pull-down list of **Custom Softkey**.
- Select **On Talk** from the pull-down list of **Call States**.
- Select **Private Hold** from the **Unselected Softkeys** column and then click .

The **Private Hold** appears in the **Selected Softkeys (Ordered by position)** column.

The screenshot shows the Yealink T236 web interface. The 'Settings' tab is selected, and the 'Softkey Layout' sub-tab is active. The 'Custom Softkey' is set to 'Enabled' and 'Call States' is set to 'On Talk'. The 'Unselected Softkeys' column lists: Empty, Mute, Swap, New Call, Switch Account, Answer, Reject, Park, Group Park, and RTP Status. The 'Selected Softkeys (Ordered by position)' column lists: Transfer, Hold, Conference, End Call, and Private Hold. The 'Private Hold' softkey is highlighted with a red box. A 'NOTE' section on the right provides information about Softkey Layout.

- Click **Confirm** to accept the change.

To configure a private hold key via web user interface:

1. Click on **DSSKey->Line Key**.
2. In the desired DSS key field, select **Private Hold** from the pull-down list of **Type**.
3. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.

Key	Type	Value	Label	Line	Extension
Line Key1	Line	1011		Line 1	
Line Key2	Private Hold			N/A	
Line Key3	ACD			N/A	

4. Click **Confirm** to accept the change.

To configure a private hold key via phone user interface:

1. Press **Menu->Features->DSS Keys**.
2. Press **Left Arrow** or **Right Arrow**, or the **Switch** soft key to select **Key Event** from the **Type** field.
3. Press **Left Arrow** or **Right Arrow**, or the **Switch** soft key to select **Private Hold** from the **Key Type** field.
4. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.
5. Press the **Save** soft key to accept the change or the **Back** soft key to cancel.

Bridge Lines Appearance (BLA)

BLA allows users to share a SIP line on two or more IP phones. Users can monitor the specific extension (BLA number) for status changes on each IP phone. To use this feature, a BLA group should be pre-configured on the server and one of them is specified as a BLA number. BLA depends on support from a SIP server.

Any IP phone can be used to originate or receive calls on the bridge line. An incoming call to the BLA number can be presented to multiple phones in the group simultaneously. The incoming call can be answered on any IP phone of the group but not all.

IP phones support BLA using a SUBSCRIBE/NOTIFY mechanism as specified in [RFC 3265](#). The event used is:

- “dialog” for bridged line appearance subscribe and notify

If the call is placed on public hold, the held call is available for all phones in the group to retrieve.

Note

BLA is not applicable to SIP VP-T49G IP phones.

Procedure

BLA can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure the registration line type. Parameters: account.X.shared_line
		Configure the BLA number. Parameters: account.X.bla_number
		Configure the period of BLA subscription. Parameters: account.X.bla_subscribe_period
Local	Web User Interface	Configure the registration line type. Configure the BLA number. Configure the period of BLA subscription. Navigate to: <a href="http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0">http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0

Details of Configuration Parameters:

Parameters	Permitted Values	Default
account.X.shared_line	0, 1 or 3	0
Description: Configures the registration line type. 0 -Disabled 1 -Shared Call Appearance 3 -Draft BLA (not applicable to SIP VP-T49G IP phones) X ranges from 1 to 16 (for SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)		

Parameters	Permitted Values	Default
X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Web User Interface: Account->Advanced->Shared Line Phone User Interface: None		
account.X.bla_number	String within 99 characters	Blank
Description: Configures the BLA number for account X. X ranges from 1 to 16 (for SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Example: account.1.bla_number = 14084588327 Note: It works only if the value of the parameter "account.X.shared_line" is set to 3 (Draft BLA). It is not applicable to SIP VPT49G IP phones. Web User Interface: Account->Advanced->BLA Number Phone User Interface: None		
account.X.bla_subscribe_period	Integer from 60 to 7200	300
Description: Configures the period (in seconds) of the BLA subscription for account X. X ranges from 1 to 16 (for SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860)		

Parameters	Permitted Values	Default
<p>Note: It works only if the value of the parameter "account.X.shared_line" is set to 3 (Draft BLA). It is not applicable to SIP VP-T49G IP phones.</p> <p>Web User Interface: Account->Advanced->BLA Subscription Period</p> <p>Phone User Interface: None</p>		

To configure the BLA feature via web user interface:

1. Click on **Account->Advanced**.
2. Select the desired account from the pull-down list of **Account**.
3. Select **Draft BLA** from the pull-down list of **Shared Line**.
4. Enter the desired value in the **BLA Number** field.
5. Enter the desired value in the **BLA Subscription Period** field.

The screenshot shows the Yealink T236 web interface. The 'Account' tab is active, and the 'Advanced' sub-tab is selected. The 'Account' dropdown is set to 'Account 1'. The 'Shared Line' dropdown is set to 'Draft BLA'. The 'BLA Number' field is '14084588327' and the 'BLA Subscription Period' field is '300'. Both fields are highlighted with red boxes. The 'Confirm' button is at the bottom.

6. Click **Confirm** to accept the change.

Message Waiting Indicator

Message Waiting Indicator (MWI) informs users of the number of messages waiting in their mailbox without calling the mailbox. IP phones support both audio and visual MWI when receiving new voice messages. MWI will be indicated in four ways: a warning tone, an indicator message (including a voice mail icon) on the LCD screen, the power

indicator LED slow flashes red and the MESSAGE key LED lights up (MESSAGE key LED is only applicable to SIP VP-T49G/SIP-T29G/T27P/T23P/T23G/T21(P) E2 IP phones). For more information on power indicator LED, refer to [Power Indicator LED](#) on page 103.

IP phones support both solicited and unsolicited MWI.

Unsolicited MWI

Unsolicited MWI is a server related feature. The IP phone sends a SUBSCRIBE message to the server for message-summary updates. The server sends a message-summary NOTIFY within the subscription dialog each time the MWI status changes.

Solicited MWI

For solicited MWI, you must enable MWI subscription feature on IP phones. IP phones support subscribing the MWI messages to the account or the voice mail number.

Procedure

Configuration changes can be performed using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure subscribe for MWI. Parameters: account.X.subscribe_mwi account.X.subscribe_mwi_expires
		Configure subscribe MWI to voice mail. Parameters: account.X.subscribe_mwi_to_vm
		Configure the voice mail number for account X. Parameter: voice_mail.number.X
		Configure the presentation of audio and visual MWI. Parameter: account.X.display_mwi.enable
Local	Web User Interface	Configure subscribe for MWI. Configure subscribe MWI to voice mail. Configure the voice mail number for account X. Configure the presentation of audio and visual MWI.

		Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/ T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p =account-adv&q=load&acc=0 For SIP VP-T49G: http://<phoneIPAddress>/servlet?m =mod_data&p=account-adv&q=lo ad&acc=0
	Phone User Interface	Configure the voice mail number for account X.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
account.X.subscribe_mwi	0 or 1	0
Description: Enables or disables the IP phone to subscribe the message waiting indicator for account X. 0 -Disabled 1 -Enabled If it is set to 1 (Enabled), the IP phone will send a SUBSCRIBE message to the server for message-summary updates. If it is set to 0 (Disabled), the server automatically sends a message-summary NOTIFY in a new dialog each time the MWI status changes. (This requires server support) X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Web User Interface: Account->Advanced->Subscribe for MWI Phone User Interface: None		

Parameters	Permitted Values	Default
account.X.subscribe_mwi_expires	Integer from 0 to 84600	3600
<p>Description:</p> <p>Configures MWI subscribe expiry time (in seconds) for account X. The IP phone is able to successfully refresh the SUBSCRIBE for message-summary events before expiration of the subscription dialog.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Note: It works only if the value of the parameter "account.X.subscribe_mwi" is set to 1 (Enabled).</p> <p>Web User Interface:</p> <p>Account->Advanced->MWI Subscription Period (Seconds)</p> <p>Phone User Interface:</p> <p>None</p>		
account.X.subscribe_mwi_to_vm	0 or 1	0
<p>Description:</p> <p>Enables or disables the IP phone to subscribe the message waiting indicator to the voice mail number for account X.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Note: It works only if the value of the parameter "account.X.subscribe_mwi" is set to 1 (Enabled) and "voice_mail.number.X" is configured.</p> <p>Web User Interface:</p> <p>Account->Advanced->Subscribe MWI To Voice Mail</p>		

Parameters	Permitted Values	Default
Phone User Interface: None		
voice_mail.number.X	String within 99 characters	Blank
Description: Configures the voice mail number for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Example: voice_mail.number.1 = 1234 Web User Interface: Account->Advanced->Voice Mail Phone User Interface: Menu->Message->Voice Mail->Set Voice Mail->AccountX Code		
account.X.display_mwi.enable	0 or 1	1
Description: Enables or disables the IP phone to present audio and visual MWI when receiving new voice messages. 0-Disabled 1-Enabled X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Note: It always works at the time of Unsolicited MWI; at the time of solicited MWI, MWI subscription feature should be configured in advance. To present audio MWI, you also need to set the value of the parameter "features.voice_mail_tone_enable" to 1 (Enabled) in advance.		

Parameters	Permitted Values	Default
Web User Interface: Account->Advanced->Voice Mail Display Phone User Interface: None		

To configure subscribe for MWI via web user interface:

1. Click on **Account->Advanced**.
2. Select the desired account from the pull-down list of **Account**.
3. Select the desired value from the pull-down list of **Subscribe for MWI**.
4. Enter the period time in the **MWI Subscription Period(Seconds)** field.

The screenshot shows the Yealink T236 web interface. The 'Account' tab is selected, and the 'Advanced' sub-tab is active. The 'Account' dropdown is set to 'Account 1'. The 'Subscribe for MWI' dropdown is set to 'Enabled', and the 'MWI Subscription Period(Seconds)' is set to '3600'. A red box highlights these two fields. The interface includes a sidebar with 'Register', 'Basic', 'Codec', and 'Advanced' options, and a top navigation bar with 'Status', 'Account', 'Network', 'DSSKey', 'Features', 'Settings', 'Directory', and 'Security' tabs. A 'NOTE' section on the right provides information about DTMF, Session Timer, Busy Lamp Field/BLF List, and Shared Call Appearance (SCA)/ Bridge Line Appearance (BLA).

5. Click **Confirm** to accept the change.

To configure subscribe MWI to voice mail via web user interface:

1. Click on **Account->Advanced**.
2. Select the desired account from the pull-down list of **Account**.
3. Select **Enabled** from the pull-down list of **Subscribe for MWI**.
4. Select the desired value from the pull-down list of **Subscribe MWI To Voice Mail**.

- Enter the desired voice number in the **Voice Mail** field.

The screenshot shows the Yealink T236 web interface. The 'Account' tab is selected. The 'Voice Mail' field is highlighted with a red box, showing the value '1234'. Other fields include 'Subscribe for MWI' (Enabled), 'Subscribe MWI To Voice Mail' (Enabled), and 'Voice Mail Display' (Enabled). The 'NOTE' section on the right contains information about DTMF, Session Timer, Busy Lamp Field/BLF List, and Shared Call Appearance (SCA)/ Bridge Line Appearance (BLA).

- Click **Confirm** to accept the change.

To configure the presentation of audio and visual MWI via web user interface:

- Click on **Account->Advanced**.
- Select the desired account from the pull-down list of **Account**.
- Select the desired value from the pull-down list of **Voice Mail Display**.

The screenshot shows the Yealink T236 web interface. The 'Account' tab is selected. The 'Voice Mail Display' field is highlighted with a red box, showing the value 'Enabled'. Other fields include 'Subscribe for MWI' (Enabled), 'Subscribe MWI To Voice Mail' (Enabled), and 'Voice Mail' (1234). The 'NOTE' section on the right contains information about DTMF, Session Timer, Busy Lamp Field/BLF List, and Shared Call Appearance (SCA)/ Bridge Line Appearance (BLA).

- Click **Confirm** to accept the change.

Short Message Service (SMS)

SMS feature allows users to send and receive text messages using Yealink IP phones. It depends on support from a SIP server.

When receiving a new text message, the phone will play a warning tone. The power indicator LED will slow flash red, and the LCD screen will prompt receiving new text messages with the number of waiting messages. You can customize the warning tone or select specialized tone sets (vary from country to country) for your IP phone. For more information, refer to [Tones](#) on page 768.

Procedure

Configuration changes can be performed using the configuration files.

Configuration File	<y0000000000xx>.cfg	Configure SMS for the IP phone. Parameter: features.text_message.enable
---------------------------	---------------------	--

Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.text_message.enable	0 or 1	1
Description: Enables or disables the IP phone to send or receive text message(s). 0-Disabled 1-Enabled Web User Interface: None Phone User Interface: None		

Multicast Paging

Multicast paging allows IP phones to send/receive Real-time Transport Protocol (RTP) streams to/from the pre-configured multicast address(es) without involving SIP signaling. Up to 10 listening multicast addresses can be specified on the IP phone.

Sending RTP Stream

Users can send an RTP stream without involving SIP signaling by pressing a configured multicast paging key or a paging list key. A multicast address (IP: Port) should be assigned to the multicast paging key, which is defined to transmit RTP stream to a group of designated IP phones. When the IP phone sends the RTP stream to a pre-configured multicast address, each IP phone preconfigured to listen to the multicast address can receive the RTP stream. When the originator stops sending the RTP stream, the

subscribers stop receiving it.

Procedure

Configuration changes can be performed using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Specify a multicast codec for the IP phone to send the RTP stream. Parameter: multicast.codec
		Configure the multicast IP address and port number for a paging list key. Parameter: multicast.paging_address.X.ip_address
		Configure the multicast paging group name for a paging list key. Parameter: multicast.paging_address.X.label
		Assign a multicast paging key. Parameters: linekey.X.type/ programmablekey.X.type/ expansion_module.X.key.Y.type linekey.X.value/ programmablekey.X.value/ expansion_module.X.key.Y.value linekey.X.label/ programmablekey.X.label/ expansion_module.X.key.Y.label
		Assign a paging list key. Parameter: linekey.X.type/ programmable.X.type/ expansion_module.X.key.Y.type linekey.X.label/ programmable.X.label/ expansion_module.X.key.Y.label

Local	Web User Interface	<p>Specify a multicast codec for the IP phone to send the RTP stream.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p=features-general&q=load</p> <p>For SIP VP-T49G: http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load</p>
		<p>Configure the multicast IP address and port number for a paging list key.</p> <p>Configure the multicast paging group name for a paging list key.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p=contacts-multicastIP&q=load</p> <p>For SIP VP-T49G: http://<phoneIPAddress>/servlet?m=mod_data&p=contacts-multicastIP&q=load</p>
		<p>Assign a multicast paging key or a paging list key.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p=dsskey&q=load&model=0</p> <p>For SIP VP-T49G: http://<phoneIPAddress>/servlet?</p>

		m=mod_data&p=dsskey&q=load
	Phone User Interface	<p>Configure the multicast IP address and port number for a paging list key.</p> <p>Configure the multicast paging group name for a paging list key.</p> <p>Assign a multicast paging key or a paging list key.</p>

Details of the Configuration Parameter:

Parameters	Permitted Values	Default
multicast.codec	PCMU, PCMA, G729, G722	G722
<p>Description: Configures the codec of multicast paging.</p> <p>Example: multicast.codec = G722</p> <p>Note: It is not applicable to SIP-T19(P) E2 IP phones.</p> <p>Web User Interface: Features->General Information->Multicast Codec</p> <p>Phone User Interface: None</p>		
multicast.paging_address.X.ip_address (X ranges from 1 to 10)	String	Blank
<p>Description: Configures the IP address and port number of the multicast paging group in the paging list. It will be displayed on the LCD screen when placing the multicast paging call.</p> <p>Example: multicast.paging_address.1.ip_address = 224.5.6.20:10008 multicast.paging_address.2.ip_address = 224.1.6.25:1001</p> <p>Note: The valid multicast IP addresses range from 224.0.0.0 to 239.255.255.255.</p> <p>Web User Interface: Directory->Multicast IP->Paging List->Paging Address</p> <p>Phone User Interface:</p>		

Parameters	Permitted Values	Default
Menu->Features->Paging List->Option->Edit->Address		
multicast.paging_address.X.label (X ranges from 1 to 10)	String	Blank
<p>Description: Configures the name of the multicast paging group to be displayed in the paging list. It will be displayed on the LCD screen when placing the multicast paging calls.</p> <p>Example: multicast.paging_address.1.label = Product multicast.paging_address.2.label = Sales</p> <p>Web User Interface: Directory->Multicast IP->Paging List->Label</p> <p>Phone User Interface: Menu->Features->Paging List->Option->Edit->Label</p>		

Multicast Paging Key

For more information on how to configure the DSS Key, refer to [Appendix D: Configuring DSS Key](#) on page 926.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
linekey.X.type/ programablekey.X.type/ expansion_module.X.key.Y.type	24	Refer to the following content
<p>Description: Configures a DSS key as a multicast paging key on the IP phone. The digit 24 stands for the key type Multicast Paging. For line keys: X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G) X ranges from 1 to 27 (for SIP-T46G/T29G) X ranges from 1 to 15 (for SIP-T42G/T41P) X ranges from 1 to 21 (for SIP-T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p>		

Parameters	Permitted Values	Default
<p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For programmable keys:</p> <p>X=1-6, 9, 13 (for CP860)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Example:</p> <p>linekey.2.type = 24</p> <p>Default:</p> <p>For SIP VPT49G/SIP-T48G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-29 is 0.</p> <p>For SIP-T46G/T29G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-27 is 0.</p> <p>For SIP-T42G IP phones:</p> <p>The default value of the line key 1-12 is 15, and the default value of the line key 13-15 is 0.</p> <p>For SIP-T41P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-15 is 0.</p> <p>For SIP-T27P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-21 is 0.</p> <p>For SIP-T40P/T23P/T23G/T21(P) E2 IP phones:</p> <p>The default value is 15.</p> <p>For ext keys:</p> <p>When Y=1, the default value is 37 (Switch).</p> <p>When Y= 2 to 20, 22 to 40, the default value is 0 (NA).</p> <p>For programmable keys:</p> <p>For CP860 IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p>		

Parameters	Permitted Values	Default
<p>When X=6, the default value is 61 (Directory).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=13, the default value is 0 (NA).</p> <p>Note: It is not applicable to SIP-T19(P) E2 IP phones.</p> <p>Web User Interface:</p> <p>DSSKey->Line Key->Type</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Type</p>		
linekey.X.value/ programablekey.X.value/ expansion_module.X.key.Y.value	String within 99 characters	Blank
<p>Description:</p> <p>Configures the multicast IP address and port number.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For programable keys:</p> <p>X=1-6, 9, 13 (for CP860)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Example:</p> <p>linekey.1.value = 224.5.5.6:10008</p> <p>Note: The valid multicast IP addresses range from 224.0.0.0 to 239.255.255.255. It is not applicable to SIP-T19(P) E2 IP phones.</p> <p>Web User Interface:</p> <p>DSSKey->Line Key->Value</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Value</p>		
linekey.X.label/ programablekey.X.label/	String within 99	Blank

Parameters	Permitted Values	Default
expansion_module.X.key.Y.label	characters	
<p>Description: (Optional.) Configures the label displayed on the LCD screen for each DSS key. For line keys: X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G) X ranges from 1 to 27 (for SIP-T46G/T29G) X ranges from 1 to 15 (for SIP-T42G/T41P) X ranges from 1 to 21 (for SIP-T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) For programmable keys: X ranges from 1 to 4. For ext keys: X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured). Note: It is not applicable to SIP-T19(P) E2 IP phones. Web User Interface: DSSKey->Line Key->Label Phone User Interface: Menu->Features->DSS Keys->Line Key X->Label</p>		

Paging List key

For more information on how to configure the DSS Key, refer to [Appendix D: Configuring DSS Key](#) on page 926.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
linekey.X.type/ programablekey.X.type/ expansion_module.X.key.Y.type	66	Refer to the following content
<p>Description: Configures a DSS key as a paging list key on the IP phone. The digit 66 stands for the key type Paging List. For line keys:</p>		

Parameters	Permitted Values	Default
<p>X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For programable keys:</p> <p>X=1-4, 12-14 (for SIP VP-T49G)</p> <p>X=1-10, 12-14 (for SIP-T48G/T46G)</p> <p>X=1-10, 13 (for SIP-T42G/T41P/T40P)</p> <p>X=1-14 (for SIP-T29G/T27P)</p> <p>X=1-10, 14 (for SIP-T23P/T23G/T21(P) E2)</p> <p>X=1-9, 13, 14 (for SIP-T19(P) E2)</p> <p>X=1-6, 9, 13 (for CP860)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Example:</p> <p>linekey.1.type = 66</p> <p>Default:</p> <p>For SIP VP-T49G/SIP-T48G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-29 is 0.</p> <p>For SIP-T46G/T29G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-27 is 0.</p> <p>For SIP-T42G IP phones:</p> <p>The default value of the line key 1-12 is 15, and the default value of the line key 13-15 is 0.</p> <p>For SIP-T41P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-15 is 0.</p> <p>For SIP-T27P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-21 is 0.</p> <p>For SIP-T40P/T23P/T23G/T21(P) E2 IP phones:</p>		

Parameters	Permitted Values	Default
<p>The default value is 15.</p> <p>For programmable keys:</p> <p>For SIP VPT49G IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIP-T48G/T46G IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIP-T42G/T41P/T40P IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p>		

Parameters	Permitted Values	Default
<p>When X=13, the default value is 0 (NA).</p> <p>For SIP-T29G/T27P IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=11, the default value is 0 (NA).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIP-T23P/T23G/T21(P) E2 IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIP-T19(P) E2 IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p>		

Parameters	Permitted Values	Default
<p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For CP860 IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=13, the default value is 0 (NA).</p> <p>For ext keys:</p> <p>When Y=1, the default value is 37 (Switch).</p> <p>When Y= 2 to 20, 22 to 40, the default value is 0 (NA).</p> <p>Web User Interface:</p> <p>DSSKey->Line Key/Programable Key->Type</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Type</p>		
linekey.X.label/ programablekey.X.label/ expansion_module.X.key.Y.label	String within 99 characters	Blank
<p>Description:</p> <p>(Optional.) Configures the label displayed on the LCD screen for each DSS key.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For programable keys:</p> <p>X ranges from 1 to 4.</p>		

Parameters	Permitted Values	Default
<p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Web User Interface:</p> <p>DSSKey->Line Key/Programable Key->Label</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Label</p>		

To configure a codec for multicast paging via web user interface:

1. Click on **Features->General Information**.
2. Select the desired codec from the pull-down list of **Multicast Codec**.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected, and the 'General Information' sub-tab is active. In the 'General Information' section, the 'Multicast Codec' dropdown menu is highlighted with a red box and currently shows 'G722'. Other settings visible include 'Call Waiting' (Enabled), 'Call Waiting On Code' (empty), 'Call Waiting Off Code' (empty), 'Auto Redial' (Disabled), 'Auto Redial Interval (1~300s)' (10), 'Auto Redial Times (1~300)' (10), 'DTMF Repetition' (3), 'Play Hold Tone' (Enabled), 'Play Hold Tone Delay' (30), 'Allow Mute' (Enabled), and 'Auto Linekeys' (Disabled). A 'NOTE' section on the right provides additional information about various features like Call Waiting, Auto Redial, Key As Send, Hotline, and Call Completion.

3. Click **Confirm** to accept the change.

To configure two sending multicast addresses via web user interface:

1. Click on **Directory->Multicast IP**.
2. Enter the sending multicast address and port number in the **Paging Address** field.
3. Enter the label in the **Label** field.

The label will appear on the LCD screen when sending the RTP multicast.

Multicast Listening

Paging Barge: 10

Paging Priority Active: Enabled

IP Address	Listening Address	Label	Priority
1 IP Address			1
2 IP Address			2
3 IP Address			3
4 IP Address			4
5 IP Address			5
6 IP Address			6
7 IP Address			7
8 IP Address			8
9 IP Address			9
10 IP Address			10

Paging List

Index	PAGING Address	Label
1	224.5.6.20:10008	Product
2	224.1.6.25:1001	Sales
3		
4		
5		
6		
7		
8		
9		
10		

Confirm Cancel

NOTE
Multicast Paging
 Multicast paging allows IP phones to send/receive Real-time Transport Protocol (RTP) streams to/from the pre-configured multicast address(es) without involving SIP signaling. Up to 10 listening multicast addresses can be specified on the IP phone.
 You can click here to get more guides.

- Click **Confirm** to accept the change.

To configure a multicast paging key via web user interface:

- Click on **DSSKey->Line Key**.
- In the desired DSS key field, select **Multicast Paging** from the pull-down list of **Type**.
- Enter the multicast IP address and port number in the **Value** field.

The valid multicast IP addresses range from 224.0.0.0 to 239.255.255.255.

- (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.

DSSKey

Key	Type	Value	Label	Line	Extension
Line Key1	Line		1011	Line 1	
Line Key2	Multicast Paging	224.5.6.20:10008	Paging	N/A	
Line Key3	Line			Line 3	

Confirm Cancel

NOTE
Line Keys
 Line keys allow you to quickly access features such as recall and voice mail.
 You can click here to get more guides.

- Click **Confirm** to accept the change.

To configure a paging list key via web user interface:

1. Click on **DSSKey->Line Key** (or **Programable Key**).
2. In the desired DSS key field, select **Paging List** from the pull-down list of **Type**.
3. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.

Key	Type	Value	Label	Line	Extension
Line Key1	Line		1011	Line 1	
Line Key2	Paging List		14/A		
Line Key3	Line			Line 3	

Confirm Cancel

NOTE
Line Keys
 Line keys allow you to quickly access features such as recall and voice mail.
 You can click here to get more guides.

4. Click **Confirm** to accept the change.

To configure a multicast paging key via phone user interface:

1. Press **Menu->Features->DSS Keys**.
2. Select the desired DSS key.
3. Press **◀** or **▶**, or the **Switch** soft key to select **Key Event** from the **Type** field.
4. Press **◀** or **▶**, or the **Switch** soft key to select **Multicast Paging** from the **Key Type** field.
5. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.
6. Enter the multicast IP address and port number in the **Value** field.
7. Press the **Save** soft key to accept the change.

To configure a paging list key via phone user interface:

1. Press **Menu->Features->DSS Keys**.
2. Select the desired DSS key.
3. Press **◀** or **▶**, or the **Switch** soft key to select **Key Event** from the **Type** field.
4. Press **◀** or **▶**, or the **Switch** soft key to select **Paging List** from the **Key Type** field.
5. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.
6. Press the **Save** soft key to accept the change.

Receiving RTP Stream

IP phones can receive an RTP stream from the pre-configured multicast address(es) without involving SIP signaling, and can handle the incoming multicast paging calls differently depending on the configurations of Paging Barge and Paging Priority Active.

Paging Barge

This parameter defines the priority of the voice call in progress, and decides how the IP phone handles the incoming multicast paging calls when there is already a voice call in progress. If the value of the parameter is configured as disabled, all incoming multicast paging calls will be automatically ignored. If the value of the parameter is the priority value, the incoming multicast paging calls with higher or equal priority are automatically answered and the ones with lower priority are ignored.

Paging Priority Active

This parameter decides how the IP phone handles the incoming multicast paging calls when there is already a multicast paging call in progress. If the value of the parameter is configured as disabled, the IP phone will automatically ignore all incoming multicast paging calls. If the value of the parameter is configured as enabled, an incoming multicast paging call with higher priority or equal is automatically answered, and the one with lower priority is ignored.

Procedure

Configuration changes can be performed using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the listening multicast address. Parameters: multicast.listen_address.X.ip_address multicast.listen_address.X.label
		Configure Paging Barge and Paging Priority Active features. Parameters: multicast.receive_priority.enable multicast.receive_priority.priority
Local	Web User Interface	Configure the listening multicast address. Configure Paging Barge and Paging Priority Active features. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p=contacts-multicastIP&q=load For SIP VP-T49G:

		http://<phoneIPAddress>/servlet?m=mod_data&p=contacts-multicastIP&q=load
--	--	--

Details of Configuration Parameters:

Parameters	Permitted Values	Default
multicast.listen_address.X.ip_address (X ranges from 1 to 10)	IP address: port	Blank
Description: Configures the multicast address and port number that the IP phone listens to. Example: multicast.listen_address.1.ip_address = 224.5.6.20:10008 Note: The valid multicast IP addresses range from 224.0.0.0 to 239.255.255.255. Web User Interface: Directory->Multicast IP->Multicast Listening->Listening Address Phone User Interface: None		
multicast.listen_address.X.label (X ranges from 1 to 10)	String within 99 characters	Blank
Description: (Optional.) Configures the label to be displayed on the LCD screen when receiving the multicast paging calls. Example: multicast.listen_address.1.label = Paging1 Web User Interface: Directory->Multicast IP->Multicast Listening->Label Phone User Interface: None		
multicast.receive_priority.enable	0 or 1	1
Description: Enables or disables the IP phone to handle the incoming multicast paging calls when there is an active multicast paging call on the IP phone. 0-Disabled 1-Enabled If it is set to 0 (Disabled), the IP phone will ignore the incoming multicast paging		

Parameters	Permitted Values	Default
<p>calls when there is an active multicast paging call on the IP phone.</p> <p>If it is set to 1 (Enabled), the IP phone will receive the incoming multicast paging call with a higher or equal priority and ignore that with a lower priority.</p> <p>Web User Interface:</p> <p>Directory->Multicast IP->Paging Priority Active</p> <p>Phone User Interface:</p> <p>None</p>		
multicast.receive_priority.priority	Integer from 0 to 10	10
<p>Description:</p> <p>Configures the priority of the voice call (a normal phone call rather than a multicast paging call) in progress.</p> <p>1 is the highest priority, 10 is the lowest priority.</p> <p>0-Disabled</p> <p>1-1</p> <p>2-2</p> <p>3-3</p> <p>4-4</p> <p>5-5</p> <p>6-6</p> <p>7-7</p> <p>8-8</p> <p>9-9</p> <p>10-10</p> <p>If it is set to 0 (Disabled), all incoming multicast paging calls will be automatically ignored when a voice call is in progress.</p> <p>If it is not set to 0 (Disabled), the IP phone will receive the incoming multicast paging call with a higher or same priority than this value and ignore that with a lower priority than this value when a voice call is in progress.</p> <p>Web User Interface:</p> <p>Directory->Multicast IP->Paging Barge</p> <p>Phone User Interface:</p> <p>None</p>		

To configure a listening multicast address via web user interface:

1. Click on **Directory->Multicast IP**.

- Enter the listening multicast address and port number in the **Listening Address** field.
1 is the highest priority and 10 is the lowest priority.
- Enter the label in the **Label** field.
The label will appear on the LCD screen when receiving the RTP multicast.

Multicast Listening

Paging Barge: 10

Paging Priority Active: Enabled

	IP Address	Listening Address	Label	Priority
1	IP Address	224.5.6.20:10008	Product	1
2	IP Address			2
3	IP Address			3
4	IP Address			4
5	IP Address			5
6	IP Address			6
7	IP Address			7
8	IP Address			8
9	IP Address			9
10	IP Address			10

NOTE

Multicast Paging
Multicast paging allows IP phones to send/receive Real-time Transport Protocol (RTP) streams to/from the pre-configured multicast address(es) without involving SIP signaling. Up to 10 listening multicast addresses can be specified on the IP phone.

[You can click here to get more guides.](#)

- Click **Confirm** to accept the change.

To configure paging barge and paging priority active features via web user interface:

- Click on **Directory->Multicast IP**.
- Select the desired value from the pull-down list of **Paging Barge**.
- Select the desired value from the pull-down list of **Paging Priority Active**.

Multicast Listening

Paging Barge: 10

Paging Priority Active: Enabled

	IP Address	Listening Address	Label	Priority
1	IP Address	224.5.6.20:10008	Product	1
2	IP Address			2
3	IP Address			3
4	IP Address			4
5	IP Address			5
6	IP Address			6
7	IP Address			7
8	IP Address			8
9	IP Address			9
10	IP Address			10

NOTE

Multicast Paging
Multicast paging allows IP phones to send/receive Real-time Transport Protocol (RTP) streams to/from the pre-configured multicast address(es) without involving SIP signaling. Up to 10 listening multicast addresses can be specified on the IP phone.

[You can click here to get more guides.](#)

- Click **Confirm** to accept the change.

Call Recording

Call recording enables users to record calls. It depends on support from a SIP server. When the user presses the call record key, the IP phone sends a record request to the server. IP phones themselves do not have memory to store the recording, what they can do is to trigger the recording and indicate the recording status.

Normally, there are 2 main methods to trigger a recording on a certain server. We call them record and URL record. Record is for the IP phone to send the server a SIP INFO message containing a specific header. URL record is for the IP phone to send the server an HTTP GET message containing a specific URL. The server processes these messages and decides to start or stop a recording.

Note

If it is a video call, you can only record the audio but not video by tapping record/ URL record key. For more information on recording video calls, refer to [Screenshot and Recording](#) on page 494.

It is not applicable to SIP-T19(P) E2 and CP860 IP phones.

Record

When a user presses a record key for the first time during a call, the IP phone sends a SIP INFO message to the server with the specific header "Record: on", and then the recording starts.

Example of a SIP INFO message:

```
Via: SIP/2.0/UDP 10.3.20.14:5060;branch=z9hG4bK1870385345
From: "1009" <sip:1009@10.2.1.48:5060>;tag=1385842459
To: <sip:1006@10.2.1.48:5060>;tag=2383911905
Call-ID: 0_1289812066@10.3.20.14
CSeq: 2 INFO
Contact: <sip:1009@10.3.20.14:5060>
Max-Forwards: 70
User-Agent: Yealink SIP-T23G 44.80.0.60
Record: on
Content-Length: 0
```

When the user presses the record key for the second time, the IP phone sends a SIP INFO message to the server with the specific header "Record: off", and then the recording stops.

Example of a SIP INFO message:

```
Via: SIP/2.0/UDP 10.3.20.14:5060;branch=z9hG4bK175716007
From: "1009" <sip:1009@10.2.1.48:5060>;tag=1385842459
To: <sip:1006@10.2.1.48:5060>;tag=2383911905
Call-ID: 0_1289812066@10.3.20.14
CSeq: 3 INFO
Contact: <sip:1009@10.3.20.14:5060>
Max-Forwards: 70
User-Agent: Yealink SIP-T23G 44.80.0.60
Record: off
Content-Length: 0
```

URL Record

When a user presses a URL record key for the first time during a call, the IP phone sends an HTTP GET message to the server.

Example of an HTTP GET message:

```
GET /URLRecord/record.xml HTTP/1.1\r\n
Request Method: GET
Request URI: /URLRecord/record.xml
Request version: HTTP/1.1
Host: 10.3.5.97:8080\r\n
User-agent: Yealink SIP-T23G 44.80.0.60 00:15:65:74:B1:50\r\n
```

If the recording is successfully started, the server will respond with a 200 OK message.

Example of a 200 OK message:

```
<YealinkIPPhoneText>
<Title>
  </Title>
<Text>
  The recording session is successfully started.
  </Text>
</YealinkIPPhoneText>
```

If the recording fails for some reasons, for example, the recording box is full, the server will respond with a 200 OK message.

Example of a 200 OK message:

```
<YealinkIPPhoneText>
<Title>
  </Title>
<Text>
  Probably the recording box is full.
  </Text>
</YealinkIPPhoneText>
```

```
</Text>
<YealinkIPPhoneText>
```

When the user presses the URL record key for the second time, the IP phone sends an HTTP GET message to the server, and then the server will respond with a 200 OK message.

Example of a 200 OK message:

```
<YealinkIPPhoneText>
<Title>
  </Title>
<Text>
  The recording session is successfully stopped.
  </Text>
<YealinkIPPhoneText>
```

Procedure

Call recording key can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Assign a record key. Parameters: linekey.X.type/ expansion_module.X.key.Y.type
		Assign a URL record key. Parameters: linekey.X.type/ expansion_module.X.key.Y.type linekey.X.value/ expansion_module.X.key.Y.value linekey.X.label/ expansion_module.X.key.Y.label
Local	Web User Interface	Assign a record key and URL record key. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2: http://<phoneIPAddress>/servlet ?p=dsskey&q=load&model=0 For SIP VP-T49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=dsskey&q=lo

		ad
	Phone User Interface	Assign a record key and URL record key.

Record Key

For more information on how to configure the DSS Key, refer to [Appendix D: Configuring DSS Key](#) on page 926.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
linekey.X.type/ expansion_module.X.key.Y.type	25	Refer to the following content
<p>Description:</p> <p>Configures a DSS key as a record key on the IP phone.</p> <p>The digit 25 stands for the key type Record.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G)</p> <p>X ranges from 1 to 27 (for SIPT46G/T29G)</p> <p>X ranges from 1 to 15 (for SIPT42G/T41P)</p> <p>X ranges from 1 to 21 (for SIPT27P)</p> <p>X ranges from 1 to 3 (for SIPT40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIPT21(P) E2)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Example:</p> <p>linekey.2.type = 25</p> <p>Default:</p> <p>For SIP VP-T49G/SIPT48G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-29 is 0.</p> <p>For SIPT46G/T29G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-27 is 0.</p> <p>For SIPT42G IP phones:</p> <p>The default value of the line key 1-12 is 15, and the default value of the line key</p>		

Parameters	Permitted Values	Default
<p>13-15 is 0.</p> <p>For SIP-T41P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-15 is 0.</p> <p>For SIP-T27P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-21 is 0.</p> <p>For SIP-T40P/T23P/T23G/T21(P) E2 IP phones:</p> <p>The default value is 15.</p> <p>For ext keys:</p> <p>When Y=1, the default value is 37 (Switch).</p> <p>When Y= 2 to 20, 22 to 40, the default value is 0 (NA).</p> <p>Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>DSSKey->Line Key->Type</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Type</p>		
linekey.X.label/ expansion_module.X.key.Y.label	String within 99 characters	Blank
<p>Description:</p> <p>(Optional.) Configures the label displayed on the LCD screen for each DSS key.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>DSSKey->Line Key->Label</p>		

Parameters	Permitted Values	Default
Phone User Interface: Menu->Features->DSS Keys->Line Key X->Label		

URL Record Key

Parameters	Permitted Values	Default
linekey.X.type/ expansion_module.X.key.Y.type	35	Refer to the following content
<p>Description:</p> <p>Configures a DSS key as a URL record key on the IP phone.</p> <p>The digit 35 stands for the key type URL Record.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Example:</p> <p>linekey.2.type = 35</p> <p>Default:</p> <p>For SIP VP-T49G/SIP-T48G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-29 is 0.</p> <p>For SIP-T46G/T29G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-27 is 0.</p> <p>For SIP-T42G IP phones:</p> <p>The default value of the line key 1-12 is 15, and the default value of the line key 13-15 is 0.</p> <p>For SIP-T41P IP phones:</p>		

Parameters	Permitted Values	Default
<p>The default value of the line key 1-6 is 15, and the default value of the line key 7-15 is 0.</p> <p>For SIP-T27P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-21 is 0.</p> <p>For SIP-T40P/T23P/T23G/T21(P) E2 IP phones:</p> <p>The default value is 15.</p> <p>For ext keys:</p> <p>When Y=1, the default value is 37 (Switch).</p> <p>When Y= 2 to 20, 22 to 40, the default value is 0 (NA).</p> <p>Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>DSSKey->Line Key->Type</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Type</p>		
linekey.X.value/ expansion_module.X.key.Y.value	String within 99 characters	Blank
<p>Description:</p> <p>Configures the URL to record a call.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VPT49G/SIP-T48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Example:</p> <p>linekey.1.value = http://10.3.5.97:8080/URLRecord/record.xml</p> <p>Note: It is not applicable to SIP-T19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>DSSKey->Line Key->Value</p> <p>Phone User Interface:</p>		

Parameters	Permitted Values	Default
Menu->Features->DSS Keys->Line Key X->Value		
linekey.X.label/ expansion_module.X.key.Y.label	String within 99 characters	Blank
<p>Description:</p> <p>(Optional.) Configures the label displayed on the LCD screen for each DSS key.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIPT21(P) E2)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Note: It is not applicable to SIPT19(P) E2 and CP860 IP phones.</p> <p>Web User Interface:</p> <p>DSSKey->Line Key->Label</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Label</p>		

To configure a record key via web user interface:

1. Click on **DSSKey->Line Key**.
2. In the desired DSS key field, select **Record** from the pull-down list of **Type**.
3. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.

The screenshot shows the Yealink T236 web interface. The 'DSSKey' tab is selected. Under 'Line Key', there is a table with the following data:

Key	Type	Value	Label	Line	Extension
Line Key1	Line		1011	Line 1	
Line Key2	Record			N/A	
Line Key3	Line			Line 3	

Below the table are 'Confirm' and 'Cancel' buttons. A 'NOTE' box on the right says: 'Line Keys allow you to quickly access features such as recall and voice mail. You can click here to get more guides.'

4. Click **Confirm** to accept the change.

To configure a URL record key via web user interface:

1. Click on **DSSKey->Line Key**.

2. In the desired DSS key field, select **URL Record** from the pull-down list of **Type**.
3. Enter the URL in the **Value** field.
4. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.

The screenshot shows the Yealink T236 web interface. The 'DSSKey' tab is active. A table lists three line keys. The second row, 'Line Key2', is highlighted with a red border. It shows 'URL Record' in the 'Type' column, 'http://10.3.5.97:8080/UR' in the 'Value' column, and 'N/A' in the 'Label' column. Below the table are 'Confirm' and 'Cancel' buttons. On the right, a 'NOTE' box states: 'Line Keys allow you to quickly access features such as recall and voice mail. You can click here to get more guides.'

5. Click **Confirm** to accept the change.

To configure a record key via phone user interface:

1. Press **Menu->Features->DSS Keys**.
2. Select the desired DSS key.
3. Press **◀** or **▶**, or the **Switch** soft key to select **Key Event** from the **Type** field.
4. Press **◀** or **▶**, or the **Switch** soft key to select **Record** from the **Key Type** field.
5. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.
6. Press the **Save** soft key to accept the change.

To configure a URL record key via phone user interface:

1. Press **Menu->Features->DSS Keys**.
2. Select the desired DSS key.
3. Press **◀** or **▶**, or the **Switch** soft key to select **URL Record** from the **Type** field.
4. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.
5. Enter the URL in the **Value** field.
6. Press the **Save** soft key to accept the change.

Hot Desking

Hot desking originates from the definition of being the temporary physical occupant of a work station or surface by a particular employee. A primary motivation for hot desking is cost reduction. Hot desking is regularly used in places where not all employees are in the office at the same time, or not in the office for a long time, which means actual personal offices would often be vacant, consuming valuable space and resources.

Hot desking allows a user to clear registration configurations of all accounts on the IP phone, and then register his account on line 1. To use this feature, you need to assign a hot desking key.

Note

Hot desking is not applicable to CP860 IP phones.

Procedure

Hot Desking feature can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	<p>Configure the hot desking login wizard.</p> <p>Parameters:</p> <p>hotdesking.dsskey_register_name_enable</p> <p>hotdesking.dsskey_username_enable</p> <p>hotdesking.dsskey_password_enable</p> <p>hotdesking.dsskey_sip_server_enable</p> <p>hotdesking.dsskey_outbound_enable</p>
		<p>Assign a hot desking key.</p> <p>Parameters:</p> <p>linekey.X.type/ programablekey.X.type/ expansion_module.X.key.Y.type</p> <p>linekey.X.label/ programablekey.X.label/ expansion_module.X.key.Y.label</p>
Local	Web User Interface	<p>Assign a hot desking key.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2:</p> <p>http://<phoneIPAddress>/servlet?p=dsskey&q=load&model=0</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet</p>

		?m=mod_data&p=dsskey&q=load
	Phone User Interface	Assign a hot desking key.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
hotdesking.dsskey_register_name_enable	0 or 1	0
Description: Enables or disables the IP phone to provide input field of register name on the hot desking login wizard when pressing the Hot Desking key. 0 -Disabled 1 -Enabled Note: It is not applicable to CP860 IP phones. Web User Interface: None Phone User Interface: None		
hotdesking.dsskey_username_enable	0 or 1	1
Description: Enables or disables the IP phone to provide input field of user name on the hot desking login wizard when pressing the Hot Desking key. 0 -Disabled 1 -Enabled Note: It is not applicable to CP860 IP phones. Web User Interface: None Phone User Interface: None		
hotdesking.dsskey_password_enable	0 or 1	1
Description: Enables or disables the IP phone to provide input field of password on the hot desking login wizard when pressing the Hot Desking key. 0 -Disabled		

Parameters	Permitted Values	Default
1-Enabled Note: It is not applicable to CP860 IP phones. Web User Interface: None Phone User Interface: None		
hotdesking.dsskey_sip_server_enable	0 or 1	0
Description: Enables or disables the IP phone to provide input field of SIP server on the hot desking login wizard when pressing the Hot Desking key. 0-Disabled 1-Enabled Note: It is not applicable to CP860 IP phones. Web User Interface: None Phone User Interface: None		
hotdesking.dsskey_outbound_enable	0 or 1	0
Description: Enables or disables the IP phone to provide input field of outbound server on the hot desking login wizard when pressing the Hot Desking key. 0-Disabled 1-Enabled Note: It is not applicable to CP860 IP phones. Web User Interface: None Phone User Interface: None		

Hot Desking Key

For more information on how to configure the DSS Key, refer to [Appendix D: Configuring DSS Key](#) on page 926.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
linekey.X.type/ programablekey.X.type/ expansion_module.X.key.Y.type	34	Refer to the following content
<p>Description:</p> <p>Configures a DSS key as a hot desking key on the IP phone.</p> <p>The digit 34 stands for the key type Hot Desking.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G)</p> <p>X ranges from 1 to 27 (for SIPT46G/T29G)</p> <p>X ranges from 1 to 15 (for SIPT42G/T41P)</p> <p>X ranges from 1 to 21 (for SIPT27P)</p> <p>X ranges from 1 to 3 (for SIPT40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIPT21(P) E2)</p> <p>For programable keys:</p> <p>X=1-4, 12-14 (for SIP VP-T49G)</p> <p>X=1-10, 12-14 (for SIPT48G/T46G)</p> <p>X=1-14 (for SIPT29G)</p> <p>X=1-9, 13, 14 (for SIPT19(P) E2)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Example:</p> <p>linekey.1.type = 34</p> <p>Default:</p> <p>For SIP VP-T49G/SIPT48G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-29 is 0.</p> <p>For SIPT46G/T29G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-27 is 0.</p> <p>For SIPT42G IP phones:</p> <p>The default value of the line key 1-12 is 15, and the default value of the line key 13-15 is 0.</p> <p>For SIPT41P IP phones:</p>		

Parameters	Permitted Values	Default
<p>The default value of the line key 1-6 is 15, and the default value of the line key 7-15 is 0.</p> <p>For SIP-T27P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-21 is 0.</p> <p>For SIP-T40P/T23P/T23G/T21(P) E2 IP phones:</p> <p>The default value is 15.</p> <p>For programable keys:</p> <p>For SIP VP-T49G IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIP-T48G/T46G IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIP-T29G IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p>		

Parameters	Permitted Values	Default
<p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=11, the default value is 0 (NA).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIP-T19(P) E2 IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For ext keys:</p> <p>When Y=1, the default value is 37 (Switch).</p> <p>When Y= 2 to 20, 22 to 40, the default value is 0 (NA).</p> <p>Note: It is not applicable to CP860 IP phones.</p> <p>Web User Interface:</p> <p>DSSKey->Line Key->Type</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Type</p>		
linekey.X.label/ programablekey.X.label/ expansion_module.X.key.Y.label	String within 99 characters	Blank
Description:		

Parameters	Permitted Values	Default
<p>(Optional.) Configures the label displayed on the LCD screen for each DSS key.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For programmable keys:</p> <p>X ranges from 1 to 4.</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>Note: It is not applicable to CP860 IP phones.</p> <p>Web User Interface:</p> <p>DSSKey->Line Key->Label</p> <p>Phone User Interface:</p> <p>Menu->Features->DSS Keys->Line Key X->Label</p>		



To configure a hot desking key via web user interface:

1. Click on **DSSKey->Line Key**.
2. In the desired DSS key field, select **Hot Desking** from the pull-down list of **Type**.
3. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.

4. Click **Confirm** to accept the change.

To configure a hot desking key via phone user interface:

1. Press **Menu->Features->DSS Keys**.
2. Select the desired DSS key.
3. Press **◀** or **▶**, or the **Switch** soft key to select **Key Event** from the **Type** field.

4. Press  or  , or the **Switch** soft key to select **Hot Desking** from the **Key Type** field.
5. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.
6. Press the **Save** soft key to accept the change.

Logon Wizard

Logon wizard allows IP phones to provide the logon wizard during the first startup.

Note

Logon wizard feature works only if there is no registered account on the IP phone. It is not applicable to CP860 IP phones.

Procedure

Logon wizard can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the logon wizard. Parameters: phone_setting.logon_wizard hotdesking.startup_register_name_enable hotdesking.startup_username_enable hotdesking.startup_password_enable hotdesking.startup_sip_server_enable hotdesking.startup_outbound_enable
Local	Web User Interface	Configure the logon wizard. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2: <a href="http://<phoneIPAddress>/servlet?p=features-general&q=load">http://<phoneIPAddress>/servlet?p=features-general&q=load For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
phone_setting.logon_wizard	0 or 1	0
Description: Enables or disables the IP phone to provide the logon wizard during the first startup. 0 -Disabled 1 -Enabled Note: It is not applicable to CP860 IP phones. It works only if there is no registered account on the IP phone. Web User Interface: Features->General Information->Logon Wizard Phone User Interface: None		
hotdesking.startup_register_name_enable	0 or 1	0
Description: Enables or disables the IP phone to provide input field of register name on the logon wizard during the first startup. 0 -Disabled 1 -Enabled Note: It is not applicable to CP860 IP phones. It works only if there is no registered account on the IP phone and the value of the parameter "phone_setting.logon_wizard" is set to 1 (Enabled). Web User Interface: None Phone User Interface: None		
hotdesking.startup_username_enable	0 or 1	1
Description: Enables or disables the IP phone to provide input field of user name on the logon wizard during the first startup. 0 -Disabled 1 -Enabled Note: It is not applicable to CP860 IP phones. It works only if there is no registered		

Parameter	Permitted Values	Default
account on the IP phone and the value of the parameter "phone_setting.logon_wizard" is set to 1 (Enabled). Web User Interface: None Phone User Interface: None		
hotdesking.startup_password_enable	0 or 1	1
Description: Enables or disables the IP phone to provide input field of password on the logon wizard during the first startup. 0 -Disabled 1 -Enabled Note: It is not applicable to CP860 IP phones. It works only if there is no registered account on the IP phone and the value of the parameter "phone_setting.logon_wizard" is set to 1 (Enabled). Web User Interface: None Phone User Interface: None		
hotdesking.startup_sip_server_enable	0 or 1	0
Description: Enables or disables the IP phone to provide input field of SIP server on the logon wizard during the first startup. 0 -Disabled 1 -Enabled Note: It is not applicable to CP860 IP phones. It works only if there is no registered account on the IP phone and the value of the parameter "phone_setting.logon_wizard" is set to 1 (Enabled). Web User Interface: None Phone User Interface: None		
hotdesking.startup_outbound_enable	0 or 1	0

Parameter	Permitted Values	Default
<p>Description:</p> <p>Enables or disables the IP phone to provide input field of outbound server on the logon wizard during the first startup.</p> <p>0-Disabled 1-Enabled</p> <p>Note: It is not applicable to CP860 IP phones. It works only if there is no registered account on the IP phone and the value of the parameter “phone_setting.logon_wizard” is set to 1 (Enabled).</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		

To configure logon wizard feature via web user interface:

1. Click on **Features->General Information**.
2. Select the desired value from the pull-down list of **Logon Wizard**.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected, and the 'General Information' section is expanded. The 'Logon Wizard' option is highlighted with a red box and is currently set to 'Disabled'. Other options in the 'General Information' section include Call Waiting, Auto Redial, Key As Send, Hotline Number, and Call Completion.

Parameter	Value
Call Waiting	Enabled
Call Waiting On Code	
Call Waiting Off Code	
Auto Redial	Disabled
Auto Redial Interval (1~300s)	10
Auto Redial Times (1~300)	10
Key As Send	#
Reserve # in User Name	Enabled
Hotline Number	
Hotline Delay(0~10s)	4
Busy Tone Delay (Seconds)	0
Return Code When Refuse	486 (Busy Here)
Return Code When DND	480 (Temporarily Unava)
Call Completion	Disabled
Feature Key Synchronization	Disabled
Time-Out for Dial-Now Rule	1
RFC 2543 Hold	Disabled
Use Outbound Proxy In Dialog	Enabled
180 Ring Workaround	Enabled
Logon Wizard	Disabled

3. Click **Confirm** to accept the change.

Action URL

Action URL allows IP phones to interact with web server applications by sending an HTTP or HTTPS GET request. You can specify a URL that triggers a GET request when a specified event occurs. Action URL can only be triggered by the pre-defined events (e.g., Open DND). The valid URL format is: *http(s)://IP address of the server/help.xml?*

The following table lists the pre-defined events for action URL.

Event	Description
Setup Completed	When the IP phone completes startup.
Registered	When the IP phone successfully registers an account.
Unregistered	When the IP phone logs off the registered account.
Register Failed	When the IP phone fails to register an account.
Off Hook	When the IP phone is off hook.
On Hook	When the IP phone is on hook.
Incoming Call	When the IP phone receives an incoming call.
Outgoing Call	When the IP phone places a call.
Established	When the IP phone establishes a call.
Terminated	When the IP phone terminates a call.
Open DND	When the IP phone enables the DND mode.
Close DND	When the IP phone disables the DND mode.
Open Always Forward	When the IP phone enables the always forward.
Close Always Forward	When the IP phone disables the always forward.
Open Busy Forward	When the IP phone enables the busy forward.
Close Busy Forward	When the IP phone disables the busy forward.
Open NoAnswer Forward	When the IP phone enables the no answer forward.
Close NoAnswer Forward	When the IP phone disables the no answer forward.
Transfer Call	When the IP phone transfers a call.
Blind Transfer	When the IP phone blind transfers a call.
Attended Transfer	When the IP phone performs the semi-attended/attended transfer.
Hold	When the IP phone places a call on hold.
UnHold	When the IP phone resumes a hold call.
Held	When a call of the IP phone is held.

Event	Description
UnHeld	When a held call is resumed.
Mute	When the IP phone mutes a call.
UnMute	When the IP phone un-mutes a call.
Missed Call	When the IP phone misses a call.
IP Changed	When the IP address of the IP phone changes.
Idle To Busy	When the state of the IP phone changes from idle to busy.
Busy To Idle	When the state of phone changes from busy to idle.
Reject Incoming Call	When the IP phone rejects an incoming call.
Answer New-In Call	When the IP phone answers a new call.
Transfer Failed	When the IP phone fails to transfer a call.
Transfer Finished	When the IP phone completes to transfer a call.
Forward Incoming Call	When the IP phone forwards an incoming call.
Autop Finish	When the IP phone completes auto provisioning via power on.
Open Call Waiting	When the IP phone enables the call waiting.
Close Call Waiting	When the IP phone disables the call waiting.
Headset	When the IP phone presses the HEADSET key (not applicable to CP860 IP phones).
Handfree	When the IP phone presses the Speakerphone key (not applicable to CP860 IP phones).
Cancel Call Out	When the IP phone cancels an outgoing call in the ring-back state.
Remote Busy	When an outgoing call is rejected.
Call Remote Canceled	When the remote party cancels the outgoing call in the ringing state.

An HTTP or HTTPS GET request may contain variable name and variable value, separated by “=”. Each variable value starts with \$ in the query part of the URL. The valid URL format is: `http(s)://IP address of server/help.xml?variable name=$variable value`. Variable name can be custom by users, while the variable value is pre-defined. For example, a URL “`http://192.168.1.10/help.xml?mac=$mac`” is specified for the event Mute, \$mac will be dynamically replaced with the MAC address of the IP phone when the IP phone mutes a call.

The following table lists pre-defined variable values.

Variable Value	Description
\$mac	The MAC address of the IP phone.
\$ip	The IP address of the IP phone.
\$model	The IP phone model.
\$firmware	The firmware version of the IP phone.
\$active_url	The SIP URI of the current account when the IP phone places a call, receives an incoming call or establishes a call.
\$active_user	The user part of the SIP URI for the current account when the IP phone places a call, receives an incoming call or establishes a call.
\$active_host	The host part of the SIP URI for the current account when the IP phone places a call, receives an incoming call or establishes a call.
\$local	The SIP URI of the caller when the IP phone places a call. The SIP URI of the callee when the IP phone receives an incoming call.
\$remote	The SIP URI of the callee when the IP phone places a call. The SIP URI of the caller when the IP phone receives an incoming call.
\$display_local	The display name of the caller when the IP phone places a call. The display name of the callee when the IP phone receives an incoming call.
\$display_remote	The display name of the callee when the IP phone places a call. The display name of the caller when the IP phone receives an incoming call.
\$call_id	The call-id of the active call.
\$callerID	The display name of the caller when the IP phone receives an incoming call.
\$calledNumber	The phone number of the callee when the IP phone places a call.

Procedure

Action URL can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure action URL. Parameters: action_url.setup_completed action_url.registered action_url.unregisterd action_url.register_failed action_url.off_hook action_url.on_hook action_url.incoming_call action_url.outgoing_call action_url.call_established action_url.dnd_on action_url.dnd_off action_url.always_fwd_on action_url.always_fwd_off action_url.busy_fwd_on action_url.busy_fwd_off action_url.no_answer_fwd_on action_url.no_answer_fwd_off action_url.transfer_call action_url.blind_transfer_call action_url.attended_transfer_call action_url.hold action_url.unhold action_url.held action_url.unheld action_url.mute action_url.unmute action_url.missed_call action_url.call_terminated action_url.busy_to_idle action_url.idle_to_busy action_url.ip_change action_url.forward_incoming_call
---------------------------	---------------------	---

		action_url.reject_incoming_call action_url.answer_new_incoming_call action_url.transfer_finished action_url.transfer_failed action_url.setup_autop_finish action_url.call_waiting_on action_url.call_waiting_off action_url.headset action_url.handfree action_url.cancel_callout action_url.remote_busy action_url.call_remote_canceled
Local	Web User Interface	Configure action URL. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29 G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?= =features-actionurl&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet?= =mod_data&p=features-actionurl& q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
action_url.setup_completed	URL within 511 characters	Blank
Description: Configures the action URL the IP phone sends after startup. The value format is: http(s)://IP address of server/help.xml? variable name=variable value. Valid variable values are: <ul style="list-style-type: none"> • \$mac • \$ip 		

Parameters	Permitted Values	Default
<ul style="list-style-type: none"> • \$model • \$firmware • \$active_url • \$active_user • \$active_host • \$local • \$remote • \$display_local • \$display_remote • \$call_id • \$callerID • \$calledNumber <p>Example: action_url.setup_completed = http://192.168.0.20/help.xml?IP=\$ip</p> <p>Web User Interface: Features->Action URL->Setup Completed</p> <p>Phone User Interface: None</p>		
action_url.registered	URL within 511 characters	Blank
<p>Description: Configures the action URL the IP phone sends after an account is registered.</p> <p>Example: action_url.registered = http://192.168.0.20/help.xml?IP=\$ip</p> <p>Web User Interface: Features->Action URL->Registered</p> <p>Phone User Interface: None</p>		
action_url.unregistered	URL within 511 characters	Blank
<p>Description: Configures the action URL the IP phone sends after an account is unregistered.</p> <p>Example:</p>		

Parameters	Permitted Values	Default
<p>action_url.unregistered = http://192.168.0.20/help.xml?IP=\$ip</p> <p>Web User Interface:</p> <p>Features->Action URL->Unregistered</p> <p>Phone User Interface:</p> <p>None</p>		
action_url.register_failed	URL within 511 characters	Blank
<p>Description:</p> <p>Configures the action URL the IP phone sends after a register failed.</p> <p>Example:</p> <p>action_url.register_failed = http://192.168.0.20/help.xml?IP=\$ip</p> <p>Web User Interface:</p> <p>Features->Action URL->Register Failed</p> <p>Phone User Interface:</p> <p>None</p>		
action_url.off_hook	URL within 511 characters	Blank
<p>Description:</p> <p>Configures the action URL the IP phone sends when off hook.</p> <p>Example:</p> <p>action_url.off_hook = http://192.168.0.20/help.xml?IP=\$ip</p> <p>Web User Interface:</p> <p>Features->Action URL->Off Hook</p> <p>Phone User Interface:</p> <p>None</p>		
action_url.on_hook	URL within 511 characters	Blank
<p>Description:</p> <p>Configures the action URL the IP phone sends when on hook.</p> <p>Example:</p> <p>action_url.on_hook = http://192.168.0.20/help.xml?IP=\$ip</p> <p>Web User Interface:</p>		

Parameters	Permitted Values	Default
Features->Action URL->On Hook Phone User Interface: None		
action_url.incoming_call	URL within 511 characters	Blank
Description: Configures the action URL the IP phone sends when receiving an incoming call. Example: action_url.incoming_call = http://192.168.0.20/help.xml?IP=\$ip Web User Interface: Features->Action URL->Incoming Call Phone User Interface: None		
action_url.outgoing_call	URL within 511 characters	Blank
Description: Configures the action URL the IP phone sends when placing a call. Example: action_url.outgoing_call = http://192.168.0.20/help.xml?IP=\$ip Web User Interface: Features->Action URL->Outgoing Call Phone User Interface: None		
action_url.call_established	URL within 511 characters	Blank
Description: Configures the action URL the IP phone sends when establishing a call. Example: action_url.call_established = http://192.168.0.20/help.xml?IP=\$ip Web User Interface: Features->Action URL->Established Phone User Interface: None		

Parameters	Permitted Values	Default
action_url.dnd_on	URL within 511 characters	Blank
Description: Configures the action URL the IP phone sends when DND feature is enabled. Example: action_url.dnd_on = http://192.168.0.20/help.xml?IP=\$ip Web User Interface: Features->Action URL->Open DND Phone User Interface: None		
action_url.dnd_off	URL within 511 characters	Blank
Description: Configures the action URL the IP phone sends when DND feature is disabled. Example: action_url.dnd_off = http://192.168.0.20/help.xml?IP=\$ip Web User Interface: Features->Action URL->Close DND Phone User Interface: None		
action_url.always_fwd_on	URL within 511 characters	Blank
Description: Configures the action URL the IP phone sends when always forward feature is enabled. Example: action_url.always_fwd_on = http://192.168.0.20/help.xml?IP=\$ip Web User Interface: Features->Action URL->Open Always Forward Phone User Interface: None		
action_url.always_fwd_off	URL within 511 characters	Blank

Parameters	Permitted Values	Default
Description: Configures the action URL the IP phone sends when always forward feature is disabled. Example: action_url.always_fwd_off = http://192.168.0.20/help.xml?IP=\$ip Web User Interface: Features->Action URL->Close Always Forward Phone User Interface: None		
action_url.busy_fwd_on	URL within 511 characters	Blank
Description: Configures the action URL the IP phone sends when busy forward feature is enabled. Example: action_url.busy_fwd_on = http://192.168.0.20/help.xml?IP=\$ip Web User Interface: Features->Action URL->Open Busy Forward Phone User Interface: None		
action_url.busy_fwd_off	URL within 511 characters	Blank
Description: Configures the action URL the IP phone sends when busy forward feature is disabled. Example: action_url.busy_fwd_off = http://192.168.0.20/help.xml?IP=\$ip Web User Interface: Features->Action URL->Close Busy Forward Phone User Interface: None		
action_url.no_answer_fwd_on	URL within 511 characters	Blank

Parameters	Permitted Values	Default
Description: Configures the action URL the IP phone sends when no answer forward feature is enabled. Example: action_url.no_answer_fwd_on = http://192.168.0.20/help.xml?IP=\$ip Web User Interface: Features->Action URL->Open NoAnswer Forward Phone User Interface: None		
action_url.no_answer_fwd_off	URL within 511 characters	Blank
Description: Configures the action URL the IP phone sends when no answer forward feature is disabled. Example: action_url.no_answer_fwd_off = http://192.168.0.20/help.xml?IP=\$ip Web User Interface: Features->Action URL->Close NoAnswer Forward Phone User Interface: None		
action_url.transfer_call	URL within 511 characters	Blank
Description: Configures the action URL the IP phone sends when performing a transfer. Example: action_url.transfer_call = http://192.168.0.20/help.xml?IP=\$ip Web User Interface: Features->Action URL->Transfer Call Phone User Interface: None		
action_url.blind_transfer_call	URL within 511 characters	Blank
Description:		

Parameters	Permitted Values	Default
<p>Configures the action URL the IP phone sends when performing a blind transfer.</p> <p>Example:</p> <p>action_url.blind_transfer_call = http://192.168.0.20/help.xml?IP=\$ip</p> <p>Web User Interface:</p> <p>Features->Action URL->Blind Transfer</p> <p>Phone User Interface:</p> <p>None</p>		
action_url.attended_transfer_call	URL within 511 characters	Blank
<p>Description:</p> <p>Configures the action URL the IP phone sends when performing an attended/semi-attended transfer.</p> <p>Example:</p> <p>action_url.attended_transfer_call = http://192.168.0.20/help.xml?IP=\$ip</p> <p>Web User Interface:</p> <p>Features->Action URL->Attended Transfer</p> <p>Phone User Interface:</p> <p>None</p>		
action_url.hold	URL within 511 characters	Blank
<p>Description:</p> <p>Configures the action URL the IP phone sends when placing a call on hold.</p> <p>Example:</p> <p>action_url.hold = http://192.168.0.20/help.xml?IP=\$ip</p> <p>Web User Interface:</p> <p>Features->Action URL->Hold</p> <p>Phone User Interface:</p> <p>None</p>		
action_url.unhold	URL within 511 characters	Blank
<p>Description:</p> <p>Configures the action URL the IP phone sends when resuming a hold call.</p> <p>Example:</p>		

Parameters	Permitted Values	Default
<p>action_url.unhold = http://192.168.0.20/help.xml?IP=\$ip</p> <p>Web User Interface: Features->Action URL->UnHold</p> <p>Phone User Interface: None</p>		
action_url.held	URL within 511 characters	Blank
<p>Description: Configures the action URL the IP phone sends when a call is held.</p> <p>Example: action_url.held = http://192.168.0.20/help.xml?IP=\$ip</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		
action_url.unheld	URL within 511 characters	Blank
<p>Description: Configures the action URL the IP phone sends when a call being held is resumed.</p> <p>Example: action_url.unheld = http://192.168.0.20/help.xml?IP=\$ip</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		
action_url.mute	URL within 511 characters	Blank
<p>Description: Configures the action URL the IP phone sends when muting a call.</p> <p>Example: action_url.mute = http://192.168.0.20/help.xml?IP=\$ip</p> <p>Web User Interface: Features->Action URL->Mute</p>		

Parameters	Permitted Values	Default
Phone User Interface: None		
action_url.unmute	URL within 511 characters	Blank
Description: Configures the action URL the IP phone sends when un-muting a call. Example: action_url.unmute = http://192.168.0.20/help.xml?IP=\$ip Web User Interface: Features->Action URL->UnMute Phone User Interface: None		
action_url.missed_call	URL within 511 characters	Blank
Description: Configures the action URL the IP phone sends when missing a call. Example: action_url.missed_call = http://192.168.0.20/help.xml?IP=\$ip Web User Interface: Features->Action URL->Missed Call Phone User Interface: None		
action_url.call_terminated	URL within 511 characters	Blank
Description: Configures the action URL the IP phone sends when terminating a call. Example: action_url.call_terminated = http://192.168.0.20/help.xml?IP=\$ip Web User Interface: Features->Action URL->Terminated Phone User Interface: None		

Parameters	Permitted Values	Default
action_url.busy_to_idle	URL within 511 characters	Blank
<p>Description: Configures the action URL the IP phone sends when changing the state of the IP phone from busy to idle.</p> <p>Example: action_url.busy_to_idle = http://192.168.0.20/help.xml?IP=\$ip</p> <p>Web User Interface: Features->Action URL->Busy To Idle</p> <p>Phone User Interface: None</p>		
action_url.idle_to_busy	URL within 511 characters	Blank
<p>Description: Configures the action URL the IP phone sends when changing the state of the IP phone from idle to busy.</p> <p>Example: action_url.idle_to_busy = http://192.168.0.20/help.xml?IP=\$ip</p> <p>Web User Interface: Features->Action URL->Idle To Busy</p> <p>Phone User Interface: None</p>		
action_url.ip_change	URL within 511 characters	Blank
<p>Description: Configures the action URL the IP phone sends when changing the IP address of the IP phone.</p> <p>Example: action_url.ip_change = http://192.168.0.20/help.xml?IP=\$ip</p> <p>Web User Interface: Features->Action URL->IP Changed</p> <p>Phone User Interface:</p>		

Parameters	Permitted Values	Default
None		
action_url.forward_incoming_call	URL within 511 characters	Blank
<p>Description: Configures the action URL the IP phone sends when forwarding an incoming call.</p> <p>Example: action_url.forward_incoming_call = http://192.168.0.20/help.xml?IP=\$ip</p> <p>Web User Interface: Features->Action URL->Forward Incoming Call</p> <p>Phone User Interface: None</p>		
action_url.reject_incoming_call	URL within 511 characters	Blank
<p>Description: Configures the action URL the IP phone sends when rejecting an incoming call.</p> <p>Example: action_url.reject_incoming_call = http://192.168.0.20/help.xml?IP=\$ip</p> <p>Web User Interface: Features->Action URL->Reject Incoming Call</p> <p>Phone User Interface: None</p>		
action_url.answer_new_incoming_call	URL within 511 characters	Blank
<p>Description: Configures the action URL the IP phone sends when answering a new incoming call.</p> <p>Example: action_url.answer_new_incoming_call = http://192.168.0.20/help.xml?IP=\$ip</p> <p>Web User Interface: Features->Action URL->Answer New-In Call</p> <p>Phone User Interface: None</p>		

Parameters	Permitted Values	Default
action_url.transfer_finished	URL within 511 characters	Blank
Description: Configures the action URL the IP phone sends when completing a call transfer. Example: action_url.transfer_finished = http://192.168.0.20/help.xml?IP=\$ip Web User Interface: Features->Action URL->Transfer Finished Phone User Interface: None		
action_url.transfer_failed	URL within 511 characters	Blank
Description: Configures the action URL the IP phone sends when failing to transfer a call. Example: action_url.transfer_failed = http://192.168.0.20/help.xml?IP=\$ip Web User Interface: Features->Action URL->Transfer Failed Phone User Interface: None		
action_url.setup_autop_finish	URL within 511 characters	Blank
Description: Configures the action URL the IP phone sends when completing auto provisioning via power on. Example: action_url.setup_autop_finish = http://192.168.0.20/help.xml?IP=\$ip Web User Interface: Features->Action URL->Autop Finish Phone User Interface: None		

Parameters	Permitted Values	Default
action_url.call_waiting_on	URL within 511 characters	Blank
Description: Configures the action URL the IP phone sends when call waiting feature is enabled. Example: action_url.call_waiting_on = http://192.168.0.20/help.xml?IP=\$ip Web User Interface: Features->Action URL->Open Call Waiting Phone User Interface: None		
action_url.call_waiting_off	URL within 511 characters	Blank
Description: Configures the action URL the IP phone sends when call waiting feature is disabled. Example: action_url.call_waiting_off = http://192.168.0.20/help.xml?IP=\$ip Web User Interface: Features->Action URL->Close Call Waiting Phone User Interface: None		
action_url.headset	URL within 511 characters	Blank
Description: Configures the action URL the IP phone sends when pressing the HEADSET key. Example: action_url.headset = http://192.168.0.20/help.xml?IP=\$ip Note: It is not applicable to CP860 IP phones. Web User Interface: Features->Action URL->Headset Phone User Interface: None		
action_url.handfree	URL within 511 characters	Blank

Parameters	Permitted Values	Default
Description: Configures the action URL the IP phone sends when pressing the Speakerphone key. Example: action_url.handfree = http://192.168.0.20/help.xml?IP=\$ip Note: It is not applicable to CP860 IP phones. Web User Interface: Features->Action URL->Handfree Phone User Interface: None		
action_url.cancel_callout	URL within 511 characters	Blank
Description: Configures the action URL the IP phone sends when cancels the outgoing call in the ring-back state. Example: action_url.cancel_callout = http://192.168.0.20/help.xml?IP=\$ip Web User Interface: Features->Action URL->Cancel Call Out Phone User Interface: None		
action_url.remote_busy	URL within 511 characters	Blank
Description: Configures the action URL the IP phone sends when the outgoing call is rejected. Example: action_url.remote_busy = http://192.168.0.20/help.xml?IP=\$ip Web User Interface: Features->Action URL->Remote Busy Phone User Interface: None		

Parameters	Permitted Values	Default
action_url.call_remote_canceled	URL within 511 characters	Blank
<p>Description:</p> <p>Configures the action URL the IP phone sends when the remote party cancels the outgoing call in the ringing state.</p> <p>Example:</p> <p>action_url.call_remote_canceled = http://192.168.0.20/help.xml?IP=\$ip</p> <p>Web User Interface:</p> <p>Features->Action URL->Call Remote Canceled</p> <p>Phone User Interface:</p> <p>None</p>		

To configure action URL via web user interface:

1. Click on **Features->Action URL**.
2. Enter the action URLs in the corresponding fields.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected, and the 'Action URL' section is active. The 'Setup Completed' field is highlighted with a red box and contains the URL 'http://192.168.0.20/help.xml?IP=\$ip'. Other fields like 'Registered', 'Unregistered', 'Register Failed', etc., are also visible but empty. A 'NOTE' box on the right explains the Action URL format and provides a link to more guides.

3. Click **Confirm** to accept the change.

Action URI

HTTP/HTTPS GET Request

Opposite to action URL, action URI allows IP phones to interact with web server

application by receiving and handling an HTTP or HTTPS GET request. When receiving a GET request, the IP phone will perform the specified action and respond with a 200 OK message. A GET request may contain variable named as "key" and variable value, which are separated by "=". The valid URI format is: *http(s)://phone IP address/servlet?key=variable value*. For example: *http://10.3.20.10/servlet?key=OK*.

Note

Yealink IP phones are compatible with other two old valid URI formats: *http(s)://phone IP address/cgi-bin/ConfigManApp.com?key=variable value* and *http(s)://phone IP address/cgi-bin/cgiServer.exx?key=variable value*.

SIP Notify Message

In addition, Yealink IP phones support performing the specified action immediately by accepting a SIP NOTIFY message with the "Event: ACTION-URI" header from a SIP proxy server. The message body of the SIP NOTIFY message may contain variable named as "key" and variable value, which are separated by "=".

This method is especially useful for users always working in the small office/home office where a secure firewall may prevent the HTTP or HTTPS GET request from the external network.

Note

If you want to only accept the SIP NOTIFY message from your SIP server and outbound proxy server, you have to enable the Accept SIP Trust Server Only feature. For more information, refer to [Accept SIP Trust Server Only](#) on page 309.

Example of a SIP Notify with the variable value (OK):

Message Header

```
NOTIFY sip:3583@10.2.40.10:5062 SIP/2.0
Via: SIP/2.0/UDP 10.2.40.27:5063;branch=z9hG4bK4163876675
From: <sip:3586@10.2.1.48>;tag=2900480538
To: "3583" <sip:3583@10.2.1.48>;tag=490600926
Call-ID: 2923387519@10.2.40.10
CSeq: 4 NOTIFY
Contact: <sip:3586@10.2.40.27:5063>
Max-Forwards: 70
User-Agent: Yealink SIP-T23G
Event: ACTION-URI
Content-Type: message/sipfrag
Content-Length: 6
```

Message Body

```
key=OK
```

The following table lists pre-defined variable values:

Variable Value	Phone Action
OK	Press the OK/v key.
ENTER	Press the Enter soft key.
SPEAKER	Press the Speakerphone key (not applicable to CP860 IP phones).
F_TRANSFER	Transfers a call to another party.
VOLUME_UP	Increase the volume.
VOLUME_DOWN	Decrease the volume.
MUTE	Mute a call.
F_HOLD/HOLD	Place an active call on hold.
F_CONFERENCE	Press the Conf soft key.
Cancel/CANCEL	Cancel actions or reject incoming calls or end a call.
X	Cancel actions or reject incoming calls or mute or un-mute calls.
0-9/*/POUND	Press the keypad (0-9, * or #).
L1-LX	Press the line keys (for SIP VP-T49G/SIP-T48G, X=29; for SIP-T46G/T29G, X=27; for SIP-T42G/T41P, X=15; for SIP-T27P, X=21; for SIP-T40P/T23P/T23G, X=3; for SIP-T21(P) E2, X=2).
F1-F4	Press the soft keys.
MSG	Press the MESSAGE key (not applicable to CP860 IP phones).
HEADSET	Press the HEADSET key (not applicable to CP860 IP phones).
RD	Press the RD/Redial key.
UP/DOWN/LEFT/RIGHT	Press the navigation keys.
Reboot	Reboot the phone.
AutoP	Perform auto provisioning.
DNDOn	Activate the DND feature.
DNDOff	Deactivate the DND feature.

Variable Value	Phone Action
number=xxx&outgoing_uri=y	Place a call to xxx from SIP URI y. Example: http://10.3.20.10/servlet?key=number=1234 &outgoing_uri=1006@10.2.1.48 (1234 means the number you dial out; 1006@10.2.1.48 means the SIP URL you dial from.)
OFFHOOK	For SIP VP-T49G/SIPT48G/T46G/T42G/T41P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2 IP phones: Pick up the handset. For CP860 IP phones: Press the off-hook key.
ONHOOK	For SIP VP-T49G/SIPT48G/T46G/T42G/T41P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2 IP phones: Hang up the handset. For CP860 IP phones: Press the on-hook key.
ANSWER/ASW/Asw	Answer a call.
Reset	Reset a phone.
ATrans=xxx	Perform a semi-attended/attended transfer to xxx.
BTrans=xxx	Perform a blind transfer to xxx.
CALLEND	End a call.
phonecfg=get[&accounts=x][&dnd=x][&fw=x]	Get firmware version, registration, DND or forward configuration information. The valid value of "x" is 0 or 1, 0 means you do not need to get configuration information. 1 means you want to get configuration information. Note: The valid URI is: http(s)://phone IP address/servlet?phonecfg=get[&accounts=x][&dnd=x][&fw=x] Example: http://10.3.20.10/servlet?phonecfg=get[&accounts=1][&dnd=0][&fw=1]
CallWaitingOn	Activate the call waiting feature.

Variable Value	Phone Action
CallWaitingOff	Deactivate the call waiting feature.
AlwaysFwdOn/BusyFwdOn/NoAnswerFwdOn=xxx=n	<p>Activate an always/busy/no answer forward feature to xxx for the IP phone ("xxx" means the destination number)</p> <p>The valid value of "n" means the duration time (seconds) before forwarding incoming calls (n is the times of 6, e.g., 24). It is only applicable to no answer forward feature.</p> <p>Note: It works only if the call forward mode is Phone, the always/busy/no answer forward feature will apply to all the accounts on the phone.</p> <p>Example:</p> <p>http://10.10.20.10/servlet?key=NoAnswFwdOn=1001=24</p>
AlwaysFwdOff/BusyFwdOff/NoAnswerFwdOff	<p>Deactivate the always/busy/no answer forward feature for the IP phone.</p> <p>Note: It works only if the call forward mode is Phone, the always/busy/no answer forward feature will apply to all the accounts on the phone.</p> <p>Example:</p> <p>http://10.10.20.10/servlet?key=NoAnswFwdOff</p>
CALLEND/CallEnd	End a call.
ASW/CANCEL/HOLD/UNHOLD:xxx	<p>Answer/end/hold/unhold a call (xxx refers to the call-id of the active call).</p> <p>Example:</p> <p>http://10.10.20.10/servlet?key=ASW:33093</p> <p>Note: To get the call-id of the active call, configure the action URL: http://phone IP address/help.xml?CallId=\$call_id. For more information, refer to Action URL on page 618.</p>

Variable Value	Phone Action
phonecfg=get[&accounts=x][&dnd=x][&fw=x]	<p>Get firmware version, registration, DND or forward configuration information.</p> <p>The valid value of "x" is 0 or 1, 0 means you do not need to get configuration information. 1 means you want to get configuration information.</p> <p>Note: The valid URI is: <i>http(s)://phone IP address/servlet?phonecfg=get[&accounts=x][&dnd=x][&fw=x]</i></p> <p>Example:</p> <p><i>http://10.10.20.10/servlet?phonecfg=get[&accounts=1][&dnd=0][&fw=1]</i></p>

Note

The variable value is not applicable to all events. For example, the variable value "MUTE" is only applicable when the IP phone is during a call.

When authentication is required, you must enter "p=login&q=login&username=xxx&pwd=yyy&jumpto=URI&" before the variable "key". xxx refers to the login user name and yyy refers to the login password.

Yealink IP phones also support a combination of the variable values in the URI, but the order of the variable value is determined by the operation of the phone. The valid URI format is: *http(s)://phone IP address/servlet?key=variable value[;variable value]*. Variable values are separated by a semicolon from each other. This method is not applicable to SIP VP-T49G and SIP-T48G IP phones.

The following shows an example for deleting all entries from the call history list when the phone is idle:

For T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2:

http://10.3.20.10/servlet?key=F1;F3;DOWN;DOWN;DOWN;OK;OK.

For CP860:

http://10.3.20.10/servlet?key=F1;OK;F3;DOWN;DOWN;DOWN;OK;OK.

Configuring Trusted IP Address for Action URI

For security reasons, IP phones do not receive and handle HTTP/HTTPS GET requests by default. You need to specify the trusted IP address for action URI. When the IP phone receives a GET request from the trusted IP address for the first time, the LCD screen prompts the message "Allow Remote Control?". You can specify one or more trusted IP addresses on the IP phone, or configure the IP phone to receive and handle the URI from any IP address.

You can use action URI feature to capture the phone's current screen. For more

information, refer to [Scenario A - Capturing the Current Screen](#) of the Phone on page 645.

Procedure

Specify the trusted IP address for action URI using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the IP phone to receive the action URI requests. Parameter: features.action_uri.enable
		Specify the trusted IP address(es) for sending the action URI to the IP phone. Parameter: features.action_uri_limit_ip
Local	Web User Interface	Specify the trusted IP address(es) for sending the action URI to the IP phone. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p=features-remotecontrl&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet?m=mod_data&p=features-remotecontrl&q=load

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
features.action_uri.enable	0 or 1	0
Description: Enables or disables the IP phone to receive the action URI requests. 0-Disabled 1-Enabled		

Parameter	Permitted Values	Default
Web User Interface: None Phone User Interface: None		
features.action_uri_limit_ip	IP address or any	Blank
Description: Configures the IP address of the server from which the IP phone receives the action URI requests. For discontinuous IP addresses, multiple IP addresses are separated by commas. For continuous IP addresses, the format likes *.*.* and the "*" stands for the values 0~255. For example: 10.10.*.* stands for the IP addresses that range from 10.10.0.0 to 10.10.255.255. If left blank, the IP phone will reject any HTTP GET request. If it is set to "any", the IP phone will accept and handle HTTP GET requests from any IP address. Example: features.action_uri_limit_ip = any Note: It works only if the value of the parameter "features.action_uri.enable" is set to 1 (Enabled). Web User Interface: Features->Remote Control->Action URI allow IP List Phone User Interface: None		

To configure the trusted IP address(es) for action URI via web user interface:

1. Click on **Features->Remote Control**.
2. Enter the IP address or any in the **Action URI allow IP List** field.

Multiple IP addresses are separated by commas. If you enter “any” in this field, the IP phone can receive and handle GET requests from any IP address. If you leave the field blank, the IP phone cannot receive or handle any HTTP GET request.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected. Under 'Remote Control', the 'Action URI allow IP List' field is highlighted with a red box and contains the text '10.3.6.117,10.3.6.119'. Other fields include 'Push XML Server IP Address', 'SIP Notify' (set to Disabled), and 'Block XML in Calling' (set to Disabled). A 'NOTE' section on the right explains the Action URI and provides a link to more guides.

3. Click **Confirm** to accept the change.

Scenario A - Capturing the Current Screen of the Phone

You can capture the screen display of the IP phone using the action URI. IP phones support handling an HTTP or HTTPS GET request. The URI format is `http(s)://<phoneIPAddress>/screencapture`. The captured picture can be saved as a BMP or JPEG file.

You can also use the URI “`http(s)://<phoneIPAddress>/screencapture/download`” to capture the screen display first, and then download the image (which is saved as a JPG file and named with the phone model and the capture time) to the local system. Before capturing the phone’s current screen, ensure that the IP address of the computer is included in the trusted IP address for Action URI on the phone.

When you capture the screen display, the IP phone may prompt you to enter the user name and password of the administrator if web browser does not remember the user name and password for web user interface login.

Note

IP phones also support capturing the screen display using the old URI “`http://<phoneIPAddress>/servlet?command=screenshot`”.

To capture the current screen of the phone:

1. Enter request URI (e.g., `http://10.3.20.8/screencapture`) in the browser's address bar and press the Enter key on the keyboard.
2. Do one of the following:


- If it is the first time you capture the phone's current screen using the computer, the browser will display "Remote control forbidden", and the LCD screen will prompt the message "Allow remote control?".



Press the **OK** soft key on the phone to allow remote control. The phone will return to the previous screen.

Refresh the web page.

The browser will display an image showing the phone's current screen. You can save the image to your local system.



- Else, the browser will display an image showing the phone's current screen directly. You can save the image to your local system.

Note

Frequent capture may affect the phone performance. Yealink recommend you to capture the phone screen display within a minimum interval of 4 seconds.

Scenario B - Placing a Call via Web User Interface

You can place a call via web user interface. Before doing it, ensure that the IP address of your computer is included in the trusted IP address for Action URI on the phone. For more information on the trusted IP address, refer to [Configuring Trusted IP Address for Action URI](#) on page 642.

If you place a call via web user interface but the trusted IP address has not been configured, the web user interface prompts “Call fail”.

To place a call via web user interface:

1. Click on **Directory->Phone Call Info**.
2. Select the desired account from the pull-down list of **Outgoing Identity**.
3. Enter the callee’s number in the **Dial Number** field.

The screenshot shows the Yealink T23G web interface. The top navigation bar includes Status, Account, Network, DSSKey, Features, Settings, Directory, and Security. The left sidebar has links for Local Directory, Remote Phone Book, Phone Call Info (selected), LDAP, Multicast IP, and Setting. The main content area is titled 'Call Panel' and contains a 'Dial Number' input field with '1011', an 'Outgoing Identity' dropdown menu with '1012@10.2.1.48', and 'Dial' and 'Hang Up' buttons. Below this is a 'Call Log' section with a 'Placed List' table. A 'NOTE' box on the right states: 'Call Log It shows the call information such as remote party identification, time and date, and call duration. Call log consists of four lists: Placed List, Missed List, Received List, and Forwarded List. You can click here to get more guides.'

4. Click **Dial** to dial out the number.

The web user interface prompts “Call Success” and the phone will automatically dial out the number. You can click **Hang Up** to end the call.

If it is the first time you place a call via web user interface, the LCD screen will prompt the message “Allow remote control?”. Press **OK** on the phone to allow remote control and then the phone will automatically dial out the number.

Note

You can also place an IP direct call via web user interface. The IP phone supports either IPv4 or IPv6 address.

Server Redundancy

Server redundancy is often required in VoIP deployments to ensure continuity of phone service, for events where the server needs to be taken offline for maintenance, the server fails, or the connection between the IP phone and the server fails.


Two types of redundancy are possible. In some cases, a combination of the two may be deployed:

- **Failover:** In this mode, the full phone system functionality is preserved by having a second equivalent capability call server take over from the one that has gone down/off-line. This mode of operation should be done using the DNS mechanism from the primary to the secondary server.
- **Fallback:** In this mode, a second less featured call server with SIP capability takes over call control to provide basic calling capability, but without some advanced features (for example, shared line, call recording and MWI) offered by the working server. IP phones support configuration of two servers per SIP registration for

fallback purpose.

Phone Configuration for Redundancy Implementation

To assist in explaining the redundancy behavior, an illustrative example of how an IP phone may be configured is shown as below. In the example, server redundancy for fallback and failover purposes is deployed. Two separate servers (a working server and a fallback server) are configured for per line registration.



Working Server: Server 1 is configured with the domain name of the working server. For example: yealink.pbx.com. DNS mechanism is used such that the working server is resolved to multiple servers for failover purpose. The working server is deployed in redundant pairs, designated as primary and secondary servers. The primary server has the highest priority server in a cluster of servers resolved by the DNS server. The secondary server backs up a primary server when the primary server fails and offers the same functionality as the primary server.

Fallback Server: Server 2 is configured with the IP address of the fallback server. For example, 192.168.1.15. A fallback server offers less functionality than the working server.

Phone Registration

Registration method of the failover mode:

The IP phone must always register to the primary server first except in failover conditions. If this is unsuccessful, the phone will re-register as many times as configured until the registration is successful. When the primary server registration is unavailable, the secondary server will serve as the working server.

Registration methods of the fallback mode include:

- **Concurrent registration (default):** The IP phone registers to two SIP servers (working server and fallback server) at the same time. In a failure situation, a fallback server

can take over the basic calling capability, but without some advanced features (for example, shared lines, call recording and MWI) offered by the working server. It is not applicable to outbound proxy servers

- **Successive registration:** The IP phone only registers to one server at a time. The IP phone first registers to the working server. In a failure situation, the IP phone registers to the fallback server.

For more information on server redundancy, refer to [Server Redundancy on Yealink IP Phones](#).

Procedure

Server redundancy can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure the SIP server redundancy. Parameters: account.X.sip_server.Y.address account.X.sip_server.Y.port account.X.sip_server.Y.expires account.X.sip_server.Y.retry_counts
		Configure the outbound proxy server redundancy. Parameters: account.X.outbound_proxy_enable account.X.outbound_host account.X.outbound_port account.X.backup_outbound_host account.X.backup_outbound_port Fallback Mode: account.X.fallback.redundancy_type account.X.fallback.timeout account.X.outbound_proxy_fallback_interval Failover Mode: account.X.sip_server.Y.fallback_mode account.X.sip_server.Y.fallback_timeout account.X.sip_server.Y.register_on_enable
Local	Web User Interface	Configure the server redundancy on the IP phone. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T2

		3P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p=account-register&q=load&acc=0 For SIP VP-T49G: http://<phoneIPAddress>/servlet?m=mod_data&p=account-register&q=load&acc=0
--	--	---

Details of Configuration Parameters:

Parameters	Permitted Values	Default
account.X.sip_server.Y.address (X ranges from 1 to 16, Y ranges from 1 to 2)	String within 256 characters	Blank
Description: Configures the IP address or domain name of the SIP server Y for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Example: account.1.sip_server.1.address = yealink.pbx.com Web User Interface: Account->Register->SIP Server Y->Server Host Phone User Interface: None		
account.X.sip_server.Y.port (X ranges from 1 to 16, Y ranges from 1 to 2)	Integer from 0 to 65535	5060
Description: Configures the port of the SIP server Y for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860)		

Parameters	Permitted Values	Default
Example: account.1.sip_server.1.port = 5060 Web User Interface: Account->Register->SIP Server Y->Port Phone User Interface: None		
account.X.sip_server.Y.expires (X ranges from 1 to 16, Y ranges from 1 to 2)	Integer from 30 to 2147483647	3600
Description: Configures the registration expiration time (in seconds) of the SIP server Y for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Example: account.1.sip_server.1.expires = 3600 Web User Interface: Account->Register->SIP Server Y->Server Expires Phone User Interface: None		
account.X.sip_server.Y.retry_counts (X ranges from 1 to 16, Y ranges from 1 to 2)	Integer from 0 to 20	3
Description: Configures the retry times for the IP phone to resend requests when the SIP server Y is unavailable or there is no response from the SIP server Y for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860)		

Parameters	Permitted Values	Default
Web User Interface: Account->Register->SIP Server Y->Server Retry Counts Phone User Interface: None		
account.X.sip_server.Y.register_on_enable (X ranges from 1 to 16, Y ranges from 1 to 2)	0 or 1	0
Description: Enables or disables the IP phone to send registration requests to the secondary server for account X when encountering a failover. 0 -Disabled 1 -Enabled X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Web User Interface: None Phone User Interface: None		
account.X.outbound_proxy_enable	0 or 1	0
Description: Enables or disables the IP phone to send requests to the outbound proxy server for account X. 0 -Disabled 1 -Enabled X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860)		

Parameters	Permitted Values	Default
Web User Interface: Account->Register->Enable Outbound Proxy Server Phone User Interface: Menu->Settings->Advanced Settings->Accounts->Outbound Status		
account.X.outbound_host	IP address or domain name	Blank
Description: Configures the IP address or domain name of the outbound proxy server 1 for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIPT42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Note: It works only if the value of the parameter "account.X.outbound_proxy_enable" is set to 1 (Enabled). Web User Interface: Account->Register->Outbound Proxy Server 1 Phone User Interface: Menu->Settings->Advanced Settings->Accounts->Outbound Proxy1		
account.X.outbound_port	Integer from 0 to 65535	5060
Description: Configures the port of the outbound proxy server 1 for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIPT42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Example: account.1.outbound_port = 5060 Note: It works only if the value of the parameter		

Parameters	Permitted Values	Default
<p>"account.X.outbound_proxy_enable" is set to 1 (Enabled).</p> <p>Web User Interface:</p> <p>Account->Register->Outbound Proxy Server 1->Port</p> <p>Phone User Interface:</p> <p>None</p>		
account.X.backup_outbound_host	IP address or domain name	Blank
<p>Description:</p> <p>Configures the IP address or domain name of the outbound proxy server 2 for account X.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Note: It works only if the value of the parameter "account.X.outbound_proxy_enable" is set to 1 (Enabled).</p> <p>Web User Interface:</p> <p>Account->Register->Outbound Proxy Server 2</p> <p>Phone User Interface:</p> <p>Menu->Settings->Advanced Settings->Accounts->Outbound Proxy2</p>		
account.X.backup_outbound_port	Integer from 0 to 65535	5060
<p>Description:</p> <p>Configures the port of the outbound proxy server 2 for account X.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Example:</p> <p>account.1.backup_outbound_port = 5060</p>		

Parameters	Permitted Values	Default
<p>Note: It works only if the value of the parameter “account.X.outbound_proxy_enable” is set to 1 (Enabled).</p> <p>Web User Interface: Account->Register->Outbound Proxy Server 2->Port</p> <p>Phone User Interface: None</p>		
account.X.fallback.redundancy_type	0 or 1	0
<p>Description: Configures the registration mode for the IP phone in fallback mode.</p> <p>0-Concurrent Registration 1-Successive Registration</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIPT42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIPT21(P) E2) X is equal to 1 (for SIPT19(P) E2/CP860)</p> <p>Note: It is not applicable to outbound proxy servers.</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		
account.X.fallback.timeout	Integer from 10 to 2147483647	120
<p>Description: Configures the time interval (in seconds) for the IP phone to detect whether the working server is available by sending the registration request for account X after the fallback server takes over call control.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G) X ranges from 1 to 12 (for SIPT42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIPT21(P) E2)</p>		

Parameters	Permitted Values	Default
<p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Note: It is not applicable to outbound proxy servers.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		
account.X.outbound_proxy_fallback_interval	Integer from 0 to 65535	3600
<p>Description:</p> <p>Configures the time interval (in seconds) for the IP phone to detect whether the working outbound proxy server is available by sending the registration request after the fallback server takes over call control.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Example:</p> <p>account.1.outbound_proxy_fallback_interval = 3600</p> <p>Note: It is only applicable to outbound proxy servers.</p> <p>Web User Interface:</p> <p>Account->Register->Proxy Fallback Interval</p> <p>Phone User Interface:</p> <p>Menu->Settings->Advanced Settings->Accounts->Proxy Fallback Interval</p>		
account.X.sip_server.Y.fallback_mode (X ranges from 1 to 16, Y ranges from 1 to 2)	0, 1, 2 or 3	0
<p>Description:</p> <p>Configures the mode for the IP phone to retry the primary server in failover for account X.</p> <p>0-newRequests: all requests are sent to the primary server first, regardless of the last server that was used.</p> <p>1-DNSTTL: the IP phone will send requests to the last registered server first. If the time defined by DNSTTL on the registered server expires, the phone will retry to send requests to the primary server.</p>		

Parameters	Permitted Values	Default
<p>2-Registration: the IP phone will send requests to the last registered server first. If the registration expires, the phone will retry to send requests to the primary server.</p> <p>3-duration: the IP phone will send requests to the last registered server first. If the time defined by the “account.X.sip_server.Y.failback_timeout” parameter expires, the phone will retry to send requests to the primary server.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		
account.X.sip_server.Y.failback_timeout (X ranges from 1 to 16, Y ranges from 1 to 2)	0, Integer from 60 to 65535	3600
<p>Description:</p> <p>Configures the time (in seconds) for the phone to retry to send requests to the primary server after failing over to the current working server for account X.</p> <p>If you set the parameter to 0, the IP phone will not send requests to the primary server until a failover event occurs with the current working server.</p> <p>If you set the parameter between 1 and 59, the timeout will be 60 seconds.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIPT48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Note: It works only if the value of the parameter “account.X.sip_server.Y.failback_mode” is set to 3 (duration).</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		

To configure server redundancy for fallback purpose via web user interface:

1. Click on **Account->Register**.
2. Select the desired account from the pull-down list of **Account**.
3. Configure registration parameters of the selected account in the corresponding fields.
4. Configure parameters of SIP server 1 and SIP server 2 in the corresponding fields.

Yealink T236 Log Out

Status **Account** Network DSSKey Features Settings Directory Security

Register Basic Codec Advanced

Account Account 1

Register Status: Registered

Line Active: Enabled

Label: 4605

Display Name: 4605

Register Name: 4605

User Name: 4605

Password: 4605

SIP Server 1

Server Host: 192.168.1.14 Port: 5060

Transport: UDP

Server Expires: 3600

Server Retry Counts: 3

SIP Server 2

Server Host: 192.168.1.15 Port: 5060

Transport: UDP

Server Expires: 3600

Server Retry Counts: 3

Enable Outbound Proxy Server: Disabled

Outbound Proxy Server 1: Port: 5060

Outbound Proxy Server 2: Port: 5060

Proxy Fallback Interval: 3600

NAT: Disabled

Confirm Cancel

NOTE

Account Registration
Registers account(s) for the IP phone.

Server Redundancy
It is often required in VoIP deployments to ensure continuity of phone service, for events where the server needs to be taken offline for maintenance, the server fails, or the connection between the IP phone and the server fails.

NAT Traversal
A general term for techniques that establish and maintain IP connections traversing NAT gateways. STUN is one of the NAT traversal techniques.

You can configure NAT traversal for this account.

You can click here to get more guides.

5. If you use outbound proxy servers, do the following:
 - 1) Select **Enabled** from the pull-down list of **Enable Outbound Proxy Server**.

- 2) Configure parameters of outbound proxy server 1 and outbound proxy server 2 in the corresponding fields.

The screenshot shows the Yealink 1736 web interface with the 'Account' tab selected. The 'Account' dropdown is set to 'Account 1'. The 'SIP Server 1' and 'SIP Server 2' sections are highlighted with a red box. The 'Outbound Proxy Server 1' and 'Outbound Proxy Server 2' fields are also visible.

SIP Server 1	
Server Host	192.168.1.14 Port: 5060
Transport	UDP
Server Expires	3600
Server Retry Counts	3

SIP Server 2	
Server Host	192.168.1.15 Port: 5060
Transport	UDP
Server Expires	3600
Server Retry Counts	3

Outbound Proxy Servers	
Enable Outbound Proxy Server	Enabled
Outbound Proxy Server 1	10.1.8.11 Port: 5060
Outbound Proxy Server 2	10.1.8.12 Port: 5060
Proxy Fallback Interval	3600
NAT	Disabled

NOTE: Account Registration registers account(s) for the IP phone. Server Redundancy: It is often required in VoIP deployments to ensure continuity of phone service, for events where the server needs to be taken offline for maintenance, the server fails, or the connection between the IP phone and the server fails. NAT Traversal: A general term for techniques that establish and maintain IP connections traversing NAT gateways. STUN is one of the NAT traversal techniques. You can configure NAT traversal for this account. You can click here to get more guides.

6. Click **Confirm** to accept the change.

To configure server redundancy for failover purpose via web user interface:

1. Click on **Account->Register**.
 2. Select the desired account from the pull-down list of **Account**.
 3. Configure registration parameters of the selected account in the corresponding fields.
 4. Configure parameters of the SIP server 1 or SIP server 2 in the corresponding fields.
- You must set the port of SIP server to 0 for NAPTR, SRV and A queries.

5. Select **DNS-NAPTR** from the pull-down list of **Transport**.

The screenshot shows the Yealink T236 web interface. The 'Account' tab is selected. The 'Account' section shows 'Account 1' is registered. The 'SIP Server 1' section is highlighted with a red box, showing the following configuration:

Field	Value
Server Host	yealink.pbx.com
Port	0
Transport	DNS-NAPTR
Server Expires	3600
Server Retry Counts	3

On the right, a 'NOTE' section contains information about Account Registration, Server Redundancy, and NAT Traversal.

6. If you use outbound proxy servers, do the following:
- 1) Select **Enabled** from the pull-down list of **Enable Outbound Proxy Server**.
 - 2) Configure parameters of outbound proxy server 1/2 in the corresponding fields.
- You must set the port of outbound proxy server to 0 for NAPTR, SRV and A queries.

The screenshot shows the Yealink T236 web interface. The 'Account' tab is selected. The 'SIP Server 1' section is highlighted with a red box, showing the same configuration as in the previous screenshot. Below it, the 'SIP Server 2' section is visible. At the bottom, the 'Enable Outbound Proxy Server' section is highlighted with a red box, showing the following configuration:

Field	Value
Enable Outbound Proxy Server	Enabled
Outbound Proxy Server 1	yealink.sbc.com
Port	0
Outbound Proxy Server 2	
Port	5060
Proxy Fallback Interval	3600
NAT	Disabled

At the bottom of the page, there are 'Confirm' and 'Cancel' buttons. The 'NOTE' section on the right is also visible.

7. Click **Confirm** to accept the change.

Server Domain Name Resolution

If a domain name is configured for a server, the IP address(es) associated with that domain name will be resolved through DNS as specified by RFC 3263. The DNS query involves NAPTR, SRV and A queries, which allows the IP phone to adapt to various deployment environments. The IP phone performs NAPTR query for the NAPTR pointer and transport protocol (UDP, TCP and TLS), the SRV query on the record returned from the NAPTR for the target domain name and the port number, and the A query for the IP addresses.

If an explicit port (except 0) is specified, A query will be performed only. If a server port is set to 0 and the transport type is set to DNS-NAPTR, NAPTR and SRV queries will be tried before falling to A query. If no port is found through the DNS query, 5060 will be used.

The following details the procedures of DNS query for the IP phone to resolve the domain name (e.g., yealink.pbx.com) of working server into the IP address, port and transport protocol.

NAPTR (Naming Authority Pointer)

First, the IP phone sends NAPTR query to get the NAPTR pointer and transport protocol.

Example of NAPTR records:

	order	pref	flags	service	regexp	replacement
IN NAPTR	90	50	"s"	"SIP+D2T"	""	_sip._tcp.yealink.pbx.com
IN NAPTR	100	50	"s"	"SIP+D2U"	""	_sip._udp.yealink.pbx.com

Parameters are explained in the following table:

Parameter	Description
order	Specify preferential treatment for the specific record. The order is from lowest to highest, lower order is more preferred.
pref	Specify the preference for processing multiple NAPTR records with the same order value. Lower value is more preferred.
Flags	The flag "s" means to perform an SRV lookup.
service	Specify the transport protocols: SIP+D2U: SIP over UDP SIP+D2T: SIP over TCP SIP+D2S: SIP over SCTP SIPS+D2T: SIPS over TCP
regexp	Always empty for SIP services.
replacement	Specify a domain name for the next query.

The IP phone picks the first record, because its order of 90 is lower than 100. The pref parameter is unimportant as there is no other record with order 90. The flag "s" indicates performing the SRV query next. TCP will be used, targeted to a host determined by an SRV query of "_sip._tcp.yealink.pbx.com". If the flag of the NAPTR record returned is empty, the IP phone will perform NAPTR query again according to the previous NAPTR query result.

SRV (Service Location Record)

The IP phone performs an SRV query on the record returned from the NAPTR for the host name and the port number. Example of SRV records:

	Priority	Weight	Port	Target
IN SRV	0	1	5060	server1.yealink.pbx.com
IN SRV	0	2	5060	server2.yealink.pbx.com

Parameters are explained in the following table:

Parameter	Description
Priority	Specify preferential treatment for the specific host entry. Lower priority is more preferred.
Weight	When priorities are equal, weight is used to differentiate the preference. The preference is from highest to lowest. Keep the same to load balance.
Port	Identify the port number to be used.
Target	Identify the actual host for an A query.

SRV query returns two records. The two SRV records point to different hosts and have the same priority 0. The weight of the second record is higher than the first one, so the second record will be picked first. The two records also contain a port "5060", the IP phone uses this port. If the Target is not a numeric IP address, the IP phone performs an A query. So in this case, the IP phone uses "server1.yealink.pbx.com" and "server2.yealink.pbx.com" for the A query.

A (Host IP Address)

The IP phone performs an A query for the IP address of each target host name. Example of A records:

```
Server1.yealink.pbx.com IN A    192.168.1.13
Server2.yealink.pbx.com IN A    192.168.1.14
```

The IP phone picks the IP address "192.168.1.14" first.

Outgoing Call When the Working Server Connection Fails

When a user initiates a call, the IP phone will go through the following steps to connect the call:

1. Sends the INVITE request to the primary server.
2. If the primary server does not respond correctly to the INVITE, then tries to make the call using the secondary server.
3. If the secondary server is also unavailable, the IP phone will try the fallback server until it either succeeds in making a call or exhausts all servers at which point the call will fail.

At the start of a call, server availability is determined by SIP signaling failure. SIP signaling failure depends on the SIP protocol being used as described below:

- If TCP is used, then the signaling fails if the connection or the send fails.
- If UDP is used, then the signaling fails if ICMP is detected or if the signal times out. If the signaling has been attempted through all servers in the list and this is the last server, then the signaling fails after the complete UDP timeout defined in [RFC 3261](#). If it is not the last server in the list, the maximum number of retries depends on the configured retry count.

Procedure

SIP Server Domain Name Resolution can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure the transport type on the IP phone. Parameters: account.X.sip_server.Y.transport_type account.X.naptr_build
Local	Web User Interface	Configure the transport type on the IP phone. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p=account-register&q=load&acc=0 For SIP VPT49G: http://<phoneIPAddress>/servlet

		?m=mod_data&p=account-register&q=load&acc=0
--	--	---

Details of Configuration Parameters:

Parameters	Permitted Values	Default
account.X.sip_server.Y.transport_type (X ranges from 1 to 16, Y ranges from 1 to 2)	0, 1, 2 or 3	0
Description: Configures the type of transport protocol for account X. 0 -UDP 1 -TCP 2 -TLS 3 -DNS-NAPTR If the value of the parameter is set to 3 (DNS-NAPTR) and no server port is given, the IP phone performs the DNS NAPTR and SRV queries for the service type and port. X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860)		
Web User Interface: Account->Register->SIP Server Y->Transport		
Phone User Interface: None		
account.X.naptr_build	0 or 1	0
Description: Configures the way of SRV query for the IP phone to be performed when no result is returned from NAPTR query for account X. 0 -SRV query using UDP only 1 -SRV query using UDP, TCP and TLS X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P)		

Parameters	Permitted Values	Default
X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Web User Interface: None Phone User Interface: None		

Static DNS Cache

Failover redundancy can only be utilized when the configured domain name of the server is resolved to multiple IP addresses. If the IP phone is not configured with a DNS server, or the DNS query returns no result from a DNS server, you can configure a set of DNS NAPTR/SRV/A records into the IP phone. The IP phone will attempt to resolve the domain name of the SIP server with static DNS cache.

When the IP phone is configured with a DNS server, the IP phone will behave as follows to resolve domain name of the server:

- The IP phone performs a DNS query to resolve the domain name from the DNS server.
- If the DNS query returns no results for the domain name, or the returned record cannot be contacted, the values in the static DNS cache (if configured) are used when their configured time intervals are not elapsed.
- If the configured time interval is elapsed, the IP phone will attempt to perform a DNS query again.
- If the DNS query returns a result, the IP phone will use the returned record and ignore the statically configured cache values.

When the IP phone is not configured with a DNS server, it will behave as follow:

- The IP phone attempts to resolve the domain name within the static DNS cache.
- The IP phone will always use the results returned from the static DNS cache.

IP phones can be configured to use static DNS cache preferentially. Static DNS cache is configurable on a per-line basis.

Procedure

Static DNS cache can be configured only using the configuration files.

Configuration File	<y0000000000xx>.cfg	Configure NAPTR/SRV/A records. Parameters: dns_cache_naptr.X.name dns_cache_naptr.X.flags dns_cache_naptr.X.order dns_cache_naptr.X.preference dns_cache_naptr.X.replace dns_cache_naptr.X.service dns_cache_naptr.X.ttl dns_cache_srv.X.name dns_cache_srv.X.port dns_cache_srv.X.priority dns_cache_srv.X.target dns_cache_srv.X.weight dns_cache_srv.X.ttl dns_cache_a.X.name dns_cache_a.X.ip dns_cache_a.X.ttl
	<MAC>.cfg	Configure the IP phone whether to cache the additional DNS records. Parameter: account.X.dns_cache_type
		Configure the IP phone whether to use static DNS cache preferentially. Parameter: account.X.static_cache_pri

Details of Configuration Parameters:

Parameters	Permitted Values	Default
dns_cache_naptr.X.name (X ranges from 1 to 12)	Domain name	Blank
Description:		

Parameters	Permitted Values	Default
<p>Configures the domain name to which NAPTR record X refers.</p> <p>Example:</p> <p>dns_cache_naptr.1.name = yealink.pbx.com</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		
<p>dns_cache_naptr.X.flags</p> <p>(X ranges from 1 to 12)</p>	S, A, U or P	Blank
<p>Description:</p> <p>Configures the flag of NAPTR record X. (Always “S” for SIP, which means to do an SRV lookup on whatever is in the replacement field).</p> <p>S-Do an SRV lookup next</p> <p>A-Do an A lookup next</p> <p>U-No need to do a DNS query next</p> <p>P-Service custom by the user</p> <p>Example:</p> <p>dns_cache_naptr.1.flags = S</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		
<p>dns_cache_naptr.X.order</p> <p>(X ranges from 1 to 12)</p>	Integer from 0 to 65535	0
<p>Description:</p> <p>Configures the order of NAPTR record X.</p> <p>NAPTR record with lower order is more preferred.</p> <p>Example:</p> <p>dns_cache_naptr.1.order = 90</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		

Parameters	Permitted Values	Default
dns_cache_naptr.X.preference (X ranges from 1 to 12)	Integer from 0 to 65535	0
Description: Configures the preference of NAPTR record X. NAPTR record with lower preference is more preferred. Example: dns_cache_naptr.1.preference = 50 Web User Interface: None Phone User Interface: None		
dns_cache_naptr.X.replace (X ranges from 1 to 12)	Domain name	Blank
Description: Configures a domain name to be used for the next SRV query in NAPTR record X. Example: dns_cache_naptr.1.replace = _sip_tcp.yealink.pbx.com Web User Interface: None Phone User Interface: None		
dns_cache_naptr.X.service (X ranges from 1 to 12)	String within 32 characters	Blank
Description: Configures the transport protocol available for the server in NAPTR record X. SIP+D2U: SIP over UDP SIP+D2T: SIP over TCP SIP+D2S: SIP over SCTP SIPS+D2T: SIPS over TCP Example: dns_cache_naptr.1.service = SIP+D2T Web User Interface:		

Parameters	Permitted Values	Default
None Phone User Interface: None		
dns_cache_naptr.X.ttl (X ranges from 1 to 12)	Integer from 30 to 2147483647	300
Description: Configures the time interval (in seconds) that NAPTR record X may be cached before the record should be consulted again. Example: dns_cache_naptr.1.ttl = 3600 Web User Interface: None Phone User Interface: None		
dns_cache_srv.X.name (X ranges from 1 to 12)	Domain name	Blank
Description: Configures the domain name in SRV record X. Example: dns_cache_srv.1.name = _sip._tcp.yealink.pbx.com Web User Interface: None Phone User Interface: None		
dns_cache_srv.X.port (X ranges from 1 to 12)	Integer from 0 to 65535	0
Description: Configures the port to be used in SRV record X. Example: dns_cache_srv.1.port = 5060 Web User Interface: None		

Parameters	Permitted Values	Default
Phone User Interface: None		
dns_cache_srv.X.priority (X ranges from 1 to 12)	Integer from 0 to 65535	0
Description: Configures the priority for the target host in SRV record X. Lower priority is more preferred. Web User Interface: None Phone User Interface: None		
dns_cache_srv.X.target (X ranges from 1 to 12)	Domain name	Blank
Description: Configures the domain name of the target host for an A query in SRV record X. Example: dns_cache_srv.1.target = server1.yealink.pbx.com Web User Interface: None Phone User Interface: None		
dns_cache_srv.X.weight (X ranges from 1 to 12)	Integer from 0 to 65535	0
Description: Configures the weight of the target host in SRV record X. When priorities are equal, weight is used to differentiate the preference. Higher weight is more preferred. Example: dns_cache_srv.1.weight = 1 Web User Interface: None Phone User Interface:		

Parameters	Permitted Values	Default
None		
dns_cache_srv.X.ttl (X ranges from 1 to 12)	Integer from 30 to 2147483647	300
<p>Description: Configures the time interval (in seconds) that SRV record X may be cached before the record should be consulted again.</p> <p>Example: dns_cache_srv.1.ttl = 3600</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		
dns_cache_a.X.name (X ranges from 1 to 12)	Domain name	Blank
<p>Description: Configures the domain name in A record X.</p> <p>Example: dns_cache_a.1.name = yealink.pbx.com</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		
dns_cache_a.X.ip (X ranges from 1 to 12)	IP address	Blank
<p>Description: Configures the IP address that the domain name in A record X maps to.</p> <p>Example: dns_cache_a.1.ip = 192.168.1.13</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		

Parameters	Permitted Values	Default
dns_cache_a.X.ttl (X ranges from 1 to 12)	Integer from 30 to 2147483647	300
Description: Configures the time interval (in seconds) that A record X may be cached before the record should be consulted again. Example: dns_cache_a.1.ttl = 3600 Web User Interface: None Phone User Interface: None		
account.X.dns_cache_type	0, 1 or 2	1
Description: Configures whether the IP phone uses the DNS cache for domain name resolution of the server and caches the additional DNS records for account X. 0 -Perform real-time DNS query rather than using DNS cache. 1 -Use DNS cache, but do not cache the additional DNS records. 2 -Use DNS cache and cache the additional DNS records. X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Example: account.1.dns_cache_type = 1 Web User Interface: None Phone User Interface: None		
account.X.static_cache_pri	0 or 1	0

Parameters	Permitted Values	Default
<p>Description:</p> <p>Configures whether preferentially to use the static DNS cache for domain name resolution of the server for account X.</p> <p>0-Use domain name resolution from the DNS server preferentially</p> <p>1-Use static DNS cache preferentially</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Example:</p> <p>account.1.static_cache_pri = 1</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		

VLAN

VLAN (Virtual Local Area Network) is used to logically divide a physical network into several broadcast domains. VLAN membership can be configured through software instead of physically relocating devices or connections. Grouping devices with a common set of requirements regardless of their physical location can greatly simplify network design. VLANs can address issues such as scalability, security and network management.

The purpose of VLAN configurations on the IP phone is to insert tag with VLAN information to the packets generated by the IP phone. When VLAN is properly configured for the ports (Internet port and PC port) on the IP phone, the IP phone will tag all packets from these ports with the VLAN ID. The switch receives and forwards the tagged packets to the corresponding VLAN according to the VLAN ID in the tag as described in IEEE Std 802.3.

VLAN on IP phones allows simultaneous access for a regular PC. This feature allows a PC to be daisy chained to an IP phone and the connection for both PC and IP phone to be trunked through the same physical Ethernet cable.

In addition to manual configuration, the IP phone also supports automatic discovery of VLAN via LLDP, CDP or DHCP. The assignment takes effect in this order: assignment via LLDP/CDP, manual configuration, then assignment via DHCP.

For more information on VLAN, refer to [VLAN Feature on Yealink IP Phones](#).

VLAN assignment method can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the VLAN assignment method. Parameter: network.vlan.vlan_change.enable
---------------------------	---------------------	---

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.vlan.vlan_change.enable	0 or 1	0
<p>Description:</p> <p>Enables or disables the IP phone to obtain VLAN ID using lower priority of VLAN assignment method or disable VLAN feature when the IP phone cannot obtain VLAN ID using the current VLAN assignment method.</p> <p>0-Disabled 1-Enabled</p> <p>The priority of each method is: LLDP/CDP>Manual>DHCP VLAN.</p> <p>If it is set to 1 (Enabled), the IP phone will attempt to use the lower priority of VLAN assignment method when failing to obtain the VLAN ID using higher priority of VLAN assignment method. If all the methods are attempted, the phone will disable VLAN feature.</p> <p>Note: If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		

LLDP

LLDP (Linker Layer Discovery Protocol) is a vendor-neutral Link Layer protocol, which allows IP phones to receive and/or transmit device-related information from/to directly

connected devices on the network that are also using the protocol, and store the information about other devices.

When LLDP feature is enabled on IP phones, the IP phones periodically advertise their own information to the directly connected LLDP-enabled switch. The IP phones can also receive LLDP packets from the connected switch. When the application type is “voice”, IP phones decide whether to update the VLAN configurations obtained from the LLDP packets. When the VLAN configurations on the IP phones are different from the ones sent by the switch, the IP phones perform an update and reboot. This allows the IP phones to be plugged into any switch, obtain their VLAN IDs, and then start communications with the call control.

Procedure

LLDP can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure LLDP. Parameters: network.lldp.enable network.lldp.packet_interval
Local	Web User Interface	Configure LLDP. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29 G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=network-adv&q=load">http://<phoneIPAddress>/servlet? p=network-adv&q=load For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=network-adv&q=load">http://<phoneIPAddress>/servlet? m=mod_data&p=network-adv&q=load
	Phone User Interface	Configure LLDP feature.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.lldp.enable	0 or 1	1
Description: Enables or disables the LLDP (Linker Layer Discovery Protocol) feature on the IP phone.		

Parameters	Permitted Values	Default
0-Disabled 1-Enabled Note: If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Network->Advanced->LLDP->Active Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->LLDP->LLDP Status		
network.lldp.packet_interval	Integer from 1 to 3600	60
Description: Configures the interval (in seconds) for the IP phone to send the LLDP (Linker Layer Discovery Protocol) request. Note: It works only if the value of the parameter "network.lldp.enable" is set to 1 (Enabled). If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Network->Advanced->LLDP->Packet Interval (1~3600s) Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->LLDP->Packet Interval		

To configure LLDP via web user interface:

1. Click on **Network->Advanced**.
2. In the **LLDP** block, select the desired value from the pull-down list of **Active**.

- Enter the desired time interval in the **Packet Interval (1~3600s)** field.

The screenshot shows the Yealink T236 web interface. The 'Network' tab is selected, and the 'LLDP' configuration page is displayed. The 'Active' dropdown is set to 'Enabled' and the 'Packet Interval (1~3600s)' field is set to '60'. The 'CDP' section shows 'Active' as 'Disabled' and 'Packet Interval (1~3600s)' as '60'. The 'VLAN' section shows 'WAN Port' and 'PC Port' both set to 'Active', with 'VID (1-4094)' set to '1' and 'Priority' set to '0'. A 'NOTE' box on the right explains VLAN and NAT Traversal.

- Click **Confirm** to accept the change.

A dialog box pops up to prompt that settings will take effect after a reboot.

- Click **OK** to reboot the phone.

To configure LLDP feature via phone user interface:

- Press **Menu->Settings->Advanced Settings (default password: admin)**
->**Network->LLDP->LLDP Status**.
- Press **←** or **→**, or the **Switch** soft key to select the desired value from the **LLDP Status** field.
- Enter the priority value (1-3600s) in the **Packet Interval** field.
- Press the **Save** soft key to accept the change.

The IP phone reboots automatically to make settings effective after a period of time.

CDP

CDP (Cisco Discovery Protocol) allows IP phones to receive and/or transmit device-related information from/to directly connected devices on the network that are also using the protocol, and store the information about other devices.

When CDP feature is enabled on IP phones, the IP phones periodically advertise their own information to the directly connected CDP-enabled switch. The IP phones can also receive CDP packets from the connected switch. When the VLAN configurations on the IP phones are different from the ones sent by the switch, the IP phones perform an update and reboot. This allows the IP phones to be plugged into any switch, obtain their VLAN IDs, and then start communications with the call control.

Procedure

CDP can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure CDP.
--------------------	---------------------	----------------

		Parameters: network.cdp.enable network.cdp.packet_interval
Local	Web User Interface	Configure CDP. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T 29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servle t?p=network-adv&q=load For SIP VP-T49G: http://<phoneIPAddress>/servle t?m=mod_data&p=network-ad v&q=load
	Phone User Interface	Configure CDP feature.


Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.cdp.enable	0 or 1	0
Description: Enables or disables the CDP (Cisco Discovery Protocol) feature on the IP phone. 0 -Disabled 1 -Enabled Note: If it is set to 1, the IP phone will attempt to determine its VLAN ID through CDP. If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Network->Advanced->CDP->Active Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->CDP->CDP Status		
network.cdp.packet_interval	Integer from 1 to 3600	60
Description: Configures the interval (in seconds) for the IP phone to send the CDP (Cisco		

Parameters	Permitted Values	Default
<p>Discovery Protocol) request.</p> <p>Note: It works only if the value of the parameter “network.cdp.enable” is set to 1 (Enabled). If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Network->Advanced->CDP->Packet Interval (1~3600s)</p> <p>Phone User Interface:</p> <p>Menu->Settings->Advanced Settings (default password: admin)</p> <p>->Network->CDP->Packet Interval</p>		

To configure CDP via web user interface:

1. Click on **Network->Advanced**.
2. In the **CDP** block, select the desired value from the pull-down list of **Active**.
3. Enter the desired time interval in the **Packet Interval (1~3600s)** field.



4. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
5. Click **OK** to reboot the phone.

To configure CDP feature via phone user interface:

1. Press **Menu->Settings->Advanced Settings (default password: admin)**
->**Network->CDP->CDP Status**.
2. Press **◀** or **▶**, or the **Switch** soft key to select the desired value from the **CDP Status** field.
3. Enter the priority value (1-3600s) in the **Packet Interval** field.
4. Press the **Save** soft key to accept the change.
The IP phone reboots automatically to make settings effective after a period of time.

Manual Configuration for VLAN in the Wired Network

VLAN is disabled on IP phones by default. You can configure VLAN for the Internet port and PC port manually. For CP860 IP phones, you can only configure VLAN for the Internet port manually, because they only have Internet port. Before configuring VLAN on the IP phone, you need to obtain the VLAN ID from your network administrator.

Procedure

VLAN can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	<p>Configure VLAN for the Internet port and PC port manually.</p> <p>Parameters:</p> <p>network.vlan.internet_port_enable</p> <p>network.vlan.internet_port_vid</p> <p>network.vlan.internet_port_priority</p> <p>network.vlan.pc_port_enable</p> <p>network.vlan.pc_port_vid</p> <p>network.vlan.pc_port_priority</p>
Local	Web User Interface	<p>Configure VLAN for the Internet port and PC port manually.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p><a href="http://<phoneIPAddress>/servlet?p=network-adv&q=load">http://<phoneIPAddress>/servlet?p=network-adv&q=load</p> <p>For SIP VP-T49G:</p> <p><a href="http://<phoneIPAddress>/servlet?m=mod_data&p=network-adv&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=network-adv&q=load</p>
	Phone User Interface	<p>Configure VLAN for the Internet port and PC port manually.</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.vlan.internet_port_enable	0 or 1	0
Description: Enables or disables VLAN for the Internet (WAN) port. 0 -Disabled 1 -Enabled Note: If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Network->Advanced->VLAN->WAN Port->Active Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->VLAN->WAN Port->VLAN Status		
network.vlan.internet_port_vid	Integer from 1 to 4094	1
Description: Configures VLAN ID for the Internet (WAN) port. Note: If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Network->Advanced->VLAN->WAN Port->VID (1-4094) Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->VLAN->WAN Port->VID		
network.vlan.internet_port_priority	Integer from 0 to 7	0
Description: Configures VLAN priority for the Internet (WAN) port. 7 is the highest priority, 0 is the lowest priority. Note: If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Network->Advanced->VLAN->WAN Port->Priority		

Parameters	Permitted Values	Default
Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->VLAN->WAN Port->Priority		
network.vlan.pc_port_enable	0 or 1	0
Description: Enables or disables VLAN for the PC (LAN) port. 0 -Disabled 1 -Enabled Note: It is not applicable to CP860 IP phones. If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Network->Advanced->VLAN->PC Port->Active Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->VLAN->PC Port->VLAN Status		
network.vlan.pc_port_vid	Integer from 1 to 4094	1
Description: Configures VLAN ID for the PC (LAN) port. Note: It is not applicable to CP860 IP phones. If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Network->Advanced->VLAN->PC Port->VID (1-4094) Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->VLAN->PC Port->VID		
network.vlan.pc_port_priority	Integer from 0 to 7	0
Description: Configures VLAN priority for the PC (LAN) port. 7 is the highest priority, 0 is the lowest priority. Note: It is not applicable to CP860 IP phones. If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface:		

Parameters	Permitted Values	Default
Network->Advanced->VLAN >PC Port->Priority Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->VLAN->PC Port->Priority		

To configure VLAN for Internet port via web user interface:

1. Click on **Network->Advanced**.
2. In the **VLAN** block, select the desired value from the pull-down list of **WAN Port Active**.
3. Enter the VLAN ID in the **VID (1-4094)** field.
4. Select the desired value (0-7) from the pull-down list of **Priority**.

The screenshot shows the Yealink T23G web interface. The 'Network' tab is selected, and the 'VLAN' configuration page is displayed. The 'VLAN' section is highlighted with a red box, showing the following settings:

- WAN Port:**
 - Active: Enabled
 - VID (1-4094): 1
 - Priority: 0
- PC Port:**
 - Active: Disabled
 - VID (1-4094): 1
 - Priority: 0

A 'NOTE' box on the right provides additional information:

VLAN
It is used to logically divide a physical network into several broadcast domains. VLAN membership can be configured through software instead of physically relocating devices or connections.

The priority of VLAN assignment method (from highest to lowest): LLDP/CDP->manual configuration->DHCP VLAN

NAT Traversal
It is a general term for techniques that establish and maintain IP connections traversing NAT gateways. STUN is one of the NAT traversal techniques.

You can configure NAT traversal for the IP phone.

5. Click **Confirm** to accept the change.
A dialog box pops up to prompt that the settings will take effect after a reboot.
6. Click **OK** to reboot the phone.

To configure VLAN for PC port via web user interface:

1. Click on **Network->Advanced**.
2. In the **VLAN** block, select the desired value from the pull-down list of **PC Port Active**.
3. Enter the VLAN ID in the **VID (1-4094)** field.

- Select the desired value (0-7) from the pull-down list of **Priority**.

The screenshot shows the Yealink T236 web interface. The 'Network' tab is selected, and the 'VLAN' configuration page is displayed. The 'PC Port' section is highlighted with a red box. It contains the following fields:

- Active:** Enabled (dropdown)
- VID (1-4094):** 1 (text input)
- Priority:** 0 (dropdown)

Other visible fields include:

- LLDP:** Active (Enabled), Packet Interval (1-3600s) (60)
- CDP:** Active (Enabled), Packet Interval (1-3600s) (60)
- VLAN:** WAN Port (Active, Enabled), VID (1-4094) (1), Priority (0)
- DHCP VLAN:** Active (Enabled), Option (1-255) (132)

A 'NOTE' section on the right explains VLAN usage and NAT Traversal.

- Click **Confirm** to accept the change.

A dialog box pops up to prompt that the settings will take effect after a reboot.

- Click **OK** to reboot the phone.

To configure VLAN for Internet port (or PC port) via phone user interface:

- Press **Menu->Settings->Advanced Settings** (default password: admin) **->Network->VLAN->WAN Port (or PC Port)**.
- Press **◀** or **▶**, or the **Switch** soft key to select the desired value from the **VLAN Status** field.
- Enter the VLAN ID (1-4094) in the **VID** field.
- Enter the priority value (0-7) in the **Priority** field.
- Press the **Save** soft key to accept the change.

The IP phone reboots automatically to make settings effective after a period of time.

DHCP VLAN

IP phones support VLAN discovery via DHCP. When the VLAN Discovery method is set to DHCP, the IP phone will examine DHCP option for a valid VLAN ID. The predefined option 132 is used to supply the VLAN ID by default. You can customize the DHCP option used to request the VLAN ID.

Procedure

DHCP VLAN can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure DHCP VLAN discovery feature.
---------------------------	---------------------	--

		Parameters: network.vlan.dhcp_enable network.vlan.dhcp_option
Local	Web User Interface	Configure DHCP VLAN discovery feature. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?<p=network-adv&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet?<m=mod_data&p=network-adv&q=load
	Phone User Interface	Configure DHCP VLAN discovery feature.


Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.vlan.dhcp_enable	0 or 1	1
Description: Enables or disables DHCP VLAN discovery feature on the IP phone. 0 -Disabled 1 -Enabled Note: If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Network->Advanced->VLAN->DHCP VLAN->Active Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->VLAN->DHCP VLAN->DHCP VLAN		
network.vlan.dhcp_option	Integer from 1 to 255	132
Description:		

Parameters	Permitted Values	Default
<p>Configures the DHCP option from which the IP phone will obtain the VLAN settings. You can configure at most five DHCP options and separate them by commas.</p> <p>Note: If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Network->Advanced->VLAN->DHCP VLAN->Option (1-255)</p> <p>Phone User Interface:</p> <p>Menu->Settings->Advanced Settings (default password: admin) ->Network->VLAN->DHCP VLAN->Option</p>		

To configure DHCP VLAN discovery via web user interface:

1. Click on **Network->Advanced**.
2. In the **VLAN** block, select the desired value from the pull-down list of **DHCP VLAN Active**.
3. Enter the desired option in the **Option (1-255)** field.
The default option is 132.



4. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
5. Click **OK** to reboot the phone.

To configure DHCP VLAN discovery via phone user interface:

1. Press **Menu->Settings->Advanced Settings** (default password: admin)
->**Network->VLAN->DHCP VLAN**.
2. Press **◀** or **▶**, or the **Switch** soft key to select the desired value from the **DHCP VLAN** field.

3. Enter the desired option in the **Option** field.
4. Press the **Save** soft key to accept the change.

The IP phone reboots automatically to make settings effective after a period of time.

Configuring VLAN Feature in the Wireless Network

Yealink IP phones support VLAN in the wireless network. This feature is disabled by default. The method that the phones use to obtain VLAN in the wireless network is the same as the one in the wired network. It is only applicable to SIP VP-T49G IP phones.

For more information on wireless network, refer to [Wi-Fi](#) on page 139.

Procedure

VLAN can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure VLAN feature in the wireless network. Parameters: wifi.vlan_enable network.vlan.wifi_enable network.vlan.wifi_vid network.vlan.wifi_priority
---------------------------	---------------------	--

Details of the Configuration Parameter:


wifi.vlan_enable	0 or 1	0
Description: Enables or disables VLAN discovery feature in the wireless network for the IP phone. 0-Disabled 1-Enabled If it is set to 1 (Enabled), the IP phone supports manual configuration of VLAN feature in the wireless network or automatic discovery of VLAN feature in the wireless network via LLDP/CDP/DHCP VLAN. The assignment takes effect in this order: assignment via LLDP/CDP, manual configuration, then assignment via DHCP. Note: If you change this parameter, the IP phone will reboot to make the change take effect. It is only applicable to SIP VP-T49G IP phones. Web User Interface: None Phone User Interface:		

None		
network.vlan.wifi_enable	0 or 1	0
<p>Description:</p> <p>Enables or disables manual configuration of VLAN feature in the wireless network for the IP phone.</p> <p>0-Disabled 1-Enabled</p> <p>Note: It works only if the value of the parameter "wifi.vlan_enable" is set to 1 (Enabled). If you change this parameter, the IP phone will reboot to make the change take effect. It is only applicable to SIP VP-T49G IP phones.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		
network.vlan.wifi_vid	Integer from 1 to 4094	1
<p>Description:</p> <p>Configures VLAN ID in the wireless network for the IP phone.</p> <p>Note: It works only if the value of the parameter "wifi.vlan_enable" is set to 1 (Enabled). If you change this parameter, the IP phone will reboot to make the change take effect. It is only applicable to SIP VP-T49G IP phones.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		
network.vlan.wifi_priority	Integer from 0 to 7	0
<p>Description:</p> <p>Configures VLAN priority in the wireless network for the IP phone.</p> <p>7 is the highest priority, 0 is the lowest priority.</p> <p>Note: It works only if the value of the parameter "wifi.vlan_enable" is set to 1 (Enabled). If you change this parameter, the IP phone will reboot to make the change take effect. It is only applicable to SIP VP-T49G IP phones.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p>		

None

VPN

VPN (Virtual Private Network) is a secured private network connection built on top of public telecommunication infrastructure, such as the Internet. It has become more prevalent due to benefits of scalability, reliability, convenience and security. VPN provides remote offices or individual users with secure access to their organization's network.



Types of VPN Access

There are two types of VPN access: remote-access VPN (connecting an individual device to a network) and site-to-site VPN (connecting two networks together). Remote-access VPN allows employees to access their company's intranet from home or outside the office, and site-to-site VPN allows employees in geographically separated offices to share one cohesive virtual network. VPN can be also classified by the protocols used to tunnel the traffic. It provides security through tunneling protocols: IPSec, SSL, L2TP and PPTP.

VPN Technology

IP phones support SSL VPN, which provides remote-access VPN capabilities through SSL. OpenVPN is a full featured SSL VPN software solution that creates secure connections in remote access facilities, designed to work with the TUN/TAP virtual network interface. TUN and TAP are virtual network kernel devices. TAP simulates a link layer device and provides a virtual point-to-point connection, while TUN simulates a network layer device and provides a virtual network segment.

IP phones use OpenVPN to achieve VPN feature. To prevent disclosure of private information, tunnel endpoints must authenticate each other before secure VPN tunnel is established. After VPN feature is configured properly on the IP phone, the IP phone acts as a VPN client and uses the certificates to authenticate the VPN server.

To use VPN, the compressed package of VPN-related files should be uploaded to the IP phone in advance. The file format of the compressed package must be *.tar. The related VPN files are: certificates (ca.crt and client.crt), key (client.key) and the configuration file (vpn.cnf) of the VPN client.

The following table lists the unified directories of the OpenVPN certificates and key in the configuration file (vpn.cnf) for Yealink IP phones:

VPN files	Description	Unified Directories
ca.crt	CA certificate	/config/openvpn/keys/ca.crt
client.crt	Server certificate	/config/openvpn/keys/client.crt
client.key	Private key of the client	/config/openvpn/keys/client.key

For more information, refer to [OpenVPN Feature on Yealink IP phones](#).

Note

VPN is not applicable to SIP-T19(P) E2 IP phones.

Procedure

VPN can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure VPN feature and upload a TAR file to the IP phone. Parameters: network.vpn_enable openvpn.url
Local	Web User Interface	Configure VPN feature and upload a TAR package to the IP phone. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?pnetwork-adv&q=load">http://<phoneIPAddress>/servlet?pnetwork-adv&q=load For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?mod_data&p=network-adv&q=load">http://<phoneIPAddress>/servlet?mod_data&p=network-adv&q=load
	Phone User Interface	Configure VPN feature.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.vpn_enable	0 or 1	0
<p>Description: Enables or disables OpenVPN feature on the IP phone. 0-Disabled 1-Enabled Note: If you change this parameter, the IP phone will reboot to make the change take effect. It is not applicable to SIP-T19(P) E2 IP phones.</p> <p>Web User Interface: Network->Advanced->VPN->Active</p> <p>Phone User Interface: Menu->Settings->Advanced Settings (default: admin) ->Network->VPN->VPN Active</p>		
openvpn.url	URL within 511 characters	Blank
<p>Description: Configures the access URL of the *.tar file for OpenVPN.</p> <p>Example: openvpn.url = http://192.168.10.25/OpenVPN.tar</p> <p>Note: It is not applicable to SIP-T19(P) E2 IP phones.</p> <p>Web User Interface: Network->Advanced->VPN->Upload VPN Config</p> <p>Phone User Interface: None</p>		

To upload a TAR file and configure VPN via web user interface:

1. Click on **Network->Advanced**.
2. Click **Browse** to locate the TAR file from the local system.

- Click **Upload** to upload the TAR file.

The screenshot shows the Yealink T236 web interface. The 'Network' tab is selected. Under the 'VPN' section, the 'Active' status is set to 'Enabled'. The 'Upload VPN Config' button is highlighted with a red box, and the 'Upload' button is also highlighted. The 'Web Server' section shows 'HTTP' and 'HTTPS' ports. The 'NOTE' section on the right provides information about VLAN, NAT Traversal, Quality of Service (QoS), Web Server Type, and 802.1X Authentication.

The web user interface prompts the message “Import config...”.

- In the **VPN** block, select the desired value from the pull-down list of **Active**.
- Click **Confirm** to accept the change.

A dialog box pops up to prompt that settings will take effect after a reboot.

- Click **OK** to reboot the phone.

To configure VPN via phone user interface after uploading a TAR file:

- Press **Menu->Settings->Advanced Settings** (default password: admin) **->Network->VPN**.
- Press **◀** or **▶**, or the **Switch** soft key to select the desired value from the **VPN Active** field.

You must upload the OpenVPN TAR file using configuration files or via web user interface in advance.

- Press the **Save** soft key to accept the change.

The IP phone reboots automatically to make settings effective after a period of time.

Voice Quality Monitoring

Voice quality monitoring feature allows the IP phones to generate various quality metrics for listening quality and conversational quality. These metrics can be sent between the phones in RTCP-XR packets. These metrics can also be sent in SIP PUBLISH

messages to a central voice quality report collector. Two mechanisms for voice quality monitoring are supported by Yealink IP phones:

- RTCP-XR
- VQ-RTCPXR

RTCP-XR

The RTCP-XR mechanism, compliant with [RFC 3611-RTP Control Extended Reports \(RTCP XR\)](#), provides the metrics contained in RTCP-XR packets for monitoring the quality of calls. These metrics include network packet loss, delay metrics, analog metrics and voice quality metrics.

Procedure

RTCP-XR can be configured using the configuration files.

Configuration File	<y0000000000xx>.cfg	Configure RTCP-XR. Parameter: voice.rtcp_xr.enable phone_setting.rtcp_xr_report.enable
Local	Web User Interface	Configure RTCP-XR. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/ T27P/T23P/T23G/T21(P) E2/T19(P) E2: http://<phoneIPAddress>/servlet?p= settings-voicemonitoring&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
voice.rtcp_xr.enable	0 or 1	0
Description: Enables or disables the IP phone to send RTCP-XR packets. 0 -Disabled 1 -Enabled Note: If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface:		

Parameters	Permitted Values	Default
Settings->Voice Monitoring->Voice RTCP-XR Report Note: For SIP VP-T49G and CP860 IP phones, you cannot configure this feature via web user interface. Phone User Interface: None		
phone_setting.rtcp_xr_report.enable	0 or 1	0
Description: Enables or disables the IP phone to periodically (every 5 seconds) send RTCP-XR packets to another participating phone during a call for call quality monitoring and diagnosing. 0-Disabled 1-Enabled Note: It works only if the value of the parameter "voice.rtcp_xr.enable" is set to 1 (Enabled). If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Settings->Voice Monitoring->Settings RTCP-XR Report Note: For SIP VP-T49G and CP860 IP phones, you cannot configure this feature via web user interface. Phone User Interface: None		

To configure RTCP-XR feature via web user interface:

1. Click on **Settings->Voice Monitoring**.
2. Select the desired value from the pull-down list of **Settings RTCP-XR Report**.

3. Select the desired value from the pull-down list of **Voice RTCP-XR Report**.

The screenshot shows the Yealink T236 web interface. The 'Settings' tab is selected. On the left sidebar, 'Voice Monitoring' is highlighted. The main content area shows the 'Voice RTCP-XR Report' configuration. The 'Settings RTCP-XR Report' and 'Voice RTCP-XR Report' are both set to 'Enabled'. Below this, there is a section for 'Report options on phone' with two lists: 'Disabled' (RoundTripDelay, SymmOneWayDelay) and 'Enabled' (Start Time, Current Time, Local User, Remote User, Local Codec, Remote Codec, Jitter, JitterBufferMax, Packets Lost, MOS-LQ). A 'NOTE' box on the right explains the Voice Quality Monitoring mechanism.

4. Click **Confirm** to accept the change.
A dialog box pops up to prompt that the settings will take effect after a reboot.
5. Click **OK** to reboot the phone.

VQ-RTCPXR

The VQ-RTCPXR mechanism, compliant with [RFC 6035](#), sends the service quality metric reports contained in SIP PUBLISH messages to the central report collector. Three types of quality reports can be enabled:

- **Session:** Generated at the end of a call.
- **Interval:** Generated during a call at a configurable period.
- **Alert:** Generated when the call quality degrades below a configurable threshold.

A wide range of performance metrics are generated in the following three ways:

- Based on current values, such as jitter, jitter buffer max and round trip delay.
- Covers the time period from the beginning of the call until the report is sent, such as network packet loss.
- Computed using other metrics as input, such as listening Mean Opinion Score (MOS-LQ) and conversational Mean Opinion Score (MOS-CQ).

To operate with central report collector, IP phones must be configured to forward their voice quality reports to the specified report collector. You can specify the report collector on a per-line basis.

Users can check the voice quality data of the last call via web user interface or phone user interface. Users can also specify the options of the RTP status to be displayed on the phone user interface. Options of the RTP status to be displayed on the web user interface cannot be specified.

Procedure

VQ-RTCPXR can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	<p>Configure the generation of session packets.</p> <p>Parameter:</p> <p>phone_setting.vq_rtcpxr.session_report.enable</p>
		<p>Configure the generation of interval packets.</p> <p>Parameters:</p> <p>phone_setting.vq_rtcpxr.interval_report.enable</p> <p>phone_setting.vq_rtcpxr_interval_period</p>
		<p>Configure the generation of alert packets.</p> <p>Parameters:</p> <p>phone_setting.vq_rtcpxr_moslq_threshold_warning</p> <p>phone_setting.vq_rtcpxr_moslq_threshold_critical</p> <p>phone_setting.vq_rtcpxr_delay_threshold_warning</p> <p>phone_setting.vq_rtcpxr_delay_threshold_critical</p>
		<p>Configure the phone to display RTP status showing the voice quality report of the last call on the web user interface.</p> <p>Parameter:</p> <p>phone_setting.vq_rtcpxr.states_show_on_web.enable</p>

		<p>Configure the phone to display RTP status showing the voice quality report of the last call or the current call on the phone user interface.</p> <p>Parameter:</p> <p>phone_setting.vq_rtcp_xr.states_show_on_gui.enable</p>
		<p>Configure the options of the RTP status displayed on the phone user interface.</p> <p>Parameters:</p> <p>phone_setting.vq_rtcp_xr_display_start_time.enable</p> <p>phone_setting.vq_rtcp_xr_display_stop_time.enable</p> <p>phone_setting.vq_rtcp_xr_display_local_call_id.enable</p> <p>phone_setting.vq_rtcp_xr_display_remote_call_id.enable</p> <p>phone_setting.vq_rtcp_xr_display_local_codec.enable</p> <p>phone_setting.vq_rtcp_xr_display_remote_codec.enable</p> <p>phone_setting.vq_rtcp_xr_display_jitter.enable</p> <p>phone_setting.vq_rtcp_xr_display_jitter_buffer_max.enable</p> <p>phone_setting.vq_rtcp_xr_display_packets_lost.enable</p> <p>phone_setting.vq_rtcp_xr_display_symm_oneway_delay.enable</p> <p>phone_setting.vq_rtcp_xr_display_round_trip_delay.enable</p> <p>phone_setting.vq_rtcp_xr_display_mos_lq.enable</p> <p>phone_setting.vq_rtcp_xr_display_mos_cq.enable</p>
	<MAC>.cfg	<p>Configure the central report collector.</p> <p>Parameters:</p> <p>account.X.vq_rtcp_xr.collector_name</p>

		account.X.vq_rtcp_xr.collector_server_host account.X.vq_rtcp_xr.collector_server_port
Local	Web User Interface	<p>Configure VQ-RTCPXR.</p> <p>Configure the phone to display RTP status showing the voice quality report of the last call on the web user interface.</p> <p>Configure the phone to display RTP status showing the voice quality report of the last call or the current call on the phone user interface.</p> <p>Configure the options of the RTP status displayed on the phone user interface.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=settings-voicemonitoring&q=load">http://<phoneIPAddress>/servlet?p=settings-voicemonitoring&q=load</p> <p>For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=settings-voicemonitoring&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=settings-voicemonitoring&q=load</p> <p>Configure the central report collector.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0">http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0</p> <p>For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0">http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
phone_setting.vq_rtcp_xr.session_report.enable	0 or 1	0

Parameters	Permitted Values	Default
Description: Enables or disables the IP phone to send a session quality report to the central report collector at the end of each call. 0-Disabled 1-Enabled Web User Interface: Settings->Voice Monitoring->VQ RTCP-XR Session Report Phone User Interface: None		
phone_setting.vq_rtcp_xr.interval_report.enable	0 or 1	0
Description: Enables or disables the IP phone to send an interval quality report to the central report collector periodically throughout a call. 0-Disabled 1-Enabled Web User Interface: Settings->Voice Monitoring->VQ RTCP-XR Interval Report Phone User Interface: None		
phone_setting.vq_rtcp_xr_interval_period	Integer from 5 to 20	20
Description: Configures the interval (in seconds) for the IP phone to send an interval quality report to the central report collector periodically throughout a call. Note: It works only if the value of the parameter "phone_setting.vq_rtcp_xr.interval_report.enable" is set to 1 (Enabled). Web User Interface: Settings->Voice Monitoring->Period for Interval Report Phone User Interface: None		
phone_setting.vq_rtcp_xr_mos_lq_threshold_warning	15 to 40	Blank

Parameters	Permitted Values	Default
<p>Description:</p> <p>Configures the threshold value of listening MOS score (MOS-LQ) multiplied by 10. The threshold value of MOS-LQ causes the phone to send a warning alert quality report to the central report collector.</p> <p>For example, a configured value of 35 corresponds to the MOS score 3.5. When the MOS-LQ value computed by the phone is less than or equal to 3.5, the phone will send a warning alert quality report to the central report collector. When the MOS-LQ value computed by the phone is greater than 3.5, the phone will not send a warning alert quality report to the central report collector.</p> <p>If it is set to blank, warning alerts are not generated due to MOS-LQ.</p> <p>Web User Interface:</p> <p>Settings->Voice Monitoring->Warning threshold for Moslq</p> <p>Phone User Interface:</p> <p>None</p>		
phone_setting.vq_rtcp_xr_moslq_threshold_critical	15 to 40	Blank
<p>Description:</p> <p>Configures the threshold value of listening MOS score (MOS-LQ) multiplied by 10. The threshold value of MOS-LQ causes the phone to send a critical alert quality report to the central report collector.</p> <p>For example, a configured value of 28 corresponds to the MOS score 2.8. When the MOS-LQ value computed by the phone is less than or equal to 2.8, the phone will send a critical alert quality report to the central report collector. When the MOS-LQ value computed by the phone is greater than 2.8, the phone will not send a critical alert quality report to the central report collector.</p> <p>If it is set to blank, critical alerts are not generated due to MOS-LQ.</p> <p>Web User Interface:</p> <p>Settings->Voice Monitoring->Critical threshold for Moslq</p> <p>Phone User Interface:</p> <p>None</p>		
phone_setting.vq_rtcp_xr_delay_threshold_warning	10 to 2000	Blank
<p>Description:</p> <p>Configures the threshold value of one way delay (in milliseconds) that causes the phone to send a warning alert quality report to the central report collector.</p> <p>For example, If it is set to 500, when the value of one way delay computed by the</p>		

Parameters	Permitted Values	Default
<p>phone is greater than or equal to 500, the phone will send a warning alert quality report to the central report collector; when the value of one way delay computed by the phone is less than 500, the phone will not send a warning alert quality report to the central report collector.</p> <p>If it is set to blank, warning alerts are not generated due to one way delay. One-way delay includes both network delay and end system delay.</p> <p>Web User Interface: Settings->Voice Monitoring->Warning threshold for Delay</p> <p>Phone User Interface: None</p>		
phone_setting.vq_rtcp_xr_delay_threshold_critical	10 to 2000	Blank
<p>Description:</p> <p>Configures the threshold value of one way delay (in milliseconds) that causes phone to send a critical alert quality report to the central report collector.</p> <p>For example, If it is set to 500, when the value of one way delay computed by the phone is greater than or equal to 500, the phone will send a critical alert quality report to the central report collector; when the value of one way delay computed by the phone is less than 500, the phone will not send a critical alert quality report to the central report collector.</p> <p>If it is set to blank, critical alerts are not generated due to one way delay. One-way delay includes both network delay and end system delay.</p> <p>Web User Interface: Settings->Voice Monitoring->Critical threshold for Delay</p> <p>Phone User Interface: None</p>		
phone_setting.vq_rtcp_xr_states_show_on_web.enable	0 or 1	0
<p>Description:</p> <p>Enables or disables the voice quality data of the last call to be displayed on web interface at the path Status->RTP Status.</p> <p>0-Disabled 1-Enabled</p> <p>Web User Interface: Settings->Voice Monitoring->Display Report options on Web</p> <p>Phone User Interface:</p>		

Parameters	Permitted Values	Default
None		
phone_setting.vq_rtcp_xr.states_show_on_gui.enable	0 or 1	0
<p>Description:</p> <p>Enables or disables the voice quality data of the last call or current call to be displayed on the LCD screen. You can view the voice quality data of the last call on the phone at the path Menu->Status->More->RTP (RTP Status). You can view the voice quality data of the current call by pressing RTP/RTP Status soft key during a call.</p> <p>0-Disabled 1-Enabled</p> <p>Web User Interface:</p> <p>Settings->Voice Monitoring->Display Report options on phone</p> <p>Phone User Interface:</p> <p>None</p>		
phone_setting.vq_rtcp_xr.display_start_time.enable	0 or 1	1
<p>Description:</p> <p>Enables or disables the phone to display Start Time on the LCD screen.</p> <p>0-Disabled 1-Enabled</p> <p>Note: It works only if the value of the parameter "phone_setting.vq_rtcp_xr.states_show_on_gui.enable" is set to 1 (Enabled).</p> <p>Web User Interface:</p> <p>Settings->Voice Monitoring->Report options on phone->Start Time</p> <p>Phone User Interface:</p> <p>None</p>		
phone_setting.vq_rtcp_xr.display_stop_time.enable	0 or 1	1
<p>Description:</p> <p>Enables or disables the phone to display Current Time or Stop Time on the LCD screen.</p> <p>0-Disabled 1-Enabled</p> <p>Note: It works only if the value of the parameter "phone_setting.vq_rtcp_xr.states_show_on_gui.enable" is set to 1 (Enabled).</p>		

Parameters	Permitted Values	Default
Web User Interface: Settings->Voice Monitoring->Report options on phone->Current Time Phone User Interface: None		
phone_setting.vq_rtcp_r_display_local_call_id.enable	0 or 1	1
Description: Enables or disables the phone to display Local User on the LCD screen. 0 -Disabled 1 -Enabled Note: It works only if the value of the parameter "phone_setting.vq_rtcp_r_states_show_on_gui.enable" is set to 1 (Enabled). Web User Interface: Settings->Voice Monitoring->Report options on phone->Local User Phone User Interface: None		
phone_setting.vq_rtcp_r_display_remote_call_id.enable	0 or 1	1
Description: Enables or disables the phone to display Remote User on the LCD screen. 0 -Disabled 1 -Enabled Note: It works only if the value of the parameter "phone_setting.vq_rtcp_r_states_show_on_gui.enable" is set to 1 (Enabled). Web User Interface: Settings->Voice Monitoring->Report options on phone->Remote User Phone User Interface: None		
phone_setting.vq_rtcp_r_display_local_codec.enable	0 or 1	1

Parameters	Permitted Values	Default
Description: Enables or disables the phone to display Local Codec on the LCD screen. 0 -Disabled 1 -Enabled Note: It works only if the value of the parameter "phone_setting.vq_rtcp_rstates_show_on_gui.enable" is set to 1 (Enabled). Web User Interface: Settings->Voice Monitoring->Report options on phone->Local Codec Phone User Interface: None		
phone_setting.vq_rtcp_rdisplay_remote_codec.enable	0 or 1	1
Description: Enables or disables the phone to display Remote Codec on the LCD screen. 0 -Disabled 1 -Enabled Note: It works only if the value of the parameter "phone_setting.vq_rtcp_rstates_show_on_gui.enable" is set to 1 (Enabled). Web User Interface: Settings->Voice Monitoring->Report options on phone->Remote Codec Phone User Interface: None		
phone_setting.vq_rtcp_rdisplay_jitter.enable	0 or 1	1
Description: Enables or disables the phone to display Jitter on the LCD screen. 0 -Disabled 1 -Enabled Note: It works only if the value of the parameter "phone_setting.vq_rtcp_rstates_show_on_gui.enable" is set to 1 (Enabled). Web User Interface: Settings->Voice Monitoring->Report options on phone->Jitter Phone User Interface: None		

Parameters	Permitted Values	Default
phone_setting.vq_rtcp_xr_display_jitter_buffer_max.enable	0 or 1	1
<p>Description: Enables or disables the phone to display JitterBufferMax on the LCD screen.</p> <p>0-Disabled 1-Enabled</p> <p>Note: It works only if the value of the parameter "phone_setting.vq_rtcp_xr_states_show_on_gui.enable" is set to 1 (Enabled).</p> <p>Web User Interface: Settings->Voice Monitoring->Report options on phone->JitterBufferMax</p> <p>Phone User Interface: None</p>		
phone_setting.vq_rtcp_xr_display_packets_lost.enable	0 or 1	1
<p>Description: Enables or disables the phone to display Packets Lost on the LCD screen.</p> <p>0-Disabled 1-Enabled</p> <p>Note: It works only if the value of the parameter "phone_setting.vq_rtcp_xr_states_show_on_gui.enable" is set to 1 (Enabled).</p> <p>Web User Interface: Settings->Voice Monitoring->Report options on phone->Packets Lost</p> <p>Phone User Interface: None</p>		
phone_setting.vq_rtcp_xr_display_symm_oneway_delay.enable	0 or 1	0
<p>Description: Enables or disables the phone to display SymmOneWayDelay on the LCD screen.</p> <p>0-Disabled 1-Enabled</p> <p>Note: It works only if the value of the parameter "phone_setting.vq_rtcp_xr_states_show_on_gui.enable" is set to 1 (Enabled).</p> <p>Web User Interface: Settings->Voice Monitoring->Report options on phone->SymmOneWayDelay</p>		

Parameters	Permitted Values	Default
Phone User Interface: None		
phone_setting.vq_rtcp_xr_display_round_trip_delay.enable	0 or 1	0
Description: Enables or disables the phone to display RoundTripDelay on the LCD screen. 0 -Disabled 1 -Enabled Note: It works only if the value of the parameter "phone_setting.vq_rtcp_xr_states_show_on_gui.enable" is set to 1 (Enabled). Web User Interface: Settings->Voice Monitoring->Report options on phone->RoundTripDelay Phone User Interface: None		
phone_setting.vq_rtcp_xr_display_mos_lq.enable	0 or 1	1
Description: Enables or disables the phone to display MOS-LQ on the LCD screen. 0 -Disabled 1 -Enabled Note: It works only if the value of the parameter "phone_setting.vq_rtcp_xr_states_show_on_gui.enable" is set to 1 (Enabled). Web User Interface: Settings->Voice Monitoring->Report options on phone->MOS-LQ Phone User Interface: None		
phone_setting.vq_rtcp_xr_display_mos_cq.enable	0 or 1	1
Description: Enables or disables the phone to display MOS-CQ on the LCD screen. 0 -Disabled 1 -Enabled Note: It works only if the value of the parameter "phone_setting.vq_rtcp_xr_states_show_on_gui.enable" is set to 1 (Enabled). Web User Interface:		

Parameters	Permitted Values	Default
Settings->Voice Monitoring->Report options on phone->MOS-CQ Phone User Interface: None		
account.X.vq_rtcp_xr.collector_name	String within 32 characters	Blank
Description: Configures the host name of the central report collector that accepts voice quality reports contained in SIP PUBLISH messages for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Web User Interface: Account->Advanced->VQ RTCP-XR Collector name Phone User Interface: None		
account.X.vq_rtcp_xr.collector_server_host	IPv4 Address	Blank
Description: Configures the IP address of the central report collector that accepts voice quality reports contained in SIP PUBLISH messages for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Web User Interface: Account->Advanced->VQ RTCP-XR Collector address Phone User Interface:		

Parameters	Permitted Values	Default
None		
account.X.vq_rtcpxr.collector_server_port	Integer from 1 to 65535	5060
<p>Description:</p> <p>Configures the port of the central report collector that accepts voice quality reports contained in SIP PUBLISH messages for account X.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Web User Interface:</p> <p>Account->Advanced->VQ RTCP-XR Collector port</p> <p>Phone User Interface:</p> <p>None</p>		

To configure session report for VQ-RTCPXR via web user interface:

1. Click on **Settings->Voice Monitoring**.
2. Select the desired value from the pull-down list of **VQ RTCP-XR Session Report**.

The screenshot displays the Yealink T236 web interface. The 'Settings' tab is active, and the 'Voice Monitoring' section is selected. The 'VQ RTCP-XR Session Report' dropdown menu is highlighted with a red rectangle and is currently set to 'Enabled'. Below it, the 'VQ RTCP-XR Interval Report' is set to 'Disabled', and the 'Period for Interval Report' is set to '20'. There are input fields for 'Warning threshold for Mosq' and 'Critical threshold for Mosq', as well as 'Warning threshold for Delay' and 'Critical threshold for Delay'. The 'Display Report options on Web' and 'Display Report options on phone' are both set to 'Disabled'. The 'Settings RTCP-XR Report' and 'Voice RTCP-XR Report' are both set to 'Enabled'. At the bottom, the 'Report options on phone' section shows 'RoundTripDelay' and 'SymmOneWayDelay' as disabled, and 'Start Time', 'Current Time', 'Local User', 'Remote User', and 'Local Codec' as enabled. On the right side, a 'NOTE' box titled 'Voice Quality Monitoring' explains that it allows IP phones to generate quality metrics for listening and conversational quality, and that the VQ-RTCPXR mechanism complies with RFC 6035, sending service quality metric reports in SIP PUBLISH messages to the central report collector. A link is provided for more guides.

3. Click **Confirm** to accept the change.

To configure interval report for VQ-RTCPXR via web user interface:

1. Click on **Settings->Voice Monitoring**.
2. Select the desired value from the pull-down list of **VQ RTCP-XR Interval Report**.
3. Enter the desired value in the **Period for Interval Report** field.

The screenshot shows the Yealink T236 web interface. The top navigation bar includes 'Status', 'Account', 'Network', 'DSSKey', 'Features', 'Settings', 'Directory', and 'Security'. The left sidebar lists various settings categories, with 'Voice Monitoring' selected. The main content area displays the 'VQ RTCP-XR Session Report' settings. The 'VQ RTCP-XR Interval Report' is set to 'Enabled' and the 'Period for Interval Report' is set to '20'. A red box highlights these two fields. Below these fields are several other settings, including 'Warning threshold for Moslq', 'Critical threshold for Moslq', 'Warning threshold for Delay', 'Critical threshold for Delay', 'Display Report options on Web', 'Display Report options on phone', 'Settings RTCP-XR Report', and 'Voice RTCP-XR Report'. At the bottom, there is a section for 'Report options on phone' with two columns: 'Disabled' (containing 'RoundTripDelay' and 'SymmOneWayDelay') and 'Enabled' (containing 'Start Time', 'Current Time', 'Local User', 'Remote User', and 'Local Codec'). The right sidebar contains a 'NOTE' about Voice Quality Monitoring.

4. Click **Confirm** to accept the change.

To configure alert report for VQ-RTCPXR via web user interface:

1. Click on **Settings->Voice Monitoring**.
2. Enter the desired value in the **Warning threshold for Moslq** field.
3. Enter the desired value in the **Critical threshold for Moslq** field.
4. Enter the desired value in the **Warning threshold for Delay** field.

- Enter the desired value in the **Critical threshold for Delay** field.

The screenshot shows the Yealink T236 web interface. The 'Settings' tab is selected, and the 'Voice Monitoring' section is active. The 'Critical threshold for Delay' field is highlighted with a red box. The 'Display Report options on Web' field is also highlighted with a red box. The 'Report options on phone' section shows a list of options: RoundTripDelay, SymmOneWayDelay, Start Time, Current Time, Local User, Remote User, and Local Codec.

Field	Value
VQ RTPC-XR Session Report	Disabled
VQ RTPC-XR Interval Report	Enabled
Period for Interval Report	20
Warning threshold for Mosq	35
Critical threshold for Mosq	25
Warning threshold for Delay	35
Critical threshold for Delay	40
Display Report options on Web	Disabled
Display Report options on phone	Disabled
Settings RTPC-XR Report	Enabled
Voice RTPC-XR Report	Enabled

Report options on phone

Disabled	Enabled
RoundTripDelay	Start Time
SymmOneWayDelay	Current Time
	Local User
	Remote User
	Local Codec

NOTE
Voice Quality Monitoring
 It allows the IP phones to generate various quality metrics for listening quality and conversational quality.
 The VQ-RTPCXR mechanism, compliant with RFC 6035, sends the service quality metric reports contained in SIP PUBLISH messages to the central report collector.
 You can click here to get more guides.

- Click **Confirm** to accept the change.

To configure RTP status displayed on the web page via web user interface:

- Click on **Settings->Voice Monitoring**.
- Select the desired value from the pull-down list of **Display Report options on Web**.

The screenshot shows the Yealink T236 web interface. The 'Settings' tab is selected, and the 'Voice Monitoring' section is active. The 'Display Report options on Web' field is highlighted with a red box. The 'Report options on phone' section shows a list of options: RoundTripDelay, SymmOneWayDelay, Start Time, Current Time, Local User, Remote User, and Local Codec.

Field	Value
VQ RTPC-XR Session Report	Disabled
VQ RTPC-XR Interval Report	Enabled
Period for Interval Report	20
Warning threshold for Mosq	35
Critical threshold for Mosq	25
Warning threshold for Delay	35
Critical threshold for Delay	40
Display Report options on Web	Enabled
Display Report options on phone	Disabled
Settings RTPC-XR Report	Enabled
Voice RTPC-XR Report	Enabled

Report options on phone

Disabled	Enabled
RoundTripDelay	Start Time
SymmOneWayDelay	Current Time
	Local User
	Remote User
	Local Codec

NOTE
Voice Quality Monitoring
 It allows the IP phones to generate various quality metrics for listening quality and conversational quality.
 The VQ-RTPCXR mechanism, compliant with RFC 6035, sends the service quality metric reports contained in SIP PUBLISH messages to the central report collector.
 You can click here to get more guides.

- Click **Confirm** to accept the change.

The RTP status will appear on the web user interface at the path: **Status->RTP Status**.


To configure RTP status displayed on the LCD screen via web user interface:

1. Click on **Settings->Voice Monitoring**.
2. Select the desired value from the pull-down list of **Display Report options on phone**.


3. Click **Confirm** to accept the change.




The RTP status will appear on the phone user interface at the path: **Menu->Status->More....**

To configure the options of the RTP status displayed on the LCD screen via web user interface:

1. Click on **Settings->Voice Monitoring**.
2. In the **Report options on phone** block, select the desired list from the **Disabled** column and then click .

The selected list appears in the **Enabled** column.



3. Repeat the step 2 to add more items to the **Enabled** column.
4. To remove an item from the **Enabled** column, select the desired item and then click .
5. To adjust the display order of enabled items, select the desired item and then click  or .

The LCD screen will display the item(s) in the adjusted order.

6. Click **Confirm** to accept the change.

To configure the central report collector via web user interface:

1. Click on **Account->Advanced**.
2. Select the desired account from the pull-down list of **Account**.
3. Enter the host name of the central report collector in the **VQ RTCP-XR Collector name** field.
4. Enter the IP address of the central report collector in the **VQ RTCP-XR Collector address** field.

5. Enter the port of the central report collector in the **VQ RTPC-XR Collector port** field.

The screenshot shows the Yealink T236 web interface with the 'Account' tab selected. The 'VQ RTPC-XR Collector port' field is highlighted with a red box and contains the value 5060. Other fields include 'VQ RTPC-XR Collector name' (collector), 'VQ RTPC-XR Collector address' (10.2.1.98), and 'VQ RTPC-XR Collector port' (5060). The 'Confirm' button is visible at the bottom.

6. Click **Confirm** to accept the change.

Quality of Service

Quality of Service (QoS) is the ability to provide different priorities for different packets in the network, allowing the transport of traffic with special requirements. QoS guarantees are important for applications that require fixed bit rate and are delay sensitive when the network capacity is insufficient. There are four major QoS factors to be considered when configuring a modern QoS implementation: bandwidth, delay, jitter and loss.

QoS provides better network service through the following features:

- Supporting dedicated bandwidth
- Improving loss characteristics
- Avoiding and managing network congestion
- Shaping network traffic
- Setting traffic priorities across the network

The Best-Effort service is the default QoS model in IP networks. It provides no guarantees for data delivering, which means delay, jitter, packet loss and bandwidth allocation are unpredictable. Differentiated Services (DiffServ or DS) is the most widely used QoS model. It provides a simple and scalable mechanism for classifying and managing network traffic and providing QoS on modern IP networks. Differentiated Services Code Point (DSCP) is used to define DiffServ classes and stored in the first six bits of the ToS (Type of Service) field. Each router on the network can provide QoS

simply based on the DiffServ class. The DSCP value ranges from 0 to 63 with each DSCP specifying a particular per-hop behavior (PHB) applicable to a packet. A PHB refers to the packet scheduling, queuing, policing, or shaping behavior of a node on any given packet.

Four standard PHBs available to construct a DiffServ-enabled network and achieve QoS:

- **Class Selector PHB** -- backwards compatible with IP precedence. Class Selector code points are of the form "xxx000". The first three bits are the IP precedence bits. These class selector PHBs retain almost the same forwarding behavior as nodes that implement IP precedence-based classification and forwarding.
- **Expedited Forwarding PHB** -- the key ingredient in DiffServ model for providing a low-loss, low-latency, low-jitter and assured bandwidth service.
- **Assured Forwarding PHB** -- defines a method by which BAs (Bandwidth Allocations) can be given different forwarding assurances.
- **Default PHB** -- specifies that a packet marked with a DSCP value of "000000" gets the traditional best effort service from a DS-compliant node.

VoIP is extremely bandwidth and delay-sensitive. QoS is a major issue in VoIP implementations, regarding how to guarantee that packet traffic not be delayed or dropped due to interference from other lower priority traffic. VoIP can guarantee high-quality QoS only if the voice and the SIP packets are given priority over other kinds of network traffic. IP phones support the DiffServ model of QoS.

Voice QoS

In order to make VoIP transmissions intelligible to receivers, voice packets should not be dropped, excessively delayed, or made to suffer varying delay. DiffServ model can guarantee high-quality voice transmission when the voice packets are configured to a higher DSCP value.

Video QoS

To ensure acceptable visual quality for video, video packets emanated from the IP phones should be configured with a high transmission priority.

SIP QoS

SIP protocol is used for creating, modifying and terminating two-party or multi-party sessions. To ensure good voice quality, SIP packets emanated from IP phones should be configured with a high transmission priority.

DSCPs for voice and SIP packets can be specified respectively.

Note

For voice and SIP packets, the IP phone obtains DSCP info from the network policy if LLDP feature is enabled, which takes precedence over manual settings. For more information on LLDP, refer to [LLDP](#) on page [674](#).

Procedure

QoS can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	<p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>Configure the DSCPs for voice packets and SIP packets.</p> <p>Parameters:</p> <p>network.qos.rtplos</p> <p>network.qos.signallos</p>
		<p>For SIP VP-T49G:</p> <p>Configure the DSCPs for voice packets, SIP packets and video packets.</p> <p>Parameters:</p> <p>network.qos.audioslos</p> <p>network.qos.signallos</p> <p>network.qos.videoslos</p>
Local	Web User Interface	<p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>Configure the DSCPs for voice packets and SIP packets.</p> <p>Navigate to:</p> <p>http://<phoneIPAddress>/servlet?p=network-adv&q=load</p>
		<p>For SIP VP-T49G:</p> <p>Configure the DSCPs for voice packets, SIP packets and video packets.</p> <p>http://<phoneIPAddress>/servlet?m=mod_data&p=network-adv&q=load</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.qos.rtptos	Integer from 0 to 63	46
Description: Configures the DSCP (Differentiated Services Code Point) for voice packets. The default DSCP value for RTP packets is 46 (Expedited Forwarding). Note: If you change this parameter, the IP phone will reboot to make the change take effect. It is not applicable to SIP VP-T49G IP phones. Web User Interface: Network->Advanced->Voice QoS (0~63) Phone User Interface: None		
network.qos.signaltos	Integer from 0 to 63	26
Description: Configures the DSCP (Differentiated Services Code Point) for SIP packets. The default DSCP value for SIP packets is 26 (Assured Forwarding). Note: If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Network->Advanced->SIP QoS (0~63) Phone User Interface: None		
network.qos.audiotos	Integer from 0 to 63	46
Description: Configures the DSCP (Differentiated Services Code Point) for voice packets. The default DSCP value for RTP packets is 46 (Expedited Forwarding). Note: If you change this parameter, the IP phone will reboot to make the change take effect. It is only applicable to SIP VP-T49G IP phones. Web User Interface: Network->Advanced->Audio QoS (0~63) Phone User Interface: None		

Parameters	Permitted Values	Default
network.qos.videotos	Integer from 0 to 63	46
<p>Description:</p> <p>Configures the DSCP (Differentiated Services Code Point) for video packets. The default DSCP value for H264 packets is 46 (Expedited Forwarding).</p> <p>Note: If you change this parameter, the IP phone will reboot to make the change take effect. It is only applicable to SIP VP-T49G IP phones.</p> <p>Web User Interface:</p> <p>Network->Advanced->Video QoS (0~63)</p> <p>Phone User Interface:</p> <p>None</p>		

To configure DSCPs for voice packets and SIP packets via web user interface (take SIP-T23G IP phones for example):

1. Click on **Network->Advanced**.
2. Enter the desired value in the **Voice QoS (0~63)** field.
3. Enter the desired value in the **SIP QoS (0~63)** field.

The screenshot shows the Yealink T23G web interface. The 'Network' tab is selected, and the 'Advanced' sub-tab is active. In the 'Voice QoS' section, the 'Voice QoS (0~63)' field is set to 46 and the 'SIP QoS (0~63)' field is set to 26. These two fields are enclosed in a red rectangular box. Other configuration options visible include LLDP (Active/Enabled), CDP (Active/Disabled), Local RTP Port (Max: 12780, Min: 11780), Span to PC (Enabled), Registration Random (0), and VPN (Active/Enabled). A 'NOTE' sidebar on the right provides information about VLAN, NAT Traversal, Quality of Service (QoS), Web Server Type, 802.1X Authentication, and VPN.

4. Click **Confirm** to accept the change.

A dialog box pops up to prompt that settings will take effect after a reboot.

- Click **OK** to reboot the phone.

To configure DSCPs for voice packets and SIP packets via web user interface (take SIP VPT49G IP phones for example):

- Click on **Network->Advanced**.
- Enter the desired value in the **Audio QoS (0~63)** field.
- Enter the desired value in the **Video QoS (0~63)** field.
- Enter the desired value in the **SIP QoS (0~63)** field.

The screenshot shows the Yealink T49G web interface. The top navigation bar includes 'Status', 'Account', 'Network', 'DSSKey', 'Features', 'Settings', 'Directory', and 'Security'. The left sidebar has 'Basic', 'PC Port', 'Advanced', and 'Wi-Fi'. The 'Network' tab is selected, and the 'Advanced' sub-tab is active. The 'Voice QoS' section is highlighted with a red box, showing the following values:


Field	Value
Audio QoS (0~63)	46
Video QoS (0~63)	46
SIP QoS (0~63)	26

Other sections visible include LLDP (Active, Enabled, Packet Interval 60), CDP (Active, Disabled, Packet Interval 60), Reserve Port (UDP Port Scope 50000 ~ 50249, TCP Port Scope 50000 ~ 50249), and VPN (Active, Disabled, Upload VPN Config button). A 'NOTE' section on the right explains VLAN and QoS concepts.

- Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
- Click **OK** to reboot the phone.

Configuring the IP phone for Use with a Firewall or NAT

A firewall protects an organization's IP network by controlling data traffic from outside the network. If your IP phone communicates with other devices through a firewall, you must configure your firewall to allow incoming and outgoing traffic to the IP phone through the reserved ports and the required ports.



You must configure your firewall to allow incoming and outgoing traffic through the following ports:

Port	Port Type	Description
5060	UDP	SIP (default transport protocol)
5060	TCP	SIP (when selecting the TCP transport protocol)
5061	TCP	SIP (when selecting the TLS transport protocol)
50000-50249 (default range)	TCP/UDP	Reserved ports on the IP phone. For more information, refer to Reserved Ports on page 719.

Reserved Ports

By default, the IP phone communicates through UDP ports in the 50000 - 50249 range for video and voice control. The phone uses only a small number of these ports during a call. The exact number depends on the number of participants in the call, the protocol used, and the number of ports required for the type of call: video or voice. It is only applicable to SIP VP-T49G IP phones.

The following tables identify the number of ports required per connection by protocol and the type of call.

Required ports for a SIP two-way call:

Call Type	Number of Required Ports
Video	6 UDP ports
Voice	2 UDP ports
Each additional video participant requires 6 UDP ports.	
Each additional audio participant requires 2 UDP ports.	

The following table lists the number of UDP ports needed for the IP phone. This information can help you to determine the range of port number to be entered in the **Reserved Port** field.

Phone	Maximum Connections	Required Ports for a SIP Call	
SIP VP-T49G	Three-way video call and two audio call	16 UDP	50000-50015

Procedure

Reserved ports can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the range of the UDP ports. Parameters: sip.min_udp_port sip.max_udp_port
		Configure the range of the TCP ports. Parameters: sip.min_tcp_port sip.max_tcp_port
Local	Web User Interface	Configure the range of the UDP ports. Configure the range of the TCP ports. Navigate to: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=network-adv&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=network-adv&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
sip.min_udp_port	Integer from 1024 to 65535	50000
Description: Configures the minimum UDP port. Note: If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Network->Advanced->UDP Port Scope Phone User Interface: None		
sip.max_udp_port	Integer from 1024 to 65535	50249
Description: Configures the maximum UDP port. Note: The value of the maximum UDP port cannot be less than that of the minimum UDP port. If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Network->Advanced->UDP Port Scope Phone User Interface: None		
sip.min_tcp_port	Integer from 1024 to 65535	50000
Description: Configures the minimum TCP port. Note: If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Network->Advanced->TCP Port Scope Phone User Interface: None		
sip.max_tcp_port	Integer from 1024 to 65535	50249

Parameters	Permitted Values	Default
<p>Description:</p> <p>Configures the maximum TCP port.</p> <p>Note: The value of the maximum TCP port cannot be less than that of the minimum TCP port. If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Network->Advanced->TCP Port Scope</p> <p>Phone User Interface:</p> <p>None</p>		

To configure reserved ports via web user interface:

1. Click on **Network->Advanced**.
2. Enter the desired port scope in the **UDP Port Scope** field.
3. Enter the desired port scope in the **TCP Port Scope** field.


The screenshot shows the Yealink T496 web interface. The 'Network' tab is selected, and the 'Advanced' sub-tab is active. In the 'Reserve Port' section, the 'UDP Port Scope' and 'TCP Port Scope' are both configured to '50000 ~ 50249'. The 'LLDP' and 'CDP' settings are also visible, with 'LLDP' set to 'Enabled' and 'CDP' set to 'Disabled'. The 'Voice QoS' section shows 'Audio QoS' set to '46', 'Video QoS' set to '46', and 'SIP QoS' set to '26'. The 'VPN' section shows 'Active' set to 'Disabled'. A 'NOTE' sidebar on the right provides information about VLAN, QoS, and Local RTP Port.

4. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
5. Click **OK** to reboot the phone.

Network Address Translation

Network Address Translation (NAT) is essentially a translation table that maps public IP

address and port combinations to private ones. This reduces the need for a large number of public IP addresses. NAT ensures security since each outgoing or incoming request must first go through a translation process.



NAT Types

Symmetrical NAT

In symmetrical NAT, the NAT router stores the address and port where the packet was sent. Only packets coming from this address and port are forwarded back to the private address.

Full Cone NAT

In full cone NAT, all packets from a private address (e.g., iAddr: port1) to public network will be sent through a public address (e.g., eAddr: port2). Packets coming from the address of any server to eAddr: port2 will be forwarded back to the private address (e.g., iAddr: port1).

Address Restricted Cone NAT

Restricted cone NAT works similar like full cone NAT. A public host (hAddr: any) can send packets to iAddr: port1 through eAddr: port2 only if iAddr: port1 has previously sent a packet to hAddr: any. "Any" means the port number doesn't matter.

Port Restricted Cone NAT

Port restricted cone NAT works similar like full cone NAT. A public host (hAddr: hPort) can send packets to iAddr: port1 through eAddr: port2 only if iAddr: port1 has previously sent a packet to hAddr: hPort.


NAT Traversal

In the VoIP environment, NAT breaks end-to-end connectivity.

NAT traversal is a general term for techniques that establish and maintain IP connections traversing NAT gateways, typically required for client-to-client networking applications, especially for VoIP deployments. STUN is one of the NAT traversal techniques supported by IP phones.

STUN (Simple Traversal of UDP over NATs)

STUN is a network protocol, used in NAT traversal for applications of real-time voice, video, messaging, and other interactive IP communications. The STUN protocol allows entities behind a NAT to first discover the presence of a NAT and the type of NAT (for more information on the NAT types, refer to [NAT Types](#) on page 723) and to obtain the mapped (public) IP address and port number that the NAT has allocated for the UDP connections to remote parties. The protocol requires assistance from a third-party network server (STUN server) usually located on public Internet. The IP phone can be configured to act as a STUN client, to send exploratory STUN messages to the STUN server. The STUN server uses those messages to determine the public IP address and port used, and then informs the client.



Capturing packets after you enable the STUN feature, you can find that the IP phone sends Binding Request to the STUN server, and then mapped IP address and port is placed in the Binding Response: Binding Success Response MAPPED-ADDRESS: 59.61.92.59:19232.

No.	Time	Source	Destination	Protocol	Length	Info
444	18.587848	192.168.1.6	218.107.220.74	STUN	62	Binding Request
447	18.711349	218.107.220.74	192.168.1.6	STUN	98	Binding Success Response MAPPED-ADDRESS: 59.61.92.59:19232

SIP and TLS Source Ports for NAT Traversal

You can configure the SIP and TLS source ports on the IP Phone. Previously, the IP phone used default values (5060 for UDP/TCP and 5061 for TLS). In the configuration files, you can use the following parameters to configure the SIP and TLS source ports:

- Local SIP Port
- TLS SIP Port

If NAT is disabled, the port number shows in the Via and Contact SIP headers of SIP messages. If NAT is enabled, the phone uses the NAT port number (and NAT IP address) in the Via and Contact SIP headers of SIP messages, but still use the configured source port.

Procedure

NAT traversal and STUN server can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure NAT traversal and STUN server on a phone basis. Parameters: sip.nat_stun.enable sip.nat_stun.server sip.nat_stun.port
		Configure local SIP port and TLS SIP port. Parameters: sip.listen_port sip.tls_listen_port
	<MAC>.cfg	Configure NAT traversal on a per-line basis. Parameters: account.X.nat.nat_traversal
Local	Web User Interface	Configure NAT traversal and STUN server on a phone basis. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/ T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet? p=network-adv&q=load">http://<phoneIPAddress>/servlet? p=network-adv&q=load For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=network-adv&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=network-adv&q=load

		<p>Configure local SIP port and TLS SIP port.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/ T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p><a href="http://<phoneIPAddress>/servlet?p=settings-sip&q=load">http://<phoneIPAddress>/servlet?p=settings-sip&q=load</p> <p>For SIP VP-T49G:</p> <p><a href="http://<phoneIPAddress>/servlet?m=mod_data&p=settings-sip&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=settings-sip&q=load</p>
		<p>Configure NAT traversal on a per-line basis.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/ T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p><a href="http://<phoneIPAddress>/servlet?p=account-register&q=load&acc=0">http://<phoneIPAddress>/servlet?p=account-register&q=load&acc=0</p> <p>For SIP VP-T49G:</p> <p><a href="http://<phoneIPAddress>/servlet?m=mod_data&p=account-register&q=load&acc=0">http://<phoneIPAddress>/servlet?m=mod_data&p=account-register&q=load&acc=0</p>
	Phone User Interface	<p>Configure NAT traversal and STUN server on a phone basis.</p> <p>Configure NAT traversal on a per-line basis.</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
sip.nat_stun.enable	0 or 1	0
<p>Description:</p> <p>Enables or disables the STUN (Simple Traversal of UDP over NATs) feature on the IP</p>		

Parameters	Permitted Values	Default
<p>phone.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>Note: If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Advanced->NAT->Active</p> <p>Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->NAT->NAT Status</p>		
sip.nat_stun.server	IP address or domain name	Blank
<p>Description: Configures the IP address or the domain name of the STUN (Simple Traversal of UDP over NATs) server.</p> <p>Example: sip.nat_stun.server = 218.107.220.201</p> <p>Note: If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Advanced->NAT->STUN Server</p> <p>Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->NAT->STUN Server</p>		
sip.nat_stun.port	Integer from 1024 to 65000	3478
<p>Description: Configures the port of the STUN (Simple Traversal of UDP over NATs) server.</p> <p>Example: sip.nat_stun.port = 3478</p> <p>Note: If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Advanced->NAT->STUN Port(1024~65000)</p>		

Parameters	Permitted Values	Default
Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->NAT->Port		
account.X.nat.nat_traversal	0 or 1	0
Description: Enables or disables the NAT traversal for account X. 0 -Disabled 1 -STUN (Enabled for SIP VPT49G) X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Note: It works only if the value of the parameter "sip.nat_stun.enable" is set to 1 (Enabled). Web User Interface: Account->Register->NAT Phone User Interface: Menu->Settings->Advanced Settings->Accounts->AccountX->NAT Status		
sip.listen_port	Integer from 1024 to 65535	5060
Description: Configures the local SIP port. Web User Interface: Settings->SIP->Local SIP Port Phone User Interface: None		
sip.tls_listen_port	Integer from 1024 to 65535	5061
Description: Configures the local TLS listen port. Web User Interface: Settings->SIP->TLS SIP Port		

Parameters	Permitted Values	Default
Phone User Interface:		
None		

To configure NAT traversal and STUN server via web user interface:

1. Click on **Network->Advanced**.
2. In the **NAT** block, select the desired value from the pull-down list of **Active**.
3. Enter the IP address or the domain name of the STUN server in the **STUN Server** field.
4. Enter the port of the STUN server in the **Port** field.

The screenshot displays the Yealink T236 web interface. The 'Network' tab is selected, and the 'Advanced' sub-tab is active. The 'NAT' configuration section is highlighted with a red rectangle. It shows the 'Active' status set to 'Enabled', the 'STUN Server' field containing '218.107.220.201', and the 'STUN Port(1024~65000)' field containing '3478'. Other visible sections include LLDP (Active: Enabled, Packet Interval: 60), CDP (Active: Disabled, Packet Interval: 60), Port Link (WAN and PC ports set to Auto Negotiate), Registration Random (set to 0), and VPN (Active: Enabled). A 'NOTE' sidebar on the right provides additional context for various features like VLAN, NAT Traversal, QoS, Web Server Type, 802.1X Authentication, and VPN.

5. Click **Confirm** to accept the change.
A dialog box pops up to prompt that settings will take effect after a reboot.
6. Click **OK** to reboot the phone.

To configure NAT traversal for account via web user interface:

1. Click on **Account->Register**.
2. Select the desired account from the pull-down list of **Account**.

3. Select **STUN** from the pull-down list of **NAT**.

The screenshot shows the Yealink T236 web interface with the 'Account' tab selected. The 'NAT' dropdown menu is highlighted with a red box and set to 'STUN'. The 'Confirm' button is visible at the bottom.

Account	
Register Status	Registered
Line Active	Enabled
Label	1011
Display Name	1011
Register Name	1011
User Name	1011
Password	*****
SIP Server 1	
Server Host	10.3.5.199 Port: 5060
Transport	UDP
Server Expires	3600
Server Retry Counts	3
SIP Server 2	
Server Host	Port: 5060
Transport	UDP
Server Expires	3600
Server Retry Counts	3
Enable Outbound Proxy Server	Disabled
Outbound Proxy Server 1	Port: 5060
Outbound Proxy Server 2	Port: 5060
Proxy Fallback Interval	3600
NAT	STUN

4. Click **Confirm** to accept the change.

To configure local SIP port and TLS SIP port via web user interface:



1. Click on **Settings->SIP**.
2. Enter the desired local SIP port in the **Local SIP Port** field.
3. Enter the desired TLS SIP port in the **TLS SIP Port** field.

The screenshot shows the Yealink T236 web interface with the 'Settings' tab selected. The 'SIP Config' section is visible, and the 'Local SIP Port' and 'TLS SIP Port' fields are highlighted with a red box. The 'Confirm' button is visible at the bottom.





SIP Config	
SIP Session Timer T1 (0.5~10s)	0.5
SIP Session Timer T2 (2~40s)	4
SIP Session Timer T4 (2.5~60s)	5
Local SIP Port	5060
TLS SIP Port	5061

4. Click **Confirm** to accept the change.

To configure NAT traversal and STUN server via phone user interface:

1. Press **Menu->Settings->Advanced Settings** (default password: admin) ->**Network->NAT->NAT Status**.
 2. Press  or  , or the **Switch** soft key to select the desired value from the **NAT Status** field.
 3. Enter the IP address or the domain name of the STUN server in the **STUN Server** field.
 4. Enter the port of the STUN server in the **Port** field.
 5. Press the **Save** soft key to accept the change.
- The IP phone reboots automatically to make settings effective after a period of time.

To configure NAT traversal for a specific account via phone user interface:

1. Press **Menu->Settings->Advanced Settings** (default password: admin) ->**Accounts**.
2. Press  or  to select the desired account and press the **Enter** soft key.
3. Press  or  , or the **Switch** soft key to select the desired value from the **NAT Status** field.
4. Press the **Save** soft key to accept the change.

Keep Alive

IP phones can send keep-alive packets to NAT device for keeping the communication port open.

Procedure

Keep alive feature can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure the type of keep-alive packets on a per-line basis. Parameters: account.X.nat.udp_update_enable
		Configure the keep-alive interval on a per-line basis. Parameters: account.X.nat.udp_update_time
Local	Web User Interface	Configure the type of keep-alive packets on a per-line basis. Configure the keep-alive interval on a per-line basis.

		<p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29 G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>http://<phoneIPAddress>/servlet?p =account-adv&q=load&acc=0</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet? m=mod_data&p=account-adv&q =load&acc=0</p>
--	--	--

Details of Configuration Parameters:

Parameters	Permitted Values	Default
account.X.nat.udp_update_enable	0, 1, 2 or 3	1
<p>Description:</p> <p>Configures the type of keep-alive packets sent by the IP phone to the NAT device to keep the communication port open so that NAT can continue to function for account X.</p> <p>0-Disabled</p> <p>1-Default (the IP phone sends UDP packets to the server)</p> <p>2-Options (the IP phone sends SIP OPTIONS packets to the server)</p> <p>3-Notify (the IP phone sends SIP NOTIFY packets to the server)</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Web User Interface:</p> <p>Account->Advanced->Keep Alive Type</p> <p>Phone User Interface:</p> <p>None</p>		
account.X.nat.udp_update_time	Integer from 15 to 2147483647	30
<p>Description:</p>		

Parameters	Permitted Values	Default
<p>Configures the keep-alive interval (in seconds) for account X.</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Example:</p> <p>account.1.nat.udp_update_time = 60</p> <p>Note: It works only if the value of the parameter “account.X.nat.udp_update_enable” is set to 1, 2 or 3.</p> <p>Web User Interface:</p> <p>Account->Advanced->Keep Alive Interval(Seconds)</p> <p>Phone User Interface:</p> <p>None</p>		

To configure the type of keep-alive packets and keep-alive interval via web user interface:

1. Click on **Account->Advanced**.
2. Select the desired account from the pull-down list of **Account**.
3. Select the desired value from the pull-down list of **Keep Alive Type**.
4. Enter the keep-alive interval in the **Keep Alive Interval(Seconds)** field.

The screenshot shows the Yealink T236 web interface. The 'Account' tab is active, and the 'Advanced' sub-tab is selected. The 'Account' dropdown is set to 'Account 1'. The 'Keep Alive Type' dropdown is set to 'Options' and the 'Keep Alive Interval(Seconds)' field is set to '30'. Other fields include 'RPort' (Disabled), 'Subscribe Period(Seconds)' (1800), 'DTMF Type' (RFC2833), 'DTMF Info Type' (DTMF-Relay), and 'DTMF Payload Type(96~127)' (101). A 'NOTE' box on the right explains DTMF and Session Timer.

5. Click **Confirm** to accept the change.

Rport

Rport in [RFC 3581](#), allows a client to request that the server sends the response back to the source port from which the request came. Rport feature depends on support from a SIP server.

Procedure

Rport feature can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure NAT Rport feature for account. Parameters: account.X.nat.rport
Local	Web User Interface	Configure NAT Rport feature for account. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?<account>-adv&q=load&acc=0">http://<phoneIPAddress>/servlet?<account>-adv&q=load&acc=0 For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0">http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0

Details of Configuration Parameters:

Parameters	Permitted Values	Default
account.X.nat.rport	0, 1 or 2	0
Description: Enables or disables NAT Rport feature for account X. 0-Disabled 1-Enabled 2-enable direct process X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Web User Interface:		

Parameters	Permitted Values	Default
Account->Advanced->RPort		
Phone User Interface:		
None		

To configure Rport feature via web user interface:

1. Click on **Account->Advanced**.
2. Select the desired account from the pull-down list of **Account**.
3. Select the desired value from the pull-down list of **RPort**.

The screenshot shows the Yealink T236 web interface. The 'Account' tab is selected. Under the 'Advanced' sub-tab, the 'RPort' dropdown menu is highlighted with a red box, showing 'Enabled' as the selected value. Other settings visible include 'Keep Alive Type' (Options), 'Keep Alive Interval(Seconds)' (30), 'Subscribe Period(Seconds)' (1800), 'DTMF Type' (RFC2833), 'DTMF Info Type' (DTMF-Relay), and 'DTMF Payload Type(96~127)' (101). A 'NOTE' box on the right explains the DTMF signal and the Session Timer feature.

4. Click **Confirm** to accept the change.

Real-Time Transport Protocol

The Real-time Transport Protocol (RTP) is a network protocol for delivering audio and video over IP networks. The UDP port used for RTP streams is traditionally an even-numbered port. For example, the default RTP min port on the IP phones is 11780. The first voice patch sends RTP on port 11780. Additional calls would then use ports 11782, 11784, 11786, etc. up to the max port. It is not applicable to SIP VPT49G IP phones.

Procedure

RTP port can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure RTP port. Parameters: network.port.max_rtpport network.port.min_rtpport
Local	Web User Interface	Configure RTP port. Navigate to: http://<phoneIPAddress>/serv let?p=network-adv&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.port.max_rtpport	Integer from 1 to 65535	12780
<p>Description: Configures the maximum local RTP port.</p> <p>Note: The value of the maximum local RTP port cannot be less than that of the minimum local RTP port. If you change this parameter, the IP phone will reboot to make the change take effect. It is not applicable to SIP VP-T49G IP phones.</p> <p>Web User Interface: Network->Advanced->Local RTP Port->Max RTP Port(1~65535)</p> <p>Phone User Interface: None</p>		
network.port.min_rtpport	Integer from 1 to 65535	11780
<p>Description: Configures the minimum local RTP port.</p> <p>Note: If you change this parameter, the IP phone will reboot to make the change take effect. It is not applicable to SIP VP-T49G IP phones.</p> <p>Web User Interface: Network->Advanced->Local RTP Port->Min RTP Port(1~65535)</p> <p>Phone User Interface: None</p>		

To configure the minimum and maximum RTP port via web user interface:

1. Click on **Network->Advanced**.

- In the **Local RTP Port** block, enter the max and min RTP port in the **Max RTP Port(1~65535)** and **Min RTP Port(1~65535)** field respectively.

The screenshot shows the Yealink T23G web interface with the 'Network' tab selected. The 'Local RTP Port' section is highlighted with a red box. It contains two input fields: 'Max RTP Port (1~65535)' with the value '12780' and 'Min RTP Port (1~65535)' with the value '11780'. Other sections visible include LLDP (Active: Enabled, Packet Interval: 60), CDP (Active: Disabled, Packet Interval: 60), Voice QoS (Voice QoS: 46, SIP QoS: 26), and VPN (Active: Disabled). A 'NOTE' sidebar on the right provides information about VLAN, NAT Traversal, and Quality of Service (QoS).

- Click **Confirm** to accept the change.

TR-069 Device Management

TR-069 is a technical specification defined by the Broadband Forum, which defines a mechanism that encompasses secure auto-configuration of a CPE (Customer-Premises Equipment), and incorporates other CPE management functions into a common framework. TR-069 uses common transport mechanisms (HTTP and HTTPS) for communication between CPE and ACS (Auto Configuration Servers). The HTTP(S) messages contain XML-RPC methods defined in the standard for configuration and management of the CPE.

TR-069 is intended to support a variety of functionalities to manage a collection of CPEs, including the following primary capabilities:

- Auto-configuration and dynamic service provisioning
- Software or firmware image management
- Status and performance monitoring
- Diagnostics

The following table provides a description of RPC methods supported by IP phones.

RPC Method	Description
GetRPCMethods	This method is used to discover the set of methods

RPC Method	Description
	supported by the CPE.
SetParameterValues	This method is used to modify the value of one or more CPE parameters.
GetParameterValues	This method is used to obtain the value of one or more CPE parameters.
GetParameterNames	This method is used to discover the parameters accessible on a particular CPE.
GetParameterAttributes	This method is used to read the attributes associated with one or more CPE parameters.
SetParameterAttributes	This method is used to modify attributes associated with one or more CPE parameters.
Reboot	This method causes the CPE to reboot.
Download	<p>This method is used to cause the CPE to download a specified file from the designated location.</p> <p>File types supported by IP phones are:</p> <ul style="list-style-type: none"> • Firmware Image • Configuration File
Upload	<p>This method is used to cause the CPE to upload a specified file to the designated location.</p> <p>File types supported by IP phones are:</p> <ul style="list-style-type: none"> • Configuration File • Log File
ScheduleInform	This method is used to request the CPE to schedule a one-time Inform method call (separate from its periodic Inform method calls) sometime in the future.
FactoryReset	This method resets the CPE to its factory default state.
TransferComplete	This method informs the ACS of the completion (either successful or unsuccessful) of a file transfer initiated by an earlier Download or Upload method call.
AddObject	This method is used to add a new instance of an object defined on the CPE.
DeleteObject	This method is used to remove a particular instance of an object.

For more information on TR-069, refer to [Yealink TR-069 Technote](#).

Procedure

TR-069 can be configured using the configuration files or locally.

Configuration File	<y00000000 00xx>.cfg	<p>Configure TR-069 feature.</p> <p>Parameters:</p> <p>managementserver.enable</p> <p>managementserver.username</p> <p>managementserver.password</p> <p>managementserver.url</p> <p>managementserver.connection_request_username</p> <p>managementserver.connection_request_password</p> <p>managementserver.periodic_inform_enable</p> <p>managementserver.periodic_inform_interval</p>
Local	Web User Interface	<p>Configure TR-069 feature.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G /T21(P) E2/T19(P) E2/CP860:</p> <p>http://<phoneIPAddress>/servlet?p=settings-tr069&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet?m=mod_data&p=settings-tr069&q=load</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
managementserver.enable	0 or 1	0
<p>Description:</p> <p>Enables or disables the TR-069 feature.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>Web User Interface:</p> <p>Settings->TR069->Enable TR069</p> <p>Phone User Interface:</p> <p>None</p>		

Parameters	Permitted Values	Default
managementserver.username	String within 128 characters	Blank
<p>Description: Configures the user name for the IP phone to authenticate with the ACS (Auto Configuration Servers). Leave it blank if no authentication is required.</p> <p>Example: managementserver.username = tr69</p> <p>Web User Interface: Settings->TR069->ACS Username</p> <p>Phone User Interface: None</p>		
managementserver.password	String within 64 characters	Blank
<p>Description: Configures the password for the IP phone to authenticate with the ACS (Auto Configuration Servers). Leave it blank if no authentication is required.</p> <p>Example: managementserver.password = tr69</p> <p>Web User Interface: Settings->TR069->ACS Password</p> <p>Phone User Interface: None</p>		
managementserver.url	URL within 511 characters	Blank
<p>Description: Configures the access URL of the ACS (Auto Configuration Servers).</p> <p>Example: managementserver.url = http://officetelprov.orangero.net:8080/ftacs-digest/ACS</p> <p>Note: Yealink SIP VPT49G IP phones also support obtaining the URL of the ACS by detecting DHCP option 43. For more information on DHCP option 43, refer to DHCP Option on page 73.</p>		

Parameters	Permitted Values	Default
Web User Interface: Settings->TR069->ACS URL Phone User Interface: None		
managementserver.connection_request_username	String within 128 characters	Blank
Description: Configures the user name for the IP phone to authenticate the incoming connection requests. Example: managementserver.connection_request_username = accuser Web User Interface: Settings->TR069->Connection Request Username Phone User Interface: None		
managementserver.connection_request_password	String within 64 characters	Blank
Description: Configures the password for the IP phone to authenticate the incoming connection requests. Example: managementserver.connection_request_password = acspwd Web User Interface: Settings->TR069->Connection Request Password Phone User Interface: None		
managementserver.periodic_inform_enable	0 or 1	1
Description: Enables or disables the IP phone to periodically report its configuration information to the ACS (Auto Configuration Servers). 0-Disabled 1-Enabled		

Parameters	Permitted Values	Default
Web User Interface: Settings->TR069->Enable Periodic Inform Phone User Interface: None		
managementserver.periodic_inform_interval	Integer from 5 to 4294967295	60
Description: Configures the interval (in seconds) for the IP phone to report its configuration to the ACS (Auto Configuration Servers). Note: It works only if the value of the parameter "managementserver.periodic_inform_enable" is set to 1 (Enabled). Web User Interface: Settings->TR069->Periodic Inform Interval (seconds) Phone User Interface: None		

To configure TR-069 via web user interface:

1. Click on **Settings->TR069**.
2. Select **Enabled** from the pull-down list of **Enable TR069**.
3. Enter the user name and password authenticated by the ACS in the **ACS Username** and **ACS Password** fields.
4. Enter the URL of the ACS in the **ACS URL** field.
5. Select the desired value from the pull-down list of **Enable Periodic Inform**.
6. Enter the desired time in the **Periodic Inform Interval (seconds)** field.

- Enter the user name and password authenticated by the IP phone in the **Connection Request Username** and **Connection Request Password** fields.

The screenshot shows the Yealink T236 web interface. The 'Settings' tab is selected, and the 'TR069' configuration page is displayed. The 'Enable TR069' dropdown is set to 'Enabled'. The 'Connection Request Username' and 'Connection Request Password' fields are highlighted with a red box. The 'Confirm' button is visible at the bottom.

- Click **Confirm** to accept the change.

IPv6 Support

Because Internet Protocol version 4 (IPv4) uses a 32-bit address, it cannot meet the increased demands for unique IP addresses for all devices that connect to the Internet. Therefore, Internet Protocol version 6 (IPv6) is the next generation network layer protocol, which designed as a replacement for the current IPv4 protocol.

IPv6 is developed by the Internet Engineering Task Force (IETF) to deal with the long-anticipated problem of IPv4 address exhaustion. Yealink IP Phone supports IPv4 addressing mode, IPv6 addressing mode, as well as an IPv4&IPv6 dual stack addressing mode. IPv4 uses a 32-bit address, consisting of four groups of three decimal digits separated by dots; for example, 192.168.1.100. IPv6 uses a 128-bit address, consisting of eight groups of four hexadecimal digits separated by colons; for example, 2026:1234:1:1:215:65ff:fe1f:caa.

VoIP network based on IPv6 can provide end-to-end security capabilities, enhanced Quality of Service (QoS), a set of service requirements to deliver performance guarantee while transporting traffic over the network.

If you configure the network settings on the phone for an IPv6 network, you can set up an IP address for the phone either by using SLAAC (ICMPv6), DHCPv6 or by manually entering an IP address. Ensure that your network environment supports IPv6. Contact your ISP for more information.

IPv6 Address Assignment Method

Supported IPv6 address assignment methods:

- Manual Assignment:** An IPv6 address and other configuration parameters (e.g.,

DNS server) for the IP phone can be statically configured by an administrator.

- Stateless Address Autoconfiguration (SLAAC)/ ICMPv6:** SLAAC is one of the most convenient methods to assign IP addresses to IPv6 nodes. SLAAC requires no manual configuration of the IP phone, minimal (if any) configuration of routers, and no additional servers. To use IPv6 SLAAC, the IP phone must be connected to a network with at least one IPv6 router connected. This router is configured by the network administrator and sends out Router Advertisement announcements onto the link. These announcements can allow the on-link connected IP phone to configure itself with IPv6 address, as specified in RFC 4862.
- Stateful DHCPv6:** The Dynamic Host Configuration Protocol for IPv6 (DHCPv6) has been standardized by the IETF through RFC 3315. DHCPv6 enables DHCP servers to pass configuration parameters such as IPv6 network addresses to IPv6 nodes. It offers the capability of automatic allocation of reusable network addresses and additional configuration flexibility. This protocol is a stateful counterpart to "IPv6 Stateless Address Autoconfiguration" ([RFC 2462](#)), and can be used separately or concurrently with the latter to obtain configuration parameters.

How the IP phone obtains the IPv6 address and network settings?

The following table lists where the IP phone obtains the IPv6 address and other network settings:

DHCPv6	SLAAC (ICMPv6)	How the IP phone obtains the IPv6 address and network settings?
Disabled	Disabled	You have to manually configure the static IPv6 address and other network settings.
Disabled	Enabled	The IP phone can obtain the IPv6 address via SLAAC, but the other network settings must be configured manually.
Enabled	Disabled	The IP phone can obtain the IPv6 address and the other network settings via DHCPv6.
Enabled	Enabled	The IP phone can obtain the IPv6 address via SLAAC and obtain other network settings via DHCPv6.

Procedure

IPv6 can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure the IPv6 address assignment method. Parameters: network.ip_address_mode network.ipv6_internet_port.type network.ipv6_internet_port.ip network.ipv6_prefix network.ipv6_internet_port.gateway network.ipv6_icmp_v6.enable
		Configure the IPv6 static DNS address. Parameters: network.ipv6_primary_dns network.ipv6_secondary_dns
	<y0000000000xx>.cfg	Configure the IPv6 static DNS. Parameter: network.ipv6_static_dns_enable
Local	Web User Interface	Configure the IPv6 address assignment method. Configure the IPv6 static DNS. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=network&q=load">http://<phoneIPAddress>/servlet?p=network&q=load For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=network&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=network&q=load
	Phone User Interface	Configure the IPv6 address assignment method. Configure the IPv6 static DNS. Configure the IPv6 static DNS address.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.ip_address_mode	0, 1 or 2	0
Description: Configures the IP address mode. 0-IPv4 1-IPv6 2-IPv4 & IPv6 Note: If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Network->Basic->Internet Port->Mode (IPv4/IPv6) Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->WAN Port->IP Mode		
network.ipv6_internet_port.type	0 or 1	0
Description: Configures the Internet (WAN) port type for IPv6. 0-DHCP 1-Static IP Address Note: It works only if the value of the parameter "network.ip_address_mode" is set to 1 (IPv6) or 2 (IPv4 & IPv6). If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Network->Basic->IPv6 Config Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->WAN Port->IPv6		
network.ipv6_static_dns_enable	0 or 1	0
Description: Triggers the static IPv6 DNS feature to on or off. 0-Off		

Parameters	Permitted Values	Default
<p>1-On</p> <p>If it is set to 0 (Off), the IP phone will use the IPv6 DNS obtained from DHCP.</p> <p>If it is set to 1 (On), the IP phone will use manually configured static IPv6 DNS.</p> <p>Note: It works only if the value of the parameter "network.ipv6_internet_port.type" is set to 0 (DHCP). If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Network->Basic->IPv6 Config->IPv6 Static DNS</p> <p>Phone User Interface:</p> <p>Menu->Settings->Advanced Settings (default: admin) ->Network->WAN Port->IPv6->DHCP IPv6 Client->Static DNS</p>		
network.ipv6_internet_port.ip	IPv6 address	Blank
<p>Description:</p> <p>Configures the IPv6 address.</p> <p>Example:</p> <p>network.ipv6_internet_port.ip = 2026:1234:1:1:215:65ff:fe1f:caa</p> <p>Note: It works only if the value of the parameter "network.ip_address_mode" is set to 1 (IPv6) or 2 (IPv4 & IPv6), and "network.ipv6_internet_port.type" is set to 1 (Static IP Address). If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Network->Basic->IPv6 Config->Static IP Address->IP Address</p> <p>Phone User Interface:</p> <p>Menu->Settings->Advanced Settings (default password: admin) ->Network->WAN Port->IPv6->Static IPv6 Client->IPv6 IP</p>		
network.ipv6_prefix	Integer from 0 to 128	64
<p>Description:</p> <p>Configures the IPv6 prefix.</p> <p>Note: It works only if the value of the parameter "network.ip_address_mode" is set to 1 (IPv6) or 2 (IPv4 & IPv6), and "network.ipv6_internet_port.type" is set to 1 (Static IP Address). If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface:</p>		

Parameters	Permitted Values	Default
Network->Basic->IPv6 Config->Static IP Address->IPv6 Prefix(0~128) Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->WAN Port->IPv6->Static IPv6 Client->IPv6 IP Prefix		
network.ipv6_internet_port.gateway	IPv6 address	Blank
Description: Configures the IPv6 default gateway. Example: network.ipv6_internet_port.gateway = 3036:1:1:c3c7:c11c:5447:23a6:255 Note: It works only if the value of the parameter "network.ip_address_mode" is set to 1 (IPv6) or 2 (IPv4 & IPv6), and "network.ipv6_internet_port.type" is set to 1 (Static IP Address). If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Network->Basic->IPv6 Config->Static IP Address->Gateway Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->WAN Port->IPv6->Static IPv6 Client->IPv6 Default Gateway		
network.ipv6_primary_dns	IPv6 address	Blank
Description: Configures the primary IPv6 DNS server. Example: network.ipv6_primary_dns = 3036:1:1:c3c7: c11c:5447:23a6:256 Note: It works only if the value of the parameter "network.ip_address_mode" is set to 1 (IPv6) or 2 (IPv4 & IPv6). In DHCP environment, you also need to make sure the value of the parameter "network.ipv6_static_dns_enable" is set to 1 (On). If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Network->Basic->IPv6 Config->Static IP Address->Primary DNS Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->WAN Port->IPv6->Static IPv6 Client->IPv6 Pri.DNS Or Menu->Settings->Advanced Settings (default password: admin) ->Network->WAN Port->IPv6->DHCP IPv6 Client->Staic DNS(Enabled) ->IPv6		

Parameters	Permitted Values	Default
Pri.DNS		
network.ipv6_secondary_dns	IPv6 address	Blank
<p>Description: Configures the secondary IPv6 DNS server.</p> <p>Example: network.ipv6_secondary_dns = 2026:1234:1:1:c3c7:c11c:5447:23a6</p> <p>Note: It works only if the value of the parameter "network.ip_address_mode" is set to 1 (IPv6) or 2 (IPv4 & IPv6). In DHCP environment, you also need to make sure the value of the parameter "network.ipv6_static_dns_enable" is set to 1 (On). If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Basic->IPv6 Config->Static IP Address->Secondary DNS</p> <p>Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->WAN Port->IPv6->Static IPv6 Client->IPv6 Sec.DNS</p> <p>Or Menu->Settings->Advanced Settings (default password: admin) ->Network->WAN Port->IPv6->DHCP IPv6 Client->Static DNS(Enabled) ->IPv6 Sec.DNS</p>		
network.ipv6_icmp_v6.enable	0 or 1	1
<p>Description: Enables or disables the IP phone to obtain IPv6 network settings via SLAAC (Stateless Address Autoconfiguration) method.</p> <p>0-Disabled 1-Enabled</p> <p>Note: If you change this parameter, the IP phone will reboot to make the change take effect. It is only applicable to SIP VP-T49G/SIP-T48G/T46G/T29G IP phones. SLAAC is enabled on SIP-T42G/T41P/T40P/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860 IP phones by default. You are not allowed to configure this parameter for those IP phones.</p> <p>Web User Interface: Network->Advanced->ICMPv6 Status->Active</p> <p>Phone User Interface: None</p>		

To configure IPv6 address assignment method via web user interface:

1. Click on **Network->Basic**.
2. Select the desired address mode (**IPv6** or **IPv4 & IPv6**) from the pull-down list of **Mode(IPv4/IPv6)**.
3. In the **IPv6 Config** block, mark the **DHCP** or the **Static IP Address** radio box.
 - If you mark the **Static IP Address** radio box, configure the IPv6 address and other configuration parameters in the corresponding fields.

Yealink T236 Log Out

Status Account **Network** DSSKey Features Settings Directory Security

Basic PC Port Advanced

Internet Port

Mode(IPv4/IPv6) IPv6

IPv4 Config

☒ DHCP

☐ Static IP Address

IP Address

Subnet Mask

Gateway

Static DNS ☐ On ☒ Off

Primary DNS

Secondary DNS

☐ PPPoE

User Name

Password

IPv6 Config

☐ DHCP

☒ Static IP Address

IP Address 2026:1234:1:1:215:65ff:fe1

IPv6 Prefix(0~128) 64

Gateway 3036:1:1:c3c7:c11c:5447:2

IPv6 Static DNS ☒ On ☐ Off

Primary DNS 3036:1:1:c3c7:c11c:5447:

Secondary DNS 2026:1234:1:1:c3c7:c11c:5

Confirm Cancel

NOTE

DHCP
DHCP (Dynamic Host Configuration Protocol) is a network protocol used to dynamically allocate network parameters to IP phones.

Static IP Address
Specifies the network parameters of IP phones manually.

PPPoE
It allows users to share a common DSL connection to the Internet.

IPv6 Support
IPv6 is developed to deal with the long-anticipated problem of IPv4 address exhaustion.

You can click here to get more guides.

- (Optional.) If you mark the **DHCP** radio box, you can configure the static DNS address in the corresponding fields.

The screenshot shows the Yealink T23G web interface. The 'Network' tab is selected. Under 'Internet Port', the 'Mode' is set to 'IPv6'. The 'IPv4 Config' section has 'DHCP' selected. The 'IPv6 Config' section is highlighted with a red box, showing 'DHCP' selected and 'IPv6 Static DNS' set to 'On'. The 'Primary DNS' is '3036:1:1:c3c7:c11c:5447::' and the 'Secondary DNS' is '2026:1234:1:1:c3c7:c11c:5'. A 'NOTE' sidebar on the right explains DHCP, Static IP Address, PPPoE, and IPv6 Support.

4. Click **Confirm** to accept the change.
A dialog box pops up to prompt that the settings will take effect after a reboot.
5. Click **OK** to reboot the phone.

To configure SLAAC feature via web user interface (only applicable to SIP VPT49G/SIPT48G/T46G/T29G):

1. Click on **Network->Advanced**.

- In the **ICMPv6 Status** block, select the desired value from the pull-down list of **Active**.

The screenshot shows the Yealink T236 web interface. The 'Network' tab is selected. Under the 'Advanced' section, the 'ICMPv6 Status' is highlighted with a red box. The 'ICMPv6 Status' is currently set to 'Enabled'. Other settings visible include LLDP (Active, Enabled), CDP (Active, Disabled), NAT (Active, Enabled), and VPN (Active, Enabled). The 'Registration Random' is set to 0. The 'STUN Server' is 218.107.220.201 and the 'STUN Port' is 3478. The 'Upload VPN Config' button is also visible.

- Click **Confirm** to accept the change.
A dialog box pops up to prompt that the settings will take effect after a reboot.
- Click **OK** to reboot the phone.

To configure IPv6 address assignment method via phone user interface:

- Press **Menu->Settings->Advanced Settings** (default password: admin)
->**Network->WAN Port**.
- Press **◀** or **▶** to select **IPv4 & IPv6** or **IPv6** from the **IP Mode** field.
- Press **▲** or **▼** to highlight **IPv6** and press the **Enter** soft key.
- Press **▲** or **▼** to select the desired IPv6 address assignment method.

If you select the **Static IPv6 Client**, configure the IPv6 address and other network parameters in the corresponding fields.

- Press the **Save** soft key to accept the change.

The IP phone reboots automatically to make settings effective after a period of time.

To configure static DNS when DHCP is used via phone user interface:

- Press **Menu->Settings->Advanced Settings** (default password: admin)
->**Network->WAN Port->IPv6->DHCP IPv6 Client**.
- Press **◀** or **▶**, or the **Switch** soft key to select **Enabled** from the **Static DNS** field.
- Enter the desired value in the **IPv6 Pri.DNS** and **IPv6 Sec.DNS** field respectively.
- Press the **Save** soft key to accept the change.

The IP phone reboots automatically to make settings effective after a period of time.

Configuring Audio Features

This chapter provides information for making configuration changes for the following audio features:

- [Ring Tones](#)
- [Distinctive Ring Tones](#)
- [Tones](#)
- [Voice Mail Tone](#)
- [Headset Prior](#)
- [Dual Headset](#)
- [Sending Volume](#)
- [Audio Codecs](#)
- [Acoustic Clarity Technology](#)

Ring Tones

Ring tones are used to indicate incoming calls acoustically. Users can select a built-in system ring tone or a custom ring tone for the phone or account. To set the custom ring tones, you need to upload the custom ring tones to the IP phone in advance.

The ring tone format must meet the following:

Phone Model	Format	Single File Size	Total File Size
SIP VP-T49G/SIP-T48G/T46G/T29G	.wav	<=8MB	<=20MB
SIP-T42G/T41P/T40P/T27P/T23P/ T23G/T21(P) E2/T19(P) E2/CP860	.wav	<=100KB	<=100KB

Note

The ring tone file must be PCMU audio format, mono channel, 8K sample rate and 16 bit resolution.

Procedure

Ring tones can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure a ring tone for the IP phone.
--------------------	---------------------	---

		Parameter: phone_setting.ring_type
		Specify the access URL of the custom ring tone. Parameter: ringtone.url
		Delete all custom ring tone files. Parameter: ringtone.delete
	<MAC>.cfg	Configure a ring tone on a per-line basis. Parameters: account.X.ringtone.ring_type
Local	Web User Interface	Upload the custom ring tones. Configure a ring tone for the IP phone. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p=settings-preference&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet?m=mod_data&p=settings-preference&q=load
		Configure a ring tone on a per-line basis. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p=account-basic&q=load&acc=0

		For SIP VP-T49G: http://<phoneIPAddress>/ser vlet?m=mod_data&p=accou nt-basic&q=load&acc=0
	Phone User Interface	Configure a ring tone for the IP phone. Configure a ring tone for the account.

Details of the Configuration Parameter:


Parameters	Permitted Values	Default
phone_setting.ring_type	Refer to the following content	Refer to the following content
<p>Description: Configures a ring tone for the IP phone.</p> <p>Permitted Values: Resource:Ring1.wav, Resource:Ring2.wav, Resource:Ring3.wav, Resource:Ring4.wav, Resource:Ring5.wav, Resource:Ring6.wav, Resource:Ring7.wav, Resource:Ring8.wav, Resource:Silent.wav, Resource:Splash.wav, Default:default-ring.wav or custom ring tone name (e.g., Config:Customring.wav).</p> <p>For SIP VP-T49G: The default value is Default:default-ring.wav.</p> <p>For SIPT48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/CP860: The default value is Resource:Ring1.wav.</p> <p>Example: To configure a phone built-in ring tone (e.g., Ring1.wav): phone_setting.ring_type = Resource:Ring1.wav To configure a custom ring tone (e.g., Customring.wav): phone_setting.ring_type = Config:Customring.wav To configure a phone default ring tone: phone_setting.ring_type = Default:default-ring.wav</p> <p>Web User Interface: Settings->Preference->Ring Type</p> <p>Phone User Interface: Settings->Basic->Sound->Ring Tones->Common</p>		
account.X.ringtone.ring_type	Refer to the following content	Common

Parameters	Permitted Values	Default
<p>Description: Configures a ring tone for account X.</p> <p>Example: account.1.ringtone.ring_type = Ring3.wav It means configuring Ring3.wav for account1. account.1.ringtone.ring_type = Common It means account1 will use the ring tone selected for the IP phone configured by the parameter "phone_setting.ring_type".</p> <p>Permitted Values: Common, Ring1.wav, Ring2.wav, Ring3.wav, Ring4.wav, Ring5.wav, Ring6.wav, Ring7.wav, Ring8.wav, Silent.wav, Splash.wav or custom ring tone name (e.g., Customring.wav). X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Web User Interface: Account->Basic->Ring Type</p> <p>Phone User Interface: Menu->Settings->Basic Settings->Sound->Ring Tones->Account X</p>		
ringtone.url	URL within 511 characters	Blank
<p>Description: Configures the access URL of the custom ring tone file.</p> <p>Example: ringtone.url = tftp://192.168.1.100/Customring.wav</p> <p>Web User Interface: Settings->Preference->Upload Ringtone</p> <p>Phone User Interface: None</p>		
ringtone.delete	http://localhost/all	Blank

Parameters	Permitted Values	Default
<p>Description: Delete all custom ring tone files.</p> <p>Example: ringtone.delete = http://localhost/all</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		

To upload a custom ring tone via web user interface:

1. Click on **Settings->Preference**.
2. In the **Upload Ringtone** field, click **Browse** to locate a ring tone file (the file format must be *.wav) from your local system.
3. Click **Upload** to upload the file.



The custom ring tone appears in the pull-down list of **Ring Type**.

To change the ring tone for the phone via web user interface:

1. Click on **Settings->Preference**.

2. Select the desired ring tone from the pull-down list of **Ring Type**.

The screenshot shows the Yealink T236 web interface. The 'Settings' tab is active. In the 'Ring' section, the 'Ring Type' dropdown is highlighted with a red box and shows 'Ring1.wav'. Below it, the 'Upload Ringtone' section has a 'Browse...' button, 'No file selected.' text, and 'Upload' and 'Cancel' buttons. At the bottom, there are 'Confirm' and 'Cancel' buttons. A 'NOTE' section on the right provides information about Language, Live Dialpad, Backlight, and Contrast settings.

3. Click **Confirm** to accept the change.

To change the ring tone for the account via web user interface:

1. Click on **Account->Basic**.
2. Select the desire account from the pull-down list of **Account**.
3. Select the desired ring tone from the pull-down list of **Ring Type**.

The screenshot shows the Yealink T236 web interface. The 'Account' tab is active. In the 'Basic' section, the 'Ring Type' dropdown is highlighted with a red box and shows 'Common'. At the bottom, there are 'Confirm' and 'Cancel' buttons. A 'NOTE' section on the right provides information about Anonymous Call and Anonymous Call Rejection settings.



4. Click **Confirm** to accept the change.

To select a ring tone for the phone via phone user interface:

1. Press **Menu->Settings->Basic Settings->Sound->Ring Tones->Common**.
2. Press **▲** or **▼** to select the desired ring tone.
3. Press the **Save** soft key to accept the change or the **Back** soft key to cancel.

To select a ring tone for the account via phone user interface:

1. Press **Menu->Settings->Basic Settings->Sound->Ring Tones**.
2. Press **▲** or **▼** to select the desired account and then press the **Enter** soft key.

3. Press  or  to select the desired ring tone.
If **Common** is selected, this account will use the ring tone selected for the phone.
4. Press the **Save** soft key to accept the change or the **Back** soft key to cancel.

Distinctive Ring Tones

Distinctive ring tones allows certain incoming calls to trigger IP phones to play distinctive ring tones. The IP phone inspects the INVITE request for an "Alert-Info" header when receiving an incoming call. If the INVITE request contains an "Alert-Info" header, the IP phone strips out the URL or keyword parameter and maps it to the appropriate ring tone.

Note

If the caller already exists in the local directory, the ring tone assigned to the caller should be preferentially played.

Alert-Info headers in the following four formats:

- 1) Alert-Info: Bellcore-drN
- 2) Alert-Info: ringtone-N (or Alert-Info: MyMelodyN)
- 3) Alert-Info: <URL>
- 4) Alert-Info: info=info text;x-line-id=0

1) Alert-Info: Bellcore-drN

When the Alert-Info header contains the keyword "Bellcore-drN", the IP phone will play the desired ring tone.

The following table identifies the corresponding ring tone:

Value of N	Ring Tone (features.alert_info_tone = 1)	Ring Tone (features.alert_info_tone = 0)
1	Bellcore-dr1	Ring1.wav
2	Bellcore-dr2	Ring2.wav
3	Bellcore-dr3	Ring3.wav
4	Bellcore-dr4	Ring4.wav
5	Bellcore-dr5	Ring5.wav
6	Ring6.wav	
7	Ring7.wav	
8	Ring8.wav	

Value of N	Ring Tone (features.alert_info_tone = 1)	Ring Tone (features.alert_info_tone = 0)
9	Silent.wav	
10	Splash.wav	
N<1 or N>10	Ring1.wav	

Examples:

Alert-Info: http://127.0.0.1/Bellcore-dr1
 Alert-Info: test/Bellcore-dr1
 Alert-Info: Bellcore-dr1
 Alert-Info: Bellcore-dr1;x-line-id=1
 Alert-Info: <http://10.1.0.31>;info=Bellcore-dr1

The following table identifies the different Bellcore ring tone patterns and cadences (These ring tones are designed for the BroadWorks server).

Bellcore Tone	Pattern ID	Pattern	Cadence	Minimum Duration (ms)	Nominal Duration (ms)	Maximum Duration (ms)
Bellcore-dr1 (standard)	1	Ring	2s	1800	2000	2200
		Silent	4s	3600	4000	4400
Bellcore-dr2	2	Ring	Long	630	800	1025
		Silent		315	400	525
		Ring	Long	630	800	1025
		Silent		3475	4000	4400
Bellcore-dr3	3	Ring	Short	315	400	525
		Silent		145	200	525
		Ring	Short	315	400	525
		Silent		145	200	525
		Ring	Long	630	800	1025
		Silent		2975	4000	4400
Bellcore-dr4	4	Ring	Short	200	300	525
		Silent		145	200	525
		Ring	Long	800	1000	1100
		Silent		145	200	525
		Ring	Short	200	300	525

Bellcore Tone	Pattern ID	Pattern	Cadence	Minimum Duration (ms)	Nominal Duration (ms)	Maximum Duration (ms)
		Silent		2975	4000	4400
Bellcore-dr5	5	Ringin		450	500	550

Note

If the user is waiting for a call, “Bellcore-dr5” is a ring splash tone that reminds the user that the DND or Always Call Forward feature is enabled on the server side.

2) Alert-Info: ringtone-N (or Alert-Info: MyMelodyN)

When the Alert-Info header contains the keyword “ringtone-N” or “MyMelodyN”, the IP phone will play the corresponding local ring tone (RingN.wav), or play the first local ring tone (Ring1.wav) in about 10 seconds if “N” is greater than 10 or less than 1.

Examples:

Alert-Info: ringtone-2

Alert-Info: ringtone-2;x-line-id=1

Alert-Info: <http://10.1.0.31>;info=ringtone-2

Alert-Info: <http://127.0.0.1/ringtone-2>

Alert-Info: MyMelody2

Alert-Info: MyMelody2;x-line-id=1

Alert-Info: <http://10.1.0.31>;x-line-id=0;info=MyMelody2

The following table identifies the corresponding local ring tone:

Value of N	Ring Tone
1	Ring1.wav
2	Ring2.wav
3	Ring3.wav
4	Ring4.wav
5	Ring5.wav
6	Ring6.wav
7	Ring7.wav
8	Ring8.wav
9	Silent.wav

Value of N	Ring Tone
10	Splash.wav
N<1 or N>10	Ring1.wav

3) Alert-Info: <URL>

When the Alert-Info header contains a remote URL, the IP phone will try to download the WAV ring tone file from the URL and then play the remote ring tone if the value of the parameter "account.X.alert_info_url_enable" is set to 1 (or the item called "Distinctive Ring Tones" on the web user interface is Enabled), or play the preconfigured local ring tone in about 10 seconds if the value of the parameter "account.X.alert_info_url_enable" is set to 0 or if the IP phone fails to download the remote ring tone.

Example:

```
Alert-Info: http://192.168.0.12:8080/Custom.wav
```

4) Alert-Info: info=info text;x-line-id=0

When the Alert-Info header contains an info text, the IP phone will map the text with the Internal Ringer Text preconfigured (or the value of the parameter "distinctive_ring_tones.alert_info.X.text" is configured) on the IP phone, and then play the ring tone associated with the Internal Ringer Text (the ring tone can be configured by the parameter "distinctive_ring_tones.alert_info.X.ringer"). If no internal ringer text maps, the IP phone will play the preconfigured local ring tone in about 10 seconds.

Example:

```
Alert-Info: info=family;x-line-id=0
Alert-Info: <http://10.1.0.31>;info=family
Alert-Info: <http://10.1.0.31>;info=family;x-line-id=0
```

Auto Answer

If the INVITE request contains the following type of strings, the IP phone will answer incoming calls automatically without playing the ring tone:

- Alert-Info: Auto Answer
- Alert-Info: info = alert-autoanswer
- Alert-Info: answer-after = 0 (or Alert-Info: Answer-After = 0)

If enable auto answer tone feature is enabled, the phone plays a warning tone to alert the user before answering the incoming call. For more information on Enable auto answer tone, refer to [Auto Answer](#) on page 299.

Note

If the Alert-Info header contains multiple types of keywords, the IP phone will process the keywords in the following order: AutoAnswer>URL>info text/Bellcore-drN/ringtone-N>MyMelodyN.

Procedure

Distinctive ring tones can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure distinctive ring tones. Parameter: account.X.alert_info_url_enable
	<y0000000000xx>.cfg	Configure the internal ringer text and internal ringer file. Parameters: features.alert_info_tone distinctive_ring_tones.alert_info.X.text distinctive_ring_tones.alert_info.X.ringer
Local	Web User Interface	Configure distinctive ring tones. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0">http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0 For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0">http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0
		Configure the internal ringer text and internal ringer file. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=settings-ring&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=settings-ring&q=load For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=settings-ring&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=settings-ring&q=load

		et?m=mod_data&p=settings-ring&q=load
--	--	--------------------------------------

Details of Configuration Parameters:

Parameters	Permitted Values	Default
account.X.alert_info_url_enable	0 or 1	1
Description: Enables or disables the IP phone to download the ring tone from the URL contained in the Alert-Info header for account X. 0 -Disabled 1 -Enabled X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Web User Interface: Account->Advanced->Distinctive Ring Tones Phone User Interface: None		
features.alert_info_tone	0 or 1	0
Description: Enables or disables the IP phone to map the keywords in the Alert-info header to the specified Bellcore ring tones. 0 -Disabled 1 -Enabled Web User Interface: None Phone User Interface: None		

Parameters	Permitted Values	Default
distinctive_ring_tones.alert_info.X.text (X ranges from 1 to 10)	String within 32 characters	Blank
Description: Configures the internal ringer text to map the keywords contained in the Alert-Info header. Example: distinctive_ring_tones.alert_info.1.text = Family Web User Interface: Settings->Ring->Internal Ringer Text Phone User Interface: None		
distinctive_ring_tones.alert_info.X.ringer (X ranges from 1 to 10)	Integer from 1 to 10	1
Description: Configures the desired ring tones for each internal ringer text. The value ranges from 1 to 10, the digit stands for the appropriate ring tone. 1-Ring1.wav 2-Ring2.wav 3-Ring3.wav 4-Ring4.wav 5-Ring5.wav 6-Ring6.wav 7-Ring7.wav 8-Ring8.wav 9-Silent.wav 10-Splash.wav Web User Interface: Settings->Ring->Internal Ringer File Phone User Interface: None		

To configure distinctive ring tones via web user interface:

1. Click on **Account->Advanced**.
2. Select the desired account from the pull-down list of **Account**.

3. Select the desired value from the pull-down list of **Distinctive Ring Tones**.

The screenshot shows the Yealink T236 web interface with the 'Account' tab selected. The 'Distinctive Ring Tones' field is highlighted with a red box and set to 'Enabled'. Other fields include 'Keep Alive Type' (Default), 'Keep Alive Interval(Seconds)' (30), 'RPort' (Disabled), 'Subscribe Period(Seconds)' (1800), 'Early Media' (Disabled), 'SIP Server Type' (Default), 'Music Server URI' (sip:moh@sip.com), 'Directed Call Pickup Code' (*97), 'Group Call Pickup Code' (*98), 'Unregister When Reboot' (Enabled), 'Out Dialog BLF' (Enabled), 'VQ RTPC-XR Collector name' (collector), 'VQ RTPC-XR Collector address' (10.2.1.98), and 'VQ RTPC-XR Collector port' (5060). A 'NOTE' section on the right provides information about DTMF, Session Timer, Busy Lamp Field/BLF List, Shared Call Appearance (SCA)/ Bridge Line Appearance (BLA), and Network Conference.

4. Click **Confirm** to accept the change.

To configure the internal ringer text and internal ringer file via web user interface:

1. Click on **Settings->Ring**.
2. Enter the keywords in the **Internal Ringer Text** fields.
3. Select the desired ring tones for each text from the pull-down lists of **Internal Ringer File**.

The screenshot shows the Yealink T236 web interface with the 'Settings' tab selected and the 'Ring' sub-tab active. The 'Internal Ringer Text' and 'Internal Ringer File' fields are highlighted with a red box. The 'Internal Ringer File' field is set to 'Ring1.wav'. Other fields include 'Internal Ringer Text', 'Internal Ringer File', and 'Internal Ringer File'. A 'NOTE' section on the right provides information about Distinctive Ring Tones.

4. Click **Confirm** to accept the change.

Tones

When receiving a message, the IP phone will play a warning tone. You can customize

tones or select specialized tone sets (vary from country to country) to indicate different conditions of the IP phone. The default tones used on IP phones are the US tone sets.

Available tone sets for IP phones:

- Australia
- Austria
- Brazil
- Belgium
- China
- Czech
- Denmark
- Finland
- France
- Germany
- Great Britain
- Greece
- Hungary
- Lithuania
- India
- Italy
- Japan
- Mexico
- New Zealand
- Netherlands
- Norway
- Portugal
- Spain
- Switzerland
- Sweden
- Russia
- United States
- Chile
- Czech ETSI

Configured tones can be heard on IP phones for the following conditions.

Condition	Description
Dial	When in the dialing interface
Ring Back	Ring-back tone

Condition	Description
Busy	When the callee is busy
Congestion	When the network is congested
Call Waiting	Call waiting tone (For more information on call waiting, refer to Call Waiting)
Dial Recall	When receiving a call back
Info	When receiving a special message
Stutter	When receiving a voice mail (For more information on voice mail tone, refer to Voice Mail Tone)
Message	When receiving a text message (For more information on text message, refer to Short Message Service (SMS))
Auto Answer	When automatically answering a call (For more information on auto answer, refer to Auto Answer)

Procedure

Tones can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	<p>Configure the tones for the IP phone.</p> <p>Parameters:</p> <p>voice.tone.country</p> <p>voice.tone.dial</p> <p>voice.tone.ring</p> <p>voice.tone.busy</p> <p>voice.tone.congestion</p> <p>voice.tone.callwaiting</p> <p>voice.tone.dialrecall</p> <p>voice.tone.info</p> <p>voice.tone.stutter</p> <p>voice.tone.message</p> <p>voice.tone.autoanswer</p>
Local	Web User Interface	<p>Configure the tones for the IP phone.</p> <p>Navigate to:</p> <p>For</p>

		SIP-T48G/T46G/T42G/T41P/T40P/T 29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servl et?p=settings-tones&q=load For SIP VP-T49G: http://<phoneIPAddress>/servl et?m=mod_data&p=settings-to nes&q=load
--	--	---

Details of Configuration Parameters:

Parameters	Permitted Values	Default
voice.tone.country	Refer to the following content	Custom
<p>Description: Configures the country tone for the IP phone.</p> <p>Permitted Values: Custom, Australia, Austria, Brazil, Belgium, Chile, China, Czech, Czech ETSI, Denmark, Finland, France, Germany, Great Britain, Greece, Hungary, Lithuania, India, Italy, Japan, Mexico, New Zealand, Netherlands, Norway, Portugal, Spain, Switzerland, Sweden, Russia, United States.</p> <p>Example: voice.tone.country = Custom</p> <p>Web User Interface: Settings->Tones->Select Country</p> <p>Phone User Interface: None</p>		
voice.tone.dial	String	Blank
<p>Description: Customizes the dial tone.</p> <p>tonelist = element[,element] [,element]...</p> <p>Where</p> <p>element = [!] Freq1[+Freq2][+Freq3][+Freq4] /Duration</p> <p>Freq: the frequency of the tone (ranges from 200 to 4000Hz). If it is set to 0Hz, it means the tone is not played.</p> <p>For SIP-T40P/T23P/T23G/T21(P) E2/T19(P) E2:</p>		

Parameters	Permitted Values	Default
<p>A tone is comprised of at most two different frequencies.</p> <p>For SIP VP-T49G/SIP-T48G/T46G/T42G/T41P/T29G/T27P/CP860:</p> <p>A tone is comprised of at most four different frequencies.</p> <p>Duration: the duration (in milliseconds) of the dial tone, ranges from 0 to 30000ms.</p> <p>You can configure at most eight different tones for one condition, and separate them by commas. (e.g., 250/200,0/1000,200+300/500,200+500+800+1500/1000).</p> <p>If you want the IP phone to play tones once, add an exclamation mark "!" before tones (e.g., !250/200,0/1000,200+300/500,200+500+800+1500/1000).</p> <p>Note: It works only if the value of the parameter "voice.tone.country" is set to Custom.</p> <p>Web User Interface: Settings->Tones->Dial</p> <p>Phone User Interface: None</p>		
voice.tone.ring	String	Blank
<p>Description:</p> <p>Customizes the ringback tone.</p> <p>The value format is Freq/Duration. For more information on the value format, refer to the parameter "voice.tone.dial".</p> <p>Note: It works only if the value of the parameter "voice.tone.country" is set to Custom.</p> <p>Web User Interface: Settings->Tones->Ring Back</p> <p>Phone User Interface: None</p>		
voice.tone.busy	String	Blank
<p>Description:</p> <p>Customizes the tone when the callee is busy.</p> <p>The value format is Freq/Duration. For more information on the value format, refer to the parameter "voice.tone.dial".</p> <p>Note: It works only if the value of the parameter "voice.tone.country" is set to Custom.</p> <p>Web User Interface: Settings->Tones->Busy</p>		

Parameters	Permitted Values	Default
Phone User Interface: None		
voice.tone.congestion	String	Blank
Description: Customizes the tone when the network is congested. The value format is Freq/Duration. For more information on the value format, refer to the parameter "voice.tone.dial". Note: It works only if the value of the parameter "voice.tone.country" is set to Custom. Web User Interface: Settings->Tones->Congestion Phone User Interface: None		
voice.tone.callwaiting	String	Blank
Description: Customizes the call waiting tone. The value format is Freq/Duration. For more information on the value format, refer to the parameter "voice.tone.dial". Note: It works only if the value of the parameter "voice.tone.country" is set to Custom. Web User Interface: Settings->Tones->Call Waiting Phone User Interface: None		
voice.tone.dialrecall	String	Blank
Description: Customizes the call back tone. The value format is Freq/Duration. For more information on the value format, refer to the parameter "voice.tone.dial". Note: It works only if the value of the parameter "voice.tone.country" is set to Custom. Web User Interface:		

Parameters	Permitted Values	Default
Settings->Tones->Dial Recall Phone User Interface: None		
voice.tone.info	String	Blank
Description: Customizes the info tone. The phone will play the info tone with the special information, for example, the number you are calling is not in service. The value format is Freq/Duration. For more information on the value format, refer to the parameter "voice.tone.dial". Note: It works only if the value of the parameter "voice.tone.country" is set to Custom. Web User Interface: Settings->Tones->Info Phone User Interface: None		
voice.tone.stutter	String	Blank
Description: Customizes the tone when the IP phone receives a voice mail. The value format is Freq/Duration. For more information on the value format, refer to the parameter "voice.tone.dial". Note: It works only if the value of the parameter "voice.tone.country" is set to Custom. Web User Interface: Settings->Tones->Stutter Phone User Interface: None		
voice.tone.message	String	Blank
Description: Customizes the tone when the IP phone receives a text message. The value format is Freq/Duration. For more information on the value format, refer to the parameter "voice.tone.dial". Note: It works only if the value of the parameter "voice.tone.country" is set to		

Parameters	Permitted Values	Default
Custom. Web User Interface: Settings->Tones->Message Phone User Interface: None		
voice.tone.autoanswer	String	Blank
Description: Customizes the warning tone for auto answer. The value format is Freq/Duration. For more information on the value format, refer to the parameter "voice.tone.dial". Note: It works only if the value of the parameter "voice.tone.country" is set to Custom. Web User Interface: Settings->Tones->Auto Answer Phone User Interface: None		

To configure tones via web user interface:

1. Click on **Settings->Tones**.
2. Select the desired value from the pull-down list of **Select Country**.
If you select **Custom**, you can customize a tone for each condition of the IP phone.

3. Click **Confirm** to accept the change.

Voice Mail Tone

Voice mail tone feature allows the IP phone to play a warning tone when receiving a new voice mail. You can customize the warning tone or select specialized tone sets (vary from country to country) for your IP phone. For more information, refer to [Tones](#) on page 768.

Procedure

Voice mail tone can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	<p>Configure whether to play a warning tone when the IP phone receives a new voice mail.</p> <p>Parameters:</p> <p>features.voice_mail_tone_enable</p>
Local	Web User Interface	<p>Configure whether to play a warning tone when the IP phone receives a new voice mail.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>http://<phoneIPAddress>/servlet?p=features-general&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load</p>


Details of the Configuration Parameter:

Parameter	Permitted Values	Default
features.voice_mail_tone_enable	0 or 1	1
<p>Description:</p> <p>Enables or disables the IP phone to play a warning tone when it receives a new voice mail.</p> <p>0-Disabled</p> <p>1-Enabled</p>		

Parameter	Permitted Values	Default
Web User Interface: Features->General Information->Voice Mail Tone Phone User Interface: None		

To configure voice mail tone via web user interface:

- Click on **Features->General Information**.
- Select the desired value from the pull-down list of **Voice Mail Tone**.



- Click **Confirm** to accept the change.

Headset Prior

Headset prior allows users to use headset preferentially if a headset is physically connected to the IP phone. This feature is especially useful for permanent or full-time headset users.

Note It is not applicable to CP860 IP phones.

Procedure

Headset prior can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure headset prior. Parameter: features.headset_prior
--------------------	---------------------	---

Local	Web User Interface	<p>Configure headset prior.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40 P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2: http://<phoneIPAddress>/ser vlet?p=features-general&q= load</p> <p>For SIP VP-T49G: http://<phoneIPAddress>/ser vlet?m=mod_data&p=featur es-general&q=load</p>
--------------	--------------------	--

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
features.headset_prior	0 or 1	0
<p>Description:</p> <p>Enables or disables headset prior feature. You need to press the HEADSET key to activate the headset mode in advance.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 1 (Enabled), the headset mode will not be deactivated until the user presses the HEADSET key again.</p> <p>If it is set to 0 (Disabled), the headset mode can be deactivated by pressing the Speakerphone key or the HEADSET key except the HANDSET key.</p> <p>Note: It is not applicable to CP860 IP phones.</p> <p>Web User Interface:</p> <p>Features->General Information->Headset Prior</p> <p>Phone User Interface:</p> <p>None</p>		

To configure headset prior via web user interface:

1. Click on **Features->General Information**.

2. Select the desired value from the pull-down list of **Headset Prior**.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected. In the 'General Information' section, the 'Headset Prior' dropdown menu is highlighted with a red box and set to 'Enabled'. Other settings include 'Call Waiting' (Enabled), 'Auto Redial' (Disabled), 'Auto Redial Interval' (10), 'Auto Redial Times' (10), 'Dual-Headset' (Enabled), 'Auto-Answer Delay' (1), 'Enable auto answer tone' (Enabled), 'Voice Mail Tone' (Enabled), and 'Auto Linekeys' (Disabled). A 'NOTE' section on the right provides details about various features: Call Waiting, Auto Redial, Key As Send, Hotline, and Call Completion. At the bottom, there are 'Confirm' and 'Cancel' buttons.

3. Click **Confirm** to accept the change.

Dual Headset

Dual headset allows users to use two headsets on one IP phone. To use this feature, users need to physically connect two headsets to the headset and handset jacks respectively. Once the IP phone connects to a call, the user with the headset connected to the headset jack has full-duplex capabilities, while the user with the headset connected to the handset jack is only able to listen.

Note It is not applicable to CP860 IP phones.

Procedure

Dual headset can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure dual headset. Parameter: features.headset_training
Local	Web User Interface	Configure dual headset. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40 P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2: http://<phoneIPAddress>/se rvlet?p=features-general&q

		=load For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=features-general&q=load
--	--	--

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
features.headset_training	0 or 1	0
<p>Description: Enables or disables dual headset feature. 0-Disabled 1-Enabled If it is set to 1 (Enabled), users can use two headsets on one phone. When the IP phone joins in a call, the users with the headset connected to the headset jack have a full-duplex conversation, while the users with the headset connected to the handset jack are only allowed to listen to. Note: It is not applicable to CP860 IP phones.</p> <p>Web User Interface: Features->General Information->Dual-Headset</p> <p>Phone User Interface: None</p>		

To configure dual headset via web user interface:

1. Click on **Features->General Information**.

2. Select the desired value from the pull-down list of **Dual-Headset**.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected. In the 'General Information' section, the 'Dual-Headset' dropdown menu is highlighted with a red box and is set to 'Enabled'. Other settings include 'Call Waiting' (Enabled), 'Call Waiting On Code' (empty), 'Call Waiting Off Code' (empty), 'Auto Redial' (Disabled), 'Auto Redial Interval (1~300s)' (10), 'Auto Redial Times (1~300)' (10), 'Auto-Answer Delay(1~4s)' (1), 'Enable auto answer tone' (Enabled), 'Headset Prior' (Enabled), 'Voice Mail Tone' (Enabled), and 'Auto Linekeys' (Disabled). A 'NOTE' section on the right provides details for 'Call Waiting', 'Auto Redial', 'Key As Send', 'Hotline', and 'Call Completion'. At the bottom, there are 'Confirm' and 'Cancel' buttons.

3. Click **Confirm** to accept the change.

Sending Volume

Sending volume allows user to adjust the sending volume of currently engaged audio devices (handset, speakerphone or headset) when the phone is in use.

Note It is not applicable to CP860 IP phones.

Procedure

Sending volume can be configured using the configuration files.

Configuration File	<y0000000000xx>.cfg	Configure the sending volume of the speaker. Parameter: voice.handfree_send
		Configure the sending volume of the handset. Parameter: voice.handset_send
		Configure the sending volume of the headset. Parameter: voice.headset_send

Local	Web User Interface	<p>Configure the sending volume of the speaker/handset/headset.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2: http://<phoneIPAddress>/servlet?p=features-audio&q=load</p> <p>For SIP VP-T49G: http://<phoneIPAddress>/servlet?m=mod_data&p=features-audio&q=load</p>
-------	--------------------	--

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
voice.handfree_send	Integer from -50 to 50	0
<p>Description: Configures the sending volume of the speaker.</p> <p>Note: It is not applicable to CP860 IP phones. We recommend that you modify this parameter cautiously. An unreasonable value may render the voice quality bad. If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface: Features->Audio->Handfree Send Volume (-50~50)</p> <p>Phone User Interface: None</p>		
voice.handset_send	Integer from -50 to 50	0
<p>Description: Configures the sending volume of the handset.</p> <p>Note: It is not applicable to CP860 IP phones. We recommend that you modify this parameter cautiously. An unreasonable value may render the voice quality bad. If you change this parameter, the IP phone will reboot to make the change take effect.</p>		

Parameter	Permitted Values	Default
Web User Interface: Features->Audio->Handset Send Volume (-50~50) Phone User Interface: None		
voice.headset_send	Integer from -50 to 50	0
Description: Configures the sending volume of the headset. Note: It is not applicable to CP860 IP phones. We recommend that you modify this parameter cautiously. An unreasonable value may render the voice quality bad. If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Features->Audio->Headset Send Volume (-50~50) Phone User Interface: None		

To configure sending volume via web user interface:

1. Click on **Features->Audio**.
2. Enter the desired value in the **Headset Send Volume (-50~50)** field.
3. Enter the desired value in the **Handset Send Volume (-50~50)** field.
4. Enter the desired value in the **Handfree Send Volume (-50~50)** field.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected, and the 'Audio Settings' page is displayed. The 'Headset Send Volume (-50~50)' field is highlighted with a red box and contains the value 0. Other settings include Call Waiting Tone, Key Tone, Send Tone, Redial Tone, Handset Send Volume, Handfree Send Volume, and Ringer Device for Headset. A NOTE section on the right provides additional information about the settings.

5. Click **Confirm** to accept the change.
A dialog box pops up to prompt that the settings will take effect after a reboot.
6. Click **OK** to reboot the phone.

Audio Codecs

CODEC is an abbreviation of COmpress-DECompress, capable of coding or decoding a digital data stream or signal by implementing an algorithm. The object of the algorithm is to represent the high-fidelity audio signal with minimum number of bits while retaining the quality. This can effectively reduce the frame size and the bandwidth required for audio transmission.

The audio codec that the phone uses to establish a call should be supported by the SIP server. When placing a call, the IP phone will offer the enabled audio codec list to the server and then use the audio codec negotiated with the called party according to the priority.

The following table lists the audio codecs supported by each phone model:

Phone Model	Supported Audio Codecs	Default Audio Codecs
SIP-T48G/T46G/T42G/T41P/T29G/CP860	G722, PCMA, PCMU, G729, G726-16, G726-24, G726-32, G726-40, iLBC, G723_53, G723_63	G722, PCMA, PCMU, G729
SIP-T40P/T27P/T23P/T23G/T21(P) E2/T19(P) E2	G722, PCMA, PCMU, G729, G726-16, G726-24, G726-32, G726-40, iLBC	G722, PCMA, PCMU, G729
SIP VP-T49G	G.722.1c(48kb/s), G.722.1c(32kb/s), G.722.1c(24kb/s), G.722.1(24kb/s), G722, PCMU, PCMA, G729, G726-16, G726-24, G726-32, G726-40, iLBC, G723, Opus	G.722.1c(48kb/s), G.722.1c(32kb/s), G.722.1c(24kb/s), G.722.1(24kb/s), G722, PCMU, PCMA, G729

The following table summarizes the supported audio codecs on IP phones:

Codec	Algorithm	Reference	Bit Rate	Sample Rate	Packetization Time
G.722.1c	G.722.1	RFC 5577	48 Kbps	32 Ksps	20ms
G.722.1c		RFC 5577	32 Kbps	32 Ksps	20ms
G.722.1c		RFC 5577	24 Kbps	32 Ksps	20ms
G.722.1	G.722.1	RFC 5577	24 Kbps	16 Ksps	20ms
G722	G.722	RFC 3551	64 Kbps	16 Ksps	20ms
PCMA	G.711	RFC 3551	64 Kbps	8 Ksps	20ms
PCMU	G.711	RFC 3551	64 Kbps	8 Ksps	20ms
G729	G.729	RFC 3551	8 Kbps	8 Ksps	20ms

Codec	Algorithm	Reference	Bit Rate	Sample Rate	Packetization Time
G726-16	G.726	RFC 3551	16 Kbps	8 Ksps	20ms
G726-24	G.726	RFC 3551	24 Kbps	8 Ksps	20ms
G726-32	G.726	RFC 3551	32 Kbps	8 Ksps	20ms
G726-40	G.726	RFC 3551	40 Kbps	8 Ksps	20ms
G723/ G723_53/ G723_63	G.723.1	RFC 3551	5.3 Kbps 6.3 Kbps	8 Ksps	30ms
iLBC	iLBC	RFC 3952	15.2 Kbps 13.33 Kbps	8 Ksps	20ms 30ms
Opus	Opus	RFC 6716	16 Kbps 20 Kbps	16 Ksps	20ms

Packetization Time

Ptime (Packetization Time) is a measurement of the duration (in milliseconds) of the audio data in each RTP packet sent to the destination, and defines how much network bandwidth is used for the RTP stream transfer. Before establishing a conversation, codec and ptime are negotiated through SIP signaling. The valid values of ptime range from 10 to 60, in increments of 10 milliseconds. The default ptime is 20ms. You can also disable the ptime negotiation.

Codecs and priorities of these codecs are configurable on a per-line basis. The attribute "rtpmap" is used to define a mapping from RTP payload codes to a codec, clock rate and other encoding parameters.

The corresponding attributes of the codec are listed as follows:

For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2:

Codec	Configuration	Priority	RTPmap
G722	Configuration Files Web User Interface	1	9
PCMU	Configuration Files Web User Interface	2	0
PCMA	Configuration Files Web User Interface	3	8
G729	Configuration Files Web User Interface	4	18

Codec	Configuration	Priority	RTPmap
G723_53	Configuration Files Web User Interface	0	4
G723_63	Configuration Files Web User Interface	0	4
G723	Configuration Files Web User Interface	0	4
G726-16	Configuration Files Web User Interface	0	103
G726-24	Configuration Files Web User Interface	0	104
G726-32	Configuration Files Web User Interface	0	102
G726-40	Configuration Files Web User Interface	0	105
iLBC	Configuration Files Web User Interface	0	106
Opus	Configuration Files Web User Interface	0	107

For SIP VP-T49G:

Codec	Configuration	Priority	RTPmap
G.722.1C(48kb/s)	Configuration Files Web User Interface	0	121
G.722.1C(32kb/s)	Configuration Files Web User Interface	1	122
G.722.1C(24kb/s)	Configuration Files Web User Interface	2	123
G.722.1(24kb/s)	Configuration Files Web User Interface	3	124
G722	Configuration Files Web User Interface	4	9
PCMU	Configuration Files Web User Interface	5	0

Codec	Configuration	Priority	RTPmap
PCMA	Configuration Files Web User Interface	6	8
G729	Configuration Files Web User Interface	7	18
G726-40	Configuration Files Web User Interface	8	105
G726-32	Configuration Files Web User Interface	9	102
G726-24	Configuration Files Web User Interface	10	104
G726-16	Configuration Files Web User Interface	11	103
iLBC	Configuration Files Web User Interface	12	106
G723	Configuration Files Web User Interface	13	4
Opus	Configuration Files Web User Interface	14	107

Procedure

Configuration changes can be performed using the configuration files or locally.

Configuration File	<MAC>.cfg	<p>Configure the codecs to use on a per-line basis.</p> <p>Parameters:</p> <p>account.X.codec.Y.enable</p> <p>account.X.codec.Y.payload_type</p>
		<p>Configure the priority and rtpmap for the enabled codec.</p> <p>Parameters:</p> <p>account.X.codec.Y.priority</p> <p>account.X.codec.Y.rtpmap</p>
		<p>Configure the ptime.</p> <p>Parameter:</p> <p>account.X.ptime</p>

Local	Web User Interface	<p>Configure the codecs to use on a per-line basis.</p> <p>Configure the priority for the enabled codec.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p><code>http://<phoneIPAddress>/servlet?p=account-codec&q=load&acc=0</code></p> <p>For SIP VP-T49G:</p> <p><code>http://<phoneIPAddress>/servlet?m=mod_data&p=account-codec&q=load&acc=0</code></p>
		<p>Configure the ptime.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p><code>http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0</code></p> <p>For SIP VP-T49G:</p> <p><code>http://<phoneIPAddress>/servlet?m=mod_data&p=account-adv&q=load&acc=0</code></p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
account.X.codec.Y.enable (X ranges from 1 to 16, Y ranges from 1 to 15)	0 or 1	Refer to the following content
Description: Enables or disables the specified codec for account X. 0-Disabled 1-Enabled X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)		

Parameters	Permitted Values	Default
<p>X ranges from 1 to 12 (for SIP-T42G)</p> <p>X ranges from 1 to 6 (for SIP-T41P/T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Y ranges from 1 to 15 (for SIP VP-T49G)</p> <p>Y ranges from 1 to 11 (for SIP-T48G/T46G/T42G/T41P/T29G/CP860)</p> <p>Y ranges from 1 to 9 (for SIP-T40P/T27P/T23P/T23G/T21(P) E2/T19(P) E2)</p> <p>Default:</p> <p>For SIP VP-T49G:</p> <p>When Y=1, the default value is 1;</p> <p>When Y=2, the default value is 1;</p> <p>When Y=3, the default value is 0;</p> <p>When Y=4, the default value is 1;</p> <p>When Y=5, the default value is 1;</p> <p>When Y=6, the default value is 0;</p> <p>When Y=7, the default value is 0;</p> <p>When Y=8, the default value is 0;</p> <p>When Y=9, the default value is 0;</p> <p>When Y=10, the default value is 0;</p> <p>When Y=11, the default value is 0;</p> <p>When Y=12, the default value is 1;</p> <p>When Y=13, the default value is 1;</p> <p>When Y=14, the default value is 1;</p> <p>When Y=15, the default value is 1;</p> <p>For SIP-T48G/T46G/T42G/T41P/T29G/CP860:</p> <p>When Y=1, the default value is 1;</p> <p>When Y=2, the default value is 1;</p> <p>When Y=3, the default value is 0;</p> <p>When Y=4, the default value is 0;</p> <p>When Y=5, the default value is 1;</p> <p>When Y=6, the default value is 1;</p> <p>When Y=7, the default value is 0;</p> <p>When Y=8, the default value is 0;</p> <p>When Y=9, the default value is 0;</p>		

Parameters	Permitted Values	Default
<p>When Y=10, the default value is 0; When Y=11, the default value is 0; For SIP-T40P/T27P/T23P/T23G/T21(P) E2/T19(P) E2: When Y=1, the default value is 1; When Y=2, the default value is 1; When Y=3, the default value is 1; When Y=4, the default value is 1; When Y=5, the default value is 0; When Y=6, the default value is 0; When Y=7, the default value is 0; When Y=8, the default value is 0; When Y=9, the default value is 0; Example: account.1.codec.1.enable = 1 It means that the codec PCMU is enabled on the account 1. Web User Interface: Account->Codec->Audio Codec Phone User Interface: None</p>		
account.X.codec.Y.payload_type (X ranges from 1 to 16, Y ranges from 1 to 15)	Refer to the following content	Refer to the following content
<p>Description: Configures the codec for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Y ranges from 1 to 15 (for SIP VP-T49G) Y ranges from 1 to 11 (for SIP-T48G/T46G/T42G/T41P/T29G/CP860) Y ranges from 1 to 9 (for SIP-T40P/T27P/T23P/T23G/T21(P) E2/T19(P) E2) Permitted Values:</p>		

Parameters	Permitted Values	Default
<p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: G722, PCMU, PCMA, G729, G726-16, G726-24, G726-32, G726-40, iLBC, G723_53, G723_63</p> <p>For SIP VPT49G: G722.1c(48kb/s), G722.1c(32kb/s), G722.1c(24kb/s), G722.1(24kb/s), G722, PCMU, PCMA, G729, G726-16, G726-24, G726-32, G726-40, iLBC, G723, Opus</p> <p>For SIP VPT49G: When Y=1, the default value is PCMU; When Y=2, the default value is PCMA; When Y=3, the default value is G723; When Y=4, the default value is G729; When Y=5, the default value is G722; When Y=6, the default value is iLBC; When Y=7, the default value is G726-16; When Y=8, the default value is G726-24; When Y=9, the default value is G726-32; When Y=10, the default value is G726-40; When Y=11, the default value is Opus; When Y=12, the default value is G7221 (it represents the codec G722.1c(48kb/s)); When Y=13, the default value is G7221 (it represents the codec G722.1c(32kb/s)); When Y=14, the default value is G7221 (it represents the codec G722.1c(24kb/s)); When Y=15, the default value is G7221 (it represents the codec G722.1(24kb/s));</p> <p>For SIP-T48G/T46G/T42G/T41P/T29G/CP860: When Y=1, the default value is PCMU; When Y=2, the default value is PCMA; When Y=3, the default value is G723_53; When Y=4, the default value is G723_63; When Y=5, the default value is G729; When Y=6, the default value is G722; When Y=7, the default value is iLBC; When Y=8, the default value is G726-16; When Y=9, the default value is G726-24; When Y=10, the default value is G726-32; When Y=11, the default value is G726-40;</p> <p>For SIP-T40P/T27P/T23P/T23G/T21(P) E2/T19(P) E2:</p>		

Parameters	Permitted Values	Default
<p>When Y=1, the default value is PCMU; When Y=2, the default value is PCMA; When Y=3, the default value is G729; When Y=4, the default value is G722; When Y=5, the default value is iLBC; When Y=6, the default value is G726-16; When Y=7, the default value is G726-24; When Y=8, the default value is G726-32; When Y=9, the default value is G726-40;</p> <p>Example: account.1.codec.1.payload_type = PCMU</p> <p>Web User Interface: Account->Codec->Audio Codec</p> <p>Phone User Interface: None</p>		
account.X.codec.Y.priority (X ranges from 1 to 16, Y ranges from 1 to 15)	Integer from 0 to 14	Refer to the following content
<p>Description: Configures the priority of the enabled codec for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Y ranges from 1 to 15 (for SIP VP-T49G) Y ranges from 1 to 11 (for SIP-T48G/T46G/T42G/T41P/T29G/CP860) Y ranges from 1 to 9 (for SIP-T40P/T27P/T23P/T23G/T21(P) E2/T19(P) E2)</p> <p>For SIP VP-T49G: When Y=1, the default value is 5; When Y=2, the default value is 6; When Y=3, the default value is 13; When Y=4, the default value is 7; When Y=5, the default value is 4;</p>		



Parameters	Permitted Values	Default
<p>When Y=6, the default value is 12; When Y=7, the default value is 11; When Y=8, the default value is 10; When Y=9, the default value is 9; When Y=10, the default value is 8; When Y=11, the default value is 14; When Y=12, the default value is 0; When Y=13, the default value is 1; When Y=14, the default value is 2; When Y=15, the default value is 3;</p> <p>For SIP-T48G/T46G/T42G/T41P/T29G/CP860:</p> <p>When Y=1, the default value is 2; When Y=2, the default value is 3; When Y=3, the default value is 0; When Y=4, the default value is 0; When Y=5, the default value is 4; When Y=6, the default value is 1; When Y=7, the default value is 0; When Y=8, the default value is 0; When Y=9, the default value is 0; When Y=10, the default value is 0; When Y=11, the default value is 0;</p> <p>For SIP-T40P/T27P/T23P/T23G/T21(P) E2/T19(P) E2:</p> <p>When Y=1, the default value is 2; When Y=2, the default value is 3; When Y=3, the default value is 4; When Y=4, the default value is 1; When Y=5, the default value is 0; When Y=6, the default value is 0; When Y=7, the default value is 0; When Y=8, the default value is 0; When Y=9, the default value is 0;</p> <p>Example:</p> <p>account.1.codec.1.priority = 2</p> <p>Note: For SIP VP-T49G IP phones, numerical value 0 is defined as the highest priority</p>		



Parameters	Permitted Values	Default
<p>in the enable codec list and disable codec list. For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2 IP phones, the priority of codec in disable codec list is not specified, and numerical value 1 is defined as the highest priority in the enable codec list.</p> <p>Web User Interface: Account->Codec->Audio Codec</p> <p>Phone User Interface: None</p>		
account.X.codec.Y.rtpmap (X ranges from 1 to 16, Y ranges from 1 to 15)	Integer from 0 to 127	Refer to the following content
<p>Description: Configures the rtpmap of the audio codec for account X. X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Y ranges from 1 to 15 (for SIP VP-T49G) Y ranges from 1 to 11 (for SIP-T48G/T46G/T42G/T41P/T29G/CP860) Y ranges from 1 to 9 (for SIP-T40P/T27P/T23P/T23G/T21(P) E2/T19(P) E2)</p> <p>For SIP VP-T49G: When Y=1, the default value is 0; When Y=2, the default value is 8; When Y=3, the default value is 4; When Y=4, the default value is 18; When Y=5, the default value is 9; When Y=6, the default value is 106; When Y=7, the default value is 103; When Y=8, the default value is 104; When Y=9, the default value is 102; When Y=10, the default value is 105; When Y=11, the default value is 107; When Y=12, the default value is 121; When Y=13, the default value is 122;</p>		


Parameters	Permitted Values	Default
<p>When Y=14, the default value is 123; When Y=15, the default value is 124; For SIP-T48G/T46G/T42G/T41P/T29G/CP860: When Y=1, the default value is 0; When Y=2, the default value is 8; When Y=3, the default value is 4; When Y=4, the default value is 4; When Y=5, the default value is 18; When Y=6, the default value is 9; When Y=7, the default value is 106; When Y=8, the default value is 103; When Y=9, the default value is 104; When Y=10, the default value is 102; When Y=11, the default value is 105; For SIP-T40P/T27P/T23P/T23G/T21(P) E2/T19(P) E2: When Y=1, the default value is 0; When Y=2, the default value is 8; When Y=3, the default value is 18; When Y=4, the default value is 9; When Y=5, the default value is 106; When Y=6, the default value is 103; When Y=7, the default value is 104; When Y=8, the default value is 102; When Y=9, the default value is 105; Example: account.1.codec.1.rtpmap = 0 Web User Interface: None Phone User Interface: None</p>		
account.X.ptime	0, 10, 20, 30, 40, 50 or 60	20
<p>Description: Configures the ptime (in milliseconds) for the codec for account X.</p>		

Parameters	Permitted Values	Default
0-Disabled 10-10 20-20 30-30 40-40 50-50 60-60 X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860) Example: account.1.ptime = 20 Web User Interface: Account->Advanced->PTime(ms) Phone User Interface: None		

To configure the codecs to use and adjust the priority of the enabled codecs on a per-line basis via web user interface:

1. Click on **Account->Codec**.
2. Select the desired account from the pull-down list of **Account**.
3. Select the desired codec from the **Disable Codecs** column and then click  .
The selected codec appears in the **Enable Codecs** column.
4. Repeat the step 4 to add more codecs to the **Enable Codecs** column.
5. To remove the codec from the **Enable Codecs** column, select the desired codec and then click  .


- To adjust the priority of codecs, select the desired codec and then click  or  .



- Click **Confirm** to accept the change.

To configure the ptime for the account via web user interface:

- Click on **Account->Advanced**.
- Select the desired account from the pull-down list of **Account**.
- Select the desired value from the pull-down list of **PTime(ms)**.



- Click **Confirm** to accept the change.

Acoustic Clarity Technology

Acoustic Echo Cancellation

Acoustic Echo Cancellation (AEC) is used to reduce acoustic echo from a voice call to provide natural full-duplex communication patterns. It also increases the capacity achieved through silence suppression by preventing echo from traveling across a network. IP phones employ advanced AEC for hands-free operation. AEC is not normally required for calls via the handset. In certain situation, where echo is experienced by the remote party, AEC may be used to reduce/avoid echo when the user uses the handset.

Note

Utilizing acoustic echo cancellation will introduce a small delay increase into audio path which might cause a lower voice quality.

Procedure

AEC can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure AEC. Parameter: voice.echo_cancellation
Local	Web User Interface	Configure AEC. Navigate to: For SIP-T48G/T46G/T42G/T41P/ T40P/T29G/T27P/T23P/T23 G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=settings-voice&q=load">http://<phoneIPAddress>/ servlet?p=settings-voice& q=load For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=settings-voice&q=load">http://<phoneIPAddress>/ servlet?m=mod_data&p =settings-voice&q=load

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
voice.echo_cancellation	0 or 1	1
Description: Enables or disables the AEC (Acoustic Echo Canceller) feature on the IP phone. 0-Disabled 1-Enabled Web User Interface: Settings->Voice->Echo Cancellation->ECHO Phone User Interface: None		

To configure AEC via web user interface:

1. Click on **Settings->Voice**.
2. Select the desired value from the pull-down list of **ECHO**.

The screenshot shows the Yealink T236 web interface. The 'Settings' tab is selected, and the 'Voice' sub-tab is active. Under 'Echo Cancellation', the 'ECHO' dropdown is set to 'Enabled' (highlighted with a red box). Other settings include 'VAD' set to 'Disabled', 'CNG' set to 'Enabled', and 'JITTER BUFFER' with 'Type' set to 'Adaptive' (radio button selected), 'Min Delay' set to 60, 'Max Delay' set to 240, and 'Normal' set to 120. A 'NOTE' section on the right provides details about Acoustic Echo Cancellation (AEC), Voice Activity Detection (VAD), and Comfort Noise Generation (CNG).

3. Click **Confirm** to accept the change.

Background Noise Suppression

Background noise suppression (BNS) is designed primarily for hands-free operation and reduces background noise to enhance communication in noisy environments.

Automatic Gain Control

Automatic Gain Control (AGC) is applicable to hands-free operation and is used to keep audio output at nearly a constant level by adjusting the gain of signals in certain

circumstances. This increases the effective user-phone radius and helps with the intelligibility of soft-talkers.

Voice Activity Detection

Voice Activity Detection (VAD) is used in speech processing to detect the presence or absence of human speech. When detecting period of "silence", VAD replaces that silence efficiently with special packets that indicate silence is occurring. It can facilitate speech processing, and deactivate some processes during non-speech section of an audio session. VAD can avoid unnecessary coding or transmission of silence packets in VoIP applications, saving on computation and network bandwidth.

Procedure

VAD can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure VAD. Parameter: voice.vad
Local	Web User Interface	Configure VAD. Navigate to: For SIP-T48G/T46G/T42G/T41P/ T40P/T29G/T27P/T23P/T23 G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=settings-voice&q=load">http://<phoneIPAddress>/ servlet?p=settings-voice& q=load For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=settings-voice&q=load">http://<phoneIPAddress>/ servlet?m=mod_data&p =settings-voice&q=load

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
voice.vad	0 or 1	0
Description: Enables or disables the VAD (Voice Activity Detection) feature on the IP phone.		

Parameter	Permitted Values	Default
0-Disabled 1-Enabled Web User Interface: Settings->Voice->Echo Cancellation->VAD Phone User Interface: None		

To configure VAD via web user interface:

1. Click on **Settings->Voice**.
2. Select the desired value from the pull-down list of **VAD**.

The screenshot shows the Yealink T23G web interface. The 'Settings' tab is active, and the 'Voice' sub-tab is selected. Under 'Echo Cancellation', the 'VAD' dropdown menu is highlighted with a red box, showing 'Enabled' as the selected value. The 'JITTER BUFFER' section shows 'Type' set to 'Adaptive' and 'Min Delay' set to '60'. The 'NOTE' section on the right provides information about Acoustic Echo Cancellation (AEC), Voice Activity Detection (VAD), and Comfort Noise Generation (CNG).

3. Click **Confirm** to accept the change.

Comfort Noise Generation

Comfort Noise Generation (CNG) is used to generate background noise for voice communications during periods of silence in a conversation. It is a part of the silence suppression or VAD handling for VoIP technology. CNG, in conjunction with VAD algorithms, quickly responds when periods of silence occur and inserts artificial noise until voice activity resumes. The insertion of artificial noise gives the illusion of a constant transmission stream, so that background sound is consistent throughout the call and the listener does not think the line has released. The purpose of VAD and CNG is to maintain an acceptable perceived QoS while simultaneously keeping transmission costs and bandwidth usage as low as possible.

Note

VAD is used to send CN packets when phone detect a "silence" period; CNG is used to generate comfortable noise when phone receives CN packets from the other side.

For example, A is talking with B.

A: VAD=1, CNG=1

B: VAD=0, CNG=1

If A mutes the call, since VAD=1, A will send CN packets to B. When receiving CN packets, B will generate comfortable noise.

If B mutes the call, since VAD=0, B will not send CN packets to A. So even if CNG=1 (B), A will not hear comfortable noise.

Procedure

CNG can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure CNG. Parameter: voice.cng
Local	Web User Interface	Configure CNG. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40 P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=settings-voice&q=load">http://<phoneIPAddress>/servlet?p=settings-voice&q=load For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=settings-voice&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=settings-voice&q=load


Details of the Configuration Parameter:

Parameter	Permitted Values	Default
voice.cng	0 or 1	1
Description: Enables or disables the CNG (Comfortable Noise Generation) feature on the IP phone. 0-Disabled 1-Enabled Web User Interface:		

Parameter	Permitted Values	Default
Settings->Voice->Echo Cancellation->CNG		
Phone User Interface:		
None		

To configure CNG via web user interface:

1. Click on **Settings->Voice**.
2. Select the desired value from the pull-down list of **CNG**.



3. Click **Confirm** to accept the change.

Jitter Buffer

Jitter buffer is a shared data area where voice packets can be collected, stored, and sent to the voice processor in even intervals. Jitter is a term indicating variations in packet arrival time, which can occur because of network congestion, timing drift or route changes. The jitter buffer, located at the receiving end of the voice connection, intentionally delays the arriving packets so that the end user experiences a clear connection with very little sound distortion. IP phones support two types of jitter buffers: fixed and adaptive. A fixed jitter buffer adds the fixed delay to voice packets. You can configure the delay time for the static jitter buffer on IP phones. An adaptive jitter buffer is capable of adapting the changes in the network's delay. The range of the delay time for the dynamic jitter buffer added to packets can be also configured on IP phones.

Procedure

Jitter buffer can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the mode of jitter buffer and the delay time for jitter buffer. Parameters:
--------------------	---------------------	---

		voice.jib.adaptive voice.jib.min voice.jib.max voice.jib.normal
Local	Web User Interface	Configure the mode of jitter buffer and the delay time for jitter buffer. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p=settings-voice&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet?m=mod_data&p=settings-voice&q=load

Details of Configuration Parameters:

Parameters	Permitted Values	Default
voice.jib.adaptive	0 or 1	1
Description: Configures the type of jitter buffer. 0 -Fixed 1 -Adaptive Web User Interface: Settings->Voice->JITTER BUFFER->Type Phone User Interface: None		
voice.jib.min	Integer from 0 to 400	60
Description: Configures the minimum delay time (in milliseconds) of jitter buffer. Note: It works only if the value of the parameter "voice.jib.adaptive" is set to 1 (Adaptive). Web User Interface:		

Parameters	Permitted Values	Default
Settings->Voice->JITTER BUFFER->Min Delay Phone User Interface: None		
voice.jib.max	Integer from 0 to 400	240
Description: Configures the maximum delay time (in milliseconds) of jitter buffer. Note: It works only if the value of the parameter "voice.jib.adaptive" is set to 1 (Adaptive). Web User Interface: Settings->Voice->JITTER BUFFER->Max Delay Phone User Interface: None		
voice.jib.normal	Integer from 0 to 400	120
Description: Configures the normal delay time (in milliseconds) of jitter buffer. Note: It works only if the value of the parameter "voice.jib.adaptive" is set to 0 (Fixed). Web User Interface: Settings->Voice->JITTER BUFFER->Normal Phone User Interface: None		

To configure Jitter Buffer via web user interface:

1. Click on **Settings->Voice**.
2. Mark the desired radio box in the **Type** field.
3. Enter the minimum delay time for adaptive jitter buffer in the **Min Delay** field.
The valid value ranges from 20 to 300.
4. Enter the maximum delay time for adaptive jitter buffer in the **Max Delay** field.
The valid value ranges from 20 to 300.

5. Enter the fixed delay time for fixed jitter buffer in the **Normal** field.

The valid value ranges from 20 to 300.

Yealink T236

Log Out

Status Account Network DSSKey Features Settings Directory Security

Preference
Time & Date
Call Display
Upgrade
Auto Provision
Configuration
Dial Plan
Voice
Ring

Echo Cancellation

ECHO Enabled
VAD Enabled
CNG Enabled

JITTER BUFFER

Type ☒ Adaptive ☐ Fixed
Min Delay 60
Max Delay 240
Normal 120

Confirm Cancel

NOTE

Acoustic Echo Cancellation (AEC)
It is used to reduce acoustic echo from a voice call to provide natural full-duplex communication patterns.

Voice Activity Detection (VAD)
It is used in speech processing to detect the presence or absence of human speech.

Comfort Noise Generation (CNG)
It is used to generate background noise for voice communications during periods of silence in a conversation.

6. Click **Confirm** to accept the change.

Configuring Video Features

The SIP VP-T49G IP phones support transmission and reception of high quality video images. The video is compatible with [RFC 3984](#) - RTP Payload Format for H.264 Video, [RFC 4629](#) - RTP Payload Format for ITU-T Rec. H.263 Video.

This section provides information for making configuration changes for the following video-related features:

- [Video Settings](#)
- [Video Codecs](#)

Video Settings

The SIP VP-T49G IP phones support USB camera for point-to-point video calls. Users can place and answer video calls. The IP phones support transmission and reception of high quality video images. To optimize video calling, you can configure camera settings as required, such as white balance, exposure compensation and sharpness.

You need to know the following basic glossaries when configuring camera settings:

Glossary	Description
White Balance	People's eyes are very good at judging what is white under different light sources, but the camera often have great difficulty with auto white balance - and can create unsightly blue, orange, or even green color casts. Adjusting white balance can help you remove unrealistic color casts and then improve the images under a wider range of lighting conditions.
Sharpness	Describes the clarity of detail in a video image. The picture will be sharp and clear, but moderate to heavy motion at low call rates can cause some frames to be dropped.
Contrast	Contrast is the difference in luminance or color that makes an object (or its representation in an image or display) distinguishable.
Saturation	Describes how bright-colored of the video image. It is also known as the purity of colour.
Noise Reduction	Image noise is interference in the video signal that shows up as grainy specks. Reduces the image noise can make the video image clearer. A 2D filter reduces the noise that can be found in low light images. This type of filter is sometimes confused by motion,

Glossary	Description
	resulting in blur trails. A 3D filter goes one step farther and effectively reduces the noise in static images and images with movement.
Compensation	Effectively compensates the camera when shooting in a backlight environment.
Flicker	Indoor lights powered by a 50Hz or 60Hz power source can produce a flicker. Adjusting the camera flicker frequency according to the power source the light is powered by.

Toggle Between Audio-only or Video Calls

The video call feature is enabled by default. You can disable this feature as required. When you disable the video call feature, the calls are audio-only.

Procedure

Configuration changes can be performed using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the video settings. Parameter: video.enable video.auto_start_video.enable video.auto_answer_video_mute.enable camera.scene_mode camera.white_balance camera.red_gain camera.blue_gain camera.sharpness camera.brightness camera.contrast camera.saturation camera.nr2d_level camera.exposure_compensation.enable camera.flicker camera.status_bar_icon.enable
Local	Web User Interface	Configure the video settings. Navigate to: <a href="http://<phoneIPAddress>/servlet">http://<phoneIPAddress>/servlet

		?m=mod_data&p=settings-camera&q=load
	Phone User Interface	Configure the video settings.

Details of the Configuration Parameter:

Parameters	Permitted Values	Default
video.enable	0 or 1	1
<p>Description: Enables or disables the video call feature for the IP phone.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 0 (Disabled), video is not sent in outgoing calls and not received in incoming calls. All calls are audio only.</p> <p>If it is set to 1 (Enabled), video is sent in outgoing calls and received in incoming calls.</p> <p>Note: If you change this parameter, the IP phone will reboot to make the change take effect. It is only applicable to SIP VP-T49G IP phones.</p> <p>Web User Interface: Settings->Video->Video Active</p> <p>Phone User Interface: Menu->Basic->Video Setting->Video Enable</p>		
video.auto_start_video.enable	0 or 1	1
<p>Description: Enables or disables the video transmission from the near site starts when a call starts.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 0 (Disabled), video transmission from the near site does not start. It means the IP phone will not transmit the video when a video call starts and the other party cannot see you before you turn on the video.</p> <p>Note: It is only applicable to SIP VP-T49G IP phones.</p> <p>Web User Interface: Settings->Video->Auto Start Video</p> <p>Phone User Interface:</p>		

Parameters	Permitted Values	Default
Menu->Basic->Video Setting->Auto Start Video		
video.auto_answer_video_mute.enable	0 or 1	0
<p>Description: Enables or disables auto answer video mute feature.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 0 (Disabled), video transmission from the near site starts when an incoming call is automatically answered.</p> <p>If it is set to 1 (Enabled), video transmission from the near site does not start. It means the IP phone will not transmit the video when an incoming call is automatically answered and the other party cannot see you before you turn on the video.</p> <p>Note: It works only if the auto answer feature is enabled and the value of the parameter "video.auto_start_video.enable" is set to 1 (Enabled). It is only applicable to SIP VP-T49G IP phones.</p> <p>Web User Interface: Settings->Video->Auto Answer Video Mute</p> <p>Phone User Interface: Menu->Basic->Video Setting->Auto Answer Video Mute</p>		
camera.scene_mode	0, 1, 2 or 3	1
<p>Description: Configures the camera scene mode.</p> <p>0-Manual 1-Standard 2-Warm Color 3-Cool Color</p> <p>Note: It is only applicable to SIP VP-T49G IP phones.</p> <p>Web User Interface: Settings->Camera->Scene Mode</p> <p>Phone User Interface: Menu->Basic->Camera Setting->Scene Mode</p>		
camera.white_balance	0 or 5	0

Parameters	Permitted Values	Default
Description: Configures the white balance mode of the camera. 0 -Auto-Yealink recommends this setting for most situations. It calculates the best white balance setting based on lighting conditions in the room. 5 -Manual-Manual set red and blue gain. Note: It works only if the value of the parameter "camera.scene_mode" is set to 0 (Manual). It is only applicable to SIP VP-T49G IP phones. Web User Interface: Settings->Camera->White Balance Mode Phone User Interface: Menu->Basic->Camera Setting->White Balance Mode		
camera.red_gain	Integer from 0 to 100	0
Description: Configures the red gain of the camera. Note: It works only if the value of the parameter "camera.scene_mode" is set to 0 (Manual) and "camera.white_balance" is set to 5 (Manual). It is only applicable to SIP VP-T49G IP phones. Web User Interface: Settings->Camera->Red Gain Phone User Interface: Menu->Basic->Camera Setting->Red Gain		
camera.blue_gain	Integer from 0 to 100	0
Description: Configures the blue gain of the camera. Note: It works only if the value of the parameter "camera.scene_mode" is set to 0 (Manual) and "camera.white_balance" is set to 5 (Manual). It is only applicable to SIP VP-T49G IP phones. Web User Interface: Settings->Camera->Blue Gain Phone User Interface: Menu->Basic->Camera Setting->Blue Gain		
camera.sharpness	Integer from 0 to 100	28

Parameters	Permitted Values	Default
Description: Configures the sharpness of the camera. Note: It works only if the value of the parameter "camera.scene_mode" is set to 0 (Manual). It is only applicable to SIP VP-T49G IP phones. Web User Interface: Settings->Camera->Sharpness Phone User Interface: Menu->Basic->Camera Setting->Sharpness		
camera.brightness	Integer from 0 to 100	50
Description: Configures the brightness of the camera. Note: It works only if the value of the parameter "camera.scene_mode" is set to 0 (Manual). It is only applicable to SIP VP-T49G IP phones. Web User Interface: Settings->Camera->Brightness Phone User Interface: Menu->Basic->Camera Setting->Brightness		
camera.contrast	Integer from 0 to 100	50
Description: Configures the contrast of the camera. Note: It works only if the value of the parameter "camera.scene_mode" is set to 0 (Manual). It is only applicable to SIP VP-T49G IP phones. Web User Interface: Settings->Camera->Contrast Phone User Interface: Menu->Basic->Camera Setting->Contrast Setting		
camera.saturation	Integer from 0 to 100	50
Description: Configures the saturation of the camera. Note: It works only if the value of the parameter "camera.scene_mode" is set to 0 (Manual). It is only applicable to SIP VP-T49G IP phones.		

Parameters	Permitted Values	Default
Web User Interface: Settings->Camera->Saturation Phone User Interface: Menu->Basic->Camera Setting->Saturation		
camera.nr2d_level	Integer from 0 to 100	40
Description: Specifies the noise reduction (2D) mode. 0-Off 1-32-Low 33-65-Middle 66-100-Hight Note: It works only if the value of the parameter "camera.scene_mode" is set to 0 (Manual). It is only applicable to SIP VP-T49G IP phones. Web User Interface: Settings->Camera->Noise Reduction(2D) Phone User Interface: Menu->Basic->Camera Setting->NR2D-level		
camera.exposure_compensation.enable	0, 1, 2 or 3	0
Description: Disables or configures the value of camera exposure compensation. 0-Off 1-1 2-2 3-3 Note: Exposure compensation is used to compensate the camera effectively when shooting in a backlight environment. If the environment light is dark, increase the compensation value. It is only applicable to SIP VP-T49G IP phones. Web User Interface: Settings->Camera->Exposure Compensation Phone User Interface: None		
camera.flicker	50 or 60	50

Parameters	Permitted Values	Default
<p>Description: Configures the value of camera flicker frequency (Hz).</p> <p>50-50Hz 60-60Hz</p> <p>Note: Indoor lights powered by a 50Hz or 60Hz power source can produce a flicker. You can adjust the camera flicker frequency according to the power source the light is powered by. It is only applicable to SIP VPT49G IP phones.</p> <p>Web User Interface: Settings->Camera->Flicker</p> <p>Phone User Interface: None</p>		
camera.status_bar_icon.enable	0 or 1	1
<p>Description: Enables or disables the video icon to display on the status bar when the camera is not detected.</p> <p>0-Disabled 1-Enabled</p> <p>Note: It is only applicable to SIP VP-T49G IP phones.</p> <p>Web User Interface: Settings->Camera->Video Icon on Status Bar</p> <p>Phone User Interface: None</p>		


To configure the camera settings via web user interface:

1. Click on **Settings->Camera**.
2. Select the desired value from the pull-down list of **Scene Mode**.
If you select **Manual** from the pull-down list of **Scene Mode**, do the following:
 - 1) Select the desired value from the pull-down list of **White Balance Mode**.
If you select **Manual**, do the following:
 - a. Enter the desired value in the **Red Gain** field.
 - b. Enter the desired value in the **Blue Gain** field.
 - 2) Enter the desired value in the **Sharpness** field.
 - 3) Enter the desired value in the **Brightness** field.
 - 4) Enter the desired value in the **Contrast** field.

- 5) Enter the desired value in the **Saturation** field.
- 6) Select the desired value from the pull-down list of **Noise Reduction(2D)**.
- 7) Click **Reset to default** to reset the manual settings.
3. Select the desired value from the pull-down list of **Exposure Compensation**.
4. Select the desired value from the pull-down list of **Flicker**.
5. Select the desired value from the pull-down list of **Video Icon on Status Bar**.

6. Click **Confirm** to accept the change.


To configure the camera settings via phone user interface:

1. Tap  -> **Basic**-> **Camera Setting**.
2. Tap the **Scene Mode** field.
3. Tap the desired value in the pop-up dialog box.
If you tap **Manual Settings**, do the following:
 - 1) Tap the **White Balance** field.
 - 2) Tap the desired value in the pop-up dialog box.
If you tap **Manual Settings**, do the following:
 - a. Enter the desired value in the **Red Gain** field.
 - b. Enter the desired value in the **Blue Gain** field.
 - 3) Enter the desired value in the **Sharpness** field.
 - 4) Enter the desired value in the **Brightness** field.
 - 5) Enter the desired value in the **Contrast Setting** field.
 - 6) Enter the desired value in the **Saturation** field.
 - 7) Tap the **NR2D-level** field.
 - 8) Tap the desired value in the pop-up dialog box.

4. Tap the **Save** soft key to accept the change.

To activate the call video feature and configure the auto video feature via web user interface:

1. Click on **Settings->Video**.
2. Select the desired value from the pull-down list of **Video Active**.
3. Select the desired value from the pull-down list of **Auto Start Video**.
4. Select the desired value from the pull-down list of **Auto Answer Video Mute**.



5. Click **Confirm** to accept the change.

Video Codecs

CODEC is an abbreviation of COmTap-DEComTap, capable of coding or decoding a digital data stream or signal by implementing an algorithm. The object of the algorithm is to represent the high-fidelity video signal with minimum number of bits while retaining the quality. This can effectively reduce the frame size and the bandwidth required for video transmission.

The video codec that the phone uses to establish a call should be supported by the SIP server. When placing a call, the IP phone will offer the enabled video codec list to the server and then use the video codec negotiated with the called party according to the priority.

RTPmap

Codecs and priorities of these codecs are configurable on a per-line basis. The attribute “rtpmap” is used to define a mapping from RTP payload codes to a codec, clock rate and other encoding parameters.

The following table lists the video codecs supported by SIP VPT49G phone model:

Name	MIME Type	Bit Rate	Frame Rate	Frame Size
H.263	H263/90000	90 kbps to 2048 kbps	5 fps to 30 fps	Tx: CIF, 4CIF RX: QCIF, CIF, 4CIF
H.264 BP	H264/90000			Tx: WQVGA, 360P, 448P, 540P, 720P, 1080P Rx: Conventional Size Below 1080P
H.264 HP	H264/90000			

Procedure

Configuration changes can be performed using the configuration files or locally.



Configuration File	<MAC>.cfg	Configure the video codecs to use on a per-line basis. Parameters: account.X.video.Y.enable account.X.video.Y.payload_type
		Configure the priority and rtpmap for the enabled video codec. Parameters: account.X.video.Y.priority
Local	Web User Interface	Configure the video codecs to use on a per-line basis. Configure the priority for the enabled video codec. Navigate to: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=account-codec&q=load&acc=0">http://<phoneIPAddress>/servlet?m=mod_data&p=account-codec&q=load&acc=0



Details of Configuration Parameters:


Parameters	Permitted Values	Default
account.X.video.Y.enable (X ranges from 1 to 16, Y ranges from 1 to 4)	0 or 1	1
<p>Description: Enables or disables the specified video codec for account X.</p> <p>0-Disabled 1-Enabled</p> <p>Default: When Y=1, the default value is 1; When Y=2, the default value is 1; When Y=3, the default value is 1; When Y=4, the default value is 1;</p> <p>Example: If you want to enable the codec H264 on the account 1, you need to configure the following two parameters: account.1.video.1.enable = 1 account.1.video.2.enable = 1 If you want to enable the codec H264HP on the account 1, you need to configure the following parameter: account.1.video.3.enable = 1 If you want to enable the codec H263 on the account 1, you need to configure the following parameter: account.1.video.4.enable = 1</p> <p>Note: It is only applicable to SIP VPT49G IP phones.</p> <p>Web User Interface: Account->Codec->Video Codec</p> <p>Phone User Interface: None</p>		
account.X.video.Y.payload_type (X ranges from 1 to 16, Y ranges from 1 to 4)	H264 or H263	Refer to the following content
<p>Description: Configures the video codec for account X.</p> <p>Default: When Y=1, the default value is H264;</p>		

Parameters	Permitted Values	Default
<p>When Y=2, the default value is H264; When Y=3, the default value is H264; When Y=4, the default value is H263; Note: It is only applicable to SIP VPT49G IP phones. Web User Interface: Account->Codec->Video Codec Phone User Interface: None</p>		
account.X.video.Y.priority (X ranges from 1 to 16, Y ranges from 1 to 4)	1, 2, 3 or 4	Refer to the following content
<p>Description: Configures the priority of the enabled video codec for account X. Default: When Y=1, the default value is 2; When Y=2, the default value is 3; When Y=3, the default value is 1; When Y=4, the default value is 4; Example: account.1.video.1.priority = 2 Note: It is only applicable to SIP VPT49G IP phones. Web User Interface: Account->Codec->Video Codec Phone User Interface: None</p>		

To configure the video codecs and adjust the priority of the enabled video codecs on a per-account basis via web user interface:

1. Click on **Account->Codec**.
2. Select the desired account from the pull-down list of **Account**.
3. In the **Video Codecs** field, select the desired codec from the **Disable Codecs** column and then click .
The selected codec appears in the **Enable Codecs** column.
4. Repeat the step 3 to add more codecs to the **Enable Codecs** column.
5. To remove the codec from the **Enable Codecs** column, select the desired codec and then click .

6. To adjust the priority of codecs, select the desired codec and then click  or  .



The screenshot shows the Yealink T49G web interface. The top navigation bar includes 'Status', 'Account', 'Network', 'DSSKey', 'Features', 'Settings', 'Directory', and 'Security'. The 'Account' tab is selected, and the 'Account 1' dropdown is visible. The 'Audio Codes' section is active, showing a list of codecs to be disabled and a list of codecs to be enabled. The 'Video codes' section is also visible, showing a list of codecs to be disabled and a list of codecs to be enabled. A red box highlights the 'Video codes' section. The 'Confirm' button is at the bottom.

Audio Codes	
Disable Codes	Enable Codes
G726-40	G.722.1c,(48kb/s)
G726-32	G.722.1c,(32kb/s)
G726-24	G.722.1c,(24kb/s)
G726-16	G.722.1,(24kb/s)
ILBC	G722
G723	PCMU
Opus	PCMA
	G729

Video codes	
Disable Codes	Enable Codes
	H264HP
	H264
	H263

7. Click **Confirm** to accept the change.

Configuring Security Features

This chapter provides information for making configuration changes for the following security-related features:

- [User Password](#)
- [Administrator Password](#)
- [Auto-Logout Time](#)
- [Phone Lock](#)
- [Transport Layer Security](#)
- [Secure Real-Time Transport Protocol](#)
- [Encrypting Configuration Files](#)
- [802.1X Authentication](#)

User Password

Some menu options are protected by two privilege levels, user and administrator, each with its own password. When logging into the web user interface, you need to enter the user name and password to access various menu options.

A user or an administrator can change the user password. The default user password is "user". For security reasons, the user or administrator should change the default user password as soon as possible.

Procedure

User password can be changed using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Change the user password of the IP phone. Parameter: security.user_password
Local	Web User Interface	Change the user password of the IP phone. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet

		<p>?p=security&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet</p> <p>?m=mod_data&p=security&q=load</p>
--	--	---

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
security.user_password	String within 32 characters	user

Description:

Configures the password of the user for phone's web user interface access.

The IP phone uses "user" as the default user password.

The valid value format is username:new password.

Example:

security.user_password = user:123 means setting the password of user (current user name is "user") to password 123.

Note: IP phones support ASCII characters 32-126(0x20-0x7E) in passwords. You can set the password to be empty via web user interface only.

Web User Interface:

Security->Password

Phone User Interface:

None

To change the user password via web user interface:

1. Click on **Security->Password**.
 2. Select **user** from the pull-down list of **User Type**.
 3. Enter new password in the **New Password** and **Confirm Password** fields.
- Valid characters are ASCII characters 32-126(0x20-0x7E) except 58(3A).

The screenshot shows the Yealink T236 web interface. The top navigation bar includes 'Status', 'Account', 'Network', 'DSSKey', 'Features', 'Settings', 'Directory', and 'Security'. The 'Security' tab is active, and the 'Password' sub-tab is selected. The 'User Type' dropdown menu is set to 'user'. The 'Old Password' field is empty. The 'New Password' and 'Confirm Password' fields are masked with asterisks. A red box highlights the 'User Type' dropdown and the password fields. A 'NOTE' box on the right states: 'User Password/Administrator Password: When logging into the web user interface, you need to enter the user name and password. You can change the user/administrator password for security reasons.'

- Click **Confirm** to accept the change.

Note

If logging into the web user interface of the phone with the user credential, you need to enter the old user password in the **Old Password** field.

Administrator Password

Advanced menu options are strictly used by administrators. Users can configure them only if they have administrator privileges. The administrator password can only be changed by an administrator. The default administrator password is "admin". For security reasons, the administrator should change the default administrator password as soon as possible.

Procedure

Administrator password can be changed using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Change the administrator password. Parameter: security.user_password
Local	Web User Interface	Change the administrator password. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet? p=security&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet? m=mod_data&p=security&q=l oad
	Phone User Interface	Change the administrator password.

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
security.user_password	String within 32 characters	admin

Parameter	Permitted Values	Default
<p>Description:</p> <p>Configures the password of the administrator for phone's web user interface access. The IP phone uses "admin" as the default administrator password.</p> <p>Example:</p> <p>security.user_password = admin:123 means setting the password of administrator (current user name is "admin") to password 123.</p> <p>Note: IP phones support ASCII characters 32-126(0x20-0x7E) in passwords. You can set the password to be empty via web user interface only.</p> <p>Web User Interface:</p> <p>Security->Password</p> <p>Phone User Interface:</p> <p>Menu->Settings->Advanced Settings->Set Password</p>		

To change the administrator password via web user interface:

1. Click on **Security->Password**.
2. Select **admin** from the pull-down list of **User Type**.
3. Enter the current administrator password in the **Old Password** field.
4. Enter new password in the **New Password** and **Confirm Password** fields.
Valid characters are ASCII characters 32-126(0x20-0x7E) except 58(3A).

5. Click **Confirm** to accept the change.

To change the administrator password via phone user interface:

1. Press **Menu->Settings->Advanced Settings** (default password: admin) ->**Set Password**.
2. Enter the current administrator password in the **Old PWD** field.
3. Enter new password in the **New PWD** field and **Confirm PWD** field.
Valid characters are ASCII characters 32-126(0x20-0x7E).
4. Press the **Save** soft key to accept the change.

Auto-Logout Time

Auto-logout time defines a specific period of time during which the IP phones will automatically log out if you have not performed any actions via web user interface. Once logging out, you must re-enter username and password for web access authentication.

Procedure

Auto-logout time can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure auto-logout time. Parameter: features.relog_offtime
Local	Web User Interface	Configure auto-logout time. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet ?p=features-general&q=load For SIP VP-T49G: http://<phoneIPAddress>/servlet ?m=mod_data&p=features-general&q=load

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
features.relog_offtime	Integer from 1 to 1000	5
Description: Configures the timeout interval (in minutes) for web access authentication. Example: features.relog_offtime = 5 If you log into the web user interface and leave it for 5 minutes, it will automatically log out. Note: If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface:		

Parameter	Permitted Values	Default
Features->General Information->Auto-Logout Time(1~1000min)		
Phone User Interface:		
None		

To configure the auto-logout time via web user interface:

1. Click on **Features->General Information**.
2. Enter the desired auto-logout time in **Auto-Logout Time(1~1000min)** field.

The screenshot shows the Yealink T236 web interface. The 'Features' tab is selected, and the 'General Information' sub-tab is active. The 'Auto-Logout Time(1~1000min)' field is highlighted with a red box and contains the value '5'. Other fields include 'Call Waiting' (Enabled), 'Call Waiting On Code', 'Call Waiting Off Code', 'Auto Redial' (Disabled), 'Auto Redial Interval (1~300s)' (10), 'Auto Redial Times (1~300)' (10), 'Diversion/History-Info' (Enabled), 'Allow Trans Exist Call' (Enabled), 'BLF LED Mode' (0), 'Call Number Filter', and 'Auto Linekeys' (Disabled). A 'NOTE' section on the right provides details about various features: Call Waiting, Auto Redial, Key As Send, Hotline, and Call Completion.

3. Click **Confirm** to accept the change.

Phone Lock

Phone lock is used to lock the IP phone to prevent it from unauthorized use. Once the IP phone is locked, a user must enter the password to unlock it. IP phones offer three types of phone lock: Menu Key, Function Keys and All Keys. The IP phone will not be locked immediately after the phone lock type is configured. One of the following steps is also needed:

- Long press the pound key when the IP phone is idle.
- Press the phone lock key (if configured) when the IP phone is idle.

In addition to the above steps, you can configure the IP phone to automatically lock the phone after a period of time.

Procedure

Phone lock can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	<p>Configure the phone lock type.</p> <p>Parameters:</p> <p>phone_setting.phone_lock.enable</p> <p>phone_setting.phone_lock.lock_key_type</p>
		<p>Change the unlock PIN.</p> <p>Parameter:</p> <p>phone_setting.phone_lock.unlock_pin</p>
		<p>Configure the IP phone to automatically lock the phone after a time interval.</p> <p>Parameter:</p> <p>phone_setting.phone_lock.lock_time_out</p>
		<p>Configure emergency numbers.</p> <p>Parameter:</p> <p>phone_setting.emergency.number</p>
		<p>Assign a phone lock key.</p> <p>Parameter:</p> <p>linekey.X.type/ programablekey.X.type/ expansion_module.X.key.Y.type</p> <p>linekey.X.label/ programablekey.X.label/ expansion_module.X.key.Y.label</p>
Local	Web User Interface	<p>Configure the phone lock type.</p> <p>Change the unlock PIN.</p> <p>Configure the IP phone to automatically lock the phone after a time interval.</p> <p>Configure emergency numbers.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p><a href="http://<phoneIPAddress>/servlet?p=features-phonelock&q=load">http://<phoneIPAddress>/servlet?p=features-phonelock&q=load</p> <p>For SIP VP-T49G:</p> <p><a href="http://<phoneIPAddress>/servlet?m=mod_data&p=features-phonelock&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=features-phonelock&q=load</p>

		<p>Assign a phone lock key.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p=dsskey&q=load&model=0</p> <p>For SIP VP-T49G: http://<phoneIPAddress>/servlet?m=mod_data&p=dsskey&q=load</p>
	Phone User Interface	<p>Configure the phone lock type.</p> <p>Change the unlock PIN.</p> <p>Configure the IP phone to automatically lock the phone after a time interval.</p> <p>Assign a phone lock key.</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
phone_setting.phone_lock.enable	0 or 1	0
<p>Description:</p> <p>Enables or disables the phone lock feature.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>Web User Interface:</p> <p>Features->Phone Lock->Phone Lock Enable</p> <p>Phone User Interface:</p> <p>Menu->Settings->Advanced Settings (default password: admin) ->Phone Lock->Lock Enable</p>		
phone_setting.phone_lock.lock_key_type	0, 1 or 2	0
<p>Description:</p> <p>Configures the type of phone lock.</p> <p>0-All Keys</p> <p>1-Function Keys</p> <p>2-Menu Keys</p> <p>For more information, refer to Phone Lock Type on page 830.</p>		

Parameters	Permitted Values	Default
<p>Note: It is not applicable to SIP VP-T49G and SIP-T48G IP phones. It works only if the value of the parameter “phone_setting.phone_lock.enable” is set to 1 (Enabled).</p> <p>Web User Interface: Features->Phone Lock->Phone Lock Type</p> <p>Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Phone Lock->Lock Type</p>		
phone_setting.phone_lock.unlock_pin	Characters within 15 digits	123
<p>Description: Configures the password for unlocking the phone.</p> <p>Web User Interface: Features->Phone Lock->Phone Unlock PIN (0~15 Digit)</p> <p>Phone User Interface: Menu->Settings->Basic Settings->Change PIN</p>		
phone_setting.phone_lock.lock_time_out	Integer from 0 to 3600	0
<p>Description: Configures the interval (in seconds) to automatically lock the phone. The default value is 0 (the phone is locked only by long pressing the pound key or pressing the phone lock key).</p> <p>Note: It works only if the value of the parameter “phone_setting.phone_lock.enable” is set to 1(Enabled).</p> <p>Web User Interface: Features->Phone Lock->Phone Lock Time Out (0~3600s)</p> <p>Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Phone Lock->Lock Time Out</p>		
phone_setting.emergency.number	String within 99 characters	112,911, 110
<p>Description: Configures emergency numbers. Multiple emergency numbers are separated by commas. For SIP-T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: If the value of the parameter “phone_setting.phone_lock.enable” is set to 1</p>		

Parameters	Permitted Values	Default
<p>(Enabled) and "phone_setting.phone_lock.lock_key_type" is set to 0 (All Keys), you can only allow to dial emergency numbers configured by "phone_setting.emergency.number".</p> <p>For SIP VP-T49G/SIP-T48G:</p> <p>If the value of the parameter "phone_setting.phone_lock.enable" is set to 1 (Enabled), you can only allow to dial emergency numbers configured by "phone_setting.emergency.number".</p> <p>Web User Interface:</p> <p>Features->Phone Lock->Emergency</p> <p>Phone User Interface:</p> <p>None</p>		

Phone Lock Type

The following table lists the operation behavior when configuring the type of phone lock:

	All Keys	Function Keys	Menu key
Idle screen	<p>Allow Behavior: You are allowed to press the desired Line Key (key type is line) or the Speakerphone key to enter the dialing screen.</p> <p>Keys not Locked: Line keys (key type is line), digit keys, volume key, Speakerphone key, off-hook key and on-hook key.</p> <p>Note: Line key is not applicable to SIP-T19(P) E2 and CP860 IP phones. Speakerphone key is not applicable to CP860 IP phones. Off-hook key and on-hook key are only applicable to CP860 IP phones.</p>	The same as All Keys.	The Menu key (key type is menu) is locked.
Incoming call	<p>Allow Behavior: You are allowed to answer or reject incoming calls.</p> <p>Keys not Locked: Answer and Reject soft key; OK/V, X, HEADSET, volume key, Speakerphone key, off-hook key and on-hook key.</p> <p>Note: Pressing X key to reject the call is not applicable to SIP-T23P/T23G/T21(P) E2/T19(P) E2 and</p>	The same as All Keys.	The Menu key (key type is menu) is locked.

	All Keys	Function Keys	Menu key
	CP860 IP phones. HEADSET and Speakerphone key are not applicable to CP860 IP phones. Off-hook key and on-hook key are only applicable to CP860 IP phones. OK/√ and X keys are not applicable to SIP VP-T49G IP phones.		
Pre-dialing/Dialing screen	<p>Allow Behavior: You are allowed to press the Line Key (key type is line), input or modify numbers, dial emergency numbers and return to idle screen.</p> <p>Keys not Locked: IME, More, Cancel, Send, Delete and Line soft key; line key (key type is line), X, OK/√, volume key, Speakerphone key, digit keys, HEADSET key, "*"/*"#" (key as send), off-hook key and on-hook key.</p> <p>Note: Line key is not applicable to SIP-T19(P) E2 and CP860 IP phones. X, HEADSET and Speakerphone key are not applicable to CP860 IP phones. Off-hook key and on-hook key are only applicable to CP860 IP phones. OK/√ and X keys are not applicable to SIP VP-T49G IP phones.</p>	The same as All Keys, but you can dial any number.	The Menu key (key type is menu) is locked.
Talking	<p>Allow Behavior: You are allowed to end the call, initiate a new call to dial the emergency number and resume a call.</p> <p>Keys not Locked: EndCall, Cancel, Resume, NewCall soft key; line key (key type is line), digit keys, X, volume key, HEADSET, Speakerphone key, off-hook key and on-hook key.</p> <p>Note: Pressing X key to end the call are not applicable to SIP-T23P/T23G/T21(P) E2/T19(P) E2 and CP860 IP phones. Line key is not applicable to SIP-T19(P) E2 and CP860 IP phones. HEADSET and Speakerphone key is not applicable to CP860 IP phones. Off-hook key and</p>	The same as All Keys, but you can dial any number.	The Menu key (key type is menu) is locked.

	All Keys	Function Keys	Menu key
	on-hook key are only applicable to CP860 IP phones. OK/√ and X keys are not applicable to SIP VP-T49G IP phones.		

Phone Lock Key

For more information on how to configure the DSS Key, refer to [Appendix D: Configuring DSS Key](#) on page 926.

Details of Configuration Parameters:

Parameter	Permitted Values	Default
linekey.X.type/ programablekey.X.type/ expansion_module.X.key.Y.type	50	Refer to the following content
<p>Description:</p> <p>Configures a DSS key as a phone lock key on the IP phone.</p> <p>The digit 50 stands for the key type Phone Lock.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For programable keys:</p> <p>X=1-4, 12-14 (for SIP VP-T49G)</p> <p>X=1-10, 12-14 (for SIP-T48G/T46G)</p> <p>X=1-10, 13 (for SIP-T42G/T41P/T40P)</p> <p>X=1-14 (for SIP-T29G/T27P)</p> <p>X=1-10, 14 (for SIP-T23P/T23G/T21(P) E2)</p> <p>X=1-9, 13, 14 (for SIP-T19(P) E2)</p> <p>X=1-6, 9, 13 (for CP860)</p> <p>For ext keys:</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p>		

Parameter	Permitted Values	Default
<p>Example:</p> <p>linekey.1.type = 50</p> <p>Default:</p> <p>For line keys:</p> <p>For SIP VP-T49G/SIPT48G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-29 is 0.</p> <p>For SIPT46G/T29G IP phones:</p> <p>The default value of the line key 1-16 is 15, and the default value of the line key 17-27 is 0.</p> <p>For SIPT42G IP phones:</p> <p>The default value of the line key 1-12 is 15, and the default value of the line key 13-15 is 0.</p> <p>For SIPT41P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-15 is 0.</p> <p>For SIPT27P IP phones:</p> <p>The default value of the line key 1-6 is 15, and the default value of the line key 7-21 is 0.</p> <p>For SIPT40P/T23P/T23G/T21(P) E2 IP phones:</p> <p>The default value is 15.</p> <p>For programmable keys:</p> <p>For SIP VP-T49G IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIPT48G/T46G IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p>		

Parameter	Permitted Values	Default
<p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIP-T42G/T41P/T40P IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>For SIP-T29G/T27P IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=11, the default value is 0 (NA).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p>		

Parameter	Permitted Values	Default
<p>For SIP-T23P/T23G/T21(P) E2 IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIP-T19(P) E2 IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For CP860 IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=13, the default value is 0 (NA).</p> <p>Web User Interface:</p> <p>DSSKey->Line Key/ Programable Key->Type</p>		

Parameter	Permitted Values	Default
Phone User Interface: Menu->Features->DSS Keys->Line Keys X->Type		
linekey.X.label/ programablekey.X.label/ expansion_module.X.key.Y.label	String within 99 characters	Blank
Description: (Optional.) Configures the label displayed on the LCD screen for each DSS key. For line keys: X ranges from 1 to 29 (for SIP VP-T49G/SIPT48G) X ranges from 1 to 27 (for SIP-T46G/T29G) X ranges from 1 to 15 (for SIP-T42G/T41P) X ranges from 1 to 21 (for SIP-T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) For programable keys: X ranges from 1 to 4. For ext keys: X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured). Web User Interface: DSSKey->Line Key/Programable Key->Label Phone User Interface: Menu->Features->DSS Keys->Line Key X->Label		

To configure phone lock via web user interface:

1. Click on **Features->Phone Lock**.
2. Select the desired value from the pull-down list of **Phone Lock Enable**.
3. Select the desired value from the pull-down list of **Phone Lock Type**.
4. Enter the unlock PIN in the **Phone Unlock PIN (0~15 Digit)** field.

- Enter the desired time in the **Phone Lock Time Out (0~3600s)** field.

Yealink | T236 Log Out

Status Account Network **DSSKey** Features Settings Directory Security

Forward&DND
General Information
Audio
Intercom
Transfer
Call Pickup
Remote Control
Phone Lock

Phone Lock Enable: Enabled
Phone Lock Type: All Keys
Phone Unlock PIN(0~15 Digit): *****
Phone Lock Time Out(0~3600s): 0
Emergency: 112,911,110

Confirm Cancel

NOTE
Phone Lock
It is used to lock the IP phone to prevent it from unauthorized use. Once the IP phone is locked, a user must enter the password to unlock it.
IP phones offer three types of phone lock: Menu Key, Function Keys and All Keys.
The IP phone will not be locked immediately after the phone lock type is configured.
You can click here to get more guides.

- Click **Confirm** to accept the change.

To configure a phone lock key via web user interface:

- Click on **DSSKey->Line Key** (or **Programable Key**).
- In the desired DSS key field, select **Phone Lock** from the pull-down list of **Type**.
- (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.

Yealink | T236 Log Out

Status Account Network **DSSKey** Features Settings Directory Security

Line Key
Programable Key

Key	Type	Value	Label	Line	Extension
Line Key1	Line		1011	Line 1	
Line Key2	Phone Lock		N/A		
Line Key3	Line			Line 3	

Confirm Cancel

NOTE
Line Keys
Line keys allow you to quickly access features such as recall and voice mail.
You can click here to get more guides.

- Click **Confirm** to accept the change.

To configure the type of phone lock via phone user interface:



- Press **Menu->Settings->Advanced Settings** (default password: admin) -> **Phone Lock**.
- Press **Left** or **Right**, or the **Switch** soft key to select the desired value from the **Lock Enable** field.
- Press **Left** or **Right**, or the **Switch** soft key to select the desired value from the **Lock Type** field.
- Enter the desired interval of automatic phone lock in the **Lock Time Out** field.
- Press the **Save** soft key to accept the change.

To change the unlock PIN via phone user interface:

- Press **Menu->Settings->Basic Settings->Change PIN**.
- Enter the current unlock PIN in the **Current PIN** field.
- Enter the new unlock PIN in the **New PIN** field.

4. Enter the new unlock PIN again in the **Confirm PIN** field.
5. Press the **Save** soft key to accept the change.

To configure a phone lock key via phone user interface:

1. Press **Menu->Features->DSS Keys**.
2. Select the desired DSS key.
3. Press  or  , or the **Switch** soft key to select **Phone Lock** from the **Type** field.
4. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.
5. Press the **Save** soft key to accept the change.

Transport Layer Security

TLS is a commonly-used protocol for providing communications privacy and managing the security of message transmission, allowing IP phones to communicate with other remote parties and connect to the HTTPS URL for provisioning in a way that is designed to prevent eavesdropping and tampering.

TLS protocol is composed of two layers: TLS Record Protocol and TLS Handshake Protocol. The TLS Record Protocol completes the actual data transmission and ensures the integrity and privacy of the data. The TLS Handshake Protocol allows the server and client to authenticate each other and negotiate an encryption algorithm and cryptographic keys before data is exchanged.

The TLS protocol uses asymmetric encryption for authentication of key exchange, symmetric encryption for confidentiality, and message authentication codes for integrity.


- **Symmetric encryption:** For symmetric encryption, the encryption key and the corresponding decryption key can be told by each other. In most cases, the encryption key is the same as the decryption key.
- **Asymmetric encryption:** For asymmetric encryption, each user has a pair of cryptographic keys – a public encryption key and a private decryption key. The information encrypted by the public key can only be decrypted by the corresponding private key and vice versa. Usually, the receiver keeps its private key. The public key is known by the sender, so the sender sends the information encrypted by the known public key, and then the receiver uses the private key to decrypt it.

IP phones support TLS version 1.0. A cipher suite is a named combination of authentication, encryption, and message authentication code (MAC) algorithms used to negotiate the security settings for a network connection using the TLS/SSL network protocol. IP phones support the following cipher suites:

- DHE-RSA-AES256-SHA
- DHE-DSS-AES256-SHA
- AES256-SHA

- EDH-RSA-DES-CBC3-SHA
- EDH-DSS-DES-CBC3-SHA
- DES-CBC3-SHA
- DHE-RSA-AES128-SHA
- DHE-DSS-AES128-SHA
- AES128-SHA
- IDEA-CBC-SHA
- DHE-DSS-RC4-SHA
- RC4-SHA
- RC4-MD5
- EXP1024-DHE-DSS-DES-CBC-SHA
- EXP1024-DES-CBC-SHA
- EDH-RSA-DES-CBC-SHA
- EDH-DSS-DES-CBC-SHA
- DES-CBC-SHA
- EXP1024-DHE-DSS-RC4-SHA
- EXP1024-RC4-SHA
- EXP1024-RC4-MD5
- EXP-EDH-RSA-DES-CBC-SHA
- EXP-EDH-DSS-DES-CBC-SHA
- EXP-DES-CBC-SHA
- EXP-RC4-MD5

The following figure illustrates the TLS messages exchanged between the IP phone and TLS server to establish an encrypted communication channel:



The image shows a Wireshark packet capture of a TLS handshake. The packet list on the left shows seven packets. The packet details pane on the right shows the structure of the selected packet (Frame 13), which is an Application Data packet. The packet bytes pane at the bottom shows the raw data of the packet.

No.	Time	Source	Destination	Protocol	Info
1	0.000000	192.168.3.86	192.168.0.230	SSLV3	Client Hello
2	0.021345	192.168.0.230	192.168.3.86	SSLV3	Server Hello, Certificate, Server Key Exchange, Server Hello Done
3	0.054947	192.168.3.86	192.168.0.230	SSLV3	Client Key Exchange, Change Cipher Spec, Encrypted Handshake Message
4	0.070099	192.168.0.230	192.168.3.86	SSLV3	Change Cipher Spec, Encrypted Handshake Message
5	1.012295	192.168.3.86	192.168.0.230	SSLV3	Application Data, Application Data
6	1.013562	192.168.0.230	192.168.3.86	SSLV3	Application Data
7	1.013667	192.168.0.230	192.168.3.86	SSLV3	Application Data

Frame 13: 652 bytes on wire (5216 bits), 652 bytes captured (5216 bits)

Ethernet II, Src: Vmware_72:c9:2e (00:0c:29:72:c9:2e), Dst: Xiamenye_11:12:b7 (00:15:65:11:12:b7)

Internet Protocol, Src: 192.168.0.230 (192.168.0.230), Dst: 192.168.3.86 (192.168.3.86)

Transmission Control Protocol, Src Port: https (443), Dst Port: nmsserver (2244), Seq: 1482, Ack: 437, Len: 586

Secure Socket Layer

Step1: IP phone sends “Client Hello” message proposing SSL options.

Step2: Server responds with “Server Hello” message selecting the SSL options, sends its public key information in “Server Key Exchange” message and concludes its part of the negotiation with “Server Hello Done” message.

Step3: IP phone sends session key information (encrypted by server’s public key) in the “Client Key Exchange” message.

Step4: Server sends "Change Cipher Spec" message to activate the negotiated options for all future messages it will send.

IP phones can encrypt SIP with TLS, which is called SIPS. When TLS is enabled for an account, the SIP message of this account will be encrypted, and a lock icon appears on the LCD screen after the successful TLS negotiation.

Certificates

The IP phone can serve as a TLS client or a TLS server. The TLS requires the following security certificates to perform the TLS handshake:

- **Trusted Certificate:** When the IP phone requests a TLS connection with a server, the IP phone should verify the certificate sent by the server to decide whether it is trusted based on the trusted certificates list. The SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23G/T21(P) E2/T19(P) E2 IP phone has 31 built-in trusted certificates, and SIP VP-T49G/CP860 IP phone has 30 built-in trusted certificates. You can upload 10 custom certificates at most. The format of the trusted certificate files must be *.pem, *.cer, *.crt and *.der and the maximum file size is 5MB. For more information on 31 trusted certificates, refer to [Appendix C: Trusted Certificates](#) on page 924.
- **Server Certificate:** When clients request a TLS connection with the IP phone, the IP phone sends the server certificate to the clients for authentication. The IP phone has two types of built-in server certificates: a unique server certificate and a generic server certificate. You can only upload one server certificate to the IP phone. The old server certificate will be overridden by the new one. The format of the server certificate files must be *.pem and *.cer and the maximum file size is 5MB.
 - **A unique server certificate:** It is unique to an IP phone (based on the MAC address) and issued by the Yealink Certificate Authority (CA).
 - **A generic server certificate:** It issued by the Yealink Certificate Authority (CA). Only if no unique certificate exists, the IP phone may send a generic certificate for authentication.

The IP phone can authenticate the server certificate based on the trusted certificates list. The trusted certificates list and the server certificates list contain the default and custom certificates. You can specify the type of certificates the IP phone accepts: default certificates, custom certificates or all certificates.

Common Name Validation feature enables the IP phone to mandatorily validate the common name of the certificate sent by the connecting server. And Security verification rules are compliant with RFC 2818.

Note

In TLS feature, we use the terms trusted and server certificate. These are also known as CA and device certificates.

Resetting the IP phone to factory defaults will delete custom certificates by default. But this feature is configurable by the parameter "phone_setting.reserve_certs_enable" using the configuration files.

Procedure

Configuration changes can be performed using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure TLS on a per-line basis. Parameter: account.X.sip_server.Y.transport_type
	<y0000000000xx>.cfg	Configure trusted certificates feature. Parameters: security.trust_certificates security.ca_cert security.cn_validation
		Configure server certificates feature. Parameters: security.dev_cert
		Upload the trusted certificates. Parameter: trusted_certificates.url
		Delete all uploaded trusted certificates. Parameter: trusted_certificates.delete
		Upload the server certificates. Parameter: server_certificates.url
		Delete all uploaded server certificates. Parameter: server_certificates.delete
		Configure the custom certificates. Parameter: phone_setting.reserve_certs_enable
Local	Web User Interface	Configure TLS on a per-line basis. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/ T27P/T23P/T23G/T21(P) E2/T19(P)

		<p>E2/CP860:</p> <p><a href="http://<phoneIPAddress>/servlet?p=account-register&q=load&acc=0">http://<phoneIPAddress>/servlet?p=account-register&q=load&acc=0</p> <p>For SIP VP-T49G:</p> <p><a href="http://<phoneIPAddress>/servlet?m=mod_data&p=account-register&q=load&acc=0">http://<phoneIPAddress>/servlet?m=mod_data&p=account-register&q=load&acc=0</p>
		<p>Configure trusted certificates feature.</p> <p>Upload the trusted certificates.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/ T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p><a href="http://<phoneIPAddress>/servlet?p=trusted-cert&q=load">http://<phoneIPAddress>/servlet?p=trusted-cert&q=load</p> <p>For SIP VP-T49G:</p> <p><a href="http://<phoneIPAddress>/servlet?m=mod_data&p=trusted-cert&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=trusted-cert&q=load</p>
		<p>Configure server certificates feature.</p> <p>Upload the server certificates.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/ T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p><a href="http://<phoneIPAddress>/servlet?p=server-cert&q=load">http://<phoneIPAddress>/servlet?p=server-cert&q=load</p> <p>For SIP VP-T49G:</p> <p><a href="http://<phoneIPAddress>/servlet?m=mod_data&p=server-cert&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=server-cert&q=load</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
account.X.sip_server.Y.transport_type (X ranges from 1 to 16, Y ranges from 1 to 2)	0, 1, 2 or 3	0
Description:		

Parameters	Permitted Values	Default
<p>Configures the type of transport protocol for account X.</p> <p>0-UDP 1-TCP 2-TLS 3-DNS-NAPTR</p> <p>X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Web User Interface: Account->Register->SIP Server Y->Transport</p> <p>Phone User Interface: None</p>		
security.trust_certificates	0 or 1	1
<p>Description:</p> <p>Enables or disables the IP phone to only trust the server certificates in the Trusted Certificates list.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 0 (Disabled), the IP phone will trust the server no matter whether the certificate sent by the server is valid or not.</p> <p>If it is set to 1 (Enabled), the IP phone will authenticate the server certificate based on the trusted certificates list. Only when the authentication succeeds, the IP phone will trust the server.</p> <p>Note: If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface: Security->Trusted Certificates->Only Accept Trusted Certificates</p> <p>Phone User Interface: None</p>		
security.ca_cert	0, 1 or 2	2

Parameters	Permitted Values	Default
Description: Configures the type of certificates in the Trusted Certificates list for the IP phone to authenticate for TLS connection. 0-Default Certificates 1-Custom Certificates 2-All Certificates Note: If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Security->Trusted Certificates->CA Certificates Phone User Interface: None		
security.cn_validation	0 or 1	0
Description: Enables or disables the IP phone to mandatorily validate the CommonName or SubjectAltName of the certificate sent by the server. 0-Disabled 1-Enabled Note: If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Security->Trusted Certificates->Common Name Validation Phone User Interface: None		
security.dev_cert	0 or 1	0
Description: Configures the type of the device certificates for the IP phone to send for TLS authentication. 0-Default Certificates 1-Custom Certificates Note: If you change this parameter, the IP phone will reboot to make the change take effect.		

Parameters	Permitted Values	Default
Web User Interface: Security->Server Certificates->Device Certificates Phone User Interface: None		
trusted_certificates.url	URL within 511 characters	Blank
Description: Configures the access URL of the custom trusted certificate used to authenticate the connecting server. Example: trusted_certificates.url = http://192.168.1.20/tc.crt Note: The certificate you want to upload must be in *.pem, *.crt, *.cer or *.der format. Web User Interface: Security->Trusted Certificates->Load trusted certificates file Phone User Interface: None		
trusted_certificates.delete	http://localhost/all	Blank
Description: Deletes all uploaded trusted certificates. Example: trusted_certificates.delete = http://localhost/all Web User Interface: None Phone User Interface: None		
server_certificates.url	URL within 511 characters	Blank
Description: Configures the access URL of the certificate the IP phone sends for authentication. Example: server_certificates.url = http://192.168.1.20/ca.pem		

Parameters	Permitted Values	Default
<p>Note: The certificate you want to upload must be in *.pem or *.cer format.</p> <p>Web User Interface: Security->Server Certificates->Load server cer file</p> <p>Phone User Interface: None</p>		
server_certificates.delete	http://localhost/all	Blank
<p>Description: Deletes all uploaded server certificates.</p> <p>Example: server_certificates.delete = http://localhost/all</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		
phone_setting.reserve_certs_enable	0 or 1	0
<p>Description: Enables or disables the IP phone to reserve custom certificates after it is reset to factory defaults.</p> <p>0-Disabled 1-Enabled</p> <p>Web User Interface: None</p> <p>Phone User Interface: None</p>		

To configure TLS on a per-line basis via web user interface:

1. Click on **Account->Register**.
2. Select the desired account from the pull-down list of **Account**.

3. Select **TLS** from the pull-down list of **Transport**.

The screenshot shows the 'Account' configuration page for a Yealink T236 device. The 'Transport' dropdown menu under the 'SIP Server 1' section is highlighted with a red box, indicating that 'TLS' has been selected. The page includes various configuration fields such as 'Register Status', 'Line Active', 'Label', 'Display Name', 'Register Name', 'User Name', 'Password', 'Server Host', 'Port', 'Server Expires', and 'Server Retry Counts'. A right sidebar contains a 'NOTE' section with information about Account Registration, Server Redundancy, and NAT Traversal.

4. Click **Confirm** to accept the change.

To configure the trusted certificates via web user interface:

1. Click on **Security->Trusted Certificates**.
2. Select the desired values from the pull-down lists of **Only Accept Trusted Certificates**, **Common Name Validation** and **CA Certificates**.

The screenshot shows the 'Security > Trusted Certificates' page. A table lists certificates with columns for Index ID, Issued To, Issued By, Expiration, and Delete. Below the table, three dropdown menus are highlighted with a red box: 'Only Accept Trusted Certificates' (set to 'Enabled'), 'Common Name Validation' (set to 'Enabled'), and 'CA Certificates' (set to 'All Certificates'). A right sidebar contains a 'NOTE' section about Transport Layer Security (TLS) Trusted Certificate.

3. Click **Confirm** to accept the change.

To upload a trusted certificate via web user interface:

1. Click on **Security->Trusted Certificates**.

- Click **Browse** to select the certificate (*.pem, *.crt, *.cer or *.der) from your local system.

Yealink T236 Log Out

Status Account Network DSSKey Features Settings Directory **Security**

Password

Trusted Certificates

Server Certificates

Index ID	Issued To	Issued By	Expiration	Delete
1				<input type="checkbox"/>
2				<input type="checkbox"/>
3				<input type="checkbox"/>
4				<input type="checkbox"/>
5				<input type="checkbox"/>
6				<input type="checkbox"/>
7				<input type="checkbox"/>
8				<input type="checkbox"/>
9				<input type="checkbox"/>
10				<input type="checkbox"/>

Only Accept Trusted Certificates: Enabled

Common Name Validation: Disabled

CA Certificates: All Certificates

Import Trusted Certificates

Load trusted certificates file: No file selected.

NOTE

Transport Layer Security (TLS)

Trusted Certificate

When the IP phone requests a TLS connection with a server, the IP phone should verify the certificate sent by the server to decide whether it is trusted based on the trusted certificates list. The IP phone has 30 built-in trusted certificates. You can upload 10 custom certificates at most. The format of the trusted certificate files must be *.pem, *.cer, *.crt and *.der and the maximum file size is 5MB.

You can click here to get more guides.

- Click **Upload** to upload the certificate.

To configure the server certificates via web user interface:

- Click on **Security->Server Certificates**.
- Select the desired value from the pull-down list of **Device Certificates**.

Yealink T236 Log Out

Status Account Network DSSKey Features Settings Directory **Security**

Password

Trusted Certificates

Server Certificates

Issued To	Issued By	Expiration	Delete
			<input type="button" value="Delete"/>

Device Certificates Default Certificates

Import Server Certificates

Load server cer file: No file selected.

NOTE

Transport Layer Security (TLS) Server Certificates


When clients request a TLS connection with the IP phone, the IP phone sends the server certificate to the clients for authentication. The IP phone has two types of built-in server certificates: a unique server certificate and a generic server certificate. You can only upload one server certificate to the IP

- Click **Confirm** to accept the change.

To upload a server certificate via web user interface:

- Click on **Security->Server Certificates**.

- Click **Browse** to select the certificate (*.pem and *.cer) from your local system.



- Click **Upload** to upload the certificate.

A dialog box pops up to prompt "Success: The Server Certificate has been loaded! Rebooting, please wait...".

Secure Real-Time Transport Protocol

Secure Real-Time Transport Protocol (SRTP) encrypts the RTP during VoIP phone calls to avoid interception and eavesdropping. The parties participating in the call must enable SRTP feature simultaneously. When this feature is enabled on both phones, the type of encryption to utilize for the session is negotiated between the IP phones. This negotiation process is compliant with [RFC 4568](#).

When a user places a call on the enabled SRTP phone, the IP phone sends an INVITE message with the RTP encryption algorithm to the destination phone. As described in [RFC 3711](#), RTP streams may be encrypted using an AES (advanced encryption standard) algorithm.

Example of the RTP encryption algorithm carried in the SDP of the INVITE message:

```
m=audio 11780 RTP/SAVP 0 8 18 9 101
a=crypto:1 AES_CM_128_HMAC_SHA1_80
inline:NzFINTUwZDk2OGVlOTc3YzNkYTkWZWVhMTM1YWFj
a=crypto:2 AES_CM_128_HMAC_SHA1_32
inline:NzkyM2FjNzQ2ZDgxYjg0MzQwMGVmMGUxMzdmNWVm
a=crypto:3 F8_128_HMAC_SHA1_80 inline:NDliMWlZGE1ZTAwZjA5ZGFhNjQ5YmEANTMzYzA0
a=rtpmap:0 PCMU/8000
a=rtpmap:8 PCMA/8000
a=rtpmap:18 G729/8000
a=fmtp:18 annexb=no
a=rtpmap:9 G722/8000
a=fmtp:101 0-15
a=rtpmap:101 telephone-event/8000
a=ptime:20
```

```
a=sendrecv
```

The callee receives the INVITE message with the RTP encryption algorithm, and then answers the call by responding with a 200 OK message which carries the negotiated RTP encryption algorithm.

Example of the RTP encryption algorithm carried in the SDP of the 200 OK message:

```
m=audio 11780 RTP/SAVP 0 101
a=rtpmap:0 PCMU/8000
a=rtpmap:101 telephone-event/8000
a=crypto:1 AES_CM_128_HMAC_SHA1_80
inline:NGY4OGViMDYzZjQzYTNiOTNkOWRiYzRiMjM0Yzcy
a=sendrecv
a=ptime:20
a=fmtp:101 0-15
```

SRTP is configurable on a per-line basis. When SRTP is enabled on both IP phones, RTP streams will be encrypted, and a lock icon appears on the LCD screen of each IP phone after successful negotiation.

Note

If you enable SRTP, then you should also enable TLS. This ensures the security of SRTP encryption. For more information on TLS, refer to [Transport Layer Security](#) on page 838.

Procedure

SRTP can be configured using the configuration files or locally.

Configuration File	<MAC>.cfg	Configure SRTP feature on a per-line basis. Parameter: account.X.srtp_encryption
Local	Web User Interface	Configure SRTP feature on a per-line basis. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0">http://<phoneIPAddress>/servlet?p=account-adv&q=load&acc=0 For SIP VP-T49G: <a href="http://<phoneIPAddress>/servl">http://<phoneIPAddress>/servl

		et?m=mod_data&p=account-a dv&q=load&acc=0
--	--	--

Details of the Configuration Parameter:

Parameters	Permitted Values	Default
account.X.srtp_encryption	0, 1 or 2	0
<p>Description: Configures whether to use voice encryption service for account X. 0-Disabled 1-Optional 2-Compulsory If it is set to 1 (Optional), the IP phone will negotiate with the other IP phone what type of encryption to utilize for the session. If it is set to 2 (Compulsory), the IP phone is forced to use SRTP during a call. X ranges from 1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G) X ranges from 1 to 12 (for SIP-T42G) X ranges from 1 to 6 (for SIP-T41P/T27P) X ranges from 1 to 3 (for SIP-T40P/T23P/T23G) X ranges from 1 to 2 (for SIP-T21(P) E2) X is equal to 1 (for SIP-T19(P) E2/CP860)</p> <p>Web User Interface: Account->Advanced->RTP Encryption(SRTP)</p> <p>Phone User Interface: None</p>		

To configure SRTP feature via web user interface:

1. Click on **Account->Advanced**.
2. Select the desired account from the pull-down list of **Account**.

3. Select the desired value from the pull-down list of **RTP Encryption(SRTP)**.

The screenshot shows the Yealink T236 web interface. The 'Account' tab is selected. The 'RTP Encryption(SRTP)' dropdown menu is highlighted with a red box, showing 'Optional' as the selected value. Other settings visible include: Keep Alive Type (Default), Keep Alive Interval(Seconds) (30), RPort (Disabled), Subscribe Period(Seconds) (1800), PTime(ms) (20), BLF List URI (4609@pbx.yealink.com), BLF List Pickup Code (*97), BLF List Barge In Code (*33), BLF List Retrieve Call Parked Code (*88), Shared Line (Shared Call Appearance), Call Pull Feature Access Code (*11), Dialog Info Call Pickup (Enabled), VQ RTPC-XR Collector name (collector), VQ RTPC-XR Collector address (10.2.1.98), and VQ RTPC-XR Collector port (5060). A 'NOTE' section on the right provides information about DTMF, Session Timer, Busy Lamp Field/BLF List, Shared Call Appearance (SCA)/ Bridge Line Appearance (BLA), and Network Conference.

4. Click **Confirm** to accept the change.

Encrypting Configuration Files

Encrypted configuration files can be downloaded from the provisioning server to protect against unauthorized access and tampering of sensitive information (e.g., login passwords, registration information). Yealink supplies a configuration encryption tool for encrypting configuration files. The encryption tool encrypts plaintext <y0000000000xx>.cfg and <MAC>.cfg files (one by one or in batch) using 16-character symmetric keys (the same or different keys for configuration files) and generates encrypted configuration files with the same file name as before. This tool also encrypts the plaintext 16-character symmetric keys using a fixed key, which is the same as the one built in the IP phone, and generates new files named as <xx_Security>.enc (xx indicates the name of the configuration file, for example, y000000000044_Security.enc for y000000000044.cfg file). This tool generates another new file named as Aeskey.txt to store the plaintext 16-character symmetric keys for each configuration file.

For a Microsoft Windows platform, you can use a Yealink-supplied encryption tool "Config_Encrypt_Tool.exe" to encrypt the <y0000000000xx>.cfg and <MAC>.cfg files respectively.

Note

Yealink also supplies a configuration encryption tool (yealinkencrypt) for Linux platform if required. For more information, refer to [Yealink Configuration Encryption Tool User Guide](#).

For security reasons, administrator should upload encrypted configuration files, <y0000000000xx_Security>.enc and/or <MAC_Security>.enc files to the root directory of the provisioning server. During auto provisioning, the IP phone requests to download <y0000000000xx>.cfg file first. If the downloaded configuration file is encrypted, the IP phone will request to download <y0000000000xx_Security>.enc file (if enabled) and decrypt it into the plaintext key (e.g., key2) using the built-in key (e.g., key1). Then the IP phone decrypts <y0000000000xx>.cfg file using key2. After decryption, the IP phone resolves configuration files and updates configuration settings onto the IP phone system.

The way the IP phone processes the <MAC>.cfg file is the same to that of the <y0000000000xx>.cfg file.

Procedure to Encrypt Configuration Files

To encrypt the <y0000000000xx>.cfg file:

1. Double click "Config_Encrypt_Tool.exe" to start the application tool.

The screenshot of the main page is shown as below:



When you start the application tool, a file folder named "Encrypted" is created automatically in the directory where the application tool is located.

2. Click **Browse** to locate configuration file(s) (e.g., y000000000044.cfg) from your local system in the **Select File(s)** field.

To select multiple configuration files, you can select the first file and then press and hold the **Ctrl** key and select the next files.

3. (Optional.) Click **Browse** to locate the target directory from your local system in the

Target Directory field.

The tool uses the file folder "Encrypted" as the target directory by default.

- (Optional.) Mark the desired radio box in the **AES Model** field.

If you mark the **Manual** radio box, you can enter an AES key in the **AES KEY** field or click **Re-Generate** to generate an AES key in the **AES KEY** field. The configuration file(s) will be encrypted using the AES key in the **AES KEY** field.

If you mark the **Auto Generate** radio box, the configuration file(s) will be encrypted using random AES key. The AES keys of configuration files are different.

Note


AES keys must be 16 characters and the supported characters contain: 0 ~ 9, A ~ Z, a ~ z and the following special characters are also supported: # \$ % * + , - . : = ? @ [] ^ _ { } ~ .

- Click **Encrypt** to encrypt the configuration file(s).



- Click **OK**.

The target directory will be automatically opened. You can find the encrypted CFG file(s), encrypted key file(s) and an Aeskey.txt file storing plaintext AES key(s).



Procedure

Decryption method can be configured using the configuration files.

Configuration File	<y0000000000xx>.cfg	<p>Configure the decryption method.</p> <p>Parameter:</p> <p>auto_provision.aes_key_in_file</p> <p>Configure AES keys.</p> <p>Parameters:</p> <p>auto_provision.aes_key_16.com</p> <p>auto_provision.aes_key_16.mac</p>
Local	Web User Interface	<p>Configure AES keys.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29 G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>http://<phoneIPAddress>/servlet?p =settings-autop&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet? m=mod_data&p=settings-autop& q=load</p>
	Phone User Interface	Configure AES keys.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
auto_provision.aes_key_in_file	0 or 1	0
<p>Description:</p> <p>Enables or disables the IP phone to decrypt configuration files using the encrypted AES keys.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>If it is set to 1 (Enabled), the IP phone will download <y0000000000xx_Security>.enc and <MAC_Security>.enc files during auto provisioning, and then decrypts these files into the plaintext keys (e.g., key2, key3) respectively using the phone built-in key (e.g., key1). The IP phone then decrypts the encrypted configuration files using corresponding key (e.g., key2, key3).</p>		

Parameters	Permitted Values	Default
<p>If it is set to 0 (Disabled), the IP phone will decrypt the encrypted configuration files using plaintext AES keys configured on the IP phone.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		
auto_provision.aes_key_16.com	16 characters	Blank
<p>Description:</p> <p>Configures the plaintext AES key for decrypting the Common CFG file.</p> <p>The valid characters contain: 0 ~ 9, A ~ Z, a ~ z and the following special characters are also supported: # \$ % * + , - . : = ? @ [] ^ _ { } ~.</p> <p>Example:</p> <p>auto_provision.aes_key_16.com = 0123456789abcdef</p> <p>Note: It works only if the value of the parameter "auto_provision.aes_key_in_file" is set to 0 (Disabled).</p> <p>Web User Interface:</p> <p>Settings->Auto Provision->Common AES Key</p> <p>Phone User Interface:</p> <p>Menu->Settings->Advanced Settings->Set AES Key->Common</p>		
auto_provision.aes_key_16.mac	16 characters	Blank
<p>Description:</p> <p>Configures the plaintext AES key for decrypting the MAC-Oriented CFG file.</p> <p>The valid characters contain: 0 ~ 9, A ~ Z, a ~ z and the following special characters are also supported: # \$ % * + , - . : = ? @ [] ^ _ { } ~.</p> <p>Example:</p> <p>auto_provision.aes_key_16.mac = 0123456789abmins</p> <p>Note: It works only if the value of the parameter "auto_provision.aes_key_in_file" is set to 0 (Disabled).</p> <p>Web User Interface:</p> <p>Settings->Auto Provision->MAC-Oriented AES Key</p> <p>Phone User Interface:</p> <p>Menu->Settings->Advanced Settings->Set AES Key->MAC-oriented</p>		

To configure AES keys via web user interface:

1. Click on **Settings->Auto Provision**.
2. Enter the values in the **Common AES Key** and **MAC-Oriented AES Key** fields.

AES keys must be 16 characters and the supported characters contain: 0-9, A-Z, a-z and the following special characters are also supported: # \$ % * + , - . : = ? @ [] ^ _ { } ~.

3. Click **Confirm** to accept the change.

To configure AES keys via phone user interface:

1. Press **Menu->Settings->Advanced Settings** (default password: admin) ->**Set AES Key**.
2. Enter the values in the **Common AES Key** and **MAC-Oriented AES Key** fields.

AES keys must be 16 characters and the supported characters contain: 0-9, A-Z, a-z and the following special characters are also supported: # \$ % * + , - . : = ? @ [] ^ _ { } ~.

3. Press the **Save** soft key to accept the change.

802.1X Authentication

IEEE 802.1X authentication is an IEEE standard for Port-based Network Access Control (PNAC), part of the IEEE 802.1 group of networking protocols. It offers an authentication mechanism for devices to connect/link to a LAN or WLAN. The 802.1X authentication involves three parties: a supplicant, an authenticator and an authentication server. The supplicant is the IP phone that wishes to attach to the LAN or WLAN. With 802.1X port-based authentication, the IP phone provides credentials, such as user name and password, for the authenticator, and then the authenticator forwards the credentials to the authentication server for verification. If the authentication server determines the credentials are valid, the IP phone is allowed to access resources located on the

protected side of the network.

IP phones support protocols EAP-MD5, EAP-TLS, EAP-PEAP/MSCHAPv2, EAP-TTLS/EAP-MSCHAPv2, EAP-PEAP/GTC, EAP-TTLS/EAP-GTC and EAP-FAST for 802.1X authentication.

For more information on 802.1X authentication, refer to [Yealink 802.1X Authentication](#).

Procedure

802.1X authentication can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	<p>Configure the 802.1X authentication.</p> <p>Parameters:</p> <p>network.802_1x.mode</p> <p>network.802_1x.identity</p> <p>network.802_1x.md5_password</p> <p>network.802_1x.root_cert_url</p> <p>network.802_1x.client_cert_url</p>
Local	Web User Interface	<p>Configure the 802.1X authentication.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>http://<phoneIPAddress>/servlet?<p=network-adv&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet?<m=mod_data&p=network-adv&q=load</p>
	Phone User Interface	Configure the 802.1X authentication.

Details of Configuration Parameters:

Parameters	Permitted Values	Default
network.802_1x.mode	0, 1, 2, 3, 4, 5, 6 or 7	0
<p>Description:</p> <p>Configures the 802.1x authentication method.</p>		

Parameters	Permitted Values	Default
<p>0-Disabled 1-EAP-MD5 2-EAP-TLS 3-EAP-PEAP/MSCHAPv2 4-EAP-TTLS/EAP-MSCHAPv2 5-EAP-PEAP/GTC 6-EAP-TTLS/EAP-GTC 7-EAP-FAST</p> <p>Note: If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Advanced->802.1x->802.1x Mode</p> <p>Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->802.1x Settings->802.1x Mode</p>		
network.802_1x.identity	String within 32 characters	Blank
<p>Description: Configures the user name for 802.1x authentication.</p> <p>Example: network.802_1x.identity = admin</p> <p>Note: It works only if the value of the parameter “network.802_1x.mode” is set to 1, 2, 3, 4, 5, 6 or 7. If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Advanced->802.1x->Identity</p> <p>Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->802.1x Settings->Identity</p>		
network.802_1x.md5_password	String within 32 characters	Blank
<p>Description: Configures the password for 802.1x authentication.</p> <p>Example: network.802_1x.md5_password = admin123</p>		

Parameters	Permitted Values	Default
<p>Note: It works only if the value of the parameter "network.802_1x.mode" is set to 1, 3, 4, 5, 6 or 7. If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Advanced->802.1x->MD5 Password</p> <p>Phone User Interface: Menu->Settings->Advanced Settings (default password: admin) ->Network->802.1x Settings->MD5 Password</p>		
network.802_1x.root_cert_url	URL within 511 characters	Blank
<p>Description: Configures the access URL of the CA certificate.</p> <p>Example: network.802_1x.root_cert_url = http://192.168.1.10/ca.pem</p> <p>Note: It works only if the value of the parameter "network.802_1x.mode" is set to 2, 3, 4, 5, 6 or 7. The format of the certificate must be *.pem, *.crt, *.cer or *.der.</p> <p>Web User Interface: Network->Advanced->802.1x->CA Certificates</p> <p>Phone User Interface: None</p>		
network.802_1x.client_cert_url	URL within 511 characters	Blank
<p>Description: Configures the access URL of the device certificate.</p> <p>Example: network.802_1x.client_cert_url = http://192.168.1.10/client.pem</p> <p>Note: It works only if the value of the parameter "network.802_1x.mode" is set to 2 (EAP-TLS). The format of the certificate must be *.pem.</p> <p>Web User Interface: Network->Advanced->802.1x->Device Certificates</p> <p>Phone User Interface: None</p>		

To configure the 802.1X authentication via web user interface:

1. Click on **Network->Advanced**.

2. In the **802.1x** block, select the desired protocol from the pull-down list of **802.1x Mode**.

a) If you select **EAP-MD5**:

- 1) Enter the user name for authentication in the **Identity** field.
- 2) Enter the password for authentication in the **MD5 Password** field.

The screenshot shows the Yealink T236 configuration interface. The 'Network' tab is selected. Under the '802.1x' section, the '802.1x Mode' is set to 'EAP-MD5'. The 'Identity' field contains 'yealink' and the 'MD5 Password' field is masked with asterisks. The 'CA Certificates' and 'Device Certificates' fields have 'Browse...' buttons. The 'Registration Random' field is set to '0'. The 'VPN' section has 'Active' set to 'Enabled' and an 'Upload VPN Config' button. A 'NOTE' sidebar on the right provides additional information about various features.

b) If you select **EAP-TLS**:

- 1) Enter the user name for authentication in the **Identity** field.
- 2) Leave the **MD5 Password** field blank.
- 3) In the **CA Certificates** field, click **Browse** to select the desired CA certificate (*.pem, *.crt, *.cer or *.der) from your local system.
- 4) In the **Device Certificates** field, click **Browse** to select the desired client (*.pem or *.cer) certificate from your local system.

5) Click **Upload** to upload the certificates.

The screenshot shows the Yealink T236 web interface. The 'Network' tab is selected. The '802.1x' section is highlighted with a red box. The fields in this section are:

- 802.1x Mode:** EAP-TLS (dropdown)
- Identity:** yealink (text field)
- MD5 Password:** (password field)
- CA Certificates:** (text field) with an 'Upload' button and a 'Browse...' link.
- Device Certificates:** (text field) with an 'Upload' button and a 'Browse...' link.

The right sidebar contains a 'NOTE' section with the following information:

- VLAN:** It is used to logically divide a physical network into several broadcast domains. VLAN membership can be configured through software instead of physically relocating devices or connections.
- NAT Traversal:** It is a general term for techniques that establish and maintain IP connections traversing NAT gateways. STUN is one of the NAT traversal techniques.
- Quality of Service (QoS):** It is the ability to provide different priorities for different packets in the network, allowing the transport of traffic with special requirements.
- Web Server Type:** It determines access protocol and port of the IP phone's web user interface.
- 802.1X Authentication:** It offers an authentication mechanism for the IP phone to connect/link to a LAN or WLAN.
- VPN:** It provides remote offices or individual users with secure access to their organization's network.

c) If you select **EAP-PEAP/MSCHAPv2**:

- 1) Enter the user name for authentication in the **Identity** field.
- 2) Enter the password for authentication in the **MD5 Password** field.
- 3) In the **CA Certificates** field, click **Browse** to select the desired CA certificate (*.pem, *.crt, *.cer or *.der) from your local system.

4) Click **Upload** to upload the certificate.

The screenshot shows the Yealink T236 web interface. The top navigation bar includes 'Status', 'Account', 'Network', 'DSSKey', 'Features', 'Settings', 'Directory', and 'Security'. The left sidebar has 'Basic', 'PC Port', and 'Advanced' options. The main content area is titled '802.1x' and contains the following configuration fields:

- LLDP**: Active (Enabled), Packet Interval (1~3600s) (60)
- CDP**: Active (Disabled), Packet Interval (1~3600s) (60)
- 802.1x**:
 - 802.1x Mode: EAP-PEAP/MSCHAPv2
 - Identity: yealink
 - MD5 Password: [masked]
 - CA Certificates: [Upload button highlighted with a red box]
 - Device Certificates: [Upload button]
- Registration Random**: Registration Random (0~60s) (0)
- VPN**: Active (Enabled), Upload VPN Config [Upload button]

At the bottom are 'Confirm' and 'Cancel' buttons. The right sidebar contains a 'NOTE' section with the following text:

VLAN
It is used to logically divide a physical network into several broadcast domains. VLAN membership can be configured through software instead of physically relocating devices or connections.

The priority of VLAN assignment method (from highest to lowest): LLDP/CDP->manual configuration->DHCP VLAN

NAT Traversal
It is a general term for techniques that establish and maintain IP connections traversing NAT gateways. STUN is one of the NAT traversal techniques.

You can configure NAT traversal for the IP phone.

Quality of Service (QoS)
It is the ability to provide different priorities for different packets in the network, allowing the transport of traffic with special requirements.

Web Server Type
It determines access protocol and port of the IP phone's web user interface.

802.1X Authentication
It offers an authentication mechanism for the IP phone to connect/link to a LAN or WLAN.

VPN
It provides remote offices or individual users with secure access to their organization's

d) If you select **EAP-TTLS/EAP-MSCHAPv2**:

- 1) Enter the user name for authentication in the **Identity** field.
- 2) Enter the password for authentication in the **MD5 Password** field.
- 3) In the **CA Certificates** field, click **Browse** to select the desired CA certificate (*.pem, *.crt, *.cer or *.der) from your local system.

4) Click **Upload** to upload the certificate.

The screenshot shows the Yealink T236 web interface with the **Network** tab selected. The left sidebar has **Advanced** selected. The main content area shows the following settings:

- LLDP**: Active (Enabled), Packet Interval (1~3600s) (60)
- CDP**: Active (Disabled), Packet Interval (1~3600s) (60)
- 802.1x** (highlighted with a red box):
 - 802.1x Mode: EAP-TTLS/EAP-MSCHAP
 - Identity: yealink
 - MD5 Password: [masked]
 - CA Certificates: [Upload button]
- Registration Random**: Registration Random (0~60s) (0)
- VPN**: Active (Enabled), Upload VPN Config [Upload button]

On the right side, there is a **NOTE** section with information about VLAN, NAT Traversal, Quality of Service (QoS), Web Server Type, 802.1X Authentication, and VPN.

e) If you select **EAP-PEAP/GTC**:

- 1) Enter the user name for authentication in the **Identity** field.
- 2) Enter the password for authentication in the **MD5 Password** field.

- 3) In the **CA Certificates** field, click **Browse** to select the desired CA certificate (*.pem, *.crt, *.cer or *.der) from your local system.

The screenshot shows the Yealink T236 configuration interface. The 'Network' tab is selected, and the '802.1x' section is highlighted with a red box. The '802.1x Mode' is set to 'EAP-PEAP/GTC'. The 'Identity' field contains 'yealink' and the 'MD5 Password' field contains '*****'. The 'CA Certificates' field has an 'Upload' button and a 'Browse...' button. Other sections include LLDP, CDP, Registration Random, and VPN. A 'NOTE' sidebar on the right contains information about VLAN, NAT Traversal, Quality of Service (QoS), Web Server Type, 802.1X Authentication, and VPN.

- 4) Click **Upload** to upload the certificate.

f) If you select **EAP-TLS/EAP-GTC**:

- 1) Enter the user name for authentication in the **Identity** field.
- 2) Enter the password for authentication in the **MD5 Password** field.

- 3) In the **CA Certificates** field, click **Browse** to select the desired CA certificate (*.pem, *.crt, *.cer or *.der) from your local system.

The screenshot shows the Yealink T236 configuration interface. The 'Network' tab is selected. On the left, the 'Advanced' section is expanded. The '802.1x' configuration section is highlighted with a red rectangle. Within this section, the '802.1x Mode' is set to 'EAP-TTLS/EAP-GTC'. The 'Identity' field contains 'yealink'. The 'MD5 Password' field is masked with asterisks. The 'CA Certificates' field has an 'Upload' button and a 'Browse...' button. Other sections visible include LLDP (Active: Enabled), CDP (Active: Disabled), Registration Random (0-60s: 0), and VPN (Active: Enabled).

- 4) Click **Upload** to upload the certificate.

g) If you select **EAP-FAST**:

- 1) Enter the user name for authentication in the **Identity** field.
- 2) Enter the password for authentication in the **MD5 Password** field.

- 3) In the **CA Certificates** field, click **Browse** to select the desired CA certificate (*.pem, *.crt, *.cer or *.der) from your local system.

- 4) Click **Upload** to upload the certificate.

3. Click **Confirm** to accept the change.

A dialog box pops up to prompt that settings will take effect after a reboot.

4. Click **OK** to reboot the phone.

To configure the 802.1X authentication via phone user interface:

- Press **Menu->Settings->Advanced Settings** (default password: admin) **->Network->802.1x Settings**.
- Press **◀** or **▶**, or the **Switch** soft key to select the desired value from the **802.1x Mode** field.
 - If you select **EAP-MD5**:
 - Enter the user name for authentication in the **Identity** field.
 - Enter the password for authentication in the **MD5 Password** field.
 - If you select **EAP-TLS**:
 - Enter the user name for authentication in the **Identity** field.
 - Leave the **MD5 Password** field blank.
 - If you select **EAP-PEAP/MSCHAPv2**:
 - Enter the user name for authentication in the **Identity** field.
 - Enter the password for authentication in the **MD5 Password** field.
 - If you select **EAP-TTLS/EAP-MSCHAPv2**:

- 1) Enter the user name for authentication in the **Identity** field.
 - 2) Enter the password for authentication in the **MD5 Password** field.
- e) If you select **EAP-PEAP/GTC**:
 - 1) Enter the user name for authentication in the **Identity** field.
 - 2) Enter the password for authentication in the **MD5 Password** field.
- f) If you select **EAP-TTLS/EAP-GTC**:
 - 1) Enter the user name for authentication in the **Identity** field.
 - 2) Enter the password for authentication in the **MD5 Password** field.
- g) If you select **EAP-FAST**:
 - 1) Enter the user name for authentication in the **Identity** field.
 - 2) Enter the password for authentication in the **MD5 Password** field.
3. Click **Save** to accept the change.

The IP phone reboots automatically to make the settings effective after a period of time.

Troubleshooting

This chapter provides an administrator with general information for troubleshooting some common problems that he (or she) may encounter while using IP phones.

Troubleshooting Methods

IP phones can provide feedback in a variety of forms such as log files, packets, status indicators and so on, which can help an administrator more easily find the system problem and fix it.

The following are helpful for better understanding and resolving the working status of the IP phone.

- [Viewing Log Files](#)
- [Capturing Packets](#)
- [Enabling Watch Dog Feature](#)
- [Getting Information from Status Indicators](#)
- [Analyzing Configuration File](#)
- [Exporting All the Diagnostic Files](#)

Viewing Log Files

If your IP phone encounters some problems, commonly the log files are needed. You can configure the phone to periodically upload the log files to the provisioning server (only support an FTP/TFTP as the provisioning server). There are two types of log files on the provisioning server: <mac>-boot.log (e.g., 0015659188f2-boot.log) and <mac>-sys.log (0015659188f2-sys.log). The <mac>-boot.log file is uploaded to the provisioning server after every boot. The <mac>-sys.log file is uploaded periodically to the provisioning server. You can export the log files to a syslog server or the local system. You can also specify the severity level of the log to be reported to a log file. The default system log level is 3.

In the configuration files, you can use the following parameters to configure system log settings:

- **syslog.log_level** -- Specify the system log level. The following lists the log level of events you can log:
 - 0: system is unusable
 - 1: action must be taken immediately
 - 2: critical condition

- 3: error conditions
- 4: warning conditions
- 5: normal but significant condition
- 6: informational

- **syslog.mode** – Specify the system log to be exported to the provisioning server, syslog server or local system.
- **syslog.server** -- Specify the IP address or domain name of the syslog server to which the log will be exported.
- **syslog.log_upload_period** - Specify the period of the log upload (in seconds) to the provisioning server.
- **syslog.ftp.post_mode** - Specify whether the log files on the provisioning server are overwritten or appended.
- **syslog.ftp.max_logfile** - Specify the maximum size of the log files on the provisioning server.
- **syslog.ftp.append_limit_mode** - Specify the phone to stop log upload or delete the old log when the log on the provisioning server reaches the max size.
- **syslog.bootlog_upload_wait_time** - Specify the waiting time before the phone uploads the log file to the provisioning server.
- **auto_provision.server.url** - Specify the access URL of the syslog server or provisioning server.

Configuring the Severity Level of the Log

Procedure

Severity level can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the severity level of the logs to be reported to a log file. Parameters: syslog.log_level
Local	Web User Interface	Configure the severity level of the logs to be reported to a log file. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/ T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?m =mod_data&p=settings-config&q=l

		oad For SIP VP-T49G: http://<phoneIPAddress>/servlet?m =mod_data&p=settings-config&q=l oad
--	--	--

Details of Configuration Parameters:

Parameters	Permitted Values	Default
syslog.log_level	Integer from 0 to 6	3
<p>Description: Configures the detail level of syslog information to be exported.</p> <p>0-system is unusable 1-action must be taken immediately 2-critical condition 3-error conditions 4-warning conditions 5-normal but significant condition 6-informational</p> <p>Note: If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface: Settings->Configuration->System Log Level</p> <p>Phone User Interface: None</p>		

To configure the level of the system log via web user interface:

1. Click on **Settings->Configuration**.

2. Select the desired level from the pull-down list of **System Log Level**.

The screenshot shows the Yealink T236 web interface. The 'Settings' tab is selected. In the 'Configuration' section, the 'System Log Level' dropdown menu is highlighted with a red box and set to '6'. The interface includes a sidebar with navigation options like Preference, Time & Date, Call Display, Upgrade, Auto Provision, Configuration, Dial Plan, Voice, Ring, Tones, Softkey Layout, TR069, and Voice Monitoring. The main content area shows various configuration options for export and import of configuration files, PCAP feature, and system logs. A 'NOTE' section on the right provides information about log files and guides.

3. Click **Confirm** to accept the change.
- The system log level is set as 6, the informational level.

Note Informational level may make some sensitive information accessible (e.g., password dial number), we recommend that you reset the system log level to 3 after providing the syslog file.

Exporting the Log File to the Local System

Procedure

Log setting can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the syslog mode. Parameters: syslog.mode
Local	Web User Interface	Configure the syslog mode. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T29G/ T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?m =mod_data&p=settings-config&q=l oad

		For SIP VP-T49G: http://<phoneIPAddress>/servlet?m =mod_data&p=settings-config&q=l oad
--	--	---


Details of Configuration Parameters:

Parameters	Permitted Values	Default
syslog.mode	0, 1 or 2	0
Description: Configures the IP phone to export log files to the local system, syslog server or an FTP/TFTP Server (provisioning server). 0-Local 1-Server 2-FTP/TFTP Server Note: If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Settings->Configuration->Export System Log Phone User Interface: None		

To export a log file to the local system via web user interface:

1. Click on **Settings->Configuration**.
2. Mark the **Local** radio box in the **Export System Log** field.
 A dialog box pops up to prompt "Warning: Some settings you changed take effect when you restart your machine! Do you want to reboot now?". The configuration will take effect after a reboot.
3. Click **OK** to reboot the phone.
4. Reproduce the issue (e.g., account registration).

- Click **Export** to open file download window, and then save the file to your local system.



A log file named **syslog.tar** is successfully exported to your local system.

To view the log file on your local system:

- Extract the combined log files to your local system.
- Open the folder you extracted to and identify the files you will view.

The following figure shows a portion of a <mac>.log (e.g., 0015659188F2.log) - an account registration:

```

Jul 22 00:37:23 sua [648]: DLG <6+info> > [000]
Jul 22 00:37:23 sua [648]: DLG <6+info> > [000] REGISTER sip:10.2.1.199:5060 SIP/2.0^M
Jul 22 00:37:23 sua [648]: DLG <6+info> > [000] Via: SIP/2.0/UDP 10.10.20.32:5060;branch=z9hG4bK2736062655^M
Jul 22 00:37:23 sua [648]: DLG <6+info> > [000] From: "10111" <sip:10111@10.2.1.199:5060>;tag=2387294866^M
Jul 22 00:37:23 sua [648]: DLG <6+info> > [000] To: "10111" <sip:10111@10.2.1.199:5060>^M
Jul 22 00:37:23 sua [648]: DLG <6+info> > [000] Call-ID: 0_1383324398@10.10.20.32^M
Jul 22 00:37:23 sua [648]: DLG <6+info> > [000] CSeq: 2 REGISTER^M
Jul 22 00:37:23 sua [648]: DLG <6+info> > [000] Contact: <sip:10111@10.10.20.32:5060>^M
Jul 22 00:37:23 sua [648]: DLG <6+info> > [000] Allow: INVITE, INFO, PRACK, ACK, BYE, CANCEL, OPTIONS, NOTIFY,
Jul 22 00:37:23 sua [648]: DLG <6+info> > [000] Max-Forwards: 70^M
Jul 22 00:37:23 sua [648]: DLG <6+info> > [000] User-Agent: Yealink SIP-T23G 44.80.0.60^M
Jul 22 00:37:23 sua [648]: DLG <6+info> > [000] Expires: 0^M
Jul 22 00:37:23 sua [648]: DLG <6+info> > [000] Allow-Events: talk,hold,conference,REFER,check-sync^M
Jul 22 00:37:23 sua [648]: DLG <6+info> > [000] Content-Length: 0^M
Jul 22 00:37:23 sua [648]: DLG <6+info> > [000] ^M
Jul 22 00:37:23 sua [648]: DLG <6+info> > [000]
Jul 22 00:37:23 sua [648]: NET <5+notice> [000] =====> UDP socket 10.2.1.199:5060: send 557 bytes
Jul 22 00:37:23 sua [648]: FSM <6+info> > [000] free transaction resource 1 0_1383324398
Jul 22 00:37:23 sua [648]: FSM <6+info> > [255] free nict resource
Jul 22 00:37:23 sua [648]: FSM <6+info> > [004] free transaction resource 8 4_307169230
Jul 22 00:37:23 sua [648]: FSM <6+info> > [255] free nict resource
Jul 22 00:37:23 sua [648]: FSM <6+info> > [001] free transaction resource 2 1_1314965025
Jul 22 00:37:23 sua [648]: FSM <6+info> > [255] free nict resource
Jul 22 00:37:23 sua [648]: NET <5+notice> [255] <<<==== UDP socket 10.2.1.199:5060: read 307 bytes
Jul 22 00:37:23 sua [648]: SIP <6+info> > [SIP] match line:name:10111 host:10.2.1.199
Jul 22 00:37:23 sua [648]: DLG <5+notice> [000] Message rcv: (from src=10.2.1.199:5060 len=307)
Jul 22 00:37:23 sua [648]: DLG <6+info> > [000]
Jul 22 00:37:23 sua [648]: DLG <6+info> > [000] SIP/2.0 200 OK^M

```

Exporting the Log File to a Syslog Server

Procedure

Log setting can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	<p>Configure the syslog mode.</p> <p>Parameters:</p> <p>syslog.mode</p> <p>Configure the IP address or domain name of the syslog server where to export the log files.</p> <p>Parameters:</p> <p>syslog.server</p>
Local	Web User Interface	<p>Configure the syslog mode.</p> <p>Configure the IP address or domain name of the syslog server where to export the log files.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p>http://<phoneIPAddress>/servlet?mod_data&p=settings-config&q=load</p> <p>For SIP VP-T49G:</p> <p>http://<phoneIPAddress>/servlet?mod_data&p=settings-config&q=load</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
syslog.mode	0, 1 or 2	0
<p>Description:</p> <p>Configures the IP phone to export log files to the local system, syslog server or an FTP/TFTP Server (provisioning server).</p> <p>0-Local</p>		

Parameters	Permitted Values	Default
1-Server 2-FTP/TFTP Server Note: If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Settings->Configuration->Export System Log Phone User Interface: None		
syslog.server	IP address or domain name	Blank
Description: Configures the IP address or domain name of the syslog server when exporting log to the syslog server. Example: syslog.server = 192.168.1.100 Note: It works only if the value of the parameter "syslog.mode" is set to 1 (Server). If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Settings->Configuration->Server Name Phone User Interface: None		

To configure the phone to export the system log to a syslog server via web user interface:

1. Click on **Settings->Configuration**.
2. Mark the **Server** radio box in the **Export System Log** field.
3. Enter the IP address or domain name of the syslog server in the **Server Name** field.

For example, the IP address of your syslog server is 192.168.1.100.

The screenshot shows the Yealink T236 web interface with the 'Settings' tab selected. The 'Export System Log' section is highlighted with a red box. It contains three radio buttons: 'Local', 'Server' (selected), and 'Ftp/Tftp Server'. Below this is a text field for 'Server Name' with the value '192.168.1.100'. Other settings visible include 'Export or Import Configuration' with 'Browse...' and 'Import' buttons; 'Export CFG Configuration File' with a dropdown set to 'Local Configuration' and an 'Export' button; 'Import CFG Configuration File' with 'Browse...' and 'Import' buttons; 'Pcap Feature' with 'Start', 'Stop', and 'Export' buttons; 'System Log Level' set to '6'; and 'Export All Diagnostic Files' with 'Start', 'Stop', and 'Export' buttons. At the bottom are 'Confirm' and 'Cancel' buttons. A 'NOTE' box on the right states: 'Configuration: IP phones can provide feedback in a variety of forms such as log files, packets, status indicators and so on, which can help an administrator more easily find the system problem and fix it. Log Files, Capturing Packets, Configuration File (*.cfg/*.bin). You can click here to get more guides.'

4. Click **Confirm** to accept the change.

A dialog box pops up to prompt "Warning: Some settings you changed take effect when you restart your machine! Do you want to reboot now?". The configuration will take effect after a reboot.

5. Click **OK** to reboot the phone.

The system log will be exported successfully to the desired syslog server (192.168.1.100) after a reboot.

6. Reproduce the issue.

To view the log file on your syslog server:

You can view the system log file in the desired folder on the syslog server. The location of the folder may differ from the syslog server. For more information, refer to the network resources.

The following figure shows a portion of the system log:

```
Aug 27 09:24:03 10.10.20.39 [000] Register: start...
Aug 27 09:24:03 10.10.20.39 [SIP] linestatus lid:0, enable=1, tick=0, old_status:1, new_status:1
Aug 27 09:24:03 10.10.20.39 [SIP] <IPC_p2my>:msg=0x00042103(270595), wparam=0, lparam=0
Aug 27 09:24:03 10.10.20.39 [SIP] <IPC_broa>:msg=0x00040001(262145), wparam=0, lparam=1
Aug 27 09:24:03 10.10.20.39 [000] core get contact nat type:0
Aug 27 09:24:03 10.10.20.39 [000] core get contact nat type:0
Aug 27 09:24:03 10.10.20.39 [000] allocating transaction resource 37 0_1057687278
Aug 27 09:24:03 10.10.20.39 [000] allocating NICT context
Aug 27 09:24:03 10.10.20.39 Line State Change AccountId:0, State:1
Aug 27 09:24:03 10.10.20.39 EtlMsgHandler NotifyApp ACCOUNT_STATUS_CHANGED(0, 4, 1)!
Aug 27 09:24:03 10.10.20.39 Aug 27 01:24:01 ipv[520]: IPV[5+notice] 641.725.333:Message=0x00040001(0x000000
Aug 27 09:24:03 10.10.20.39 Aug 27 01:24:01 ipv[520]: IPV[6+info] 641.728.924:unknown msg,0x00040001,fr
Aug 27 09:24:03 10.10.20.39 [000] Message sent: (to dest=10.2.1.48:5060 len=545)
Aug 27 09:24:03 10.10.20.39 [000]
Aug 27 09:24:03 10.10.20.39 [000] REGISTER sip:10.2.1.48:5060 SIP/2.0
Aug 27 09:24:03 10.10.20.39 [000] Via: SIP/2.0/UDP 10.10.20.39:5060;branch=z9hG4bK951979898
Aug 27 09:24:03 10.10.20.39 [000] From: "1012" <sip:1012@10.2.1.48:5060>;tag=2152532079
Aug 27 09:24:03 10.10.20.39 [000] To: "1012" <sip:1012@10.2.1.48:5060>
Aug 27 09:24:03 10.10.20.39 [000] Call-ID: 0_1057687278@10.10.20.39
Aug 27 09:24:03 10.10.20.39 [000] CSeq: 1 REGISTER
Aug 27 09:24:03 10.10.20.39 [000] Contact: <sip:1012@10.10.20.39:5060>
Aug 27 09:24:03 10.10.20.39 [000] Register: get expires:3600
Aug 27 09:24:03 10.10.20.39 [SIP] <IPC_broa>:msg=0x00040001(262145), wparam=0, lparam=2
Aug 27 09:24:03 10.10.20.39 [000] Allow: INVITE, INFO, PRACK, ACK, BYE, CANCEL, OPTIONS, NOTIFY, REGISTER,
Aug 27 09:24:03 10.10.20.39 [255] <<<<== UDP socket 10.10.20.31:5060: read 681 bytes
Aug 27 09:24:03 10.10.20.39 [000] *****Core event:(0x0043)ECORE_SUBSCRIPTION_NOTIFY *****
Aug 27 09:24:03 10.10.20.39 [000] From: <sip:10111@10.2.1.48:5060>;tag=2198906946
Aug 27 09:24:03 10.10.20.39 OnConfigChangeMsg objMsg.message[262145],objMsg.wParam[0]
```

Exporting the Log File to a Provisioning Server (FTP/TFTP Server)

Procedure

Log setting can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the syslog mode. Parameters: syslog.mode
		Configure the period of the log upload (in seconds) to the provisioning server. Parameters: syslog.log_upload_period
		Configure whether the log files on the provisioning server are overwritten or appended. Parameters: syslog.ftp.post_mode
		Configure the maximum size of the log files on the provisioning server. Parameters: syslog.ftp.max_logfile

		<p>Configure the phone to stop log upload or delete the old log when the log on the provisioning server reaches the max size.</p> <p>Parameters:</p> <p>syslog.ftp.append_limit_mode</p>
		<p>Configure the waiting time before the phone uploads the log file to the provisioning server.</p> <p>Parameters:</p> <p>syslog.bootlog_upload_wait_time</p>
		<p>Configure the access URL of the provisioning server.</p> <p>Parameters:</p> <p>auto_provision.server.url</p>

Local	Web User Interface	<p>Configure the syslog mode.</p> <p>Configure the period of the log upload (in seconds) to the provisioning server.</p> <p>Configure whether the log files on the provisioning server are overwritten or appended.</p> <p>Configure the maximum size of the log files on the provisioning server.</p> <p>Configure the phone to stop log upload or delete the old log when the log on the provisioning server reaches the max size.</p> <p>Configure the waiting time before the phone uploads the log file to the provisioning server.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p><a href="http://<phoneIPAddress>/servlet?pn=mod_data&p=settings-config&q=load">http://<phoneIPAddress>/servlet?pn=mod_data&p=settings-config&q=load</p> <p>For SIP VP-T49G:</p> <p><a href="http://<phoneIPAddress>/servlet?pn=mod_data&p=settings-config&q=load">http://<phoneIPAddress>/servlet?pn=mod_data&p=settings-config&q=load</p>
		<p>Configure the access URL of the provisioning server.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860:</p> <p><a href="http://<phoneIPAddress>/servlet?pn=mod_data&p=settings-autop&q=load">http://<phoneIPAddress>/servlet?pn=mod_data&p=settings-autop&q=load</p> <p>For SIP VP-T49G:</p> <p><a href="http://<phoneIPAddress>/servlet?pn=mod_data&p=settings-autop&q=load">http://<phoneIPAddress>/servlet?pn=mod_data&p=settings-autop&q=load</p>

Details of Configuration Parameters:

Parameters	Permitted Values	Default
syslog.mode	0, 1 or 2	0
Description: Configures the IP phone to export log files to the local system, syslog server or an FTP/TFTP Server (provisioning server). 0 -Local 1 -Server 2 -FTP/TFTP Server Note: If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Settings->Configuration->Export System Log Phone User Interface: None		
syslog.log_upload_period	Integer from 30 to 2592000	30
Description: Configures the period of the log upload (in seconds) to the provisioning server. Example: syslog.log_upload_period = 60 Note: It works only if the value of the parameter "syslog.mode" is set to 2 (FTP/TFTP Server). If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Settings->Configuration->Upload Period(30~2592000)s Phone User Interface: None		
syslog.ftp.post_mode	1 or 2	1
Description: Configures whether the log files on the provisioning server are overwritten or appended. 1 -Post Append		

Parameters	Permitted Values	Default
2-Post Stor (not applicable to TFTP Server) If it is set to 1 (Post Append), the log files on the provisioning server are appended. If it is set to 2 (Post Stor), the log files on the provisioning server are overwritten. Note: It works only if the value of the parameter "syslog.mode" is set to 2 (FTP/TFTP Server). If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Settings->Configuration->Post Mode Phone User Interface: None		
syslog.ftp.max_logfile	Integer from 200 to 65535	512
Description: Configures the maximum size of the log files on the provisioning server. Example: syslog.ftp.max_logfile = 511 Note: It works only if the value of the parameter "syslog.mode" is set to 2 (FTP/TFTP Server). If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Settings->Configuration->Append Limit Size(200~65535)K Phone User Interface: None		
syslog.ftp.append_limit_mode	1 or 2	1
Description: Configures the phone to stop upload log or delete the old log when the log on the provisioning server reaches the max size. 1-Append Delete 2-Append Stop Note: It works only if the value of the parameter "syslog.mode" is set to 2 (FTP/TFTP Server). If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: Settings->Configuration->Append Limit Mode		

Parameters	Permitted Values	Default
Phone User Interface: None		
syslog.bootlog_upload_wait_time	Integer from 1 to 86400	120
Description: Configures the waiting time (in seconds) before the phone uploads the log file to the provisioning server. Example: syslog.bootlog_upload_wait_time = 121 Note: It works only if the value of the parameter "syslog.mode" is set to 2 (FTP/TFTP Server). If you change this parameter, the IP phone will reboot to make the change take effect. Web User Interface: None Phone User Interface: None		
auto_provision.server.url	URL within 511 characters	Blank
Description: Configures the access URL of the provisioning server. Example: auto_provision.server.url = tftp://10.3.6.133/ Web User Interface: Settings->Auto Provision->Server URL Phone User Interface: None		

To configure the URL of the provisioning server via web user interface:

1. Click on **Settings->Auto Provision**.
2. Enter the URL of the FTP/TFTP server in the **Server URL** field.

For example, if the IP address TFTP server is 192.168.1.100, then the URL "tftp://192.168.1.100/" is where the IP phone exports the system log. For more information on TFTP server, refer to [Yealink_SIP-T2 Series_T19\(P\) E2_T4 Series_CP860_W56P_IP_Phones_Auto_Provisioning_Guide](#).

The screenshot shows the Yealink T236 web interface. The 'Settings' tab is selected, and the 'Auto Provision' sub-tab is active. The 'Server URL' field is highlighted with a red box, and a callout bubble points to it with the text: "Enter the access URL of the provisioning server in the Server URL field." The 'Auto Provision' section includes fields for PIP Active, DHCP Active, Custom Option, DHCP Option Value, User Name, Password, Attempt Expired Time, Common AES Key, MAC-Oriented AES Key, Zero Active, Wait Time, Power On, Repeatedly, Interval, Weekly, Time, and Day of Week. A 'NOTE' section on the right explains the auto provisioning process.

3. Click **Confirm** to accept the change.

To configure the phone to export the system log to an FTP/TFTP server via web user interface:

1. Click on **Settings->Configuration**.
2. Mark the **Ftp/Tftp server** radio box in the **Export System Log** field.
3. Enter the upload period of the log files in the **Upload Period (30~2592000)s** field.
4. Select the desired post mode from the pull-down list of **Post Mode**.
5. Enter the limit size of the log files in the **Append Limit Size (200~65535)K** field.

- Select the desired limit mode from the pull-down list of **Append Limit Mode**.

The screenshot shows the Yealink T236 web interface. The 'Settings' tab is active, and the 'Configuration' section is expanded. Within the 'Export System Log' section, the 'Ftp/Tftp Server' radio button is selected. A red box highlights the following settings:

- Export System Log: ☒ Local ☐ Server ☒ Ftp/Tftp Server
- Upload Period(30~2592000)s: 30
- Post Mode: Post Append
- Append Limit Size(200~65535)K: 512
- Append Limit Mode: Append Delete

- Click **Confirm** to accept the change.

A dialog box pops up to prompt "Warning: Some settings you changed take effect when you restart your machine! Do you want to reboot now?". The configuration will take effect after a reboot.

- Click **OK** to reboot the phone.

The system log will be exported successfully to the desired FTP/TFTP server after a reboot.

- Reproduce the issue.

To view the log file on your FTP/TFTP server:


You can view the system log file in the root directory folder you have configured on the FTP/TFTP server.

The following figure shows a portion of a <mac>-boot.log (e.g., 0015659188f2-boot.log):

```

Jul 22 02:11:36 sua [641]: SIP <6+info> > [SIP] match line:name:101 host:10.2.1.43
Jul 22 02:11:36 sua [641]: DLG <5+notice> [001] Message rcv: (from src=10.2.1.43:5060 len=470)
Jul 22 02:11:36 sua [641]: DLG <6+info> > [001]
Jul 22 02:11:36 sua [641]: DLG <6+info> > [001] SIP/2.0 200 OK^M
Jul 22 02:11:36 sua [641]: DLG <6+info> > [001] Via: SIP/2.0/UDP 10.10.20.32:5060;branch=z9hG4bK1171808243^M
Jul 22 02:11:36 sua [641]: DLG <6+info> > [001] Contact: <sip:101@10.10.20.32:5060>;expires=1800^M
Jul 22 02:11:36 sua [641]: DLG <6+info> > [001] Contact: <sip:101@10.10.20.35:5065>;expires=8400^M
Jul 22 02:11:36 sua [641]: DLG <6+info> > [001] Contact: <sip:101@10.3.19.158:5060;line=a11212c315d0011>;expires=1223^M
Jul 22 02:11:36 sua [641]: DLG <6+info> > [001] To: "101"<sip:101@10.2.1.43:5060>;tag=b815982a^M
Jul 22 02:11:36 sua [641]: DLG <6+info> > [001] From: "101"<sip:101@10.2.1.43:5060>;tag=708126600^M
Jul 22 02:11:36 sua [641]: DLG <6+info> > [001] Call-ID: 1_3847383156@10.10.20.32^M
Jul 22 02:11:36 sua [641]: DLG <6+info> > [001] CSeq: 2 REGISTER^M
Jul 22 02:11:36 sua [641]: DLG <6+info> > [001] User-Agent: 3CXPhoneSystem 12.0.41311.996 (34969)^M
Jul 22 02:11:36 sua [641]: DLG <6+info> > [001] Content-Length: 0^M
Jul 22 02:11:36 sua [641]: DLG <6+info> > [001] ^M
Jul 22 02:11:36 sua [641]: DLG <6+info> > [001]
Jul 22 02:11:36 sua [641]: DLG <6+info> > [255] <<<<== UDP socket 10.2.1.43:5060: read 639 bytes
Jul 22 02:11:36 sua [641]: NET <5+notice> [SIP] match line:name:101 host:10.10.20.32
Jul 22 02:11:36 sua [641]: SIP <6+info> > [001] Message rcv: (from src=10.2.1.43:5060 len=639)
Jul 22 02:11:36 sua [641]: DLG <6+info> > [001]
Jul 22 02:11:36 sua [641]: DLG <6+info> > [001] NOTIFY sip:101@10.10.20.32:5060 SIP/2.0^M
Jul 22 02:11:36 sua [641]: SUA <6+info> > [001] ****eCore event:(0x0001)ECORE_REGISTRATION_SUCCESS ****
Jul 22 02:11:36 sua [641]: REG <6+info> > [001] Register: get expires:1800
Jul 22 02:11:36 sua [641]: REG <6+info> > [001] Register: update server0 period to 1800
Jul 22 02:11:36 sua [641]: REG <5+notice> [001] Register: current register success, server id=0
Jul 22 02:11:36 sua [641]: APP <5+notice> [SIP] linestatus lid:1, enable=1, tick=0, old_status:1, new_status:2
Jul 22 02:11:36 sua [641]: APP <6+info> > [SIP] <IPC_p2my>;msg=0x00042103(270595), wparam=1, lparam=0
Jul 22 02:11:36 sua [641]: APP <6+info> > [SIP] <IPC_broa>;msg=0x00040001(262145), wparam=1, lparam=2
  
```

The following figure shows a portion of a <mac>-sys.log (e.g., 0015659188f2-sys.log):



```

Jul 22 02:14:31 sua [641]: FSM <6+info > [000] allocating NICT context
Jul 22 02:14:31 sua [641]: DLG <5+notice> [000] Message sent: (to dest=10.2.1.199:5060 len=557)
Jul 22 02:14:31 sua [641]: DLG <6+info > [000] REGISTER sip:10.2.1.199:5060 SIP/2.0^M
Jul 22 02:14:31 sua [641]: DLG <6+info > [000] Via: SIP/2.0/UDP 10.10.20.32:5060;branch=z9hG4bK3415956455^M
Jul 22 02:14:31 sua [641]: DLG <6+info > [000] From: "10111" <sip:10111@10.2.1.199:5060>;tag=3309866322^M
Jul 22 02:14:31 sua [641]: DLG <6+info > [000] To: "10111" <sip:10111@10.2.1.199:5060>^M
Jul 22 02:14:31 sua [641]: DLG <6+info > [000] Call-ID: 0 2045832538@10.10.20.32^M
Jul 22 02:14:31 sua [641]: DLG <6+info > [000] CSeq: 2 REGISTER^M
Jul 22 02:14:31 sua [641]: DLG <6+info > [000] Contact: <sip:10111@10.10.20.32:5060>^M
Jul 22 02:14:31 sua [641]: DLG <6+info > [000] Allow: INVITE, INFO, PRACK, ACK, BYE, CANCEL, OPTIONS, NOTIFY, REGISTER,
Jul 22 02:14:31 sua [641]: DLG <6+info > [000] Max-Forwards: 70^M
Jul 22 02:14:31 sua [641]: DLG <6+info > [000] User-Agent: Yealink SIP-T23G 44.80.0.60^M
Jul 22 02:14:31 sua [641]: DLG <6+info > [000] Expires: 0^M
Jul 22 02:14:31 sua [641]: DLG <6+info > [000] Allow-Events: talk,hold,conference,refer,check-sync^M
Jul 22 02:14:31 sua [641]: DLG <6+info > [000] Content-Length: 0^M
Jul 22 02:14:31 sua [641]: DLG <6+info > [000] ^M
Jul 22 02:14:31 sua [641]: NET <5+notice> [000] ==>>>> UDP socket 10.2.1.199:5060: send 557 bytes
Jul 22 02:14:31 sua [641]: FSM <6+info > [000] free transaction resource 12 0_2045832538
Jul 22 02:14:31 sua [641]: FSM <6+info > [255] free nict resource
Jul 22 02:14:31 sua [641]: NET <5+notice> [255] <<<== UDP socket 10.2.1.199:5060: read 308 bytes
Jul 22 02:14:31 sua [641]: SIP <6+info > [81P] match line:name:10111 host:10.2.1.199
Jul 22 02:14:31 sua [641]: DLG <5+notice> [000] Message rcv: (from src=10.2.1.199:5060 len=308)
Jul 22 02:14:31 sua [641]: DLG <6+info > [000]
Jul 22 02:14:31 sua [641]: DLG <6+info > [000] SIP/2.0 200 OK^M
Jul 22 02:14:31 sua [641]: DLG <6+info > [000] To: "10111" <sip:10111@10.2.1.199:5060>;tag=31974^M
Jul 22 02:14:31 sua [641]: DLG <6+info > [000] From: "10111" <sip:10111@10.2.1.199:5060>;tag=3309866322^M

```

Capturing Packets

You can capture packet in two ways: capturing the packets via web user interface or using the Ethernet software. You can analyze the packet captured for troubleshooting purpose.

Capturing the Packets via Web User Interface

For Yealink IP phones, you can export the packets file to the local system and analyze it.

If you capture the packets for SIP VP-T49G IP phones, you can configure the maximum size and the filter type of the packets.

Procedure

Pcap feature can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure Pcap feature. Parameter: packet_capture.max_file_counts packet_capture.max_file_bytes packet_capture.filter_type packet_capture.filter
Local	Web User Interface	Configure Pcap feature. Navigate to: http://<phoneIPAddress>/servlet ?m=mod_data&p=settings-confi g&q=load

Details of the Configuration Parameter:


Parameter	Permitted Values	Default
packet_capture.max_file_counts	Integer from 1 to 100	15
Description: Configures the count of the number of packets to capture. Note: It is only applicable to SIP VP-T49G IP phones. Web User Interface: Settings->Configuration->Packet Capture Count Phone User Interface: None		
packet_capture.max_file_bytes	Integer from 100 to 1024	1024
Description: Configures the number of bytes (in KB) of the packet to capture. Note: It is only applicable to SIP VP-T49G IP phones. Web User Interface: Settings->Configuration->Packet Capture Clip Bytes Phone User Interface: None		
packet_capture.filter_type	0, 1 or 2	0
Description: Configures the filter type of the packet to capture. 0 -Custom-Customize the packet filter string. 1 -SIP or H245 or H225-Capture SIP, H245 and H225 packets. 2 -RTP-Capture RTP packets. Note: It is only applicable to SIP VP-T49G IP phones. Web User Interface: Settings->Configuration->Pcap Filter Type Phone User Interface: None		
packet_capture.filter	String within 255 characters	Blank
Description:		

Parameter	Permitted Values	Default
<p>Customizes the packet filter string.</p> <p>If it is left blank, the IP phone will not automatically filter any string when capturing packets.</p> <p>Syntax:</p> <p>Protocol+Direction+Host(s)+ Value +Logical Operations+Other Expression</p> <p>Protocol:</p> <p>Values: ether, fddi, ip, arp, rarp, decnet, lat, sca, moprc, mopdl, tcp and udp.</p> <p>Application-level protocol, such as http, dns and sip are not supported.</p> <p>If no protocol is specified, all the protocols are used.</p> <p>Direction:</p> <p>Values: src, dst, src and dst, src or dst</p> <p>If no source or destination is specified, the "src or dst" keywords are applied.</p> <p>For example: "host 10.2.2.2" is equivalent to "src or dst host 10.2.2.2".</p> <p>Host(s):</p> <p>Values: net, port, host, portrange.</p> <p>If no host(s) is specified, the "host" keyword is used.</p> <p>For example: "src 10.1.1.1" is equivalent to "src host 10.1.1.1".</p> <p>Logical Operations:</p> <p>Values: not, and, or.</p> <p>Negation ("not") has highest precedence. Alternation ("or") and concatenation ("and") have equal precedence and associate left to right.</p> <p>For example:</p> <p>"not tcp port 3128 and tcp port 23" is equivalent to "(not tcp port 3128) and tcp port 23".</p> <p>"not tcp port 3128 and tcp port 23" is NOT equivalent to "not (tcp port 3128 and tcp port 23)".</p> <p>Example: (src host 10.4.1.12 or src net 10.6.0.0/16) and tcp dst port range 200-10000 and dst net 10.0.0.0/8</p> <p>Displays packets with source IP address 10.4.1.12 or source network 10.6.0.0/16, the result is then concatenated with packets having destination TCP port range from 200 to 10000 and destination IP network 10.0.0.0/8.</p> <p>Note: It works only if the value of the parameter "packet_capture.filter_type" is set to 0 (Custom). It is only applicable to SIP VP-T49G IP phones.</p> <p>Web User Interface:</p> <p>Settings->Configuration->Packet Filter String</p> <p>Phone User Interface:</p>		

Parameter	Permitted Values	Default
None		

To capture packets via web user interface (take SIP-T23G IP phones for example):

1. Click on **Settings->Configuration**.
2. Click **Start** to start capturing signal traffic.
3. Reproduce the issue to get stack traces.
4. Click **Stop** to stop capturing.
5. Click **Export** to open the file download window, and then save the file to your local system.



To capture packets via web user interface (take SIP VP-T49G IP phones for example):

1. Click on **Settings->Configuration**.
2. Enter the desired value in the **Packet Capture Count** field.
3. Enter the desired value in the **Packet Capture Clip Bytes** field.
4. Select the desired value from the pull-down list of **Pcap Filter Type**.
If **Custom** is selected, enter the desired packet filter string in the **Packet Filter String** field.
5. Enter the desired value in the **Packet Filter String** field.
6. Click **Start** to start capturing signal traffic.
7. Reproduce the issue to get stack traces.
8. Click **Stop** to stop capturing.

- Click **Export** to open the file download window, and then save the file to your local system.

Capturing the Packets Using the Ethernet Software

Receiving data packets from the HUB

Connect the Internet port of the IP phone and the PC to the same HUB, and then use Sniffer, Ethereal or Wireshark software to capture the signal traffic.

Receiving data packets from PC port

Connect the Internet port of the IP phone to the Internet and the PC port of the IP phone to a PC. Before capturing the signal traffic, make sure the data packets can be received from the WAN (Internet) port to the PC (LAN) port. It is not applicable to CP860 IP phones.

Procedure

Span to PC port can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure span to PC Port. Parameter: network.span_to_pc_port
Local	Web User Interface	Configure span to PC Port. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T 29G/T27P/T23P/T23G/T21(P)

		E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet ?p=network-adv&q=load For SIP VP-T49G: http://<phoneIPAddress>/servl et?m=mod_data&p=network-a dv&q=load
--	--	--

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
network.span_to_pc_port	0 or 1	0
<p>Description: Enables or disables the IP phone to span data packets received from the WAN (Internet) port to the PC (LAN) port.</p> <p>0-Disabled 1-Enabled</p> <p>If it is set to 1 (Enabled), all data packets from WAN port can be received by PC port.</p> <p>Note: It is not applicable to CP860 IP phones. It works only if the value of the parameter "network.pc_port.enable" is set to 1 (Auto Negotiate). If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface: Network->Advanced->Span to PC->Span to PC Port</p> <p>Phone User Interface: None</p>		

To enable span to PC port via web user interface:

1. Click on **Network->Advanced**.

2. Select **Enabled** from the pull-down list of **Span to PC Port**.

The screenshot shows the Yealink T236 web interface with the 'Network' tab selected. The left sidebar has 'Basic', 'PC Port', and 'Advanced' options. The main content area is divided into sections: LLDP, CDP, Voice QoS, Local RTP Port, Span to PC, Registration Random, and VPN. The 'Span to PC' section is highlighted with a red box, showing a pull-down menu set to 'Enabled'. The right sidebar contains a 'NOTE' section with information about VLAN, NAT Traversal, Quality of Service (QoS), Web Server Type, and 802.1X Authentication.

3. Click **Confirm** to accept the change.

A dialog box pops up to prompt that settings will take effect after a reboot.

4. Click **OK** to reboot the phone.

Then you can use Sniffer, Ethereal or Wireshark software to capture the signal traffic.

Enabling Watch Dog Feature

The IP phone provides a troubleshooting feature called “Watch Dog”, which helps you monitor the IP phone status and provides the ability to get stack traces from the last time the IP phone failed. If Watch Dog feature is enabled, the IP phone will automatically reboot when it detects a fatal failure. This feature can be configured using the configuration files or via web user interface.

Procedure

Watch Dog can be configured using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure Watch Dog feature. Parameter: watch_dog.enable
Local	Web User Interface	Configure Watch Dog feature. Navigate to: For SIP-T48G/T46G/T42G/T41P/T40P/T 29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servle t?p=settings-preference&q=loa d For SIP VP-T49G: http://<phoneIPAddress>/servle t?m=mod_data&p=settings-pre ference&q=load

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
watch_dog.enable	0 or 1	1
Description: Enables or disables the Watch Dog feature. 0-Disabled 1-Enabled If it is set to 1 (Enabled), the IP phone will reboot automatically when the system is broken down. Web User Interface: Settings->Preference->WatchDog Phone User Interface: None		

To configure watch dog feature via web user interface:

1. Click on **Settings->Preference**.

2. Select the desired value from the pull-down list of **WatchDog**.


The screenshot shows the Yealink T23G web interface. The 'Settings' tab is selected. In the 'Settings' section, the 'WatchDog' option is highlighted with a red box, and its value is 'Enabled'. Other settings visible include Language (English), Live Dialpad (Disabled), Inter Digit Time (4), Backlight Time (30), Contrast (6), Ring Type (Ring1.wav), and an Upload Ringtone button. A 'Confirm' button is at the bottom. A 'NOTE' section on the right provides details for Language, Live Dialpad, Backlight, and Contrast.

3. Click **Confirm** to accept the change.

Getting Information from Status Indicators

Status indicators may consist of the power LED, MESSAGE key LED, line key indicator, headset key indicator and the on-screen icon.

The following shows two examples of obtaining the IP phone information from status indicators on SIP-T23G IP phones:

- If a LINK failure of the IP phone is detected, a prompting message “Network unavailable” and the icon  will appear on the LCD screen.
- If a voice mail is received, the MESSAGE key LED illuminates.

For more information on the icons, refer to [Reading Icons](#) on page 37.

Getting Information from Talk Statistics

Talk statistics may consist of the video and audio data during an active call.

You can view the talk statistics during an active call via web phone user interface.

Information includes:

- **Video:** Resolution, Codec, Bandwidth (Uplink Bandwidth and Downlink Bandwidth), Frame Rate, Jitter, Total Packet Lost, Packet Lost Rate
- **Audio:** Codec, Bandwidth (Uplink Bandwidth and Downlink Bandwidth), Sample Rate, Jitter, Total Packet Lost, Packet Lost Rate

The following shows the IP phone information when having an active call with 1000 (the phone number):

Type	Parameter	Recv(2006 kb/s)	Send(1511 kb/s)
Video	Resolution	1920 X 1080	1280 X 720
	Codec	H264	H264
	Bandwidth	1944 kb/s	1449 kb/s
	Frame Rate	30 fps	29 fps
	Jitter	16 ms	19 ms
	Total Packets Lost	0	56
	Packets Lost Rate	0%	2%
Audio	Codec	G722	G722
	Bandwidth	62 kb/s	62 kb/s
	Sample Rate	15 k	15 k
	Jitter	124 ms	3 ms
	Total Packets Lost	0	786444
	Packets Lost Rate	0%	0%

Analyzing Configuration File

Wrong configurations may have an impact on your phone use. You can export configuration file to check the current configuration of the IP phone and troubleshoot if necessary. You can also import configuration files for a quick and easy configuration.

Three types of configuration files can be exported to your local system:

- config.bin
- <mac>-all.cfg
- <mac>-local.cfg

We recommend you to edit the exported CFG file instead of the BIN file to change the phone's current settings if your phone is running firmware version 73 or later. For more information on configuration files, refer to [Configuration Files](#) on page 48.

BIN Configuration Files

The config.bin file is an encrypted file. For more information on config.bin file, contact your Yealink reseller.

Procedure

Configuration changes can be performed using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Specify the access URL for the custom configuration files. Parameter:
---------------------------	---------------------	---

		configuration.url
Local	Web User Interface	<p>Export or import the custom configuration files.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2/CP860: http://<phoneIPAddress>/servlet?p=settings-config&q=load</p> <p>For SIP VP-T49G: http://<phoneIPAddress>/servlet?m=mod_data&p=settings-config&q=load</p>


Details of the Configuration Parameter:

Parameter	Permitted Values	Default
configuration.url	URL within 511 characters	Blank
<p>Description: Configures the access URL for the custom configuration files.</p> <p>Note: The file format of custom configuration file must be *.bin.</p> <p>Web User Interface: Settings->Configuration->Export or Import Configuration</p> <p>Phone User Interface: None</p>		

To export BIN configuration files via web user interface:


1. Click on **Settings->Configuration**.

2. In the **Export or Import Configuration** block, click **Export** to open the file download window, and then save the file to your local system.



To import a BIN configuration file via web user interface:

1. Click on **Settings->Configuration**.
2. In the **Export or Import Configuration** block, click **Browse** to locate a BIN configuration file from your local system.



3. Click **Import** to import the configuration file.


CFG Configuration Files

The <mac>-all.cfg configuration file contains all changes made via phone user interface, web user interface and using configuration files. The <mac>-local.cfg configuration file contains changes made via phone user interface and web user

interface.


To export CFG configuration files via web user interface:

1. Click on **Settings->Configuration**.
2. Select **Local Configuration** or **All Configuration** from the pull-down list of **Export CFG Configuration File**.
3. Click **Export** to open file download window, and then save the file to your local system.



To import CFG configuration files via web user interface:

1. Click on **Settings->Configuration**.
2. In the **Import CFG Configuration File** block, click **Browse** to locate a CFG configuration file from your local system.




3. Click **Import** to import the configuration file.

Exporting All the Diagnostic Files

Yealink IP phones support three types of diagnostic files (including Pcap trace, log files and BIN configuration files) to help analyze your problem. You can export these files at a time and troubleshoot if necessary. The file format of exported diagnostic file is *.tar. It is not applicable to SIP VP-T49G and CP860 IP phones.

To export all diagnostic files via web user interface:

1. Click on **Settings->Configuration**.
2. Click **Start** to begin capturing signal traffic.
The system log level will be automatically set to 6.
3. Reproduce the issue.
4. Click **Stop** to stop the capture.
The system log level will be reset to 3.
5. Click **Export** to open file download window, and then save the diagnostic file to your local system.



A diagnostic file named **allconfig.tar** is successfully exported to your local system.

Note

If the issue cannot be reproduced, just directly click **Export** to export all diagnostic files.

To view the diagnostic files on your local system:

1. Extract the combined diagnostic files to your local system.
2. Open the folder you extracted to and identify the files you will view.

You can select to export the Pcap trace, log files and BIN configuration files respectively.

For more information, refer to [Capturing Packets](#) on page 886, [Viewing Log Files](#) on page 869 and [BIN Configuration Files](#) on page 895.

Troubleshooting Solutions

This section describes solutions to common issues that may occur while using the IP phone. Upon encountering a scenario not listed in this section, contact your Yealink reseller for further support.

IP Address Issues

Why doesn't the IP phone get an IP address?

Do one of the following:

If your phone connects to the wired network:

- Ensure that the Ethernet cable is plugged into the Internet port on the IP phone and the Ethernet cable is not loose.
- Ensure that the Ethernet cable is not damaged.
- Ensure that the IP address and related network parameters are set correctly.
- Ensure that your network switch or hub is operational.
- Ensure that the Wi-Fi feature is disabled.

If your phone connects to the wireless network:

- If the network is secure, ensure the entered password is right.
- Ensure your gateway/router enables the wireless network feature.

How to solve the IP conflict problem?

Do one of the following:

- Reset another available IP address for the IP phone.
- Check network configuration via phone user interface at the path **Menu->Advanced->Network->WAN Port->IPv4 (or IPv6)**. If the Static IP is selected, select DHCP instead.

Is there a specific format in configuring IPv6 on Yealink IP phones?

Scenario 1:

If the IP phone obtains the IPv6 address, the format of the URL to access the web user interface is "*[IPv6 address]*" or "*http(s)://[IPv6 address]*". For example, if the IPv6 address of your phone is "fe80::204:13ff:fe30:10e", you can enter the URL (e.g., "[fe80::204:13ff:fe30:10e]" or "http(s)://[fe80::204:13ff:fe30:10e]") in the address bar of a web browser on your PC to access the web user interface.

Scenario 2:

Yealink IP phones support using FTP, TFTP, HTTP and HTTPS protocols to download configuration files or resource files. You can use one of these protocols for provisioning.

When provisioning your IP phone obtaining an IPv6 address, the provisioning server should support IPv6 and the format of the access URL of the provisioning server can be "*tftp://[IPv6 address or domain name]*". For example, if the provisioning server address is "2001:250:1801::1", the access URL of the provisioning server can be "tftp://[2001:250:1801::1]". For more information on provisioning, refer to [Yealink_SIPT2 Series_T19\(P\) E2_T4 Series_CP860_W56P_IP_Phones_Auto_Provisioning_Guide](#).

Time and Date Issues

Why doesn't the IP phone display time and date correctly?

Check if the IP phone is configured to obtain the time and date from the NTP server automatically. If your phone is unable to access the NTP server, configure the time and date manually.

Display Issues

Why is the LCD screen blank?

Do one of the following:

- Ensure that the IP phone is properly plugged into a functional AC outlet.
- Ensure that the IP phone is plugged into a socket controlled by a switch that is on.
- If the IP phone is plugged into a power strip, try plugging it directly into a wall outlet.
- If your phone is PoE powered, ensure that you are using a PoE-compliant switch or hub.

- Check if the IP phone enters the power-saving mode. For more information, refer to [Power Saving](#) on page 124.

Why does the IP phone display “No Service”?

The LCD screen prompts “No Service” message when there is no available SIP account on the IP phone.

Do one of the following:

- Ensure that an account is actively registered on the IP phone at the path **Menu->Status->Accounts**.
- Ensure that the SIP account parameters have been configured correctly.

Phone Book Issues

What is the difference between a remote phone book and a local phone book?

A remote phone book is placed on a server, while a local phone book is placed on the IP phone flash. A remote phone book can be used by everyone that can access the server, while a local phone book can only be used by a specific phone. A remote phone book is always used as a central phone book for a company; each employee can load it to obtain the real-time data from the same server.

Audio Issues

How to increase or decrease the volume?

Press the volume key to increase or decrease the ringer volume when the IP phone is idle, or to adjust the volume of engaged audio device (handset, speakerphone or headset) when there is an active call in progress.

Why do I get poor sound quality during a call?

If you have poor sound quality/acoustics like intermittent voice, low volume, echo or other noises, the possible reasons could be:

- Users are seated too far out of recommended microphone range and sound faint, or are seated too close to sensitive microphones and cause echo.
- Intermittent voice is mainly caused by packet loss, due to network congestion, and

jitter, due to message recombination of transmission or receiving equipment (e.g., timeout handling, retransmission mechanism, buffer under run).

- Noisy equipment, such as a computer or a fan, may cause voice interference. Turn off any noisy equipment.
- Line issues can also cause this problem; disconnect the old line and redial the call to ensure another line may provide better connection.

Why is there no sound when the other party picks up the call?

If the caller and receiver cannot hear anything - there is no sound at all when the other party picks up the call, the possible reason could be: the phone cannot send the real-time transport protocol (RTP) streams, in which audio data is transmitted, to the connected call.

Try to disable the 180 ring workaround feature. For more information, refer to [180 Ring Workaround](#) on page [343](#).

Why does the IP phone play the local ringback tone instead of media when placing a long distance number without plus 0?

Ensure that the 180 ring workaround feature is disabled. For more information, refer to [180 Ring Workaround](#) on page [343](#).

Camera and Video Issues

Why is the video quality bad?

- Ensure that the display device has suitable resolution.
- Check whether the packet has been lost. For more information on packet loss, refer to [Getting Information from Talk Statistics](#) on page [894](#).
- Ensure that camera settings are configured correctly, such as brightness and white balance.
- Avoid high-intensity indoor light or direct sunlight on the camera.

Why is the camera indicator LED off?

- Ensure that the IP phone is powered off.
- Check if the camera is not properly connected to the phone.
- Make sure that the shutter switch of the camera is opened.

- Replace the camera.

Why can't I preview local camera when the phone is idle?

If the camera is properly connected to the IP phone but there are no images on the screen when you press the VIDEO key, you may need to replace the camera.

Why is there some dazzle light on the images when previewing the local camera?

If the camera lens is oily or soiled, there may be some dazzle light on the images. Please try to clean it up.

Why does the external monitor display the serrate or incomplete image?

- Ensure that the HDMI cable is plugged into the HDMI port on the IP phone and the HDMI cable is not loose.
- Ensure that the HDMI cable is not damaged.

Wi-Fi and Bluetooth Issues

Why is the wireless signal strength low?

Ensure the IP phone and your gateway/ router are within the working range and there is no obvious interference (walls, doors, etc.) between them.

Why can't I connect the IP phone to the 2.4G/5G wireless network?

If you successfully connect the IP phone to the 2.4G/5G wireless network, but the video images is not smooth. Or, you cannot connect the IP phone to the 2.4G/5G wireless network.

- Check if there are too many wireless devices connecting to the same 2.4G/5G wireless network.
- Verify whether the distance between IP phone and the wireless router is too far.

Why can't I connect the Bluetooth device with the IP phone all the time?

Try to delete the registration information of the Bluetooth device on both IP phone and

Bluetooth device, and then pair and connect it again. Contact Yealink field application engineer and your Bluetooth device manufacturer for more information.

Firmware and Upgrading Issues


Why doesn't the IP phone upgrade firmware successfully?

Do one of the following:

- Ensure that the target firmware is not the same as the current firmware.
- Ensure that the target firmware is applicable to the IP phone model.
- Ensure that the current or the target firmware is not protected.
- Ensure that the power is on and the network is available in the process of upgrading.
- Ensure that the web browser is not closed or refreshed when upgrading firmware via web user interface.

How can I verify the firmware generation and version of the phone?

Press the **OK/V** key when the IP phone is idle to check the firmware version. For example: 44.80.0.90.



	Item	Description
1	44	<p>Hardware version.</p> <p>The hardware version for each IP phone model is:</p> <p>51: SIP VPT49G</p> <p>35: SIP-T48G</p> <p>28: SIP-T46G</p> <p>29: SIP-T42G</p> <p>36: SIP-T41P</p>

	Item	Description
		54: SIP-T40P 46: SIP-T29G 45: SIP-T27P 44: SIP-T23P/G 52: SIP-T21(P) E2 53: SIP-T19(P) E2 37: CP860
2	80	Firmware generation. Note: The larger it is, the newer the firmware generation is.
3	0	A fixed number.
4	90	Firmware version. Note: With the same firmware generation, the larger it is, the newer the firmware version is.

Why doesn't the IP phone update the configuration?

Do one of the following:

- Ensure that the configuration is set correctly.
- Reboot the phone. Some configurations require a reboot to take effect.
- Ensure that the configuration is applicable to the IP phone model.
- The configuration may depend on support from a server.

Provisioning Issues

What is auto provisioning?

Auto provisioning refers to the update of IP phones, including update on configuration parameters, local phone book, firmware and so on. You can use auto provisioning on a single phone, but it makes more sense in mass deployment.

What is PnP?

Plug and Play (PnP) is a method for IP phones to acquire the provisioning server address. With PnP enabled, the IP phone broadcasts the PnP SUBSCRIBE message to obtain a provisioning server address during startup. Any SIP server recognizing the message will

respond with the preconfigured provisioning server address, so the IP phone will be able to download the CFG files from the provisioning server. PnP depends on support from a SIP server.

System Log Issues

Why can't I export the system log to a provisioning server (FTP/TFTP server)?

Do one of the following:

- Ensure that the FTP/TFTP server is downloaded and installed on your local system.
- Ensure that you have configured the FTP/TFTP server address correctly via web user interface on your IP phone.
- Reboot the phone. The configurations require a reboot to take effect.

Why can't I export the system log to a syslog server?

Do one of the following:

- Ensure that the syslog server supports saving the syslog files exported from IP phone.
- Ensure that you have configured the syslog server address correctly via web user interface on your IP phone.
- Reboot the phone. The configurations require a reboot to take effect.

Resetting Issues

Generally, some common issues may occur while using the IP phone. You can reset your phone to factory configurations after you have tried all troubleshooting suggestions but do not solve the problem. Resetting the phone to factory configurations clears the flash parameters, removes log files, user data, and cached data, and resets the administrator password to admin. All custom settings will be overwritten after resetting. You can reset the IP phone to default factory configurations. The default factory configurations are the settings that reside on the IP phone after it has left the factory. For more information, refer to [How to reset the IP phone to default factory configurations?](#) on page 908.

You can also reset the IP phone to custom factory configurations if required. The custom factory configurations are the settings that defined by the user to keep some custom settings after resetting. You have to import the custom factory configuration files in


advance. For more information, refer to [How to reset the IP phone to custom factory configurations?](#) on page 908.

How to reset the IP phone to default factory configurations?

To reset the IP phone via web user interface:

1. Click on **Settings->Upgrade**.
2. Click **Reset to Factory Setting** in the **Reset to Factory Setting** field.

The web user interface prompts the message "Do you want to reset to factory?".



3. Click **OK** to confirm the resetting.

The IP phone will be reset to factory successfully after startup.

Note

Reset of your phone may take a few minutes. Do not power off until the phone starts up successfully.

How to reset the IP phone to custom factory configurations?

Procedure

Configuration changes can be performed using the configuration files or locally.

Configuration File	<y0000000000xx>.cfg	Configure the Import Factory Configuration feature. Parameters: features.custom_factory_config.enable
		Configure the access URL of the custom factory configuration files. Parameters: custom_factory_configuration.url
Local	Web User Interface	Configure the access URL of the custom

		<p>factory configuration files.</p> <p>Navigate to:</p> <p>For SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/ T23P/T23G/T21(P) E2/T19(P) E2/CP860: <a href="http://<phoneIPAddress>/servlet?p=settings-config&q=load">http://<phoneIPAddress>/servlet?p=settings-config&q=load</p> <p>For SIP VP-T49G: <a href="http://<phoneIPAddress>/servlet?m=mod_data&p=settings-config&q=load">http://<phoneIPAddress>/servlet?m=mod_data&p=settings-config&q=load</p>
--	--	--


Details of Configuration Parameters:

Parameters	Permitted Values	Default
features.custom_factory_config.enable	0 or 1	0
<p>Description:</p> <p>Enables or disables the Import Factory Configuration feature.</p> <p>0-Disabled</p> <p>1-Enabled</p> <p>If it is set to 1 (Enabled), Import Factory Configuration item will be displayed on the IP phone's web user interface at the path Settings->Configuration. You can import a custom factory configuration file or delete the user-defined factory configuration via web user interface.</p> <p>Web User Interface:</p> <p>None</p> <p>Phone User Interface:</p> <p>None</p>		
custom_factory_configuration.url	URL within 511 characters	Blank
<p>Description:</p> <p>Configures the access URL of the custom factory configuration files.</p> <p>Note: It works only if the value of the parameter "features.custom_factory_config.enable" is set to 1 (Enabled) and the file format of custom factory configuration file must be *.bin. If you change this parameter, the IP phone will reboot to make the change take effect.</p> <p>Web User Interface:</p> <p>Settings->Configuration->Import Factory Configuration</p> <p>Phone User Interface:</p>		

Parameters	Permitted Values	Default
None		

To import the custom factory configuration files via web user interface:

1. Click on **Settings->Configuration**.
2. Click **Browse** to locate the custom factory configuration file from your local system.



3. Click **Import**.


When the custom factory configuration file is imported successfully, you can reset the IP phone to custom factory configurations. For more information on how to reset to factory configuration via web user interface, refer to [How to reset the IP phone to default factory configurations?](#) on page 908.

You can delete the user-defined factory configurations via web user interface.

To delete the custom factory configuration files via web user interface:

1. Click on **Settings->Configuration**.
2. Click **Del** in the **Import Factory Configuration** field.

The web user interface prompts the message “Are you sure delete user-defined factory configuration?”.



3. Click **OK** to delete the custom factory configuration files.

The imported custom factory file will be deleted. The IP phone will be reset to default factory configurations after resetting.

Rebooting Issues

How to reboot the IP phone remotely?

IP phones support remote reboot by a SIP NOTIFY message with “Event: check-sync” header. Whether the IP phone reboots or not depends on the value of the parameter “sip.notify_reboot_enable”. If the value is set to 1, or the value is set to 0 and the header of the SIP NOTIFY message contains an additional string “reboot=true”, the IP phone will reboot immediately.

The NOTIFY message is formed as shown:

```
NOTIFY sip:<user>@<dsthost> SIP/2.0
To: sip:<user>@<dsthost>
From: sip:sipsak@<srchost>
CSeq: 10 NOTIFY
Call-ID: 1234@<srchost>
Event: check-sync;reboot=true
```

Procedure

Changes can only be configured using the configuration files.

Configuration File	<y0000000000xx>.cfg	Configure the IP phone behavior when receiving a SIP NOTIFY message which contains the header "Event: check-sync". Parameter: sip.notify_reboot_enable
---------------------------	---------------------	---

Details of the Configuration Parameter:

Parameter	Permitted Values	Default
sip.notify_reboot_enable	0, 1 or 2	1
Description: Configure the IP phone behavior when receiving a SIP NOTIFY message which contains the header "Event: check-sync". 0- The IP phone will reboot only if the SIP NOTIFY message contains an additional string "reboot=true". 1- The IP phone will be forced to reboot. 2- The IP phone will ignore the SIP NOTIFY message. Web User Interface: None Phone User Interface: None		


How to reboot the IP phone via web/phone user interface?

You can reboot your IP phone via web/phone user interface.

To reboot the phone via phone user interface:

1. Press **Menu->Settings->Advanced Settings** (default password: admin) ->**Reboot**.

The LCD screen prompts the following warning:




2. Press the **OK** soft key to reboot the phone.

The phone begins rebooting. Any reboot of the phone may take a few minutes.

To reboot the phone via web user interface:

1. Click on **Settings->Upgrade**.
2. Click **Reboot** to reboot the IP phone.



The phone begins rebooting. Any reboot of the phone may take a few minutes.

Protocols and Ports Issues

What communication protocols and ports do Yealink IP phones support?

Source Device	Source IP	Source Port	Destination Device	Destination IP	Destination Port (Listening port)	Protocol	Description of destination port
IP phones	IP address of IP phones	2~65535	IP phone or voice gateway	IP address of IP phone or voice gateway	Determined by destination device.	UDP	RTP protocol port, it is used to send or receive audio stream.
		1024~65535	SIP Server	IP address of SIP server	Determined by destination device.	UDP/TCP	SIP protocol port, it is used for signaling interaction with SIP server.
		1024~65535	TR-069 Server	IP address of TR-069 server	Determined by destination device.	TCP	TR-069 protocol port, it is used to communicate with TR-069server.
		1024~65535	File server	IP address of file server	Determined by destination device.	TCP	HTTP protocol port, it is used to download file.
		1024~65535	Remote phone book server	IP address of remote phone book server	Determined by destination device.	TCP	HTTP protocol port, it is used to access the remote phone book.
		1024~65535	AA	IP address of AA	Determined by destination device.	TCP	HTTP protocol port, it is used for AA communication.

Source Device	Source IP	Source Port	Destination Device	Destination IP	Destination Port (Listening port)	Protocol	Description of destination port
		1024~65535	SNMP Server	IP address of SNMP server	Determined by destination device.	UDP	SNMP protocol port, it is used to communicate with SNMP server.
		68	DHCP Server	IP address of DHCP server	67	UDP	DHCP protocol port, it is used to obtain IP address from DHCP server.
		1024~65535	LDAP Server	IP address of LDAP server	Determined by destination device.	TCP	LDAP protocol port, it is used to obtain the contact information from LDAP server.
		1024~65535	NTP Server	IP address of NTP server	123	UDP	NTP protocol port, it is used to synchronize time from NTP time server.
		1024~65535	Syslog Server	IP address of syslog server	514	UDP	Syslog protocol port, it is used for IP phones to upload syslog information to syslog server.
		1024~65535	PNP Server	IP address of PNP server (Default value: 224.0.1.75)	5059	UDP/TCP	Protocol port, it is used to obtain the URL of updating file from PNP server.
			Multipaging	Multipaging	65000 65001		
PC	IP				1~65535	TCP	HTTP port (default value: 80)

Source Device	Source IP	Source Port	Destination Device	Destination IP	Destination Port (Listening port)	Protocol	Description of destination port
	address of PC	Determined by the destination device.	IP phones	IP address of IP phones	1~65535	TCP	HTTP port (default value: 443)
SIP Server	IP address of SIP Server				1024~65534	UDP/TCP	SIP protocol port, it is used for signaling interaction with SIP server.
IP phone of voice gateway	IP address of IP phone or voice gateway				2~65535	UDP	RTP protocol port, it is used by destination device to send or receive audio stream.
TR-069 Server	IP address of TR-069 Server				1024~65535	TCP	TR-069 protocol port, it is used to communicate with TR-069server.

Password Issues

How to restore the administrator password?

Factory reset can restore the original password. All custom settings will be overwritten after reset.

Logo Issues

Why does the IP phone use DOB format logo file instead of popular BMP, JPG and so on?

The IP phone only uses logo file in DOB format, as the DOB format file has a high compression ratio (the size of the uncompressed file compared to that of the compressed file) and can be stored in smaller space. Tools for converting BMP format to DOB format are available. For more information, refer to [Customizing a Logo Template File](#) on page 216.

Power and Startup Issues

What will happen if I connect both PoE cable and power adapter? Which has the higher priority?

IP phones use the PoE preferentially.

Why does the IP phone have no power?

If no lights appear on the IP phone when it is powered up, do one of the following:

- Reboot your IP phone.
- Replace the power adapter.

Why is the LCD screen black?

If the power indicator LED is on, the keypad is usable but the LCD screen is black, please reboot your IP phone.

Why does the IP phone always display the Yealink logo?

If your IP phone does not boot, check if the provisioning server is accessible on the network and a valid software firmware and valid configuration files are available. Try to use recovery mode to get your phone ready. For more information on recovery mode, refer to [Recovery Mode on Yealink IP phones](#).

Why can't IP phone supply power for device using USB port?

The USB port of Yealink IP phone has a limit current of 500 ~ 700mA. Make sure that the device is USB flash drive or mobile hard disk with low power.

Hardware Issues

Why is the sending/receiving volume of the speaker too low?

- If there is no volume sending from the speaker or sending volume is too low, the Hands-free MIC cable may not have been properly connected.
- If there is no volume receiving from the speaker or receiving volume is too low, the speaker cable may not have been properly connected.

Why is the sending/receiving volume of the headset or handset too low?

Ensure that the headset or handset is not damaged. If the headset or handset is usable, it may be the codec problem on the mainboard.

Why is there no response when pressing the keys on the keypad?

Do one of the following:

- Ensure that the keypad cables is properly connected and not damaged.
- Check if the keypad surface is clean.

Why is there no response when tapping the items on the touch screen?

Do one of the following:

- Ensure that the FPC of the touch screen is properly connected.
- Check if the touch screen is damaged.

Why is the LED off when pressing the hard key with LED indicator?

Make sure that the cable of keypad board is properly connected. If the cable is properly connected, it may be the LED on the board is damaged.

Other Issues

How do I find the basic information of the IP phone?

Tap **Menu->Status** when the IP phone is idle to check the basic information (e.g., IP address, MAC address and firmware version).

What is the difference among user name, register name and display name?

Both user name and register name are defined by the server. User name identifies the account, while register name matched with a password is for authentication purposes. Display name is the caller ID that will be displayed on the callee's phone LCD screen. Server configurations may override the local ones.

What do "on code" and "off code" mean?


They are codes that the IP phone sends to the server when a certain action takes place. On code is used to activate a feature on the server side, while off code is used to deactivate a feature on the server side.

For example, if you set the Always Forward on code to be *78 (may vary on different servers), and the target number to be 201. When you enable Always Forward on the IP phone, the IP phone sends *78201 to the server, and then the server will enable Always Forward feature on the server side, hence being able to get the right status of the extension.

For anonymous call/anonymous call rejection feature, the phone will send either the on code or off code to the server according to the value of Send Anonymous Code/Send Rejection Code. For more information, refer to [Anonymous Call](#) on page 314 and [Anonymous Call Rejection](#) on page 319.

What is the difference between enabling and disabling the RFC 2543 Hold feature?

Capturing packets after you enable the RFC 2543 Hold feature. SDP media direction attributes (such as a=sendonly) per RFC 2543 is used in the INVITE message when placing a call on hold.




No.	Time	Source	Destination	Protocol	Length	Info
54	2.018991	10.3.20.14	10.3.5.199	SIP/SDP	904	Request: INVITE sip:1021@10.3.5.199:5060, with session description
55	2.021424	10.3.5.199	10.3.20.14	SIP	314	Status: 100 Trying
56	2.034665	10.3.5.199	10.3.20.14	SIP	342	Status: 487 Request Cancelled
57	2.037965	10.3.20.14	10.3.5.199	SIP	305	Request: ACK sip:1010@10.3.5.199:5060
58	2.251601	10.3.5.199	10.3.20.14	SIP	547	Status: 180 Ringing
60	4.650231	10.3.5.199	10.3.20.14	SIP/SDP	746	Status: 200 OK, with session description
61	4.670808	10.3.20.14	10.3.20.4	SIP	405	Request: ACK sip:1021@10.3.20.4:5063
192	6.064543	10.3.5.199	10.3.20.14	SIP	342	Status: 487 Request Cancelled
193	6.067820	10.3.20.14	10.3.5.199	SIP	305	Request: ACK sip:1010@10.3.5.199:5060
263	6.733904	10.3.20.14	10.3.20.4	SIP/SDP	918	Request: INVITE sip:1021@10.3.20.4:5063, in-dialog, with session description
264	6.741532	10.3.20.4	10.3.20.14	SIP	336	Status: 100 Trying
267	6.790510	10.3.20.4	10.3.20.14	SIP/SDP	746	Status: 200 OK, with session description
269	6.803767	10.3.20.14	10.3.20.4	SIP	405	Request: ACK sip:1021@10.3.20.4:5063

Session Description Protocol

- Session Description Protocol Version (v): 0
- Owner/Creator, Session Id (o): - 20037 20038 IN IP4 10.3.20.14
- Session Name (s): SDP data
- Connection Information (c): IN IP4 10.3.20.14
- Time Description, active time (t): 0 0
- Media Description, name and address (m): audio 11854 RTP/AVP 18 9 0 8 101
- Media Attribute (a): rtpmap:18 G729/8000
- Media Attribute (a): fmp:18 annexb=no
- Media Attribute (a): rtpmap:9 G722/8000
- Media Attribute (a): rtpmap:0 PCMU/8000
- Media Attribute (a): rtpmap:8 PCMA/8000
- Media Attribute (a): rtpmap:101 telephone-event/8000
- Media Attribute (a): fmp:101 0-15
- Media Attribute (a): ptim:20
- Media Attribute (a): sendonly

Capturing packets after you disable the RFC 2543 Hold feature. SDP media connection address c=0.0.0.0 per RFC 3264 is used in the INVITE message when placing a call on hold.



No.	Time	Source	Destination	Protocol	Length	Info
56	3.074205	10.3.20.14	10.3.5.199	SIP/SDP	904	Request: INVITE sip:1021@10.3.5.199:5060, with session description
57	3.076752	10.3.5.199	10.3.20.14	SIP	314	Status: 100 Trying
59	3.328526	10.3.5.199	10.3.20.14	SIP	546	Status: 180 Ringing
60	5.121648	10.3.5.199	10.3.20.14	SIP/SDP	745	Status: 200 OK, with session description
61	5.141647	10.3.20.14	10.3.20.4	SIP	403	Request: ACK sip:1021@10.3.20.4:5063
85	5.463380	10.3.20.9	224.0.1.75	SIP	544	Request: SUBSCRIBE sip:MAC001565770984@224.0.1.75
182	6.429073	10.3.20.14	10.3.20.4	SIP/SDP	914	Request: INVITE sip:1021@10.3.20.4:5063, in-dialog, with session description
186	6.439904	10.3.20.4	10.3.20.14	SIP	335	Status: 100 Trying
187	6.482474	10.3.20.4	10.3.20.14	SIP/SDP	743	Status: 200 OK, with session description
189	6.496305	10.3.20.14	10.3.20.4	SIP	404	Request: ACK sip:1021@10.3.20.4:5063

Session Description Protocol

- Session Description Protocol Version (v): 0
- Owner/Creator, Session Id (o): - 20038 20039 IN IP4 10.3.20.14
- Session Name (s): SDP data
- Connection Information (c): IN IP4 0.0.0.0
- Connection Network Type: IN
- Connection Address Type: IP4
- Connection Address: 0.0.0.0
- Time Description, active time (t): 0 0
- Media Description, name and address (m): audio 11856 RTP/AVP 18 9 0 8 101
- Media Attribute (a): rtpmap:18 G729/8000
- Media Attribute (a): fmp:18 annexb=no
- Media Attribute (a): rtpmap:9 G722/8000
- Media Attribute (a): rtpmap:0 PCMU/8000
- Media Attribute (a): rtpmap:8 PCMA/8000
- Media Attribute (a): rtpmap:101 telephone-event/8000
- Media Attribute (a): fmp:101 0-15
- Media Attribute (a): ptim:20
- Media Attribute (a): inactive

For more information on RFC 2543 hold feature, refer to [Call Hold](#) on page 352. For more information on capturing packets, refer to [Capturing Packets](#) on page 886.

Appendix

Appendix A: Glossary

802.1x--an IEEE Standard for port-based Network Access Control (PNAC). It is a part of the IEEE 802.1 group of networking protocols. It provides an authentication mechanism to devices wishing to attach to a LAN or WLAN.

ACS (Auto Configuration server)--responsible for auto-configuration of the Central Processing Element (CPE).

Cryptographic Key--a piece of variable data that is fed as input into a cryptographic algorithm to perform operations such as encryption and decryption, or signing and verification.

DHCP (Dynamic Host Configuration Protocol)--built on a client-server model, where designated DHCP server hosts allocate network addresses and deliver configuration parameters to dynamically configured hosts.

DHCP Option--can be configured for specific values and enabled for assignment and distribution to DHCP clients based on server, scope, class or client-specific levels.

DNS (Domain Name System)--a hierarchical distributed naming system for computers, services, or any resource connected to the Internet or a private network.

EAP-MD5 (Extensible Authentication Protocol-Message Digest Algorithm 5)--only provides authentication of the EAP peer to the EAP server but not mutual authentication.

EAP-TLS (Extensible Authentication Protocol-Transport Layer Security) --provides for mutual authentication, integrity-protected cipher suite negotiation between two endpoints.

PEAP-MSCHAPv2 (Protected Extensible Authentication Protocol-Microsoft Challenge Handshake Authentication Protocol version 2) --provides for mutual authentication, but does not require a client certificate on the IP phone.

FAC (Feature Access Code)--special patterns of characters that are dialed from a phone keypad to invoke particular features.

HTTP (Hypertext Transfer Protocol)--used to request and transmit data on the World Wide Web.

HTTPS (Hypertext Transfer Protocol over Secure Socket Layer)--a widely-used communications protocol for secure communication over a network.

IEEE (Institute of Electrical and Electronics Engineers)--a non-profit professional association headquartered in New York City that is dedicated to advancing

technological innovation and excellence.

LAN (Local Area Network)--used to interconnects network devices in a limited area such as a home, school, computer laboratory, or office building.

MIB (Management Information Base)--a virtual database used for managing the entities in a communications network.

OID (Object Identifier)--assigned to an individual object within a MIB.

PnP (Plug and Play)--a term used to describe the characteristic of a computer bus, or device specification, which facilitates the discovery of a hardware component in a system, without the need for physical device configuration, or user intervention in resolving resource conflicts.

ROM (Read-only Memory)--a class of storage medium used in computers and other electronic devices.

RTP (Real-time Transport Protocol)--provides end-to-end service for real-time data.

TCP (Transmission Control Protocol)--a transport layer protocol used by applications that require guaranteed delivery.

UDP (User Datagram Protocol)--a protocol offers non-guaranteed datagram delivery.

URI (Uniform Resource Identifier)--a compact sequence of characters that identifies an abstract or physical resource.

URL (Uniform Resource Locator)--specifies the address of an Internet resource.

VLAN (Virtual LAN)-- a group of hosts with a common set of requirements, which communicate as if they were attached to the same broadcast domain, regardless of their physical location.

VoIP (Voice over Internet Protocol)--a family of technologies used for the delivery of voice communications and multimedia sessions over IP networks.

WLAN (Wireless Local Area Network)--a type of local area network that uses high-frequency radio waves rather than wires to communicate between nodes.

XML-RPC (Remote Procedure Call Protocol)--which uses XML to encode its calls and HTTP as a transport mechanism.

Appendix B: Time Zones

Time Zone	Time Zone Name
-11	Samoa
-10	United States-Hawaii-Aleutian, United States-Alaska-Aleutian
-9:30	French Polynesia
-9	United States-Alaska Time
-8	Canada(Vancouver,Whitehorse), Mexico(Tijuana,Mexicali), United States-Pacific Time
-7	Canada(Edmonton,Calgary), Mexico(Mazatlan,Chihuahua), United States-MST no DST, United States-Mountain Time
-6	Canada-Manitoba(Winnipeg), Chile(Easter Islands), Mexico(Mexico City,Acapulco), United States-Central Time
-5	Bahamas(Nassau), Canada(Montreal,Ottawa,Quebec), Cuba(Havana), United States-Eastern Time
-4:30	Venezuela(Caracas)
-4	Canada(Halifax,Saint John), Chile(Santiago), Paraguay(Asuncion), United Kingdom-Bermuda(Bermuda), United Kingdom(Falkland Islands), Trinidad&Tobago
-3:30	Canada-New Foundland(St.Johns)
-3	Argentina(Buenos Aires), Brazil(DST), Brazil(no DST), Denmark-Greenland(Nuuk)
-2:30	Newfoundland and Labrador
-2	Brazil(no DST)
-1	Portugal(Azores)
0	Denmark-Faroe Islands(Torshavn), GMT, Greenland, Ireland(Dublin), Morocco, Portugal(Lisboa,Porto,Funchal), Spain-Canary Islands(Las Palmas), United Kingdom(London)
+1	Albania(Tirane), Austria(Vienna), Belgium(Brussels), Caicos, Chad, Croatia(Zagreb), Czech Republic(Prague), Denmark(Kopenhagen), France(Paris), Germany(Berlin), Hungary(Budapest), Italy(Rome), Luxembourg(Luxembourg), Macedonia(Skopje), Namibia(Windhoek), Netherlands(Amsterdam), Spain(Madrid)
+2	Estonia(Tallinn), Finland(Helsinki), Gaza Strip(Gaza), Greece(Athens), Israel(Tel Aviv), Jordan(Amman), Latvia(Riga), Lebanon(Beirut), Moldova(Kishinev), Romania(Bucharest), Russia(Kaliningrad), Syria(Damascus), Turkey(Ankara), Ukraine(Kyiv, Odessa)
+3	East Africa Time, Iraq(Baghdad), Russia(Moscow)
+3:30	Iran(Teheran)
+4	Armenia(Yerevan), Azerbaijan(Baku), Georgia(Tbilisi), Kazakhstan(Aktau), Russia(Samara)

Time Zone	Time Zone Name
+4:30	Afghanistan(Kabul)
+5	Kazakhstan(Aqtobe), Kyrgyzstan(Bishkek), Pakistan(Islamabad), Russia(Chelyabinsk)
+5:30	India(Calcutta)
+5:45	Nepal(Katmandu)
+6	Kazakhstan(Astana, Almaty), Russia(Novosibirsk,Omsk)
+6:30	Myanmar(Naypyitaw)
+7	Russia(Krasnoyarsk), Thailand(Bangkok)
+8	Australia(Perth), China(Beijing), Russia(Irkutsk, Ulan-Ude), Singapore(Singapore)
+8:45	Eucla
+9	Japan(Tokyo), Korea(Seoul), Russia(Yakutsk,Chita)
+9:30	Australia(Adelaide), Australia(Darwin)
+10	Australia(Brisbane), Australia(Hobart), Australia(Sydney,Melbourne,Canberra), Russia(Vladivostok)
+10:30	Australia(Lord Howe Islands)
+11	New Caledonia(Noumea), Russia(Srednekolymsk Time)
+11:30	Norfolk Island
+12	New Zealand(Wellington,Auckland), Russia(Kamchatka Time)
+12:45	New Zealand(Chatham Islands)
+13	Tonga(Nukualofa)
+13:30	Chatham Islands
+14	Kiribati

Appendix C: Trusted Certificates

Yealink IP phones trust the following CAs by default:

- DigiCert High Assurance EV Root CA
- Deutsche Telekom AG Root CA-2
- Equifax Secure Certificate Authority
- Equifax Secure eBusiness CA-1
- Equifax Secure Global eBusiness CA-1
- GeoTrust Global CA
- GeoTrust Global CA2
- GeoTrust Primary CA
- GeoTrust Primary CA G2 ECC
- GeoTrust Universal CA
- GeoTrust Universal CA2
- Thawte Personal Freemail CA
- Thawte Premium Server CA

- Thawte Primary Root CA - G1 (EV)
- Thawte Primary Root CA - G2 (ECC)
- Thawte Primary Root CA - G3 (SHA256)
- Thawte Server CA
- VeriSign Class 1 Public Primary Certification Authority
- VeriSign Class 1 Public Primary Certification Authority - G2
- VeriSign Class 1 Public Primary Certification Authority - G3
- VeriSign Class 2 Public Primary Certification Authority - G2
- VeriSign Class 2 Public Primary Certification Authority - G3
- VeriSign Class 3 Public Primary Certification Authority
- VeriSign Class 3 Public Primary Certification Authority - G2
- VeriSign Class 3 Public Primary Certification Authority - G3
- VeriSign Class 3 Public Primary Certification Authority - G4
- VeriSign Class 3 Public Primary Certification Authority - G5
- VeriSign Class 4 Public Primary Certification Authority - G2
- VeriSign Class 4 Public Primary Certification Authority - G3
- VeriSign Universal Root Certification Authority
- ISRG Root X1 (intermediate certificates: Let's Encrypt Authority X1 and Let's Encrypt Authority X2 are signed by the root certificate ISRG Root X1.)
- Baltimore CyberTrust Root
- DST Root CA X3
- Version Public SureServer CA G14-SHA2

Note

Yealink endeavors to maintain a built-in list of most common used CA Certificates. Due to memory constraints, we cannot ensure a complete set of certificates. If you are using a certificate from a commercial Certificate Authority not in the list above, you can send a request to your local distributor. At this point, you can upload your particular CA certificate into your phone. For more information on uploading custom CA certificate, refer to [Transport Layer Security](#) on page 838.

ISRG Root X1, Let's Encrypt Authority X1 and Let's Encrypt Authority X2 certificates are only applicable to SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2 IP phones running firmware version X.80.0.95 or later.

Baltimore CyberTrust Root, DST Root CA X3 and Version Public SureServer CA G14-SHA2 certificates are only applicable to SIP-T48G/T46G/T42G/T41P/T40P/T29G/T27P/T23P/T23G/T21(P) E2/T19(P) E2 IP phones running firmware version X.80.0.130 or later.

Appendix D: Configuring DSS Key

This section provides the DSS key parameters you can configure on IP phones. DSS key consists of line key (line key is not applicable to SIP-T19(P) E2 and CP860 IP phones), programable key and ext key (ext key is only applicable to SIP-T48G/T46G/T29G/T27P IP phones).

The following table lists the number of DSS keys you can configure for each phone model:

Phone Model	Line Key	Programable Key	Ext Key
SIP VP-T49G	29	7	/
SIP-T48G	29	13	39
SIP-T46G	27	13	39
SIP-T42G	15	11	/
SIP-T41P	15	11	/
SIP-T40P	3	11	/
SIP-T29G	27	14	39
SIP-T27P	21	14	39
SIP-T23P/G	3	11	/
SIP-T21(P) E2	2	11	/
SIP-T19(P) E2	/	11	/
CP860	/	8	/

Note

The programable key takes effect only if the IP phone is idle.

The ext key takes effect only if the expansion module is connected to the IP phone.

The following tables list relationship between the values of X in the following parameters and programmable keys for each phone model.

X ranges from 1 to 14.

programmablekey.X.type =

programmablekey.X.line =

programmablekey.X.value =

programmablekey.X.xml_phonebook =

programmablekey.X.history_type =

programmablekey.X.pickup_value =

X ranges from 1 to 4.

programmablekey.X.label =

X Phone Model	SIP-T19(P) E2	SIP-T23P/T23G/ T21(P) E2	SIP-T29G/ T27P	SIP-T42G/ T41P/T40 P	SIP-T48G/ T46G	CP860	SIP VP-T49G
1	SoftKey1	SoftKey1	SoftKey1	SoftKey1	SoftKey1	SoftKey1	SoftKey1
2	SoftKey2	SoftKey2	SoftKey2	SoftKey2	SoftKey2	SoftKey2	SoftKey2
3	SoftKey3	SoftKey3	SoftKey3	SoftKey3	SoftKey3	SoftKey3	SoftKey3
4	SoftKey4	SoftKey4	SoftKey4	SoftKey4	SoftKey4	SoftKey4	SoftKey4
5	Up	Up	Up	Up	Up	Up	
6	Down	Down	Down	Down	Down	Down	
7	Left	Left	Left	Left	Left		

X Phone Model	SIP-T19(P) E2	SIP-T23P/T23G/ T21(P) E2	SIP-T29G/ T27P	SIP-T42G/ T41P/T40 P	SIP-T48G/ T46G	CP860	SIP VP-T49G
8	Right	Right	Right	Right	Right		
9	OK	OK	OK	OK	OK	OK	
10		Cancel	Cancel	Cancel	Cancel		
11			CONF				
12			Hold		Hold		Hold
13	Mute		Mute	Mute	Mute	Mute	Mute
14	TRAN	TRAN	TRAN		TRAN		TRAN

DSS key can be assigned with various key features. The parameters of the DSS key are detailed in the following:

Parameter linekey.X.type	Configuration File <y0000000000xx>.cfg
Parameter programablekey.X.type	
Parameter expansion_module.X.key.Y.type	
Description	<p>Configures key feature for the DSS key.</p> <p>For line keys (not applicable to SIP-T19(P) E2 IP phones and CP860 IP phones):</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For programable keys:</p> <p>X=1-4, 12-14 (for SIP VP-T49G)</p> <p>X=1-10, 12-14 (for SIP-T48G/T46G)</p> <p>X=1-10, 13 (for SIP-T42G/T41P/T40P)</p> <p>X=1-14 (for SIP-T29G/T27P)</p> <p>X=1-10, 14 (for SIP-T23P/T23G/T21(P) E2)</p> <p>X=1-9, 13, 14 (for SIP-T19(P) E2)</p> <p>X=1-6, 9, 13 (for CP860)</p> <p>For ext keys (only applicable to SIP-T48G/T46G/T29G/T27P IP phones):</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>For line keys:</p> <p>Valid types are:</p> <p>0-N/A</p> <p>1-Conference</p> <p>2-Forward</p>

	3-Transfer
	4-Hold
	5-DND
	7-ReCall
	8-SMS
	9-Direct Pickup
	10-Call Park
	11-DTMF
	12-Voice Mail
	13-Speed Dial
	14-Intercom
	15-Line
	16-BLF
	17-URL
	18-Group Listening
	20-Private Hold
	22-XML Group
	23-Group Pickup
	24-Multicast Paging
	25-Record
	27-XML Browser
	34-Hot Desking
	35-URL Record
	37-Switch
	38-LDAP
	39-BLF List
	40-Prefix
	41-Zero Touch
	42-ACD
	45-Local Group
	50-Phone Lock
	56-Retrieve Park (not applicable to SIP VP-T49G/CP860 IP phones)
	61-Directory
	66-Paging List
	77-Mobile Account (only applicable to SIP VP-T49G IP phones)

	<p>For programable keys:</p> <p>Valid types are:</p> <p>0-N/A</p> <p>2-Forward</p> <p>5-DND</p> <p>7-ReCall</p> <p>8-SMS</p> <p>9-Direct Pickup</p> <p>13-Speed Dial</p> <p>14-Intercom (only applicable to CP860 IP phones)</p> <p>22-XML Group</p> <p>23-Group Pickup</p> <p>24-Multicast Paging (only applicable to CP860 IP phones)</p> <p>27-XML Browser</p> <p>28-History</p> <p>30-Menu</p> <p>32-New SMS</p> <p>33-Status</p> <p>34-Hot Desking (only applicable to SIP VP-T49G/SIP-T48G/T46G/T29G/T19(P) E2 IP phones)</p> <p>38-LDAP (not applicable to SIP-T19(P) E2 IP phones)</p> <p>40-Prefix</p> <p>41-Zero Touch</p> <p>43-Local Directory</p> <p>45-Local Group</p> <p>47-XML Directory</p> <p>50-Phone Lock</p> <p>51-Switch Account Up (not applicable to SIP-T19(P) E2 and CP860 IP phones)</p> <p>52-Switch Account Down (not applicable to SIP-T19(P) E2 and CP860 IP phones)</p> <p>61-Directory</p> <p>66-Paging List</p> <p>77-Mobile Account (only applicable to SIP</p>
--	---

	<p>VP-T49G IP phones)</p> <p>For ext keys:</p> <p>Valid types are:</p> <p>0-NA</p> <p>1-Conference</p> <p>2-Forward</p> <p>3-Transfer</p> <p>4-Hold</p> <p>5-DND</p> <p>7-ReCall</p> <p>8-SMS</p> <p>9-Direct Pickup</p> <p>10-Call Park</p> <p>11-DTMF</p> <p>12-Voice Mail</p> <p>13-Speed Dial</p> <p>14-Intercom</p> <p>15-Line</p> <p>16-BLF</p> <p>17-URL</p> <p>18-Group Listening</p> <p>20-Private Hold</p> <p>22-XML Group</p> <p>23-Group Pickup</p> <p>24-Multicast Paging</p> <p>25-Record</p> <p>27-XML Browser</p> <p>34-Hot Desking</p> <p>35-URL Record</p> <p>37-Switch (only applicable to ext key 1)</p> <p>38-LDAP</p> <p>39-BLF List</p> <p>40-Prefix</p> <p>41-Zero Touch</p> <p>42-ACD</p> <p>45-Local Group</p> <p>50-Phone Lock</p>
--	---

	56 -Retrieve Park 61 -Directory 66 -Paging List
Format	Integer
Default Value	<p>For line keys:</p> <p>For SIP VPT49G/SIPT48G IP phones: The default value of the line key 1-16 is 15, and the default value of the line key 17-29 is 0.</p> <p>For SIP-T46G/T29G IP phones: The default value of the line key 1-16 is 15, and the default value of the line key 17-27 is 0.</p> <p>For SIP-T42G IP phones: The default value of the line key 1-12 is 15, and the default value of the line key 13-15 is 0.</p> <p>For SIP-T41P IP phones: The default value of the line key 1-6 is 15, and the default value of the line key 7-15 is 0.</p> <p>For SIP-T27P IP phones: The default value of the line key 1-6 is 15, and the default value of the line key 7-21 is 0.</p> <p>For SIP-T40P/T23P/T23G/T21(P) E2 IP phones: The default value is 15.</p> <p>For programmable keys:</p> <p>For SIP VPT49G IP phones: When X=1, the default value is 28 (History). When X=2, the default value is 61 (Directory). When X=3, the default value is 5 (DND). When X=4, the default value is 30 (Menu). When X=12, the default value is 0 (NA). When X=13, the default value is 0 (NA). When X=14, the default value is 2 (Forward).</p> <p>For SIP-T48G/T46G IP phones: When X=1, the default value is 28 (History). When X=2, the default value is 61 (Directory). When X=3, the default value is 5 (DND). When X=4, the default value is 30 (Menu). When X=5, the default value is 28 (History).</p>

	<p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIP-T42G/T41P/T40P IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>For SIP-T29G/T27P IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=11, the default value is 0 (NA).</p> <p>When X=12, the default value is 0 (NA).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIP-T23P/T23G/T21(P) E2 IP phones:</p> <p>When X=1, the default value is 28 (History).</p>
--	---

	<p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=10, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For SIP-T19(P) E2 IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=7, the default value is 0 (NA).</p> <p>When X=8, the default value is 0 (NA).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=13, the default value is 0 (NA).</p> <p>When X=14, the default value is 2 (Forward).</p> <p>For CP860 IP phones:</p> <p>When X=1, the default value is 28 (History).</p> <p>When X=2, the default value is 61 (Directory).</p> <p>When X=3, the default value is 5 (DND).</p> <p>When X=4, the default value is 30 (Menu).</p> <p>When X=5, the default value is 28 (History).</p> <p>When X=6, the default value is 61 (Directory).</p> <p>When X=9, the default value is 33 (Status).</p> <p>When X=13, the default value is 0 (NA).</p> <p>For ext keys:</p> <p>For SIP-T48G/T46G/T29G/T27P IP phones:</p> <p>The default value of the ext key 1, 21 is 37, and the default value of the ext key 2-20, 22-40 is 0.</p>
Range	<p>Valid values are:</p> <p>0-N/A</p>

	1-Conference
	2-Forward
	3-Transfer
	4-Hold
	5-DND
	7-ReCall
	8-SMS
	9-Direct Pickup
	10-Call Park
	11-DTMF
	12-Voice Mail
	13-Speed Dial
	14-Intercom
	15-Line
	16-BLF
	17-URL
	18-Group Listening
	20-Private Hold
	22-XML Group
	23-Group Pickup
	24-Multicast Paging
	25-Record
	27-XML Browser
	28-History
	30-Menu
	32-New SMS
	33-Status
	34-Hot Desking
	35-URL Record
	37-Switch
	38-LDAP
	39-BLF List
	40-Prefix
	41-Zero Touch
	42-ACD
	43-Local Directory
	45-Local Group

	47 -XML Directory 50 -Phone Lock 51 -Switch Account Up 52 -Switch Account Down 56 -Retrieve Park (not applicable to SIP VP-T49G/CP860 IP phones) 61 -Directory 66 -Paging List 77 -Mobile Account (only applicable to SIP VP-T49G IP phones)
Example	linekey.1.type = 8

Parameter- linekey.X.line	Configuration File <y0000000000xx>.cfg
Parameter- programablekey.X.line	
Parameter- expansion_module.X.key.Y.line	
Description	<p>Configures the desired line to apply the key feature. (not applicable to SIP-T19(P) E2 and CP860 IP phones)</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For programable keys:</p> <p>X=1-4, 12-14 (for SIP VP-T49G)</p> <p>X=1-10, 12-14 (for SIP-T48G/T46G)</p> <p>X=1-10, 13 (for SIP-T42G/T41P/T40P)</p> <p>X=1-14 (for SIP-T29G/T27P)</p> <p>X=1-10, 14 (for SIP-T23P/T23G/T21(P) E2)</p>

	<p>For ext keys (only applicable to SIP-T48G/T46G/T29G/T27P IP phones):</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>When assigning the following features, you do not need to configure this parameter:</p> <p>1-Conference</p> <p>2-Forward</p> <p>3-Transfer</p> <p>4-Hold</p> <p>5-DND</p> <p>7-ReCall</p> <p>8-SMS</p> <p>9-Direct Pickup</p> <p>11-DTMF</p> <p>17-URL</p> <p>18-Group Listening</p> <p>20-Private Hold</p> <p>22-XML Group</p> <p>24-Multicast Paging</p> <p>25-Record</p> <p>27-XML Browser</p> <p>34-Hot Desking</p> <p>35-URL Record</p> <p>38-LDAP</p> <p>39-BLF List</p> <p>40-Prefix</p> <p>41-Zero Touch</p> <p>42-ACD</p> <p>45-Local Group</p> <p>50-Phone Lock</p> <p>56-Retrieve Park</p> <p>61-Directory</p> <p>66-Paging List</p> <p>77-Mobile Account (only applicable to SIP VPT49G IP phones)</p>
Format	Integer

Default Value	<p>For the programable key and ext key, the default value is not applicable.</p> <p>For the line key, when X=1, the default value is 1.</p> <p>When X=2, the default value is 2.</p> <p>When X=3 the default value is 3</p> <p>...</p> <p>When X=16 the default value is 16.</p>
Range	<p>Permitted Values:</p> <p>1 to 16 (for SIP VP-T49G/SIP-T48G/T46G/T29G)</p> <p>1 to 12 (for SIP-T42G)</p> <p>1 to 6 (for SIP-T41P/T27P)</p> <p>1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>1 to 2 (for SIP-T21(P) E2)</p> <p>1-Line 1</p> <p>2-Line 2</p> <p>...</p> <p>16-Line 16</p>
Example	linekey.1.line = 2

Parameter- linekey.X.value	<p>Configuration File</p> <p><y0000000000xx>.cfg</p>
Parameter- programablekey.X.value	
Parameter- expansion_module.X.key.Y.value	
Description	<p>Configures the value for some key features.</p> <p>For line keys (not applicable to SIP-T19(P) E2 and CP860 IP phones):</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p>

	<p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For programmable keys:</p> <p>X=1-4, 12-14 (for SIP VP-T49G)</p> <p>X=1-10, 12-14 (for SIP-T48G/T46G)</p> <p>X=1-10, 13 (for SIP-T42G/T41P/T40P)</p> <p>X=1-14 (for SIP-T29G/T27P)</p> <p>X=1-10, 14 (for SIP-T23P/T23G/T21(P) E2)</p> <p>X=1-9, 13, 14 (for SIP-T19(P) E2)</p> <p>X=1-6, 9, 13 (for CP860)</p> <p>For ext keys (only applicable to SIP-T48G/T46G/T29G/T27P IP phones):</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p>
Format	String
Default Value	Blank
Range	String within 99 characters
Example	<p>When you assign the Speed Dial to the line key, this parameter is used to specify the number you want to dial out.</p> <p>linekey.1.value = 1001</p>

Parameter- linekey.X.label	<p>Configuration File</p> <p><y0000000000xx>.cfg</p>
Parameter- programablekey.X.label	
Parameter- expansion_module.X.key.Y.label	
Description	<p>(Optional.) Configures the label displaying on the LCD screen for each line key and each soft key.</p> <p>This is an optional configuration.</p> <p>For line keys (not applicable to SIP-T19(P) E2 IP phones and CIP860 IP phones):</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p>

	<p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For programable keys:</p> <p>X ranges from 1 to 4.</p> <p>For ext keys (only applicable to SIP-T48G/T46G/T29G/T27P IP phones):</p> <p>X ranges from 1 to 6, Y ranges from 1 to 40. (Ext key 21 cannot be configured.)</p>
Format	String
Default Value	Blank
Range	String within 99 characters
Example	linekey.1.label = Dir

Parameter- linekey.X.pickup_value	Configuration File <y0000000000xx>.cfg
Parameter- expansion_module.X.key.Y.pick up_value	
Description	<p>Configures the pickup code for BLF feature. (not applicable to SIP-T19(P) E2 IP phones and CP860 IP phones)</p> <p>This parameter is only applicable to BLF feature.</p> <p>For line keys:</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For ext keys (only applicable to SIP-T48G/T46G/T29G/T27P IP phones):</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p>


Format	String
Default Value	Blank
Range	String within 256 characters
Example	linekey.1.pickup_value = *88

Parameter- linekey.X.xml_phonebook	Configuration File <y0000000000xx>.cfg
Parameter- programablekey.X.xml_phonebook	
Parameter- expansion_module.X.key.Y.xml_phonebook	
Description	<p>Configures the desired group or remote phone book when multiple groups or remote phone books are configured on the IP phone.</p> <p>This parameter is only applicable to Local Group/XML Group features.</p> <p>For line keys (not applicable to SIP-T19(P) E2 IP phones and CP860 IP phones):</p> <p>X ranges from 1 to 29 (for SIP VP-T49G/SIP-T48G)</p> <p>X ranges from 1 to 27 (for SIP-T46G/T29G)</p> <p>X ranges from 1 to 15 (for SIP-T42G/T41P)</p> <p>X ranges from 1 to 21 (for SIP-T27P)</p> <p>X ranges from 1 to 3 (for SIP-T40P/T23P/T23G)</p> <p>X ranges from 1 to 2 (for SIP-T21(P) E2)</p> <p>For programable keys:</p> <p>X=1-4, 12-14 (for SIP VP-T49G)</p> <p>X=1-10, 12-14 (for SIP-T48G/T46G)</p> <p>X=1-10, 13 (for SIP-T42G/T41P/T40P)</p> <p>X=1-14 (for SIP-T29G/T27P)</p> <p>X=1-10, 14 (for SIP-T23P/T23G/T21(P) E2)</p> <p>X=1-9, 13, 14 (for SIP-T19(P) E2)</p> <p>X=1-6, 9, 13 (for CP860)</p> <p>For ext keys (only applicable to</p>

	<p>SIP-T48G/T46G/T29G/T27P IP phones):</p> <p>X ranges from 1 to 6, Y ranges from 1 to 20, 22 to 40 (Ext key 21 cannot be configured).</p> <p>When the key feature is configured as Local Group, valid values are:</p> <p>0-All contacts</p> <p>1-First local group</p> <p>...</p> <p>5-Fifth local group</p> <p>...</p> <p>48-Forty-eighth local group</p> <p>When the key feature is configured as XML Group (remote phone book), valid values are:</p> <p>0-First XML group</p> <p>1-Second XML group</p> <p>...</p> <p>4-Fifth XML group</p>
Format	Integer
Default Value	0
Range	0 to 48
Example	<p>Configures the second remote phone book.</p> <p>linekey.1.xml_phonebook = 1</p>

Appendix E: Auto Provisioning Flowchart (Keep user personalized configuration settings)

The following shows auto provisioning flowchart for Yealink IP phones when a user wishes to keep user personalized configuration settings.



Appendix F: Configurations Defined Never be Saved to <MAC>-local.cfg file

The following tables list all the configurations defined never be saved to <MAC>-local.cfg file.

Item	Configurations
Server Type	account.X.sip_server_type
	account.X.xsi.server_type
Network	network.dhcp_host_name
	network.pppoe.user
	network.pppoe.password
	network.pc_port.enable
	network.internet_port.speed_duplex
	network.pc_port.speed_duplex
	network.static_dns_enable
	network.ipv6_static_dns_enable
	network.vlan.pc_port_mode
	network.dns.ttl_enable
	network.mtu_value
	network.vlan.internet_port_enable
	network.vlan.internet_port_vid
	network.vlan.internet_port_priority
	network.vlan.pc_port_enable
	network.vlan.pc_port_vid
	network.vlan.pc_port_priority
	network.vlan.dhcp_enable
	network.vlan.dhcp_option
	network.vlan.vlan_change.enable
	network.port.http
	network.port.https
	network.qos.rtplos
	network.qos.signallos

Item	Configurations
	network.qos.audiosos
	network.qos.videosos
	network.802_1x.mode
	network.802_1x.identity
	network.802_1x.md5_password
	network.802_1x.root_cert_url
	network.802_1x.client_cert_url
	network.802_1x.proxy_eap_logoff.enable
	network.vpn_enable
	network.lldp.enable
	network.lldp.packet_interval
	network.span_to_pc_port
	network.port.max_rtpport
	network.port.min_rtpport
	network.ipv6_prefix
	network.ipv6_internet_port.type
	network.ipv6_internet_port.ip
	network.ipv6_internet_port.gateway
	network.ipv6_primary_dns
	network.ipv6_secondary_dns
	network.ipv6_icmp_v6.enable
	network.internet_port.type
	network.internet_port.ip
	network.internet_port.mask
	network.internet_port.gateway
	network.primary_dns
	network.secondary_dns
Wi-Fi	wifi.enable
	wifi.X.label
	wifi.X.ssid
	wifi.X.priority

Item	Configurations
	wifi.X.security_mode
	wifi.X.cipher_type
	wifi.X.password
	wifi.country
	wifi.status_detection_timeout
	wifi.vlan_enable
	network.vlan.wifi_enable
	network.vlan.wifi_vid
	network.vlan.wifi_priority
Openvpn	openvpn.url
Security	security.user_name.user
	security.user_name.admin
	security.user_name.var
	security.user_password
	security.trust_certificates
	security.ca_cert
	security.dev_cert
	security.cn_validation
	security.var_enable
	trusted_certificates.url
	trusted_certificates.delete
	server_certificates.url
	server_certificates.delete
	wui.https_enable
	wui.http_enable
Log	syslog.mode
	syslog.server
	syslog.log_level
Autoprovision	auto_provision.custom.sync
	auto_provision.custom.protect
	auto_provision.custom.upload_method

Item	Configurations
	auto_provision.power_on
	auto_provision.pnp_enable
	auto_provision.dhcp_option.enable
	auto_provision.dhcp_option.list_user_options
	auto_provision.repeat.enable
	auto_provision.repeat.minutes
	auto_provision.weekly.enable
	auto_provision.weekly.dayofweek
	auto_provision.weekly.begin_time
	auto_provision.weekly.end_time
	auto_provision.server.url
	auto_provision.server.username
	auto_provision.server.password
	auto_provision.aes_key_16.com
	auto_provision.aes_key_16.mac
	auto_provision.aes_key_in_file
	auto_provision.dhcp_option.option60_value
	auto_provision.reboot_force.enable
	auto_provision.url_wildcard.pn
	zero_touch.enable
	zero_touch.wait_time
	autoprovision.X.name
	autoprovision.X.code
	autoprovision.X.user
	autoprovision.X.password
	autoprovision.X.url
	autoprovision.X.com_aes
	autoprovision.X.mac_aes
SIP	sip.notify_reboot_enable
	sip.escape_characters.enable
	sip.listen_mode

Item	Configurations
	sip.reserve_characters
	sip.use_23_as_pound
	sip.rfc2543_hold
	account.X.custom_ua
	sip.reg_surge_prevention
	sip.send_response_by_request
	sip.refer_by_header_auto_build
	sip.tcp_port_random_mode
	sip.use_out_bound_in_dialog
	sip.call_park_without_blf
	sip.min_udp_port
	sip.max_udp_port
	sip.min_tcp_port
	sip.max_tcp_port
Configurations associated with the password	ldap.password
	phone_setting.phone_lock.unlock_pin
	account.X.hoteling.password
	account.X.xsi.password
	account.X.password
	managementserver.connection_request_password
	managementserver.password
DND&Forward	account.X.always_fwd.enable
	account.X.always_fwd.target
	account.X.always_fwd.off_code
	account.X.always_fwd.on_code
	account.X.busy_fwd.enable
	account.X.busy_fwd.target
	account.X.busy_fwd.off_code
	account.X.busy_fwd.on_code
	account.X.timeout_fwd.enable
	account.X.timeout_fwd.target

Item	Configurations
	account.X.timeout_fwd.timeout
	account.X.timeout_fwd.off_code
	account.X.timeout_fwd.on_code
	account.X.dnd.enable
	account.X.dnd.off_code
	account.X.dnd.on_code
	features.fwd_mode
	features.fwd_diversion_enable
	forward.always.enable
	forward.always.target
	forward.always.on_code
	forward.always.off_code
	forward.busy.enable
	forward.busy.target
	forward.busy.on_code
	forward.busy.off_code
	forward.no_answer.enable
	forward.no_answer.target
	forward.no_answer.timeout
	forward.no_answer.on_code
	forward.no_answer.off_code
	forward.international.enable
	features.dnd_mode
	features.dnd.enable
	features.dnd.on_code
	features.dnd.off_code
	features.dnd_refuse_code
Feature access code	account.X.anonymous_call_oncode
	account.X.anonymous_call_offcode
	account.X.anonymous_reject_oncode
	account.X.anonymous_reject_offcode

Item	Configurations
	features.pickup.direct_pickup_code
	account.X.direct_pickup_code
	features.pickup.group_pickup_code
	account.X.group_pickup_code
	call_waiting.on_code
	call_waiting.off_code
	features.call_park.park_code
	features.call_park.group_park_code
	features.call_park.park_retrieve_code
	account.X.blf_list_code
	account.X.blf_list_barge_in_code
	account.X.blf_list_retrieve_call_parked_code
	account.X.shared_line_callpull_code
	voice_mail.number.X
Access URL of the xml format resoures files/configuration files	custom_mac_cfg.url
	dialplan_dialnow.url
	dialplan_replace_rule.url
	remote_phonebook.data.X.url
	super_search.url
	web_item_level.url
	trusted_certificates.url
	server_certificates.url
	local_contact.data.url
	directory_setting.url
	custom_factory_configuration.url
	configuration.url
	custom_softkey_call_failed.url
	custom_softkey_call_in.url
	custom_softkey_connecting.url
	custom_softkey_dialing.url
	custom_softkey_ring_back.url

Item	Configurations
	custom_softkey_talking.url
	firmware.url
	gui_onscreen_keyboard.url
DNS	dns_cache_a.X.name
	dns_cache_a.X.ip
	dns_cache_a.X.ttl
	dns_cache_srv.X.name
	dns_cache_srv.X.port
	dns_cache_srv.X.priority
	dns_cache_srv.X.target
	dns_cache_srv.X.weight
	dns_cache_srv.X.ttl
	dns_cache_naptr.X.name
	dns_cache_naptr.X.flags
	dns_cache_naptr.X.order
	dns_cache_naptr.X.preference
	dns_cache_naptr.X.replace
	dns_cache_naptr.X.service
	dns_cache_naptr.X.ttl
Configurations requiring a reboot during auto provisioning	features.relog_offtime
	features.blf_list_version
	phone_setting.show_code403
	features.show_default_account
	account.X.subscribe_expires_overlap
	account.X.register_expires_overlap
	bw.enable
	features.uc_enable
	features.uc_username
	features.uc_password
	voice.handfree_send
	voice.handset_send

Item	Configurations
	voice.headset_send
	video.enable
	directory.sorted_alphabetically
	local_contact.photo.url
	local_contact.icon_image.url
	local_contact.image.url (only for SIP VP-T49G)
	local_contact.icon.url (only for SIP VP-T49G)
	local_contact.data_photo_tar.url (only for SIP

Appendix G: SIP (Session Initiation Protocol)

This section describes how Yealink IP phones comply with the IETF definition of SIP as described in [RFC 3261](#).

This section contains compliance information in the following:

- [RFC and Internet Draft Support](#)
- [SIP Request](#)
- [SIP Header](#)
- [SIP Responses](#)
- [SIP Session Description Protocol \(SDP\) Usage](#)

RFC and Internet Draft Support

The following RFC's and Internet drafts are supported:

- RFC 1321—The MD5 Message-Digest Algorithm
- RFC 1889—RTP Media control
- RFC 2112—Multipart MIME
- RFC 2327—SDP: Session Description Protocol
- RFC 2387—The MIME Multipart/Related Content-type
- RFC 2543—SIP: Session Initiation Protocol
- RFC 2617—Http Authentication: Basic and Digest access authentication
- RFC 2782—A DNS RR for specifying the location of services (DNS SRV)
- RFC 2806—URLs for Telephone Calls
- RFC 2833—RTP Payload for DTMF Digits, Telephony Tones and Telephony Signals
- RFC 2915—The Naming Authority Pointer (NAPTR) DNS Resource Record

- RFC 2976—The SIP INFO Method
- RFC 3087—Control of Service Context using SIP Request-URI
- RFC 3261—SIP: Session Initiation Protocol (replacement for RFC 2543)
- RFC 3262—Reliability of Provisional Responses in the Session Initiation Protocol (SIP)
- RFC 3263—Session Initiation Protocol (SIP): Locating SIP Servers
- RFC 3264—An Offer/Answer Model with the Session Description Protocol (SDP)
- RFC 3265—Session Initiation Protocol (SIP) - Specific Event Notification
- RFC 3266—Support for IPv6 in Session Description Protocol (SDP)
- RFC 3310—HTTP Digest Authentication Using Authentication and Key Agreement (AKA)
- RFC 3311—The Session Initiation Protocol (SIP) UPDATE Method
- RFC 3312—Integration of Resource Management and SIP
- RFC 3313—Private SIP Extensions for Media Authorization
- RFC 3323—A Privacy Mechanism for the Session Initiation Protocol (SIP)
- RFC 3324—Requirements for Network Asserted Identity
- RFC 3325—SIP Asserted Identity
- RFC 3326—The Reason Header Field for the Session Initiation Protocol (SIP)
- RFC 3361—DHCP-for-IPv4 Option for SIP Servers
- RFC 3372—SIP for Telephones (SIP-T): Context and Architectures
- RFC 3398—ISUP to SIP Mapping
- RFC 3420—Internet Media Type message/sipfrag
- RFC 3428—Session Initiation Protocol (SIP) Extension for Instant Messaging
- RFC 3455—Private Header (P-Header) Extensions to the SIP for the 3GPP
- RFC 3486—Compressing the Session Initiation Protocol (SIP)
- RFC 3489—STUN - Simple Traversal of User Datagram Protocol (UDP) Through Network Address Translators (NATs)
- RFC 3515—The Session Initiation Protocol (SIP) Refer Method
- RFC 3550—RTP: Transport Protocol for Real-Time Applications
- RFC 3555—MIME Type Registration of RTP Payload Formats
- RFC 3581—An Extension to the SIP for Symmetric Response Routing
- RFC 3608—SIP Extension Header Field for Service Route Discovery During Registration
- RFC 3611—RTP Control Protocol Extended Reports (RTCP XR)
- RFC 3665—Session Initiation Protocol (SIP) Basic Call Flow Examples
- RFC 3666—SIP Public Switched Telephone Network (PSTN) Call Flows.
- RFC 3680—SIP Event Package for Registrations
- RFC 3702—Authentication, Authorization, and Accounting Requirements for the SIP
- RFC 3711—The Secure Real-time Transport Protocol (SRTP)

- RFC 3725—Best Current Practices for Third Party Call Control (3pcc) in the Session Initiation Protocol (SIP)
- RFC 3842—A Message Summary and Message Waiting Indication Event Package for the Session Initiation Protocol (SIP)
- RFC 3856—A Presence Event Package for Session Initiation Protocol (SIP)
- RFC 3863—Presence Information Data Format
- RFC 3890—A Transport Independent Bandwidth Modifier for the SDP
- RFC 3891—The Session Initiation Protocol (SIP) “Replaces” Header
- RFC 3892—The Session Initiation Protocol (SIP) Referred-By Mechanism
- RFC 3959—The Early Session Disposition Type for SIP
- RFC 3960—Early Media and Ringing Tone Generation in SIP
- RFC 3966—The tel URI for telephone number
- RFC 3968—IANA Registry for SIP Header Field
- RFC 3969—IANA Registry for SIP URI
- RFC 4028—Session Timers in the Session Initiation Protocol (SIP)
- RFC 4083—3GPP Release 5 Requirements on SIP
- RFC 4235—An INVITE-Initiated Dialog Event Package for the Session Initiation Protocol (SIP)
- RFC 4244—An Extension to the SIP for Request History Information
- RFC 4317—Session Description Protocol (SDP) Offer/Answer Examples
- RFC 4353—A Framework for Conferencing with the SIP
- RFC 4458—SIP URIs for Applications such as Voicemail and Interactive Voice Response (IVR)
- RFC 4475—Session Initiation Protocol (SIP) Torture
- RFC 4485—Guidelines for Authors of Extensions to the SIP
- RFC 4504—SIP Telephony Device Requirements and Configuration
- RFC 4566—SDP: Session Description Protocol.
- RFC 4568—Session Description Protocol (SDP) Security Descriptions for Media Streams
- RFC 4575—A SIP Event Package for Conference State
- RFC 4579—SIP Call Control - Conferencing for User Agents
- RFC 4583—Session Description Protocol (SDP) Format for Binary Floor Control Protocol (BFCP) Streams
- RFC 4662—A SIP Event Notification Extension for Resource Lists
- RFC 4730—Event Package for KPML
- RFC 5009—P-Early-Media Header
- RFC 5079—Rejecting Anonymous Requests in SIP
- RFC 5359—Session Initiation Protocol Service Examples

- RFC 5589—Session Initiation Protocol (SIP) Call Control – Transfer
- RFC 5630—The Use of the SIPS URI Scheme in SIP
- RFC 5806—Diversion Indication in SIP
- RFC 5954—Essential Correction for IPv6 ABNF and URI Comparison in RFC 3261
- RFC 6026—Correct Transaction Handling for 2xx Responses to SIP INVITE Requests
- RFC 6141—Re-INVITE and Target-Refresh Request Handling in SIP
- draft-ietf-sip-cc-transfer-05.txt—SIP Call Control - Transfer
- draft-anil-sipping-bla-02.txt—Implementing Bridged Line Appearances (BLA) Using Session Initiation Protocol (SIP)
- draft-anil-sipping-bla-03.txt—Implementing Bridged Line Appearances (BLA) Using Session Initiation Protocol (SIP)
- draft-ietf-sip-privacy-00.txt—SIP Extensions for Caller Identity and Privacy, November
- draft-ietf-sip-privacy-04.txt—SIP Extensions for Network-Asserted Caller Identity and Privacy within Trusted Networks
- draft-levy-sip-diversion-08.txt—Diversion Indication in SIP
- draft-ietf-sipping-cc-conferencing-03.txt—SIP Call Control - Conferencing for User Agents
- draft-ietf-sipping-cc-conferencing-05.txt—Connection Reuse in the Session Initiation Protocol (SIP)
- draft-ietf-sipping-rtcp-summary-02.txt—Session Initiation Protocol Package for Voice Quality Reporting Event
- draft-ietf-sip-connect-reuse-06.txt—Connection Reuse in the Session Initiation Protocol (SIP)
- draft-ietf-bliss-shared-appearances-15.txt—Shared Appearances of a Session Initiation Protocol (SIP) Address of Record (AOR)

To find the applicable Request for Comments (RFC) document, go to <http://www.ietf.org/rfc.html> and enter the RFC number.

SIP Request

The following SIP request messages are supported:

Method	Supported	Notes
REGISTER	Yes	
INVITE	Yes	Yealink IP phones support mid-call changes such as placing a call on hold as signaled by a new INVITE that contains an existing

Method	Supported	Notes
		Call-ID.
ACK	Yes	
CANCEL	Yes	
BYE	Yes	
OPTIONS	Yes	
SUBSCRIBE	Yes	
NOTIFY	Yes	
REFER	Yes	
PRACK	Yes	
INFO	Yes	
MESSAGE	Yes	
UPDATE	Yes	
PUBLISH	Yes	

SIP Header

The following SIP request headers are supported:

Note In the following table, a “Yes” in the Supported column means the header is sent and properly parsed.

Method	Supported	Notes
Accept	Yes	
Alert-Info	Yes	
Allow	Yes	
Allow-Events	Yes	
Authorization	Yes	
Call-ID	Yes	
Call-Info	Yes	
Contact	Yes	
Content-Length	Yes	
Content-Type	Yes	

Method	Supported	Notes
CSeq	Yes	
Diversion	Yes	
History-Info	Yes	
Event	Yes	
Expires	Yes	
From	Yes	
Max-Forwards	Yes	
Min-SE	Yes	
P-Asserted-Identity	Yes	
P-Preferred-Identity	Yes	
Proxy-Authenticate	Yes	
Proxy-Authorization	Yes	
RAck	Yes	
Record-Route	Yes	
Refer-To	Yes	
Referred-By	Yes	
Remote-Party-ID	Yes	
Replaces	Yes	
Require	Yes	
Route	Yes	
RSeq	Yes	
Session-Expires	Yes	
Subscription-State	Yes	
Supported	Yes	
To	Yes	
User-Agent	Yes	
Via	Yes	

SIP Responses

The following SIP responses are supported:

Note

In the following table, a “Yes” in the Supported column means the header is sent and properly parsed. The phone may not actually generate the response.

1xx Response—Information Responses

1xx Response	Supported	Notes
100 Trying	Yes	
180 Ringing	Yes	
181 Call Is Being Forwarded	Yes	
183 Session Progress	Yes	

2xx Response—Successful Responses

2xx Response	Supported	Notes
200 OK	Yes	
202 Accepted	Yes	In REFER transfer.

3xx Response—Redirection Responses

3xx Response	Supported	Notes
300 Multiple Choices	Yes	
301 Moved Permanently	Yes	
302 Moved Temporarily	Yes	

4xx Response—Request Failure Responses

4xx Response	Supported	Notes
400 Bad Request	Yes	
401 Unauthorized	Yes	
402 Payment Required	Yes	
403 Forbidden	Yes	

4xx Response	Supported	Notes
404 Not Found	Yes	
405 Method Not Allowed	Yes	
406 Not Acceptable	No	
407 Proxy Authentication Required	Yes	
408 Request Timeout	Yes	
409 Conflict	No	
410 Gone	No	
411 Length Required	No	
413 Request Entity Too Large	No	
414 Request-URI Too Long	Yes	
415 Unsupported Media Type	Yes	
416 Unsupported URI Scheme	No	
420 Bad Extension	No	
421 Extension Required	No	
423 Interval Too Brief	Yes	
480 Temporarily Unavailable	Yes	
481 Call/Transaction Does Not Exist	Yes	
482 Loop Detected	Yes	
483 Too Many Hops	No	
484 Address Incomplete	Yes	
485 Ambiguous	No	
486 Busy Here	Yes	
487 Request Terminated	Yes	
488 Not Acceptable Here	Yes	
491 Request Pending	No	
493 Undecipherable	No	

5xx Response—Server Failure Responses

5xx Response	Supported	Notes
500 Internal Server Error	Yes	
501 Not Implemented	Yes	
502 Bad Gateway	No	
503 Service Unavailable	No	
504 Gateway Timeout	No	
505 Version Not Supported	No	

6xx Response—Global Responses

6xx Response	Supported	Notes
600 Busy Everywhere	Yes	
603 Decline	Yes	
604 Does Not Exist Anywhere	No	
606 Not Acceptable	No	

SIP Session Description Protocol (SDP) Usage

SDP Headers	Supported
v—Protocol version	Yes
o—Owner/creator and session identifier	Yes
a—Media attribute	Yes
c—Connection information	Yes
m—Media name and transport address	Yes
s—Session name	Yes
t—Active time	Yes

Appendix H: SIP Call Flows

SIP uses six request methods:

INVITE—Indicates a user is being invited to participate in a call session.

ACK—Confirms that the client has received a final response to an INVITE request.

BYE—Terminates a call and can be sent by either the caller or the callee.

CANCEL—Cancels any pending searches but does not terminate a call that has already been accepted.

OPTIONS—Queries the capabilities of servers.

REGISTER—Registers the address listed in the To header field with a SIP server.

The following types of responses are used by SIP and generated by the IP phone or the SIP server:

SIP 1xx—Informational Responses

SIP 2xx—Successful Responses

SIP 3xx—Redirection Responses

SIP 4xx—Client Failure Responses

SIP 5xx—Server Failure Responses

SIP 6xx—Global Failure Responses


Successful Call Setup and Disconnect

The following figure illustrates the scenario of a successful call. In this scenario, the two end users are User A and User B. User A and User B are located at Yealink SIP IP phones.

The call flow scenario is as follows:

1. User A calls User B.
2. User B answers the call.

3. User B hangs up.



Step	Action	Description
F1	INVITE—User A to Proxy Server	<p>User A sends a SIP INVITE message to a proxy server. The INVITE request is an invitation to User B to participate in a call session.</p> <p>In the INVITE request:</p> <ul style="list-style-type: none"> The IP address of User B is inserted in the Request-URI field. User A is identified as the call session initiator in the From field. A unique numeric identifier is assigned to the call and is inserted in the Call-ID field. The transaction number within a single call leg is identified in the CSeq field.

Step	Action	Description
		<ul style="list-style-type: none"> The media capability User A is ready to receive is specified. The port on which User B is prepared to receive the RTP data is specified.
F2	INVITE—Proxy Server to User B	The proxy server maps the SIP URI in the To field to User B. The proxy server sends the INVITE message to User B.
F3	100 Trying—User B to Proxy Server	User B sends a SIP 100 Trying response to the proxy server. The 100 Trying response indicates that the INVITE request has been received by User B.
F4	100 Trying—Proxy Server to User A	The proxy server forwards the SIP 100 Trying to User A to indicate that the INVITE request has been received by User B.
F5	180 Ringing—User B to Proxy Server	User B sends a SIP 180 Ringing response to the proxy server. The 180 Ringing response indicates that the User B is being alerted.
F6	180 Ringing—Proxy Server to User A	The proxy server forwards the 180 Ringing response to User A. User A hears the ring-back tone indicating that User B is being alerted.
F7	200 OK— User B to Proxy Server	User B sends a SIP 200 OK response to the proxy server. The 200 OK response notifies User A that the connection has been made.
F8	200OK—Proxy Server to User A	The proxy server forwards the 200 OK message to User A. The 200 OK response notifies User A that the connection has been made.
F9	ACK—User A to Proxy Server	User A sends a SIP ACK to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now active.
F10	ACK—Proxy Server to User B	The proxy server sends the SIP ACK to User B. The ACK confirms that the proxy server has received the 200 OK

Step	Action	Description
		response. The call session is now active.
F11	BYE—User B to Proxy Server	User B terminates the call session by sending a SIP BYE request to the proxy server. The BYE request indicates that User B wants to release the call.
F12	BYE—Proxy Server to User A	The proxy server forwards the SIP BYE request to User A to notify that User B wants to release the call.
F13	200 OK—User A to Proxy Server	User A sends a SIP 200 OK response to the proxy server. The 200 OK response indicates that User A has received the BYE request. The call session is now terminated.
F14	200 OK—Proxy Server to User B	The proxy server forwards the SIP 200 OK response to User B to indicate that User A has received the BYE request. The call session is now terminated.


Unsuccessful Call Setup—Called User is Busy

The following figure illustrates the scenario of an unsuccessful call caused by the called user's being busy. In this scenario, the two end users are User A and User B. User A and User B are located at Yealink SIP IP phones.

The call flow scenario is as follows:

1. User A calls User B.
2. User B is busy on the IP phone and unable or unwilling to take another call.

The call cannot be set up successfully.



Step	Action	Description
F1	INVITE—User A to Proxy Server	<p>User A sends the INVITE message to a proxy server. The INVITE request is an invitation to User B to participate in a call session.</p> <p>In the INVITE request:</p> <ul style="list-style-type: none"> The IP address of User B is inserted in the Request-URI field. User A is identified as the call session initiator in the From field. A unique numeric identifier is assigned to the call and is inserted in the Call-ID field. The transaction number within a single call leg is identified in the CSeq field. The media capability User A is ready to receive is specified. The port on which User B is prepared to receive the RTP data is specified.
F2	INVITE—Proxy Server to User B	The proxy server maps the SIP URI in the To field to User B. Proxy server forwards the INVITE message to User B.
F3	100 Trying—User B to Proxy	User B sends a SIP 100 Trying response

Step	Action	Description
	Server	to the proxy server. The 100 Trying response indicates that the INVITE request has been received by User B.
F4	100 Trying—Proxy Server to User A	The proxy server forwards the SIP 100 Trying to User A to indicate that the INVITE request has already been received.
F5	486 Busy Here—User B to Proxy Server	User B sends a SIP 486 Busy Here response to the proxy server. The 486 Busy Here response is a client error response indicating that User B is successfully connected but User B is busy on the IP phone and unable or unwilling to take the call.
F6	486 Busy Here—Proxy Server to User A	The proxy server forwards the 486 Busy Here response to notify User A that User B is busy.
F7	ACK—User A to Proxy Server	User A sends a SIP ACK to the proxy server. The SIP ACK message indicates that User A has received the 486 Busy Here message.
F8	ACK—Proxy Server to User B	The proxy server forwards the SIP ACK to User B to indicate that the 486 Busy Here message has already been received.


Unsuccessful Call Setup—Called User Does Not Answer

The following figure illustrates the scenario of an unsuccessful call caused by the called user's no answering. In this scenario, the two end users are User A and User B. User A and User B are located at Yealink SIP IP phones.

The call flow scenario is as follows:

1. User A calls User B.
2. User B does not answer the call.
3. User A hangs up.

The call cannot be set up successfully.



Step	Action	Description
F1	INVITE—User A to Proxy Server	<p>User A sends an INVITE message to a proxy server. The INVITE request is an invitation to User B to participate in a call session.</p> <p>In the INVITE request:</p> <ul style="list-style-type: none"> The IP address of User B is inserted in the Request-URI field. User A is identified as the call session initiator in the From field. A unique numeric identifier is assigned to the call and is inserted in the Call-ID field. The transaction number within a single call leg is identified in the CSeq field. The media capability User A is ready to receive is specified. The port on which User B is prepared to receive the RTP data is specified.
F2	INVITE—Proxy Server to User B	<p>The proxy server maps the SIP URI in the To field to User B. Proxy server forwards the INVITE message to User B.</p>

Step	Action	Description
F3	180 Ringing—User B to Proxy Server	User B sends a SIP 180 Ringing response to the proxy server. The 180 Ringing response indicates that the user is being alerted.
F4	180 Ringing—Proxy Server to User A	The proxy server forwards the 180 Ringing response to User A. User A hears the ring-back tone indicating that User B is being alerted.
F5	CANCEL—User A to Proxy Server	User A sends a SIP CANCEL request to the proxy server after not receiving an appropriate response within the time allocated in the INVITE request. The SIP CANCEL request indicates that User A wants to disconnect the call.
F6	CANCEL—Proxy Server to User B	The proxy server forwards the SIP CANCEL request to notify User B that User A wants to disconnect the call.
F7	200 OK—User B to Proxy Server	User B sends a SIP 200 OK response to the proxy server. The SIP 200 OK response indicates that User B has received the CANCEL request.
F8	200 OK—Proxy Server to User A	The proxy server forwards the SIP 200 OK response to notify User A that the CANCEL request has been processed successfully.


Successful Call Setup and Call Hold

The following figure illustrates a successful call setup and call hold. In this scenario, the two end users are User A and User B. User A and User B are located at Yealink SIP IP phones.

The call flow scenario is as follows:

1. User A calls User B.
2. User B answers the call.

3. User A places User B on hold.



Step	Action	Description
F1	INVITE—User A to Proxy Server	<p>User A sends an INVITE message to a proxy server. The INVITE request is an invitation to User B to participate in a call session.</p> <p>In the INVITE request:</p> <ul style="list-style-type: none"> The IP address of User B is inserted in the Request-URI field. User A is identified as the call session initiator in the From field. A unique numeric identifier is assigned to the call and is inserted in the Call-ID field. The transaction number within a single call leg is identified in the

Step	Action	Description
		<p>CSeq field.</p> <ul style="list-style-type: none"> The media capability User A is ready to receive is specified. The port on which User B is prepared to receive the RTP data is specified.
F2	INVITE—Proxy Server to User B	The proxy server maps the SIP URI in the To field to User B. The proxy server sends the INVITE message to User B.
F3	180 Ringing—User B to Proxy Server	User B sends a SIP 180 Ringing response to the proxy server. The 180 Ringing response indicates that the user is being alerted.
F4	180 Ringing—Proxy Server to User A	The proxy server forwards the 180 Ringing response to User A. User A hears the ring-back tone indicating that User B is being alerted.
F5	200 OK—User B to Proxy Server	User B sends a SIP 200 OK response to the proxy server. The 200 OK response notifies the proxy server that the connection has been made.
F6	200 OK—Proxy Server to User A	The proxy server forwards the 200 OK message to User A. The 200 OK response notifies User A that the connection has been made.
F7	ACK—User A to Proxy Server	User A sends a SIP ACK to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now active.
F8	ACK—Proxy Server to User B	The proxy server sends the SIP ACK to User B. The ACK confirms that the proxy server has received the 200 OK response. The call session is now active.
F9	INVITE—User A to Proxy Server	User A sends a mid-call INVITE request to the proxy server with new SDP session parameters, which are used to place the call on hold.
F10	INVITE—Proxy Server to User	The proxy server forwards the mid-call

Step	Action	Description
	B	INVITE message to User B.
F11	200 OK—User B to Proxy Server	User B sends a SIP 200 OK response to the proxy server. The 200 OK response notifies User A that the INVITE is successfully processed.
F12	200 OK—Proxy Server to User A	The proxy server forwards the 200 OK response to User A. The 200 OK response notifies User B is successfully placed on hold.
F13	ACK—User A to Proxy Server	User A sends an ACK message to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now temporarily inactive. No RTP packets are being sent.
F14	ACK—Proxy Server to User B	The proxy server sends the ACK message to User B. The ACK confirms that the proxy server has received the 200 OK response.


Successful Call Setup and Call Waiting

The following figure illustrates a successful call between Yealink SIP IP phones in which two parties are in a call, one of the participants receives and answers an incoming call from a third party. In this call flow scenario, the end users are User A, User B, and User C. They are all using Yealink SIP IP phones, which are connected via an IP network.

The call flow scenario is as follows:

1. User A calls User B.
2. User B answers the call.
3. User C calls User B.

4. User B accepts the call from User C.



Step	Action	Description
F1	INVITE—User A to Proxy Server	<p>User A sends an INVITE message to a proxy server. The INVITE request is an invitation to User B to participate in a call session.</p> <p>In the INVITE request:</p> <ul style="list-style-type: none"> The IP address of User B is inserted in the Request-URI field. User A is identified as the call

Step	Action	Description
		<p>session initiator in the From field.</p> <ul style="list-style-type: none"> • A unique numeric identifier is assigned to the call and is inserted in the Call-ID field. • The transaction number within a single call leg is identified in the CSeq field. • The media capability User A is ready to receive is specified. • The port on which User B is prepared to receive the RTP data is specified.
F2	INVITE—Proxy Server to User B	The proxy server maps the SIP URI in the To field to User B. The proxy server sends the INVITE message to User B.
F3	180 Ringing—User B to Proxy Server	User B sends a SIP 180 Ringing response to the proxy server. The 180 Ringing response indicates that the user is being alerted.
F4	180 Ringing—Proxy Server to User A	The proxy server forwards the 180 Ringing response to User A. User A hears the ring-back tone indicating that User B is being alerted.
F5	200 OK—User B to Proxy Server	User B sends a SIP 200 OK response to the proxy server. The 200 OK response notifies proxy server that the connection has been made.
F6	200 OK—Proxy Server to User A	The proxy server forwards the 200 OK message to User A. The 200 OK response notifies User A that the connection has been made.
F7	ACK—User A to Proxy Server	User A sends a SIP ACK to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now active.
F8	ACK—Proxy Server to User B	The proxy server sends the SIP ACK to User B. The ACK confirms that the proxy server has received the 200 OK response. The call session is now active.

Step	Action	Description
F9	INVITE—User C to Proxy Server	<p>User C sends a SIP INVITE message to the proxy server. The INVITE request is an invitation to User A to participate in a call session.</p> <p>In the INVITE request:</p> <ul style="list-style-type: none"> • The IP address of User A is inserted in the Request-URI field. • User C is identified as the call session initiator in the From field. • A unique numeric identifier is assigned to the call and is inserted in the Call-ID field. • The transaction number within a single call leg is identified in the CSeq field. • The media capability User C is ready to receive is specified. • The port on which User A is prepared to receive the RTP data is specified.
F10	INVITE—Proxy Server to User A	The proxy server maps the SIP URI in the To field to User A. The proxy server sends the INVITE message to User A.
F11	180 Ringing—User A to Proxy Server	User A sends a SIP 180 Ringing response to the proxy server. The 180 Ringing response indicates that the user is being alerted.
F12	180 Ringing—Proxy Server to User C	The proxy server forwards the 180 Ringing response to User C. User C hears the ring-back tone indicating that User A is being alerted.
F13	INVITE—User A to Proxy Server	User A sends a mid-call INVITE request to the proxy server with new SDP session parameters, which are used to place the call on hold.
F14	INVITE—Proxy Server to User B	The proxy server forwards the mid-call INVITE message to User B.
F15	200 OK—User B to Proxy	User B sends a 200 OK to the proxy server. The 200 OK response indicates

Step	Action	Description
	Server	that the INVITE was successfully processed.
F16	200 OK—Proxy Server to User A	The proxy server forwards the 200 OK response to User A. The 200 OK response notifies User B is successfully placed on hold.
F17	ACK—User A to Proxy Server	User A sends an ACK message to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now temporarily inactive. No RTP packets are being sent.
F18	ACK—Proxy Server to User B	The proxy server sends the ACK message to User B. The ACK confirms that the proxy server has received the 200 OK response.
F19	200 OK—User A to Proxy Server	User A sends a 200 OK response to the proxy server. The 200 OK response notifies that the connection has been made.
F20	200 OK—Proxy Server User C	The proxy server forwards the 200 OK message to User C.
F21	ACK—User C to Proxy Server	User C sends a SIP ACK to the proxy server. The ACK confirms that User C has received the 200 OK response. The call session is now active.
F22	ACK—Proxy Server to User A	The proxy server forwards the SIP ACK to User A to confirm that User C has received the 200 OK response.


Call Transfer without Consultation

The following figure illustrates a successful call between Yealink SIP IP phones in which two parties are in a call and then one of the parties transfers the call to a third party without consultation. This is called a blind transfer. In this call flow scenario, the end users are User A, User B, and User C. They are all using Yealink SIP IP phones, which are connected via an IP network.

The call flow scenario is as follows:

1. User A calls User B.
2. User B answers the call.
3. User B transfers the call to User C.
4. User C answers the call.

Call is established between User A and User C.



Step	Action	Description
F1	INVITE—User A to Proxy Server	User A sends an INVITE message to the proxy server. The INVITE request is an invitation to User B to participate in a call session. In the INVITE request:

Step	Action	Description
		<ul style="list-style-type: none"> The IP address of User B is inserted in the Request-URI field. User A is identified as the call session initiator in the From field. A unique numeric identifier is assigned to the call and is inserted in the Call-ID field. The transaction number within a single call leg is identified in the CSeq field. The media capability User A is ready to receive is specified. The port on which User B is prepared to receive the RTP data is specified.
F2	INVITE—Proxy Server to User B	The proxy server maps the SIP URI in the To field to User B. The proxy server sends the INVITE message to User B.
F3	180 Ringing—User B to Proxy server	User B sends a SIP 180 Ringing response to the proxy server. The 180 Ringing response indicates that the user is being alerted.
F4	180 Ringing—Proxy Server to User A	The proxy server forwards the 180 Ringing response to User A. User A hears the ring-back tone indicating that User B is being alerted.
F5	200 OK—User B to Proxy Server	User B sends a SIP 200 OK response to the proxy server. The 200 OK response notifies User A that the connection has been made.
F6	200 OK—Proxy Server to User A	The proxy server forwards the 200 OK message to User A. The 200 OK response notifies User A that the connection has been made.
F7	ACK—User A to Proxy Server	User A sends a SIP ACK to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now active.
F8	ACK—Proxy Server to User B	The proxy server sends the SIP ACK to

Step	Action	Description
		User B. The ACK confirms that the proxy server has received the 200 OK response. The call session is now active.
F9	REFER—User B to Proxy Server	User B sends a REFER message to the proxy server. User B performs a blind transfer of User A to User C.
F10	202 Accepted—Proxy Server to User B	The proxy server sends a SIP 202 Accept response to User B. The 202 Accepted response notifies User B that the proxy server has received the REFER message.
F11	REFER—Proxy Server to User A	The proxy server forwards the REFER message to User A.
F12	202 Accepted—User A to Proxy Server	User A sends a SIP 202 Accept response to the proxy server. The 202 Accepted response indicates that User A accepts the transfer.
F13	BYE—User B to Proxy Server	User B terminates the call session by sending a SIP BYE request to the proxy server. The BYE request indicates that User B wants to release the call.
F14	BYE—Proxy Server to User A	The proxy server forwards the BYE request to User A.
F15	200OK—User A to Proxy Server	User A sends a SIP 200 OK response to the proxy server. The 200 OK response confirms that User A has received the BYE request.
F16	200OK—Proxy Server to User B	The proxy server forwards the SIP 200 OK response to User B.
F17	INVITE—User A to Proxy Server	User A sends a SIP INVITE request to the proxy server. In the INVITE request, a unique Call-ID is generated and the Contact-URI field indicates that User A requests the call.
F18	INVITE—Proxy Server to User C	The proxy server maps the SIP URI in the To field to User C.
F19	180 Ringing—User C to Proxy Server	User C sends a SIP 180 Ringing response to the proxy server. The 180

Step	Action	Description
		Ringing response indicates that the user is being alerted.
F20	180 Ringing—Proxy Server to User A	The proxy server forwards the 180 Ringing response to User A. User A hears the ring-back tone indicating that User C is being alerted
F21	200OK—User C to Proxy Server	User C sends a SIP 200 OK response to the proxy server. The 200 OK response notifies the proxy server that the connection has been made.
F22	200OK—Proxy Server to User A	The proxy server forwards the SIP 200 OK response to User A.
F23	ACK— User A to Proxy Server	User A sends a SIP ACK to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now active.
F24	ACK—Proxy Server to User C	The proxy server forwards the ACK message to User C. The ACK confirms that User A has received the 200 OK response. The call session is now active.


Call Transfer with Consultation

The following figure illustrates a successful call between Yealink SIP IP phones in which two parties are in a call and then one of the parties transfers the call to the third party with consultation. This is called attended transfer. In this call flow scenario, the end users are User A, User B, and User C. They are all using Yealink SIP IP phones, which are connected via an IP network.

The call flow scenario is as follows:

1. User A calls User B.
2. User B answers the call.
3. User A calls User C.
4. User C answers the call.
5. User A transfers the call to User C.

Call is established between User B and User C.



Step	Action	Description
F1	INVITE—User A to Proxy Server	<p>User A sends an INVITE message to a proxy server. The INVITE request is an invitation to User B to participate in a call session.</p> <p>In the INVITE request:</p> <ul style="list-style-type: none"> The IP address of User B is inserted in the Request-URI field.

Step	Action	Description
		<ul style="list-style-type: none"> • User A is identified as the call session initiator in the From field. • A unique numeric identifier is assigned to the call and is inserted in the Call-ID field. • The transaction number within a single call leg is identified in the CSeq field. • The media capability User A is ready to receive is specified. • The port on which User B is prepared to receive the RTP data is specified.
F2	INVITE—Proxy Server to User B	The proxy server maps the SIP URI in the To field to User B. The proxy server sends the INVITE message to User B.
F3	180 Ringing—User B to Proxy Server	User B sends a SIP 180 Ringing response to the proxy server. The 180 Ringing response indicates that the user is being alerted.
F4	180 Ringing—Proxy Server to User A	The proxy server forwards the 180 Ringing response to User A. User A hears the ring-back tone indicating that User B is being alerted.
F5	200 OK—User B to Proxy Server	User B sends a SIP 200 OK response to the proxy server. The 200 OK response notifies User A that the connection has been made.
F6	200 OK—Proxy Server to User A	The proxy server forwards the 200 OK message to User A. The 200 OK response notifies User A that the connection has been made.
F7	ACK—User A to Proxy Server	User A sends a SIP ACK to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now active.
F8	ACK—Proxy Server to User B	The proxy server sends the SIP ACK to User B. The ACK confirms that the proxy server has received the 200 OK

Step	Action	Description
		response. The call session is now active.
F9	INVITE—User A to Proxy Server	User A sends a mid-call INVITE request to the proxy server with new SDP session parameters, which are used to place the call on hold.
F10	INVITE—Proxy Server to User B	The proxy server forwards the mid-call INVITE message to User B.
F11	200 OK—User B to Proxy Server	User B sends a SIP 200 OK response to the proxy server. The 200 OK response notifies User A that the INVITE was successfully processed.
F12	200 OK—Proxy Server to User A	The proxy server forwards the 200 OK response to User A. The 200 OK response notifies User B is successfully placed on hold.
F13	ACK—User A to Proxy Server	User A sends an ACK message to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now temporarily inactive. No RTP packets are being sent.
F14	ACK—Proxy Server to User B	The proxy server sends the ACK message to User B. The ACK confirms that the proxy server has received the 200 OK response.
F15	INVITE—User A to Proxy Server	User A sends a SIP INVITE request to the proxy server. In the INVITE request, a unique Call-ID is generated and the Contact-URI field indicates that User A requests the call.
F16	INVITE—Proxy Server to User C	The proxy server maps the SIP URI in the To field to User C. The proxy server sends the INVITE request to User C.
F17	180 Ringing—User C to Proxy Server	User C sends a SIP 180 Ringing response to the proxy server. The 180 Ringing response indicates that the user is being alerted.
F18	180 Ringing—Proxy Server to	The proxy server forwards the 180

Step	Action	Description
	User A	Ringing response to User A. User A hears the ring-back tone indicating that User C is being alerted.
F19	200OK—User C to Proxy Server	User C sends a SIP 200 OK response to the proxy server. The 200 OK response notifies User A that the connection has been made.
F20	200OK—Proxy Server to User A	The proxy server forwards the SIP 200 OK response to User A. The 200 OK response notifies User A that the connection has been made.
F21	ACK—User A to Proxy Server	User A sends a SIP ACK to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now active.
F22	ACK—Proxy Server to User C	The proxy server forwards the ACK message to User C. The ACK confirms that the proxy server has received the 200 OK response. The call session is now active.
F23	REFER—User A to Proxy Server	User A sends a REFER message to the proxy server. User A performs a transfer of User B to User C.
F24	202 Accepted—Proxy Server to User A	The proxy server sends a SIP 202 Accepted response to User A. The 202 Accepted response notifies User A that the proxy server has received the REFER message.
F25	REFER—Proxy Server to User B	The proxy server forwards the REFER message to User B.
F26	202 Accepted—User B to Proxy Server	User B sends a SIP 202 Accept response to the proxy server. The 202 Accepted response indicates that User B accepts the transfer.
F27	BYE—User A to Proxy Server	User A terminates the call session by sending a SIP BYE request to the proxy server. The BYE request indicates that User A wants to release the call.

Step	Action	Description
F28	BYE—Proxy Server to User B	The proxy server forwards the BYE request to User B.
F29	200OK—User B to Proxy Server	User B sends a SIP 200 OK response to the proxy server. The 200 OK response notifies User A that User B has received the BYE request.
F30	200OK—Proxy Server to User A	The proxy server forwards the SIP 200 OK response to User A.

Always Call Forward


The following figure illustrates successful call forwarding between Yealink SIP IP phones in which User B has enabled always call forward. The incoming call is immediately forwarded to User C when User A calls User B. In this call flow scenario, the end users are User A, User B, and User C. They are all using Yealink SIP IP phones, which are connected via an IP network.

The call flow scenario is as follows:

1. User B enables always call forward, and the destination number is User C.
2. User A calls User B.
3. User B forwards the incoming call to User C.

4. User C answers the call.

Call is established between User A and User C.



Step	Action	Description
F1	INVITE—User A to Proxy Server	<p>User A sends an INVITE message to a proxy server. The INVITE request is an invitation to User B to participate in a call session.</p> <p>In the INVITE request:</p> <ul style="list-style-type: none"> The IP address of the User B is inserted in the Request-URI field. User A is identified as the call session initiator in the From field. A unique numeric identifier is assigned to the call and is inserted in the Call-ID field. The transaction number within a single call leg is identified in the CSeq field. The media capability User A is ready to receive is specified. The port on which User B is

Step	Action	Description
		prepared to receive the RTP data is specified.
F2	INVITE—Proxy Server to User B	The proxy server maps the SIP URI in the To field to User B. The proxy server sends the INVITE message to User B.
F3	302 Move Temporarily—User B to Proxy Server	User B sends a SIP 302 Moved Temporarily message to the proxy server. The message indicates that User B is not available at SIP phone B. User B rewrites the contact-URI.
F4	ACK—Proxy Server to User B	The proxy server sends a SIP ACK to User B, the ACK message notifies User B that the proxy server has received the 302 Move Temporarily message.
F5	302 Move Temporarily—Proxy Server to User A	The proxy server forwards the 302 Moved Temporarily message to User A.
F6	ACK—User A to Proxy Server	User A sends a SIP ACK to the proxy server. The ACK message notifies the proxy server that User A has received the 302 Move Temporarily message.
F7	INVITE—User A to Proxy Server	User A sends a SIP INVITE request to the proxy server. In the INVITE request, a unique Call-ID is generated and the Contact-URI field indicates that User A requested the call.
F8	INVITE—Proxy Server to User C	The proxy server maps the SIP URI in the To field to User C. The proxy server sends the SIP INVITE request to User C.
F9	180 Ringing—User C to Proxy Server	User C sends a SIP 180 Ringing response to the proxy server. The 180 Ringing response indicates that the user is being alerted.
F10	180 Ringing—Proxy Server to User A	The proxy server forwards the 180 Ringing response to User A. User A hears the ring-back tone indicating that User C is being alerted.
F11	200OK—User C to Proxy Server	User C sends a SIP 200 OK response to the proxy server. The 200 OK response

Step	Action	Description
		notifies User A that the connection has been made.
F12	200OK—Proxy Server to User A	The proxy server forwards the SIP 200 OK response to User A. The 200 OK response notifies User A that the connection has been made.
F13	ACK—User A to Proxy Server	User A sends a SIP ACK to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now active.
F14	ACK—Proxy Server to User C	The proxy server forwards the ACK message to User C. The ACK confirms that the proxy server has received the 200 OK response. The call session is now active.


Busy Call Forward

The following figure illustrates successful call forwarding between Yealink SIP IP phones in which User B has enabled busy call forward. The incoming call is forwarded to User C when User B is busy. In this call flow scenario, the end users are User A, User B, and User C. They are all using Yealink SIP IP phones, which are connected via an IP network.

The call flow scenario is as follows:

1. User B enables busy call forward, and the destination number is User C.
2. User A calls User B.
3. User B is busy.
4. User B forwards the incoming call to User C.
5. User C answers the call.

Call is established between User A and User C.



Step	Action	Description
F1	INVITE—User A to Proxy Server	<p>User A sends the INVITE message to a proxy server. The INVITE request is an invitation to User B to participate in a call session.</p> <p>In the INVITE request:</p> <ul style="list-style-type: none"> The IP address of User B is inserted in the Request-URI field. User A is identified as the call session initiator in the From field. A unique numeric identifier is assigned to the call and is inserted in the Call-ID field. The transaction number within a single call leg is identified in the CSeq field. The media capability User A is ready to receive is specified.

Step	Action	Description
		<ul style="list-style-type: none"> The port on which User B is prepared to receive the RTP data is specified.
F2	INVITE—Proxy Server to User B	The proxy server maps the SIP URI in the To field to User B. The proxy server sends the INVITE message to User B.
F3	180 Ringing—User B to Proxy Server	User B sends a SIP 180 Ringing response to the proxy server. The 180 Ringing response indicates that the user is being alerted.
F4	180 Ringing—Proxy Server to User A	The proxy server forwards the 180 Ringing response to User A. User A hears the ring-back tone indicating that User B is being alerted.
F5	302 Move Temporarily—User B to Proxy Server	User B sends a SIP 302 Moved Temporarily message to the proxy server. The message indicates that User B is not available at SIP phone B. User B rewrites the contact-URI.
F6	ACK—Proxy Server to User B	The proxy server sends a SIP ACK to User B, the ACK message notifies User B that the proxy server has received the ACK message.
F7	302 Move Temporarily—Proxy Server to User A	The proxy server forwards the 302 Moved Temporarily message to User A.
F8	ACK—User A to Proxy Server	User A sends a SIP ACK to the proxy server. The ACK message notifies the proxy server that User A has received the ACK message.
F9	INVITE—User A to Proxy Server	User A sends a SIP INVITE request to the proxy server. In the INVITE request, a unique Call-ID is generated and the Contact-URI field indicates that User A requests the call.
F10	INVITE—Proxy Server to User C	The proxy server forwards the SIP INVITE request to User C.
F11	180 Ringing—User C to Proxy Server	User C sends a SIP 180 Ringing response to the proxy server. The 180

Step	Action	Description
		Ringing response indicates that the user is being alerted.
F12	180 Ringing—Proxy Server to User A	The proxy server forwards the 180 Ringing response to User A. User A hears the ring-back tone indicating that User C is being alerted.
F13	200OK—User C to Proxy Server	User C sends a SIP 200 OK response to the proxy server. The 200 OK response notifies User A that the connection has been made.
F14	200OK—Proxy Server to User A	The proxy server forwards the SIP 200 OK response to User A.
F15	ACK— User A to Proxy Server	User A sends a SIP ACK to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now active.
F16	ACK—Proxy Server to User C	The proxy server sends the ACK message to User C.


No Answer Call Forward

The following figure illustrates successful call forwarding between Yealink SIP IP phones in which User B has enabled no answer call forward. The incoming call is forwarded to User C when User B does not answer the incoming call after a period of time. In this call flow scenario, the end users are User A, User B, and User C. They are all using Yealink SIP IP phones, which are connected via an IP network.

The call flow scenario is as follows:

1. User B enables no answer call forward, and the destination number is User C.
2. User A calls User B.
3. User B does not answer the incoming call.
4. User B forwards the incoming call to User C.
5. User C answers the call.

Call is established between User A and User C.



Step	Action	Description
F1	INVITE—User A to Proxy Server	<p>User A sends the INVITE message to a proxy server. The INVITE request is an invitation to User B to participate in a call session.</p> <p>In the INVITE request:</p> <ul style="list-style-type: none"> The IP address of User B is inserted in the Request-URI field. User A is identified as the call session initiator in the From field. A unique numeric identifier is assigned to the call and is inserted in the Call-ID field. The transaction number within a single call leg is identified in the CSeq field. The media capability User A is ready to receive is specified.

Step	Action	Description
		<ul style="list-style-type: none"> The port on which User B is prepared to receive the RTP data is specified.
F2	INVITE—Proxy Server to User B	The proxy server maps the SIP URI in the To field to User B. The proxy server sends the INVITE message to User B.
F3	180 Ringing—User B to Proxy Server	User B sends a SIP 180 Ringing response to the proxy server. The 180 Ringing response indicates that the user is being alerted.
F4	180 Ringing—Proxy Server to User A	The proxy server forwards the 180 Ringing response to User A. User A hears the ring-back tone indicating that User B is being alerted.
F5	302 Move Temporarily—User B to Proxy Server	User B sends a SIP 302 Moved Temporarily message to the proxy server. The message indicates that User B is not available at SIP phone B. User B rewrites the contact-URI.
F6	ACK—Proxy Server to User B	The proxy server sends a SIP ACK to User B, the ACK message notifies User B that the proxy server has received the ACK message.
F7	302 Move Temporarily—Proxy Server to User A	The proxy server forwards the 302 Moved Temporarily message to User A.
F8	ACK—User A to Proxy Server	User A sends a SIP ACK to the proxy server. The ACK message notifies the proxy server that User A has received the ACK message.
F9	INVITE—User A to Proxy Server	User A sends a SIP INVITE request to the proxy server. In the INVITE request, a unique Call-ID is generated and the Contact-URI field indicates that User A requests the call.
F10	INVITE—Proxy Server to User C	The proxy server forwards the SIP INVITE request to User C.
F11	180 Ringing—User C to Proxy Server	User C sends a SIP 180 Ringing response to the proxy server. The 180

Step	Action	Description
		Ringing response indicates that the user is being alerted.
F12	180 Ringing—Proxy Server to User A	The proxy server forwards the 180 Ringing response to User A. User A hears the ring-back tone indicating that User C is being alerted.
F13	200OK—User C to Proxy Server	User C sends a SIP 200 OK response to the proxy server. The 200 OK response notifies User A that the connection has been made.
F14	200OK—Proxy Server to User A	The proxy server forwards the SIP 200 OK response to User A. The 200 OK response notifies User A that the connection has been made.
F15	ACK— User A to Proxy Server	User A sends a SIP ACK to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now active.
F16	ACK—Proxy Server to User C	The proxy server sends the ACK message to User C. The ACK confirms that the proxy server has received the 200 OK response.


Call Conference

The following figure illustrates successful 3-way calling between Yealink IP phones in which User A mixes two RTP channels and therefore establishes a conference between User B and User C. In this call flow scenario, the end users are User A, User B, and User C. They are all using Yealink SIP IP phones, which are connected via an IP network.

The call flow scenario is as follows:

1. User A calls User B.
2. User B answers the call.
3. User A places User B on hold.
4. User A calls User C.
5. User C answers the call.

6. User A mixes the RTP channels and establishes a conference between User B and User C.



Step	Action	Description
F1	INVITE—User A to Proxy Server	<p>User A sends the INVITE message to a proxy server. The INVITE request is an invitation to User B to participate in a call session.</p> <p>In the INVITE request:</p> <ul style="list-style-type: none"> The IP address of User B is inserted in the Request-URI field. User A is identified as the call session initiator in the From field. A unique numeric identifier is assigned to the call and is inserted in the Call-ID field.

Step	Action	Description
		<ul style="list-style-type: none"> The transaction number within a single call leg is identified in the CSeq field. The media capability User A is ready to receive is specified. The port on which User B is prepared to receive the RTP data is specified.
F2	INVITE—Proxy Server to User B	The proxy server maps the SIP URI in the To field to User B. Proxy server forwards the INVITE message to User B.
F3	180 Ringing—User B to Proxy Server	User B sends a SIP 180 Ringing response to the proxy server. The 180 Ringing response indicates that the user is being alerted.
F4	180 Ringing—Proxy Server to User A	The proxy server forwards the 180 Ringing response to User A. User A hears the ring-back tone indicating that User B is being alerted.
F5	200 OK—User B to Proxy Server	User B sends a SIP 200 OK response to the proxy server. The 200 OK response notifies User A that the connection has been made.
F6	200 OK—Proxy Server to User A	The proxy server forwards the 200 OK message to User A. The 200 OK response notifies User A that the connection has been made.
F7	ACK—User A to Proxy Server	User A sends a SIP ACK to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now active.
F8	ACK—Proxy Server to User B	The proxy server sends the SIP ACK to User B. The ACK confirms that the proxy server has received the 200 OK response. The call session is now active.
F9	INVITE—User A to Proxy Server	User A sends a mid-call INVITE request to the proxy server with new SDP session parameters, which are used to place the call on hold.

Step	Action	Description
F10	INVITE—Proxy Server to User B	The proxy server forwards the mid-call INVITE message to User B.
F11	200 OK—User B to Proxy Server	User B sends a SIP 200 OK response to the proxy server. The 200 OK response notifies User A that the INVITE is successfully processed.
F12	200 OK—Proxy Server to User A	The proxy server forwards the 200 OK response to User A. The 200 OK response notifies User A that User B is successfully placed on hold.
F13	ACK—User A to Proxy Server	User A sends the ACK message to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now temporarily inactive. No RTP packets are being sent.
F14	ACK—Proxy Server to User B	The proxy server sends the ACK message to User B. The ACK confirms that the proxy server has received the 200 OK response.
F15	INVITE—User A to Proxy Server	User A sends a SIP INVITE request to the proxy server. In the INVITE request, a unique Call-ID is generated and the Contact-URI field indicates that User A requests the call.
F16	INVITE—Proxy Server to User C	The proxy server maps the SIP URI in the To field to User C. The proxy server sends the SIP INVITE request to User C.
F17	180 Ringing—User C to Proxy Server	User C sends a SIP 180 Ringing response to the proxy server. The 180 Ringing response indicates that the user is being alerted.
F18	180 Ringing—Proxy Server to User A	The proxy server forwards the 180 Ringing response to User A. User A hears the ring-back tone indicating that User C is being alerted.
F19	200OK—User C to Proxy Server	User C sends a SIP 200 OK response to the proxy server. The 200 OK response notifies User A that the connection has

Step	Action	Description
		been made.
F20	200OK—Proxy Server to User A	The proxy server forwards the SIP 200 OK response to User A. The 200 OK response notifies User A that the connection has been made.
F21	ACK— User A to Proxy Server	User A sends a SIP ACK to the proxy server. The ACK confirms that User A has received the 200 OK response. The call session is now active.
F22	ACK—Proxy Server to User C	The proxy server sends the ACK message to User C. The ACK confirms that the proxy server has received the 200 OK response.

Index

Numeric

- 100 Reliable Retransmission [486](#)
- 180 Ring Workaround [343](#)
- 802.1X Authentication [857](#)

A

- About This Guide [v](#)
- Accept SIP Trust Server Only [309](#)
- Account Registration [150](#)
- Acoustic Echo Cancellation [798](#)
- Action URL [618](#)
- Action URI [637](#)
- Administrator Password [823](#)
- Allow IP Call [307](#)
- Allow Trans Exist Call [391](#)
- Always Forward [359](#)
- Analyzing Configuration Files [895](#)
- Anonymous Call [314](#)
- Anonymous Call Rejection [319](#)
- Answer By Hand [490](#)
- Appendix [921](#)
- Appendix A: Glossary [921](#)
- Appendix B: Time Zones [923](#)
- Appendix C: Trusted Certificates [924](#)
- Appendix D: Configuring DSS Keys [926](#)
- Appendix E: Auto Provisioning Flowchart [944](#)
- Appendix G: SIP [953](#)
- Appendix H: SIP Call Flows [962](#)
- Area Code [248](#)
- Attended Transfer [381](#)
- Audio Codecs [784](#)
- Auto Answer [299](#)
- Auto-Logout Time [825](#)
- Automatic Call Distribution (ACD) [549](#)
- Automatic Gain Control [799](#)
- Auto Redial [297](#)

B

- Backlight [124](#)
- Background Noise Suppression [799](#)
- Bandwidth [491](#)
- Blind Transfer [381](#)
- BLF List [539](#)
- Block Out [251](#)
- Bluetooth [136](#)
- Bridge Lines Appearance (BLA) [569](#)
- Busy Forward [359](#)
- Busy Lamp Field (BLF) [524](#)
- Busy Tone Delay [339](#)

C

- Call Completion [310](#)
- Call Forward [359](#)
- Call Hold [352](#)
- Call Number Filter [427](#)
- Call Park [429](#)
- Call Recording [598](#)
- Call Timeout [471](#)
- Call Transfer [381](#)
- Call Waiting [289](#)
- Calling Line Identification Presentation [439](#)
- Connected Line Identification Presentation [446](#)
- Capturing Packets [886](#)
- Capturing the Current Screen of the Phone [645](#)
- CDP [677](#)
- Comfort Noise Generation [801](#)
- Configuration Files [48](#)
- Configuration Methods [48](#)
- Configuring Audio Features [755](#)
- Configuring Advanced features [501](#)
- Configuring Basic Features [101](#)
- Configuring Basic Network Parameters [68](#)
- Configuring Video Features [807](#)
- Configuring Security Features [821](#)
- Connecting the IP phone [19](#)

Contrast [111](#)

Conventions Used in Yealink Documentations

[v](#)

D

DHCP [68](#)

DHCP Option [73](#)

Dial Plan [231](#)

Dial-now [242](#)

Dial-now Template File [246](#)

Directed Call Pickup [393](#)

Directory [258](#)

Display Method on Dialing [168](#)

Distinctive Ring Tones [761](#)

Do Not Disturb (DND) [323](#)

Documentations [v](#)

DTMF [448](#)

Dual Headset [779](#)

E

Early Media [342](#)

Enable Page Tips [147](#)

Encrypting Configuration Files [849](#)

Enabling the Watch Dog Feature [892](#)

Expansion Module [17](#)

Exporting All the Diagnostic Files [899](#)

External Monitor (EXT Display) [497](#)

F

Feature Key Synchronization [386](#)

G

Getting Information from Status Indicators [894](#)

Getting Information from Talk Statistics [894](#)

Getting Started [19](#)

Group Call Pickup [405](#)

H

H.323 [1](#)

Headset Prior [777](#)

Hide Features Access Code [547](#)

Hot Desking [606](#)

Hotline [253](#)

I

Index [999](#)

Initialization Process Overview [36](#)

Intercom [462](#)

IPv6 Support [743](#)

IP Direct Auto Answer [306](#)

J

Jitter Buffer [803](#)

K

Keep User Personalized Settings [55](#)

Keyboard Input Method Customization [202](#)

Key As Send [231](#)

Key Features of IP Phones [15](#)

L

Label Length [149](#)

Language [191](#)

LDAP [509](#)

Live Dialpad [287](#)

LLDP [674](#)

Loading Language Packs [192](#)

Local Contact File [270](#)

Local Directory [270](#)

Logo Customization [215](#)

Logon Wizard [614](#)

M

Message Waiting Indicator [572](#)

Missed Call Log [268](#)

Multicast Paging [579](#)

Music on Hold (MoH) [356](#)

N

NAT Traversal [724](#)

Network Address Translation (NAT) [722](#)

Network Conference [384](#)

No Answer Forward [359](#)

Notification Popups [108](#)

O

Off Hook Hot Line Dialing [256](#)

Onscreen Keyboard Input Method
Customization [206](#)

P

Password Dial [481](#)

Phone Lock [826](#)

Phone User Interface [48](#)

Physical Features of IP Phones [15](#)

Power Indicator LED [101](#)

Power Saving [124](#)

Product Overview [1](#)

Q

Quality of Service [713](#)

R

Reading Icons [38](#)

Real-Time Transport Protocol (RTP) [733](#)

Reboot in Talking [488](#)

ReCall [421](#)

Redial Tone [293](#)

Remote Phone Book [502](#)

Remote Phone Book Template File [502](#)

Replace Rule [237](#)

Replace Rule Template File [239](#)

Reserve # in User Name [480](#)

Reserved Ports [719](#)

Return Message When DND [324](#)

Return Code When Refuse [341](#)

RFC and Internet Draft Support [953](#)

Ringer Device for Headset [295](#)

Ringing Timeout [472](#)

Ring Tones [755](#)

RTCP-XR [693](#)

S

Save Call Log [264](#)

Screen Saver [117](#)

Screenshot [494](#)

Screenshot and Recording [494](#)

Search Source List in Dialing [261](#)

Secure Real-Time Transport Protocol [849](#)

Semi-attended Transfer [381](#)

Send user=phone [473](#)

Sending Volume [781](#)

Server Redundancy [647](#)

Session Timer [349](#)

Shared Call Appearance (SCA) [556](#)

Short Message Service (SMS) [578](#)

SIP [2](#)

SIP Components [2](#)

SIP Header [957](#)

SIP IP Phone Models [3](#)

SIP Request [956](#)

SIP Responses [959](#)

SIP Send Line [477](#)

SIP Send MAC [475](#)

SIP Session Description Protocol Usage [961](#)

SIP Session Timer [346](#)

Softkey Layout [219](#)

Specifying the Language to Use [199](#)

Static DNS [70](#)

STUN [724](#)

Suppress DTMF Display [449](#)

T

Table of Contents [xv](#)

Time and Date [173](#)

Transfer on Conference Hang Up [388](#)

Transfer Mode via Dsskey [390](#)

Transfer via DTMF [457](#)

Transport Layer Security (TLS) [838](#)

Troubleshooting [869](#)

Troubleshooting Methods [869](#)

Troubleshooting Solutions [900](#)

TR-069 Device Management [737](#)

U

- Unregister When Reboot [484](#)
- Upgrading Firmware [93](#)
- Use Outbound Proxy in Dialog [344](#)
- User Agent Client (UAC) [996](#)
- User Agent Server (UAS) [505](#)
- User Password [821](#)

V

- Verifying Startup [37](#)
- Video Codecs [816](#)
- Video Settings [807](#)
- Viewing Log Files [869](#)
- VLAN [673](#)
- VLAN Feature in the Wireless Network [687](#)
- Voice Activity Detection [800](#)
- Voice Mail Tone [776](#)
- Voice Quality Monitoring [692](#)
- VoIP Principle [1](#)
- VPN [689](#)
- VQ-RTCPXR [695](#)

W

- Wallpaper [113](#)
- Web Server Type [169](#)
- Web User Interface [48](#)
- Wi-Fi [139](#)